



Spare parts for the professional sector:  
**Food processing equipment**



Suitable for:

# RHENINGHAUS-TECMAL



This catalogue is automatically generated.  
Therefore, the sequence of the items might  
not be always shown at best.  
Updates will be issued in case of additions  
and/or amendments.  
*Suitable **universal spare parts** may not be included*

Rel. 2017-07241351






Suitable for:

Suitable for:

## Accident prevention devices-protections

### 9716019 CARRIAGE PROTECTION OF POLYCARBONATE

max.overall dimensions 150x255 mm  
distance between holes 80 mm  
for Slicer (RHENINGHAUS-TECMAL)



RHENINGHAUS-TECMAL

### 9716032 CARRIAGE PROTECTION OF POLYCARBONATE


max.overall dimensions 170x250 mm  
distance between holes 115 mm  
for Slicer (RHENINGHAUS-TECMAL) MONDIAL250  
MONDIAL280 - MONDIAL300



RHENINGHAUS-TECMAL

### 9014170 POLYCARBONATE PLATE PROTECTION

max.overall dimensions 240x165 mm  
distance between holes 117 mm  
for Slicer (RHENINGHAUS-TECMAL) BETA330 - BETA350  
HF - MONDIAL - PRIMA300



RHENINGHAUS-TECMAL

## Bearings

### 9004010 BEARING 626 Z MOUNTED ON BUSHING

external nylon bushing  
external  $\varnothing$  22 mm - internal  $\varnothing$  6 mm -thickness 6 mm  
for Slicer (RHENINGHAUS-TECMAL)



RHENINGHAUS-TECMAL


## Belts

**9062020 BELT MULTIGRIP TB2 330 H12 5 GROOVES**  
for Slicer (RHENINGHAUS-TECMAL) STELLINA220  
STELLINA250



RHENINGHAUS-TECMAL

**9003751 MULTIGRIP BELT J 381 H21 8 GROOVES**  
for Slicer (RHENINGHAUS-TECMAL)



RHENINGHAUS-TECMAL

Suitable for:

**9003760 MULTIGRIP BELT J 610 H19 7 GROOVES**  
for Slicer (RHENINGHAUS-TECMAL) BETA300 - LUXOR350  
LUXOR370



RHENINGHAUS-TECMAL

Suitable for:

**9062030 MULTIGRIP BELT J 610 H28 11 GROOVES**



RHENINGHAUS-TECMAL

**9003761 MULTIGRIP BELT J 660 H19 7 GROOVES**  
for Slicer (RHENINGHAUS-TECMAL) BETA330 - BETA350  
MONDIAL250 - MONDIAL280 - MONDIAL300



RHENINGHAUS-TECMAL

**9003763 MULTIGRIP BELT J 711 H19 7 GROOVES**  
for Slicer (RHENINGHAUS-TECMAL) MONDIAL330  
MONDIAL350



RHENINGHAUS-TECMAL

**9003659 MULTIGRIP BELT TB2 330 H16 7 GROOVES**  
for Slicer (RHENINGHAUS-TECMAL) STELLINA



RHENINGHAUS-TECMAL

**9003662 MULTIGRIP BELT TB2 360 H16 7 GROOVES**  
for Slicer (RHENINGHAUS-TECMAL) STAR



RHENINGHAUS-TECMAL

**9003671 MULTIGRIP BELT TB2 598 H12 5 GROOVES**  
for Slicer (RHENINGHAUS-TECMAL) PRISMA250



RHENINGHAUS-TECMAL

**9003673 MULTIGRIP BELT TB2 660 H12 5 GROOVES**  
for Slicer (RHENINGHAUS-TECMAL) PRISMA300



RHENINGHAUS-TECMAL

**9003674 MULTIGRIP BELT TB2 675 H16 7 GROOVES**  
for Slicer (RHENINGHAUS-TECMAL) PRISMA300



RHENINGHAUS-TECMAL

**9003504 V-BELT 6x280 mm**  
for (RHENINGHAUS-TECMAL)



RHENINGHAUS-TECMAL



Suitable for:

**9003510 V-BELT 6x352 mm Y381**  
for Slicer (RHENINGHAUS-TECMAL)



RHENINGHAUS-TECMAL

**9003515 V-BELT 6x400 mm Y425**  
for Slicer (RHENINGHAUS-TECMAL) 330



RHENINGHAUS-TECMAL

**9003523 V-BELT 6x640 mm Y665**  
for Slicer (RHENINGHAUS-TECMAL) BETA300 - BETA330



RHENINGHAUS-TECMAL

Suitable for:

**9003512 V-BELT 6x372 mm Y394**  
for Slicer (RHENINGHAUS-TECMAL)



RHENINGHAUS-TECMAL

**9003520 V-BELT 6x565 mm Y588**  
for Slicer (RHENINGHAUS-TECMAL) 350LUXOR  
370LUXOR



RHENINGHAUS-TECMAL


**9003524 V-BELT 6x675 mm Y700**  
for Slicer (RHENINGHAUS-TECMAL) BETA350  
MONDIAL250 - MONDIAL280 - MONDIAL300



RHENINGHAUS-TECMAL

## Blade guides

**9016061 BLADE GUIDE ø 40 mm RHENINGHAUS**  
external ø 40 mm  
height 10 mm  
for Bone bandsaw (RHENINGHAUS-TECMAL)



RHENINGHAUS-TECMAL

## Blade protectors for slicers

**9706102 BLADE COVER MONDIAL/BETA 300**  
external ø 315 mm - internal ø for blade 254 mm  
thread internal ø 5 mm



RHENINGHAUS-TECMAL

**9002766 BLADE COVER RHENINGHAUS BETA/MONDIAL 350**  
ø ext. overall 387 mm  
ø int. blade 280 mm  
ø ext. thread 10 mm - ø int. thread 6 mm




RHENINGHAUS-TECMAL

## Blades for meat slicer

### 9006560 BLADE 330-57-4-270 MOD.C W/EXTRACT.HOLES


B = external  $\varnothing$  330 mm  
 D = central hole  $\varnothing$  57 mm  
 C = blade internal  $\varnothing$  270 mm  
 4 fastening screws  
 with extraction holes  
 100CR6 forged stainless steel



RHENINGHAUS-TECMAL

### 9006539 BLADE 350-57-4-280 MOD.C W/EXTRACT.HOLES

B = external  $\varnothing$  350 mm  
 D = central hole  $\varnothing$  57 mm  
 C = blade internal  $\varnothing$  280 mm  
 4 fastening screws  
 with extraction holes  
 100CR6 forged stainless steel



RHENINGHAUS-TECMAL

### 9006510 ST. STEEL BLADE $\varnothing$ 220-40-3-180 MOD.C

B = external  $\varnothing$  220 mm  
 D = central hole  $\varnothing$  40 mm  
 C = blade internal  $\varnothing$  180 mm  
 3 fastening screws  
 100CR6 forged stainless steel



RHENINGHAUS-TECMAL

### 9006512 ST. STEEL BLADE $\varnothing$ 250-40-3-200-190 MOD.F

B = external  $\varnothing$  250 mm  
 D = central hole  $\varnothing$  40 mm  
 C = blade internal  $\varnothing$  200 mm  
 A = rise element  $\varnothing$  190 mm  
 3 fastening screws  
 100CR6 forged stainless steel



RHENINGHAUS-TECMAL

### 9006518 ST. STEEL BLADE $\varnothing$ 275-40-3-218 MOD.C

B = external  $\varnothing$  275 mm  
 D = central hole  $\varnothing$  40 mm  
 C = blade internal  $\varnothing$  218 mm  
 3 fastening screws  
 100CR6 forged stainless steel



RHENINGHAUS-TECMAL

### 9006530 ST. STEEL BLADE $\varnothing$ 300-40-3-250-245 MOD.F


B = external  $\varnothing$  300 mm  
 D = central hole  $\varnothing$  40 mm  
 C = blade internal  $\varnothing$  250 mm  
 A = rise element  $\varnothing$  245 mm  
 3 fastening screws  
 100CR6 forged stainless steel  
 for Slicer (RHENINGHAUS-TECMAL) BETA300  
 MONDIAL300



RHENINGHAUS-TECMAL

### 9006525 ST. STEEL BLADE $\varnothing$ 300-40-3-254 MOD.C


B = external  $\varnothing$  300 mm  
 D = central hole  $\varnothing$  40 mm  
 C = blade internal  $\varnothing$  254 mm  
 3 fastening screws  
 100CR6 forged stainless steel



RHENINGHAUS-TECMAL

### 9006535 ST. STEEL BLADE $\varnothing$ 330-57-4-270 MOD.C

B = external  $\varnothing$  330 mm  
 D = central hole  $\varnothing$  57 mm  
 C = blade internal  $\varnothing$  270 mm  
 4 fastening screws  
 100CR6 forged stainless steel



RHENINGHAUS-TECMAL



Suitable for:


**9006536 ST. STEEL BLADE  $\varnothing$  330-57-4-273-265 MOD.F**  
 B = external  $\varnothing$  330 mm  
 D = central hole  $\varnothing$  57 mm  
 C = blade internal  $\varnothing$  273 mm  
 A = rise element  $\varnothing$  265 mm  
 4 fastening screws  
 100CR6 forged stainless steel  
 for Slicer (RHENINGHAUS-TECMAL) BETA330  
 MONDIAL330



RHENINGHAUS-TECMAL

Suitable for:

**9006538 ST. STEEL BLADE  $\varnothing$  350-57-4-280 MOD.C**  
 B = external  $\varnothing$  350 mm  
 D = central hole  $\varnothing$  57 mm  
 C = blade internal  $\varnothing$  280 mm  
 4 fastening screws  
 100CR6 forged stainless steel




RHENINGHAUS-TECMAL

**9006541 ST. STEEL BLADE  $\varnothing$  350-57-4-285 MOD.F**  
 B = external  $\varnothing$  350 mm  
 D = central hole  $\varnothing$  57 mm  
 C = blade internal  $\varnothing$  285 mm  
 A = rise element  $\varnothing$  285 mm  
 4 fastening screws  
 100CR6 forged stainless steel



RHENINGHAUS-TECMAL

**9006545 ST. STEEL BLADE  $\varnothing$  370-57-4-300 MOD.C**  
 B = external  $\varnothing$  370 mm  
 D = central hole  $\varnothing$  57 mm  
 C = blade internal  $\varnothing$  300 mm  
 4 fastening screws  
 100CR6 forged stainless steel



RHENINGHAUS-TECMAL

## Capacitors, electrical

**3068014 CAPACITOR DUCATI  $\mu$ F 8 450V 50/60Hz**  
 operating temperature  $-25+85^{\circ}\text{C}$   
 in compliance with EEC 93/68 and 92/31 regulations  
 for Slicer (RHENINGHAUS-TECMAL) PRIMA250



RHENINGHAUS-TECMAL

**3068079 CAPACITOR ELECTRICAL  $8\mu\text{F}$**   
 450V 50/60Hz -  $\varnothing$  30xh71 mm  
 for Slicer (RHENINGHAUS-TECMAL) PRIMA250



RHENINGHAUS-TECMAL LF-3068014

## Castors, rollers and accessories

**9004028 NYLON CARRIAGE WHEEL  $\varnothing$  18-6x8 mm**  
 external  $\varnothing$  18 mm  
 internal  $\varnothing$  6 mm  
 height 8 mm



RHENINGHAUS-TECMAL

**9004002 NYLON WHEEL  $\varnothing$  26-8x10 mm**  
 external  $\varnothing$  26 mm  
 internal  $\varnothing$  8 mm  
 height 10 mm



RHENINGHAUS-TECMAL



Suitable for:

Suitable for:


**9004023 PTFE CARRIAGE WHEEL  $\varnothing$  22-6x10 mm**  
 internal steel bushing  
 external  $\varnothing$  22 mm  
 internal  $\varnothing$  6 mm  
 height 10 mm



RHENINGHAUS-TECMAL

## Covers for sharpener

**9002707 COVER RHENINGHAUS BETA/MONDIAL**  
 aluminium made  
 for Slicer (RHENINGHAUS-TECMAL) BETA - MONDIAL



RHENINGHAUS-TECMAL

## Eccentrics

**9005010 ALUMINIUM ECCENTRIC  $\varnothing$  74 mm**  
 internal hole  $\varnothing$  14 mm - grooving 9 mm  
 for Slicer (RHENINGHAUS-TECMAL) BETA VT - LUXOR VT  
 MONDIAL



RHENINGHAUS-TECMAL

**9005007 ALUMINIUM ECCENTRIC OBERWERK  $\varnothing$  75 mm**  
 internal hole  $\varnothing$  14 mm - grooving 8 mm  
 for Slicer (RHENINGHAUS-TECMAL)




RHENINGHAUS-TECMAL

**9005009 BAKELITE ECCENTRIC  $\varnothing$  103 mm**  
 internal hole  $\varnothing$  14 mm - groove 8 mm  
 with external stopping notch  
 for Slicer (RHENINGHAUS-TECMAL)



RHENINGHAUS-TECMAL

**9707007 PLASTIC ECCENTRIC  $\varnothing$  56 mm**  
 internal hole  $\varnothing$  12 mm - grooving 6.5 mm  
 for Slicer (RHENINGHAUS-TECMAL)



RHENINGHAUS-TECMAL



Suitable for:

Suitable for:

**9005018 PLASTIC UNIVERSAL ECCENTRIC  $\varnothing$  56 mm**  
 internal hole  $\varnothing$  12 mm - groove 6 mm  
 for Slicer (RHENINGHAUS-TECMAL) PRM/STT-L



RHENINGHAUS-TECMAL

## Emeries for blades

**9013006 CUP GRINDERS 45-6-15**  
 A = external  $\varnothing$  45 mm  
 B = hole  $\varnothing$  6 mm  
 H = height 15 mm  
 COARSE GRAIN  
 for Slicer (RHENINGHAUS-TECMAL) HF350



RHENINGHAUS-TECMAL

**9013010 CUP GRINDERS 45-8-12**  
 A = external  $\varnothing$  45 mm  
 B = hole  $\varnothing$  8 mm  
 H = height 12 mm  
 COARSE GRAIN  
 for Slicer (RHENINGHAUS-TECMAL) 370



RHENINGHAUS-TECMAL

**9013011 CUP GRINDERS 48-8-15**  
 A = external  $\varnothing$  48 mm  
 B = hole  $\varnothing$  8 mm  
 H = height 15 mm  
 COARSE GRAIN



RHENINGHAUS-TECMAL

**9013201 RIMMED GRINDERS WITH DRUM 40-6-7.8**  
 A = external  $\varnothing$  40 mm  
 B = hole  $\varnothing$  6 mm  
 H = height 7.8 mm  
 FINE GRAIN  
 for Slicer (RHENINGHAUS-TECMAL) JADE - MONDIAL



RHENINGHAUS-TECMAL

**9013202 RIMMED GRINDERS WITH DRUM 40-6-7.8**  
 A = external  $\varnothing$  40 mm  
 B = hole  $\varnothing$  6 mm  
 H = height 7.8 mm  
 COARSE GRAIN  
 for Slicer (RHENINGHAUS-TECMAL) JADE - MONDIAL



RHENINGHAUS-TECMAL

**9013209 RIMMED GRINDERS WITH DRUM 45-6-8**  
 A = external  $\varnothing$  45 mm  
 B = hole  $\varnothing$  6 mm  
 H = height 8 mm  
 FINE GRAIN



RHENINGHAUS-TECMAL



Suitable for:

**9013213 RIMMED GRINDERS WITH DRUM 50-6-8**

A = external  $\varnothing$  50 mm  
 B = hole  $\varnothing$  6 mm  
 H = height 8 mm  
 FINE GRAIN  
 for Slicer (RHENINGHAUS-TECMAL) HF350 - MONDIAL280



RHENINGHAUS-TECMAL

Suitable for:

**9013214 RIMMED GRINDERS WITH DRUM 50-6-8**


A = external  $\varnothing$  50 mm  
 B = hole  $\varnothing$  6 mm  
 H = height 8 mm  
 COARSE GRAIN  
 for Slicer (RHENINGHAUS-TECMAL) MONDIAL280



RHENINGHAUS-TECMAL

**9013101 RIMMED GRINDERS 40-6-7.8**

A = external  $\varnothing$  40 mm  
 B = hole  $\varnothing$  6 mm  
 H = height 7.8 mm  
 FINE GRAIN



RHENINGHAUS-TECMAL

**9731003 RIMMED GRINDERS 43-12-9**

A = external  $\varnothing$  43 mm  
 B = hole  $\varnothing$  12 mm  
 H = height 9 mm  
 FINE GRAIN



RHENINGHAUS-TECMAL

**9013123 RIMMED GRINDERS 45-8-7**

A = external  $\varnothing$  45 mm  
 B = hole  $\varnothing$  8 mm  
 H = height 7 mm  
 FINE GRAIN  
 for Slicer (RHENINGHAUS-TECMAL) 370



RHENINGHAUS-TECMAL

## Gear Protectors

**9010003 COMPLETE GEAR PROTECTION OMAS**



RHENINGHAUS-TECMAL



Suitable for:

Suitable for:

## Gears

### 9005513 31-TOOTH GEAR IN PTFE

external  $\varnothing$  63 mm  
internal  $\varnothing$  36 mm  
height 20 mm  
6 fittings  
gear protection  $\varnothing$  6 mm



RHENINGHAUS-TECMAL

## Handles

### 9014151 CARRIAGE HANDLE DISTANCE BW HOLES 134 mm

thread  $\varnothing$  6 mm - length 150 mm  
for Slicer (RHENINGHAUS-TECMAL) 350HF



RHENINGHAUS-TECMAL

## Knives for meat mincers

### 9014602 STAINLESS STEEL KNIFE F/MEAT MINCER 22

model ENTERPRISE 22 self-sharpening  
external  $\varnothing$  73 mm - square hole 13x13 mm



RHENINGHAUS-TECMAL

## Knobs

### 9241014 ADJUSTABLE KNOB BLACK $\varnothing$ 12x100 mm

pin  $\varnothing$  12x54 mm  
knob 40x38 mm  
mounting frame  $\varnothing$  50 mm  
for Slicer (RHENINGHAUS-TECMAL) PRIMA 250  
PRIMA 300



RHENINGHAUS-TECMAL

### 9007505 ADJUSTABLE KNOB BLACK $\varnothing$ 14x125 mm

pin  $\varnothing$  14x55 mm  
knob  $\varnothing$  62 mm  
mounting frame  $\varnothing$  70 mm  
for Slicer (RHENINGHAUS-TECMAL) BETA - MONDIAL



RHENINGHAUS-TECMAL

Suitable for:

Suitable for:

**9007545 BLACK KNOB  $\varnothing$  40 mm PITCH M10**  
with pin length 30 mm  
for Slicer (RHENINGHAUS-TECMAL)



RHENINGHAUS-TECMAL

## Pins

**9011021 BUSHING FOR BLADE COVER THREAD**  
hole  $\varnothing$  8 mm - fixing thread M14  
overall height 9 mm



RHENINGHAUS-TECMAL

**9015060 PIN FOR MEAT MINCER 22 RHENINGHAUS**  
shaft  $\varnothing$  11 mm  
square part 12.6x12.6 mm  
pin  $\varnothing$  16x30 mm  
oval flange  $\varnothing$  24x16 mm



RHENINGHAUS-TECMAL


**9011022 PIN FOR SLICER BLADE COVER**  
fitting for blade cover with fitting cone  
hole  $\varnothing$  6 mm - fastening thread M10  
overall height 15 mm  
for Slicer (RHENINGHAUS-TECMAL) LUXOR



RHENINGHAUS-TECMAL

## Rolls for graters and spares

**9016514 GRATING ROLL ST. STEEL RHENINGHAUS**  
external  $\varnothing$  w/ points 76 mm -  $\varnothing$  central hole 25 mm  
overall roller length 147 mm



RHENINGHAUS-TECMAL



## Safety control devices f.food process.

- 9014019 MODIFICATION KIT 230V 0.75HP**  
 maximum load 0.75Hp 12(2)A 230V  
 power supply 230V 50/60Hz  
 watertight box IP54 with cable grommets  
 box dimensions 107x107x58 mm  
 power cord with plug PE1663 IP44  
 preset cable for in-line micro switch  
 WHITE/BLACK touch-sensitive button w/indic.light  
 in compliance with EC regulation  
 for SLICER



RHENINGHAUS-TECMAL LF-9057016

## Sharpeners

- 9000042 BLADE SHARPENER RGV**  
 with knob - without cover  
 for Slicer (RHENINGHAUS-TECMAL) BETA - MONDIAL  
 START



RHENINGHAUS-TECMAL

- 9000043 BLADE SHARPENER MONDIAL/BETA 300-330-350**  
 without cover  
 for Slicer (RHENINGHAUS-TECMAL) BETA300 - BETA330  
 BETA350 - MONDIAL300 - MONDIAL330 - MONDIAL350



RHENINGHAUS-TECMAL

## Springs

- 9008501 CONICAL SPRING FOR CARRIAGE**  
 external  $\varnothing$  27 mm  
 internal  $\varnothing$  22 mm  
 height 19 mm



RHENINGHAUS-TECMAL

- 9008500 SPRING FOR CARRIAGE**  
 external  $\varnothing$  16 mm  
 internal  $\varnothing$  13.5 mm  
 height 27 mm



RHENINGHAUS-TECMAL

## Tie rods for blade cover

- 9013528 BLADE COVER TIE ROD SHAFT 155mm PITCH M6**  
 for Slicer (RHENINGHAUS-TECMAL) LUXOR



RHENINGHAUS-TECMAL

- 9714026 BLADE COVER TIE ROD SHAFT 225mm PITCH M6**  
 for Slicer (RHENINGHAUS-TECMAL) 300TG



RHENINGHAUS-TECMAL



# RHENINGHAUS-TECMAL



Suitable for:

**9013546** **BLADE COVER TIE ROD SHAFT 76 mm PITCH M6**  
thread length 12 mm  
for Slicer (RHENINGHAUS-TECMAL) - Series BETA  
Series MONDIAL



RHENINGHAUS-TECMAL

Suitable for:

**9013529** **BLADE COVER TIE 60 mm PITCH M6**  
maximum grip  $\varnothing$  105 mm  
minimum handgrip  $\varnothing$  60 mm  
complete of magnet for micro  
for Slicer (RHENINGHAUS-TECMAL) - Series BETA  
Series MONDIAL



RHENINGHAUS-TECMAL

The data herewith contained may change without notice and LF SpA cannot be held responsible for possible errors stated or resulting by the use of this document. All rights reserved. No part of this publication may be reproduced without written permission by LF SpA.



## Distributing Components, Spare Parts & Accessories in original quality worldwide

- 
- LF SpA HEADQUARTERS**  
via Voltri, 80 - 47522 Cesena (FC) ITALY  
Tel. +39 0547 34 11 11 - Fax +39 0547 34 11 10  
[www.lfircambi724.it](http://www.lfircambi724.it) - [info@lfircambi.it](mailto:info@lfircambi.it)  
Export Dept. Tel. +39 0547 34 11 50 - Fax +39 0547 34 11 55  
[www.lfspareparts724.com](http://www.lfspareparts724.com) - [export@lfspareparts.com](mailto:export@lfspareparts.com)
- LF SpA HOUSEHOLD COMPONENTS DIVISION**  
Via Padriciano, 99 - AREA Science Park - 34149 Trieste (TS) ITALY  
Tel. +39 0547 34 12 42 - Fax +39 0547 34 12 48  
[www.lfspareparts724.com](http://www.lfspareparts724.com) - [info@lfspareparts.com](mailto:info@lfspareparts.com)
- EPGC Sas FRANCE**  
13, Rue des Forts - 59960 Neuville en Ferrain  
Tel. +33 (0)3 20 25 06 21 - Fax +33 (0)3 20 25 34 12  
[www.epgc.com](http://www.epgc.com) - [epgc@epgc.com](mailto:epgc@epgc.com)
- LF GmbH GERMANY**  
Junkersstrasse, 3 - D-82178 Puchheim - München  
Tel. +49 89 89 45 78 66 - Fax +49 89 89 45 78 88  
[www.lfersatzteile724.de](http://www.lfersatzteile724.de) - [info@lfersatzteile.de](mailto:info@lfersatzteile.de)
- LF China REPUBLIC OF CHINA**  
Room 403, No.2, Huadu Mansion, Lane 422, Huanghua Rd.  
Minhang Dist. - 201103 Shanghai  
Tel. +86 (0)21 33 53 66 31 - Fax +86 (0)21 33 53 66 32  
[www.lfspareparts724.com](http://www.lfspareparts724.com) - [china@lfspareparts.com](mailto:china@lfspareparts.com)
- OOO LF RUSSIAN FEDERATION**  
Ul. Anatoliya Zhivova, 8 - office 1 - 123100 Moscow  
Tel./Fax +7 495 725 26 53  
[www.lfspareparts724.ru](http://www.lfspareparts724.ru) - [info@lfspareparts.ru](mailto:info@lfspareparts.ru)
- LF Repuestos Horeca S.L.U. SPAIN**  
Poligono Industrial Carpetania - C/Miguel Faraday, 8 - 28906 Getafe  
Tel. +34 91 477 91 00 - Fax +34 91 477 90 81  
[www.lfrepuestos-horeca724.es](http://www.lfrepuestos-horeca724.es) - [info@lfrepuestos.es](mailto:info@lfrepuestos.es)
- LF Scandinavia Aps - LF Spareparts S.p.A. DENMARK**  
Nupark, 51 - 7500 Holstebro  
Tel. +45 70 70 77 33  
[www.lfspareparts724.dk](http://www.lfspareparts724.dk) - [denmark@lfspareparts.dk](mailto:denmark@lfspareparts.dk)
- LF SpA Cesena (IT) Swiss Branch Steinhausen SWITZERLAND**  
Sennweidstrasse, 45 - CH-6312 Steinhausen  
Tel. +41 (0)41 760 15 80/1 - Fax +41 (0)41 760 15 85  
[www.lfersatzteile724.ch](http://www.lfersatzteile724.ch) - [info@lfersatzteile.ch](mailto:info@lfersatzteile.ch)
- LF Spare Parts Ltd. UNITED KINGDOM**  
A10a Lakeside Business Park, Broadway Lane  
South Cerney, Gloucestershire GL7 5XL  
Tel. +44 (0)1285 86 16 25 - Fax +44 (0)1285 86 39 49  
[www.lfspareparts724.co.uk](http://www.lfspareparts724.co.uk) - [info@lfspareparts.co.uk](mailto:info@lfspareparts.co.uk)
- LF Central Est Europe S.r.o. CZECH REPUBLIC**  
Antala Staska 1859/34  
14000 Praha 4 - KRC  
Tel. +420 730 156 910  
[www.lfspareparts724.cz](http://www.lfspareparts724.cz) - [info@lfspareparts.cz](mailto:info@lfspareparts.cz)
- LF SPARE PARTS INC. USA**  
Legal address:  
155 Office Plaza Dr - Suite A - Tallahassee, FL 32301  
Business/Mailing address:  
1100 South Tower, 225 Peachtree St., N.E. - Atlanta, GA 30303, USA  
Tel. +1-404-525-2600 - Fax +1-404-586-3528  
[www.lfspareparts724.us](http://www.lfspareparts724.us) - [info@lfspareparts.us](mailto:info@lfspareparts.us)  
Tel. West Coast and Midwest: 206-349-1525 Sauro  
Tel. East Coast and the Caribbean: 786-817-1764 Luis
- 
- AUSTRALIA AND NEW ZEALAND**  
[www.lfspareparts724.com](http://www.lfspareparts724.com)  
[andrea.calvio@lfspareparts.com](mailto:andrea.calvio@lfspareparts.com)
- AUSTRIA**  
[www.lfersatzteile724.at](http://www.lfersatzteile724.at)  
[info@lfersatzteile.at](mailto:info@lfersatzteile.at)
- BALKAN COUNTRIES**  
[www.lfspareparts724.com](http://www.lfspareparts724.com)  
[matija.ramov@lfspareparts.com](mailto:matija.ramov@lfspareparts.com)
- BALTIC COUNTRIES**  
[www.lfspareparts724.com](http://www.lfspareparts724.com)  
[inara.silina@lfspareparts.com](mailto:inara.silina@lfspareparts.com)
- LATIN AMERICA AND THE CARRIBEANS**  
[www.lfrepuestos-horeca724.es](http://www.lfrepuestos-horeca724.es)  
[export@lfrepuestos.es](mailto:export@lfrepuestos.es)
- POLAND**  
[www.lfspareparts724.pl](http://www.lfspareparts724.pl)  
[info@lfspareparts.pl](mailto:info@lfspareparts.pl)
- SOUTH KOREA**  
[www.lfspareparts724.com](http://www.lfspareparts724.com)  
[fabio.doni@lfspareparts.com](mailto:fabio.doni@lfspareparts.com)
- TURKEY**  
[www.lfyedekparca724.com](http://www.lfyedekparca724.com)  
[export@lfspareparts.com](mailto:export@lfspareparts.com)