



Spare parts for:

Domestic



Suitable for:

CANDY



This catalogue is automatically generated.
Therefore, the sequence of the items might
not be always shown at best.

Updates will be issued in case of additions
and/or amendments.

*Suitable **universal spare parts** may not be included*





Suitable for:

CANDY



Suitable for:

Axial motors


D319386 BLOWER NO-FROST WITH FAN
COMPLETE - SHAF L35/ø 3.2mm 7 Watt - 220V



CANDY 92129063

Baking-pans

D309008 PLATE FOR MICROWAVE ø 245 mm CANDY
17 L




CANDY 49008516

D309009 PLATE FOR MICROWAVE ø 310 mm CANDY



CANDY 49008503

D309018 PLATE FOR MICROWAVE ø245mm SMOOTH



CANDY 49018556

D309010 PLATE FOR MICROWAVE OVEN CANDY
Ø270

CANDY 49012374

Baskets for washing and drying machines

D056010 CONVEYOR FOR BASKET 153 mm CANDY



CANDY 41021914

D056012 CONVEYOR FOR BASKET 180 mm CANDY



CANDY 41021913

D056011 CONVEYOR FOR BASKET 213 mm CANDY



CANDY 41001234



Belts

D062281 BELT ELASTIC CANDY 1890H9



CANDY 90469974

D062096 BELT HUTCHINSON 1145 H5 EL



CANDY 41009626

D062118 BELT HUTCHINSON 1200 H8 EL



CANDY 4600003

D062125 BELT HUTCHINSON 1210 J5



CANDY 90444580

D062135 BELT HUTCHINSON 1230 H8 EL



CANDY 41003164

D062173 BELT HUTCHINSON 1860 H8 EL



CANDY 90446634

D062177 BELT HUTCHINSON 1885 H5



CANDY 90405531

D062097 BELT MEGADYNE 1148 J4 EL



CANDY 41003977

D062022 BELT MULTIGRIP 1133 J4 EL



CANDY 90477167

D062041 BELT MULTIGRIP 1140 J5 EL
CANDY - ARISTON - WHIRLPOOL - COD ORIG 1500345



CANDY 1500345

D062042 BELT MULTIGRIP 1233 J5 EL
CANDY - WHIRLPOOL - COD ORIG 92130442



CANDY 92130442

D062219 BELT MULTIGRIP 1890 H6 EL



CANDY



CANDY



Suitable for:

Suitable for:

D062035 BELT MULTIGRIP 1890 H8 EL

D062036 BELT MULTIGRIP 1890 H9 EL



CANDY LFD062****

CANDY 90469974

D062016 BELT MULTIGRIP 1930 H7 CANDY

D062046 BELT WASHING MACHINE 8EPH1200 CANDY



CANDY 40001012

CANDY 4600003

CANDY 46007433

D319304 BELT 1233 J4 HUTCHINSON

D062076 BELT 1234 J5 EL POLYURETHANE



CANDY 92130442

CANDY D062****

D062017 BELT 3LX 1186EL TEM474 CANDY

D062018 BELT 3LX 1286EL 3L512TEM



CANDY 80001712

CANDY 92130871

CANDY 92607183

CANDY 90426362

CANDY 90462441

CANDY 92607795

D319301 BELT 3L491 ECOLINE



CANDY 92607837

Bosses and hubs

D319178 BOSS
KIT bearing 6203ZZ - V-RING \varnothing 20mm

D319185 BOSS
600RPM - no rod bearing 6203



CANDY 80018096

CANDY 80037468

CANDY 80051647



Suitable for:

CANDY




D319186 BOSS
with fastening screw bearing 1X6204ZZ



CANDY 80051643

Suitable for:

D319255 BOSS
external flange \varnothing 103 mm - bearings 6203



CANDY 46002361

CANDY 81452603

D319256 BOSS
FLANGE \varnothing 103mm bearings 6204




CANDY 81452602

D021017 BOSS CANDY
shaft \varnothing 20-25 mm - bushing \varnothing 30 mm



CANDY 49002387

D319181 BOSS CANDY



CANDY 80018088


D319182 BOSS CANDY
LH

D319183 BOSS CANDY
RH



CANDY 80000516

D319184 BOSS CANDY
BEARING 1X6204ZZ



CANDY 80037476

CANDY 80051645

D319257 BOSS CANDY
1X6203



CANDY 80037484

D319179 BOSS CANDY 646



CANDY 92796663

D319155 BOSS HOOVER



CANDY 09519125

D063003 BUSHING FOR HUB CANDY



CANDY 3210179



Suitable for:

CANDY



D021019 DRUM SPIDER



CANDY 49003268

CANDY 92994870

CANDY 92994904

D021014 HUB FOR TANK CANDY



CANDY 46005903

D021015 HUB 90 mm CANDY



CANDY 49000891

D021016 WHEEL SUPPORT WASHING MACHINE CANDY
Radius 178 mm - shaft 105mm



CANDY 92999333

Burners, flame spreaders and accessories

D025027 BURNER CAP CANDY ø 83 mm



CANDY 93680569

Castors, rollers and accessories

D346013 WHEEL FOR BASKET CANDY



CANDY 91601039


CANDY 91601253

D346014 WHEEL FOR BASKET CANDY



CANDY 92156108

D346012 WHEEL FOR BEARING CANDY



CANDY 40004307

Contact thermostats**D444049 CONTACT THERMOSTAT CANDY 10A 250V**

CANDY 41024208

**D444050 CONTACT THERMOSTAT WASHING MACHINE CANDY
NA30°C - NC84°C**

CANDY 92744499

Door catches**D398009 LATCH CANDY**

CANDY 91670364

CANDY 92155738

D398011 LATCH CANDY

CANDY 91941168

D398010 LATCH WITH MICROSWITCH CANDY
code 673001800135

CANDY 49017982

Door gaskets for dishwashers**D886015 GASKET DISHWASHER DOOR CANDY**

CANDY 41010838

D886016 GASKET LOWER 540 mm CANDY

CANDY 49011698

D886018 GASKET 1700x15 mm CANDY

CANDY 92130962

CANDY 92605740

D886014 GUARNIZONE DOOR BOTTOM 528 mm CANDY

CANDY 91620003



Suitable for:

CANDY



Suitable for:

D886017 GUARNIZIONE DOOR BOTTOM 540mm CANDY



CANDY 92130707

Door gaskets for laundry equipment

D686054 BELLOW GASKET PORTHOLE



CANDY 92603976

D686057 BELLOW GASKET PORTHOLE ø 345 mm



CANDY 632309

D686077 BELLOW GASKET PORTHOLE 370 mm



CANDY 41008852

D319124 BELLOW PORTHOLE CANDY



CANDY 92131713

D686047 BELLOW/GASK. PORTHOLE ø 350 mm CANDY



CANDY 90489153

D686049 BELLOW/GASK. PORTHOLE ø 365 mm CANDY




CANDY 41008853

CANDY 41010580

CANDY 91620027

D686037 BELLOW/GASK. PORTHOLE ø 370 mm CANDY




CANDY 41003066
CANDY 49002461

CANDY 41006047
CANDY 91620028

CANDY 41008852

D686035 BELLOW/GASK. PORTHOLE ø 400 mm CANDY



CANDY 41027514


D686038 BELLOW/GASK. PORTHOLE CANDY



CANDY 41021143

CANDY 41037248

D686046 BELLOW/GASK. PORTHOLE CANDY



CANDY 91620118



CANDY



Suitable for:

Suitable for:

D686036 BELLOW/GASK. PORTHOLE MPS 30SH CANDY

D686043 BELLOW/GASK. PORTHOLE STD M500 CANDY



CANDY 41037572

CANDY 41021401

D686039 BELLOW/GASK. PORTHOLE TOP LOAD CANDY

D686048 BELLOW/GASK. PORTHOLE ZEROWATT




CANDY 41016070

CANDY 90450404

D686050 BELLOW/GASK. PORTHOLE ZEROWATT

D686042 BELLOW/GASK. PORTHOLE ZEROWATT ø 370 mm



CANDY 90440280

CANDY 49007606

CANDY 90489151

D686044 BELLOW/GASK. PORTHOLE 385x300 mm CANDY

D686034 BELLOW/GASK. PORTHOLE 400x360 mm CANDY




CANDY 80007818

CANDY 81452545

CANDY 81452547

D686045 BELLOW/GASK. PORTHOLE 410x360 mm CANDY

D686074 GASKET FOR PORTHOLE ø 345 mm CANDY



CANDY 80049141


CANDY 80051553

CANDY 81452546

CANDY 92607373

D686105 GASKET FOR PORTHOLE ø 390 mm CANDY

D686109 GASKET FOR PORTHOLE CANDY



CANDY 41021401

CANDY 41021143



CANDY



Suitable for:

Suitable for:

D686060 GASKET FOR PORTHOLE 385x300 mm CANDY

D686061 GASKET FOR PORTHOLE 410x360 mm CANDY




CANDY 81452545

CANDY 81452546

D686040 RING PORTHOLE FIXING CANDY

D686041 RING PORTHOLE FIXING CANDY




CANDY 41018408

CANDY 90488603

Doors

D386033 DOOR FOR EVAPORATOR 10022293 CANDY

D386032 DOOR FOR EVAPORATOR 10200526 CANDY





CANDY 49019475

CANDY 49015317

D386031 DOOR FOR EVAPORATOR 460x205 mm CANDY

D386030 DOOR FOR EVAPORATOR 470x185 mm CANDY



CANDY 91670337

CANDY 4102261

D386045 DOOR FOR FREEZER CANDY

D386029 KIT FRAME FOR DISHWASHER DOOR CANDY



CANDY 49018870

CANDY 41007269

CANDY 41012952

CANDY 41015996

CANDY 41030153

CANDY 41900626

CANDY 91501078

Drain hoses

D248018 HOSE FOR DRYER FAN CANDY

D248045 HOSE OUTLET CANDY 1900 mm



CANDY 40002137

CANDY 49002903

CANDY 49013945



Drain pumps

D422023 DRAIN PUMP CANDY



CANDY 41019104

D422066 DRAIN PUMP CANDY
100W - 220/240V 50Hz



CANDY 92213503

D422086 DRAIN PUMP CANDY
100W - 220/240V 50Hz



CANDY 92208008


D422072 DRAIN PUMP CANDY LS
100W - 220/240V 50Hz

D422027 DRAIN PUMP DISHWASHER CANDY



CANDY 49002911

D422065 DRAIN PUMP HOOVER LS
100W - 220/240V 50Hz



CANDY 674210

Drain tanks

D527002 TANK FOR WATER RECOVERY CANDY



CANDY 40006253

CANDY 40008542

D521001 TRAY CONDENSATE CANDY




CANDY 40006629

CANDY 40008549

Electromagnets


D121060 DOOR LOCK ELECTR. CANDY



CANDY 91955807

CANDY 92214642

D121062 DOOR LOCK ELECTR. CANDY



CANDY 90489300



Suitable for:

D121107 DOOR LOCK ELECTRIC



CANDY 90452814


Suitable for:

D121115 DOOR LOCK ELECTRIC CANDY




CANDY 41016879

D121086 DOOR LOCK ELECTRIC.



CANDY 49017376

D121063 DOOR LOCK ELECTRIC. CANDY



CANDY 46002826

CANDY 80049349

D240062 KIT DOOR LOCK WITH SCREW
1 PCS. - 5X12.5 - FASTON 4.8mm



CANDY 49000466

CANDY 49030389

D121042 MICRO SWITCH CANDY
250V - 16(4)A




CANDY 80001407

CANDY 90476490

Electronic printed-circuit boards

D390091 HOUSING FOR PC BOARD CANDY



CANDY 41029071

D390090 PC BOARD CANDY




CANDY 41014239

D390092 PC BOARD CANDY
motor interface AC/DC



CANDY 41021535

D390093 PC BOARD CANDY
with buzzer




CANDY 41008098

CANDY 41016113


CANDY 49007819

D390094 PC BOARD MAIN 4 RELAYS CANDY



CANDY 41032220

D390095 PC BOARD W /INDICATOR CANDY



CANDY 49007758



Feet

D313004 FOOT FOR DRYER CANDY



CANDY 41001349

Filters


D160017 FILTER CANDY



CANDY 41021232

CANDY 41021233

D160018 FILTER DRYER CANDY



CANDY 40004787

D160036 FILTER FOR PUMP MOTOR CANDY self-cleaning



CANDY 91940540

D160020 FILTER SELF-CLEANING CANDY



CANDY 41004157

D160021 FILTER SELF-CLEANING CANDY



CANDY 91940540

D160019 FILTER SPONGE CANDY



CANDY 40006731

Fuses

D049007 FUSE FOR MICROWAVE CANDY HT 5KV 700mA - HV-251203301549



CANDY 49021682



Suitable for:

CANDY



Suitable for:

Gaskets and seals

D186013 GASKET DISH WASHER TRAY
code 673001500016



CANDY 49017708

D186014 GASKET SCALE REMOVER CANDY
code 673001700001



CANDY 49017716

D186015 GASKET UPPER IMPELLER CANDY
code 672030170003



CANDY 49011764

Gaskets for oven door

D586012 GASKET OVEN DOOR CANDY



CANDY 91620091

Gaskets for refrigerators

D286013 GASKET CANDY



CANDY 41020352

CANDY 41028813

D286017 GASKET CANDY



CANDY 92980408

D286012 GASKET CANDY 526x882 mm



CANDY 49002327


D286014 GASKET CANDY 720x580 mm



CANDY 41028814



Gearmotors

D240065 MOTOR MICROWAVE OVEN CANDY - 4W

CANDY 49021718

Grids for kitchen

D195011 RUBBER PIECE FOR PAN SUPPORT GRID CANDY

CANDY 92131218

Handles

D242067 COVER FOR HANDLE BLACK CANDY

CANDY 41000010

D242054 DOOR-LOCK CANDY

CANDY 40004091

D242055 HANDLE BASKET WHITE CANDY

CANDY 49010813

D242069 HANDLE CANDY

CANDY 41012318

D242073 HANDLE CANDY

CANDY 49008604

D242070 HANDLE FOR PORTHOLE CANDY KIT

CANDY 90473547



Suitable for:

CANDY



D242095 HANDLE FOR PORTHOLE CANDY



CANDY 49017446

Suitable for:

D242060 HANDLE LID WHITE CANDY
for TOP LOAD WASHING MACHINE



CANDY 46000973

D242063 HANDLE PORTHOLE GRAY CANDY



CANDY 40000967

CANDY 41010388

D248012 HANDLE PORTHOLE WASHING MACHINE CANDY HK



CANDY 9200566

D242052 HANDLE PORTHOLE WHITE CANDY



CANDY 41013809

D242061 HANDLE PORTHOLE WHITE CANDY



CANDY 41021016

CANDY 43000463

D242065 HANDLE WHITE CANDY



CANDY 91609859

D242064 HANDLE WHITE PORTHOLE CANDY



CANDY 90447699

D242066 HANDLE WHITE REFRIG. CANDY



CANDY 49026727

D242072 HOOK FOR MICROWAVE DOOR CANDY
251300500045



CANDY 49012605

D242062 HOOK WITH SPRING CANDY



CANDY 91941759

D242058 HOOKING FOR PORTHOLE DOOR CANDY



CANDY 09200399

CANDY 9200399

Suitable for:


D242053 KIT HANDLE PORTHOLE GRAY CANDY



CANDY 49007818

Suitable for:

D242057 KIT HANDLE PORTHOLE WHITE CANDY



CANDY 49001136

D242056 KIT HANDLE PORTHOLE WHITE ZEROWATT



CANDY 91967430

D242059 KIT LOCK-STRIKE FOR PORTHOLE CANDY



CANDY 49005176

**D242071 LOCK-
252100100016**



CANDY 49006032

Heating elements

D355161 HEATING ELEMENT CANDY 2040W 230V



CANDY 91943054

D355091 HEATING ELEMENT CIRCULAR 2000W 230V CAND



CANDY 49013542

D355107 HEATING ELEMENT DISHWASHER 1950W 230V
length 355 mm - width 177 mm
flange 50x26 mm



CANDY 91200137

D355096 HEATING ELEMENT DISHWASHER 2040W 230V
length 145 mm - hose \varnothing 40 mm



CANDY 91943054

D355114 HEATING ELEMENT FOR DRYER 1050+1050W 240
length 192 mm - width 41.5 mm



CANDY 40004314

D355115 HEATING ELEMENT FOR DRYER 1200+1200W 230
length 192 mm - width 41.5 mm



CANDY 04820091

CANDY 40004317



Suitable for:

CANDY



D355092 HEATING ELEMENT FOR OVEN 1530W 230V CAND

Suitable for:

D355093 HEATING ELEMENT LOWER 2000W 230V CANDY



CANDY 93696821

CANDY 93386829

D355088 HEATING ELEMENT 1050+450W 230V-98V CANDY

D355334 HEATING ELEMENT 1200+1200W/230V



CANDY 41000114
CANDY 93710127

CANDY 41020672

CANDY 91206722

CANDY 40004315

D355303 HEATING ELEMENT 1200+2110W 230V
length 360 mm - width 360 mm
flange 80x30 mm - grill - crosspiece 350-370 mm

D355304 HEATING ELEMENT 1200+2110W 230V
length 360 mm - width 360 mm
flange 80x30 mm - grill - crosspiece 367-371 mm



CANDY 44001369

CANDY 44001353

D355312 HEATING ELEMENT 1200+2110W 230V
length 360 mm - width 355 mm
flange 80x30 mm - crosspiece 320 mm

D355327 HEATING ELEMENT 1200W 230V C/TP
dimensions 255x69 mm




CANDY 44003282

CANDY 41008073

D355305 HEATING ELEMENT 1300W 230V
length 360 mm - width 340 mm
flange 70x22 mm

D355330 HEATING ELEMENT 1300W 230V C/TP
dimensions 160x67 mm



CANDY 92741487

CANDY 41034901

CANDY 41042459

Suitable for:

D355095 HEATING ELEMENT 1300W 230V CANDY
immersed depth 155 mm
with thermal protector




CANDY 41039780

CANDY 41042459


Suitable for:

D355300 HEATING ELEMENT 1500W/230V
crosspiece 450mm



CANDY 92206051

D355302 HEATING ELEMENT 1500W/230V
length 352 mm - width 375 mm
flange 100x22 mm - crosspiece 448 mm



CANDY 92740984

D355307 HEATING ELEMENT 1530W 230V
length 420 mm - width 310 mm
flange 106x38 mm - crosspiece 360-445 mm



CANDY 44002687

D355311 HEATING ELEMENT 1530W 230V
length 430 mm - width 305 mm
flange 100x22 mm - crosspiece 320 mm



CANDY 44003315

D355301 HEATING ELEMENT 1530W/1670 230/240V
length 375 mm - width 265 mm
flange 106x38 mm



CANDY 93700953

D355308 HEATING ELEMENT 1600W 230V
length 315 mm width 305 mm
flange 100x22 mm - crosspiece 463 mm



CANDY 93710119

D355325 HEATING ELEMENT 1640W 230V C/TP
dimensions 180x67 mm



CANDY 41009027

D355331 HEATING ELEMENT 1640W 230V C/TP
dimensions 190x67 mm



CANDY 41032112

D355090 HEATING ELEMENT 1800W 230V CANDY



CANDY 49008968



CANDY



Suitable for:

D355315 HEATING ELEMENT 1850W 230V C/TP
dimensions 275x67 mm



CANDY 91211045

D355321 HEATING ELEMENT 1850W/230V
dimensions 240x67 mm



CANDY 92216878

D355106 HEATING ELEMENT 1950W 220V CANDY
length 244 mm - width 168.5 mm
flange 50x26 mm
for DISHWASHER



CANDY 92218049

D355319 HEATING ELEMENT 1950W 230V C/TP
dimensions 245x67 mm



CANDY 41026962

D355317 HEATING ELEMENT 1950W 230V C/TP AND PROB
dimensione 224x67 mm



CANDY 41021737

CANDY 41028717

Suitable for:

D355328 HEATING ELEMENT 1850W 230V C/TP
dimensions 245x67 mm



CANDY 91209825

D355087 HEATING ELEMENT 1900W 230V CANDY



CANDY 91200592

CANDY 92220151

D355320 HEATING ELEMENT 1950W 230V
dimensions 245x65 mm



CANDY 91201638

CANDY 91211011

D355326 HEATING ELEMENT 1950W 230V C/TP
dimensions 275x67 mm



CANDY 91201546

D355332 HEATING ELEMENT 1950W 230V C/TP AND PROB
dimensions 272x67 mm



CANDY 41032114



CANDY



Suitable for:

Suitable for:

D355086 HEATING ELEMENT 1950W 230V CANDY
immersed length 310 mm

D355333 HEATING ELEMENT 1950W/230V




CANDY 41006831

CANDY 41019592

CANDY 92201730

D355309 HEATING ELEMENT 2000W 230V
length 355 mm - width 355 mm
flange 80x30 mm - crosspiece 371mm

D355316 HEATING ELEMENT 2000W 230V
with probe
dimensions 205x67 mm





CANDY 93780171

CANDY 90457722

CANDY 92247303

D355089 HEATING ELEMENT 2000W 230V CANDY
transverse 445 mm

D355310 HEATING ELEMENT 2110W 230V
length 340 mm - width 330 mm
flange 80x30 mm - crosspiece 345 mm



CANDY 41020728

CANDY 92749688

CANDY 93779668

D355094 HEATING ELEMENT 2200W 230V
immersed length 260 mm
with thermoprotection

D355313 HEATING ELEMENT 2200W 230V
external \varnothing 190 mm - flange 70x22 mm



CANDY 41021738

CANDY 91200888

D355329 HEATING ELEMENT 2200W 230V
with probe
dimensions 270x67 mm

D355323 HEATING ELEMENT 2200W 230V C/TP
dimensions 265x67 mm



CANDY 41029722

CANDY 90478223

CANDY 91201834



Suitable for:

CANDY



D355322 HEATING ELEMENT 2350W /230V C/TP
DIM 272X110mm



CANDY 41019073


Suitable for:

D355314 HEATING ELEMENT 2700W 230V
external ø 190 mm - flange 70x22 mm



CANDY 93592731


D355306 HEATING ELEMENT 800+1500W 230V
length 355 mm - width 375 mm
flange 100x22 mm - crosspiece 447 mm



CANDY 92206127

Hinges, catches and accessories

D319369 HINGE CANDY



CANDY 91944063


D053040 HINGE FOR PORTHOLE DOOR CANDY 91700103



CANDY 91700103

CANDY 91944063

D053038 HINGE LOWER CANDY




CANDY 92140359

D053047 HINGE RH OVEN CANDY



CANDY 93703924

D053048 HINGE SNAP-IN CANDY



CANDY 92784297

D053045 HINGE WASHING MACHINE CANDY



CANDY 92993526

D053046 HINGE WASHING MACHINE CANDY



CANDY 92734813

D053039 HINGE WHITE UPPER CANDY



CANDY 92140342



CANDY



Suitable for:

Suitable for:

D053042 HOOK FOR HINGE CABLE CANDY

D053044 KIT 'HINGE WASHING MACHINE CANDY



CANDY 92734912

CANDY 49001262

CANDY 91700102

CANDY 91944064

D053079 KIT HINGE CANDY

D053043 KIT HINGE WASHING MACHINE CANDY



CANDY 49023528

CANDY 90489729

CANDY 91944061

D053041 PIN FOR DOOR HINGE CANDY



CANDY 81453714

Hood filters

D560010 FILTER CARBON HOOD CANDY

D560009 FILTER HOOD CANDY ACK00023 250x92 mm



CANDY 49002519

CANDY 49016876

D560008 FILTER HOOD CANDY ACM9 240x222 mm

D560108 HOOD FILTER CANDY MOD 200 KIT 2 PCS



CANDY 49002532

CANDY 49004428

D560105 HOOD FILTER CANDY MOD 28

D560095 HOOD FILTER CANDY MOD 29 KIT 2 PCS



CANDY 91941349

CANDY 49010821



Suitable for:

D560101 HOOD FILTER CANDY MOD 30



CANDY 49001333

Suitable for:

D560098 HOOD FILTER CANDY MOD 303



CANDY 91941981

D560007 KIT FILTER HOOD ø 134 h38 mm 2 PCS CANDY
bayonet fitting



CANDY 49016875

Indicator lights

D221015 LAMP MICROWAVE 263600500007 CANDY



CANDY 49021712

Inlet hoses domestic

D248013 HOSE WATER-INLET ZEROWATT



CANDY 90440397

Interference suppression filters

D068017 CAPACITOR CANDY



CANDY 91200489


D159001 INTERF.SUPP.FILTER HE.ELEMENT 10A CANDY



CANDY 41038124

**Knobs****D241028 COVER FOR KNOB CANDY**

CANDY 80049865

D241024 KNOB ø 35 mm CANDY

CANDY 42380726

CANDY 42800495

D241026 KNOB BLACK CANDY


CANDY 41019601

D241027 KNOB CHROME-PLATED ELECTRIC PLATE CANDY

CANDY 93672152

D241025 KNOB FOR REFRIGERATOR 5 POSITIONS CANDY

CANDY 92959139

Microswitches**D803006 MICROSWITCH SAFETY CANDY**


CANDY 41900729

D121061 MICROSWITCH SAFETY DOOR CANDY

CANDY 41000264

Motors**D240064 CARBON BRUSHES FOR MOTOR CANDY**
2 pc kit

CANDY 49028931

D240063 MOTOR FAN 18W 240V CANDY
fan ø 120 mm


CANDY 41031300

CANDY 92740760



Suitable for:

D540001 MOTOR FAN 60W 240V CANDY



CANDY 41040068

CANDY



Suitable for:

D240058 MOTOR FOR WASHING MACHINE CANDY



CANDY 41015501

D240105 MOTOR MICROWAVE CANDY
240V 50Hz 4W 5/6rpm
D-shaped shaft height 13 mm



CANDY 49021718

Outlet hoses domestic

D248016 DRAIN-HOSE CANDY



CANDY 41001597

CANDY 41002867

CANDY 92131630

D248028 HOSE OUTLET



CANDY 92607506

D248014 HOSE WATER-OUTLET CANDY



CANDY 41015227

D248015 HOSE WATER-OUTLET CANDY



CANDY 41015226

D248017 HOSE WATER-OUTLET CANDY



CANDY 41021741

Portholes

D393008 FRAME INNER FOR PORTHOLE ø 420 mm CANDY



CANDY 91601644

D393009 GLASS PORTHOLE COMPLETE CANDY



CANDY 41014742



D393010 GLASS PORTHOLE TOP 47-54 CANDY



CANDY 41018077

Pressure switches

D320009 PRESSURE SWITCH 1 LEVEL CANDY
calibration 70/50 mm



CANDY 41030745

D320010 PRESSURE SWITCH 1 LEVEL CANDY
calibration 59/40 mm



CANDY 41030820

Probes

D397010 PROBE FOR TEMPERATURE NTC CANDY



CANDY 49005297

CANDY 91201325

CANDY 92743616

D397009 PROBE FOR TEMPERATURE NTC NYLON CANDY



CANDY 41020334

CANDY 41022107

D397022 SENSOR NTC TABLET



CANDY 49005297

D397023 SENSOR NTC TABLET



CANDY 41022107

D397024 SENSOR NTC TABLET



CANDY 40003258

D397025 SENSOR NTC TABLET



CANDY 41013142

D397026 SENSOR NTC TABLET



CANDY 41032956



Suitable for:

CANDY



Suitable for:

Pulleys

D318018 BUSHING FOR PULLEY TOP CANDY ϕ 275 mm



CANDY 92730860

D318014 NUT FOR BASKET SHEAVE CANDY



CANDY 41021881

**D318015 SHEAVE ϕ 210 mm CANDY
400 REVOLUTIONS/RPM**



CANDY 92735406

D318017 SHEAVE ϕ 272 mm CANDY



CANDY 92719020

D318011 SHEAVE ϕ 276 mm CANDY



CANDY 41017885

D318010 SHEAVE ϕ 280 mm CANDY



CANDY 46004459

D318013 SHEAVE ϕ 280 mm CANDY



CANDY 41029410

D318012 SHEAVE 500 RPM CANDY



CANDY 41021329
CANDY 41024467

CANDY 41022792

CANDY 41022794

D318016 SHEAVE 600 RPM ϕ 85 mm CANDY



CANDY 92791466



Pump motors

D240109 PUMP MOTOR CANDY



CANDY 49020183

D122022 PUMP MOTOR DISH WASHER CANDY
inlet \varnothing 37 mm - outlet \varnothing 37 mm
capacitor 6.3 μ F



CANDY 91207001

D122019 PUMP MOTOR 60W 230V CANDY
inlet \varnothing 38 mm
 \varnothing outlet 39 mm



CANDY 41014580

D122020 PUMP MOTOR 75W 240V CANDY
inlet \varnothing - outlet 38 mm



CANDY 49017693

CANDY 91200502

D122021 PUMP MOTOR 75W 240V CANDY
inlet \varnothing /outlet 38 mm



CANDY 49017692

D122023 PUMP MOTOR 75W 240V CANDY
inlet \varnothing 38 mm
 \varnothing outlet 39 mm



CANDY 41029135

D122024 PUMP MOTOR 75W 240V CANDY
inlet \varnothing 38 mm - \varnothing outlet 38 mm



CANDY 49019159

CANDY 91207068

CANDY 91943317

CANDY 92225242

CANDY 92741255

Rectifiers (diodes)

D344002 DIODE MICROWAVE HOOVER
code 251200900599



CANDY 49008464



Suitable for:

CANDY

Suitable for:



Rinse aid containers and accessories

D066005 LID FOR DETERGENT DRAWER CANDY



CANDY 41030135

Rinse aid pumps and accessories

D090007 DOSER MOTOR DISH WASHER CANDY



CANDY 41010261

CANDY 41900461

D090011 DOSING PUMP ELECTR. DISHWASHER CANDY



CANDY 49027436


Rotary switches

D057010 SELECTOR SWITCH CANDY




CANDY 91201719

D057007 SELECTOR SWITCH CANDY 22 POSITIONS




CANDY 41014503

D057011 SELECTOR SWITCH FOR OVEN CANDY



CANDY 91204784

D057009 SELECTOR SWITCH 16 POSITIONS CANDY



CANDY 41014502

Salt containers and accessories

D067001 GASKET FOR RING NUT CANDY



CANDY 91941722



Suitable for:

CANDY



Suitable for:

Scale removers for dishwashers


D094006 CAP FOR SCALE REMOVER CANDY



CANDY 49017965

Shelves

D380072 BOTTLE SHELF REFRIG. 430 mm CANDY



CANDY 91616797

D380075 BOTTLE SHELF REFRIG. 450 mm CANDY



CANDY 9160081
CANDY 91619080

CANDY 91602553

CANDY 91616805

D380076 GLASS PROFILE REFRIG. 520 mm CANDY




CANDY 49024989

D380135 RACK FOR REFRIGERATOR CANDY 500 mm




CANDY 49003347

D380073 SHELF GLASS REFRIG. 468x245 mm CANDY



CANDY 92955004

D380071 SHELF GLASS REFRIG. 470x240 mm CANDY



CANDY 41005410

CANDY 91602970

D380074 SHELF GLASS REFRIG. 523x300 mm CANDY



CANDY 91615435

D380070 SHELF GLASS SMOKE GRAY 468x265 mm CANDY



CANDY 91616789

CANDY 91617019

D380077 SHELF REFRIG. 465x290 mm CANDY



CANDY 91602621



Suitable for:

CANDY



Suitable for:

Shock absorbers

D708003 BRAKING-SLIDE CANDY



CANDY 92261148

CANDY 92262039

CANDY 92697838

D708002 KIT FOR BRAKING SLIDE CANDY



CANDY 90415571

CANDY 91941756

D007071 RUBBER PIECE FOR SHOCK ABSORBER CANDY



CANDY 90421165

CANDY 92260227

D007069 SHOCK ABSORBER WAS. MACHINE 120N CANDY



CANDY 41009196

D007070 SHOCK ABSORBER WASH. MACHINE CANDY



CANDY 41017170

Solenoid valves

3120004 SOLEN. VALVE ELBI TYPE 319 1 WAY 90°
220/240V 50/60Hz - max. temperature 90°C
inlet 3/4" - outlet \varnothing 10.5 mm



CANDY 25686057

3120019 ADJUSTER FOR INLET ELBI BLACK
flow rate 5.5 L/min - tolerance +/- 15%



3120021 ADJUSTER FOR INLET ELBI BLACK
flow rate 12 L/min - tolerance +/- 15%



3120022 ADJUSTER FOR INLET ELBI BLACK
flow rate 16 L/min - tolerance +/- 15%



3120204 ADJUSTER FOR OUTLET ELBI BROWN
flow rate 5.5 L/min - tolerance +/- 25%



3120201 ADJUSTER FOR OUTLET ELBI GRAY
flow rate 4.7 L/min - tolerance +/- 25%





Suitable for:

3120037 ADJUSTER FOR OUTLET ELBI GREEN
flow rate 0.25 L/min - tolerance +/- 25%



3120017 ADJUSTER FOR OUTLET ELBI ORANGE
flow rate 2.5 L/min - tolerance +/- 25%



3120203 ADJUSTER FOR OUTLET ELBI WHITE
flow rate 2 L/min - tolerance +/- 25%



3120000 FILTER FOR INLET SOLENOID VALVE ELBI



3120405 SOLEN. VALVE T&P 1 WAY 180°
230V 50/60Hz - max. temperature 90°C
inlet 3/4" - outlet ø 10.5 mm



CANDY 90422130

D120064 SOLENOID VALVE T&P 1 WAY 90°
220/240V 50/60Hz - max. temperature 90°C
inlet 3/4" - outlet ø 10.5 mm



CANDY 41014222

CANDY



Suitable for:

3120016 ADJUSTER FOR OUTLET ELBI NEUTRAL
flow rate 1.2 L/min - tolerance +/- 25%



3120015 ADJUSTER FOR OUTLET ELBI RED
flow rate 0.5 L/min - tolerance +/- 25%



3120202 ADJUSTER FOR OUTLET ELBI YELLOW
flow rate 0.35 L/min / tolerance +/- 25%



D120062 SOLENOID VALVE T&P 1 WAY 90°
220/240V 50/60Hz 8VA - max. temperature 90°C
inlet 3/4" - outlet ø 10.5 mm



CANDY 41014222

D120051 SOLENOID VALVE T&P 2-WAY 180°
adjustable CANDY
220/240V 50/60Hz - max. temperature 90°C
inlet 3/4" - two outlets ø 10.5 mm



CANDY 41018989



Suitable for:

CANDY



D120073 SOLENOID VALVE T&P 2-WAY 180°
220/240V 50/60Hz - max. temperature 90°C
inlet 3/4" - two outlets ø 10.5 mm



CANDY 41020418

D120074 SOLENOID VALVE T&P 2-WAY 180°
220/240V 50/60Hz - max. temperature 90°C
inlet 3/4" - two outlets ø 10.5 mm



CANDY 41028879

D120076 SOLENOID VALVE T&P 2-WAY 90°
220/240V 50/60Hz - max. temperature 90°C
inlet 3/4" - two outlets ø 10.5 mm



CANDY 41026491

D120031 SOLENOID VALVE 1 WAY 90° 92741156 CANDY

CANDY 92741156

D120024 SOLENOID VALVE 2-WAY 180° CANDY



CANDY 41018989

Spare parts for pumps

D125010 HOUSING FOR FILTER PUMP CANDY



CANDY 49002227

D125011 HOUSING FOR FILTER PUMP CANDY



CANDY 49007894

Springs

D250015 SPRING EVAPORATOR DOOR CANDY



CANDY 92140326

D250013 SPRING FOR DOOR HINGE 672000100000 CANDY



CANDY 49018055



CANDY



Suitable for:

D250014 SPRING FOR HINGE DX CANDY



CANDY 92484435

Suitable for:

D250011 SPRING FOR HINGE 200 mm CANDY



CANDY 92483809

D250012 SPRING WASHING MACHINE TANK CANDY



CANDY 41023091

Suction accessories

D029004 ACCESSORY MULTI-PURP. HOSE HOOVER



CANDY 49016672

D029003 HANDGRIP HOSE HOOVER



CANDY 48000874

D029034 HOSE FOR VACUUM CLEANER MOD ALYX



CANDY 35600419

D029038 HOSE FOR VACUUM CLEANER MOD SENSORY



CANDY 35600361

D029035 HOSE FOR VACUUM CLEANER MOD TELIOS



CANDY 4345142

D029036 HOSE FOR VACUUM CLEANER MOD XARION XARIO



CANDY 35600815

D029006 HOSE TELESCOPIC HOOVER



CANDY 48001438

D029001 HOSE WITH CONNECTION HOOVER



CANDY 48003095



CANDY



Suitable for:

D029002 HOSE WITH CONNECTION HOOVER



CANDY 48001397


Suitable for:

D029005 HOSE-END MULTI-PURPOSE HOOVER



CANDY 49010409

D029007 KIT WHEEL BACK PPOW



CANDY 9200823

Switches

D319052 PEDAL GRAY OUTLET CANDY



CANDY 3841400

D319051 PEDAL PUSH-BUTTON ON-OFF CANDY HOOVER




CANDY 49010394

D319063 PULH -BUTTON PANEL FREEZER CANDY
2 SWITCHES/3 INDICATORS



CANDY 92123546

D319055 PUSH-BUTTON BOARD ALISE 105 - 5 BU. CAND



CANDY 92125897

CANDY 92126234


CANDY 92127794

D319049 PUSH-BUTTON FOR WATER CONTROL CANDY




CANDY 91600536

D319056 PUSH-BUTTON 4 BUTTONS CANDY




CANDY 91207977

D319048 SELECTOR FOR FUNCTIONS 12 POSIT. CANDY



CANDY 41028011

D319023 SWITCH ROLD 6 CONTACTS
250V - 16(4)A



CANDY 90434770




CANDY



Suitable for:


D319031 SWITCH 2-POLE CANDY
6 contacts 250V 16(4)A



CANDY 90434622

Suitable for:

D319053 SWITCH CHANGEOVER CANDY




CANDY 41005481

D319405 SWITCH FOR DISHWASHER CANDY




CANDY 91942212

D319050 SWITCH 1-POLE ON/OFF



CANDY 2805027

D319054 SWITCH 2-POLE 6 CONTACTS



CANDY 90467317

Technical gases


D170001 GAS COOLING R134a
BOTTLE 900g



CANDY 49028097

Thermostats

D444045 SAFETY THERMOSTAT DOUBLE CANDY




CANDY 41034167

D444046 THERMOSTAT REFRIG. 20060355 CANDY



CANDY 49011362

D444047 THERMOSTAT REFRIG. 20060567 CANDY



CANDY 49018486

D444048 THERMOSTAT REFRIG. 20060703 CANDY



CANDY 49014732



Suitable for:

CANDY



Suitable for:

Vibrating pumps

D331005 VIBRATORY PUMP EP5 48W 230V 50Hz



CANDY 49016844

Wash and rinse arms for warewashers

D063004 BEARING OUTLET CANDY



CANDY 91607275

D243044 CONDUIT FOR IMPELLER UPPER CANDY



CANDY 49028231

D243037 IMPELLER UPPER CANDY 315 mm



CANDY 49017700

D243038 LOCKING NUT IMPELLER LOWER CANDY



CANDY 91613554


D243036 RING NUT FOR IMPELLER 673001600021 CANDY



CANDY 49005700

CANDY 49017698


D243035 WASHER IMPELLER PTFE CANDY
external \varnothing 11 mm - internal \varnothing 5 mm



CANDY 92434174

Washing baskets and accessories

D055046 BASKET FOR CUTLERY CANDY



CANDY 41027980
CANDY 92678762

CANDY 91607465
CANDY 92965912

CANDY 92678754

D055039 BASKET FOR CUTLERY WHITE CANDY



CANDY 49018009



CANDY




Suitable for:

Suitable for:

D055038 BASKET FOR CUTLERY 673002200080 CANDY

D055036 BASKET LOWER 510x510 mm CANDY



CANDY 49017778


CANDY 41020392
CANDY 92797588

CANDY 41030312
CANDY 92799949

CANDY 91750507
CANDY 92992478

D055044 BASKET SLIDE LOWER LH CANDY

D055043 BASKET SLIDE LOWER RH CANDY





CANDY 41017656

CANDY 41017657

D055042 KIT BASKET SLIDE LH CANDY

D055041 KIT BASKET SLIDE RH CANDY



CANDY 41011423

CANDY 41011424

D055045 PIN BASKET WHEEL CANDY

D055040 SLIDE-LOCK FOR BASKET CANDY



CANDY 91601247

CANDY 92608637

CANDY 91619627

D055037 SUPPORT FOR BASKET WHEEL CANDY

D055047 WHEEL FOR BASKET CANDY



CANDY 49018003

CANDY 91601248

Watertight seals and rings

D453045 SEALING RING ø 20mm CANDY

D453044 SEALING RING ø 6mm CANDY



CANDY 91941698

CANDY 92445485



CANDY



Suitable for:

Suitable for:

D453060 SEALING RING CANDY 30x52x11/12,5 mm pre-smeared

D319140 SEALING RING V-RING ø 20mm KIT



CANDY 06015542
CANDY 90484999

CANDY 09201251
CANDY 92445600

CANDY 41024550

CANDY 80018054

CANDY 80018104

D453043 SEALING RING 22x40x11.5 mm CANDY

D453066 SEALING RING 25X47X8



CANDY 92445576

CANDY 92445212

D453046 SEALING RING 30x47x10 mm CANDY

D453042 SEALING RING 30x52/60x11/15 TYPE G2




CANDY 92445535

CANDY 92445543

D453090 SEALING RING 30X52/60X11/15

D453065 SEALING RING 30X52X11/12.5



CANDY 92445543

CANDY 41024550

D453041 SEALING RING 35x62.1x11 mm HV16IT CANDY





















CANDY 91406201

The data herewith contained may change without notice and LF SpA cannot be held responsible for possible errors stated or resulting by the use of this document. All rights reserved. No part of this publication may be reproduced without written permission by LF SpA.



Distributing Components, Spare Parts & Accessories in original quality worldwide

-
-  **LF SpA HEADQUARTERS**
via Voltri, 80 - 47522 Cesena (FC) ITALY
Tel. +39 0547 34 11 11 - Fax +39 0547 34 11 10
www.lfircambi724.it - www.lfircambi724.mobi
info@lfircambi.it
Export Dept.: Tel. +39 0547 34 11 50 - Fax: +39 0547 34 11 55
www.lfspareparts724.com - www.lfspareparts724.mobi
export@lfspareparts.com
 -  **LF SpA HOUSEHOLD COMPONENTS DIVISION**
Via Padriciano, 34149 Trieste - Italia - AREA Science Park
Tel. +39 0547 34 12 42 - Fax +39 0547 34 12 48
www.lfspareparts724.com - www.lfspareparts724.mobi
info@lfspareparts.com
 -  **EPGC Sas FRANCE**
13, Rue des Forts - 59960 Neuville en Ferrain
Tel. +33 (0)3 20 25 06 21
Fax +33 (0)3 20 25 34 12
www.epgc.com
www.epgc724.mobi
epgc@epgc.com
 -  **LF GmbH GERMANY**
Junkersstrasse, 3 - D-82178 Puchheim - München
Tel. +49 89 89 45 78 66
Fax +49 89 89 45 78 88
www.lfersatzteile724.de
www.lfersatzteile724.mobi
info@lfersatzteile.de
 -  **LF China REPUBLIC OF CHINA**
Room 403, No.2, Huadu Mansion, Lane 422, Huanghua Rd.
Minhang Dist. - 201103 Shanghai
Tel. +86 (0)21 33 53 66 31
Fax +86 (0)21 33 53 66 32
www.lfspareparts724.com
www.lfspareparts724.mobi
china@lfspareparts.com
 -  **OOO LF RUSSIAN FEDERATION**
Ul. Anatoliya Zhivova, 8 - office 1 - 123100 Moscow
Tel./Fax +7 495 725 26 53
www.lfspareparts724.ru
www.lfspareparts724.mobi
info@lfspareparts.ru
 -  **LF Repuestos Horeca S.L.U. SPAIN**
Poligono Industrial Carpetania - C/Miguel Faraday, 8 - 28906 Getafe
Tel. +34 91 477 91 00
Fax +34 91 477 90 81
www.lfrepuestos-horeca724.es
www.lfrepuestos724.mobi
info@lfrepuestos.es
 -  **LF SpA Cesena (IT) Swiss Branch Steinhausen SWITZERLAND**
Sennweidstrasse, 45 - CH-6312 Steinhausen
Tel. +41 (0)41 760 15 80-1
Fax +41 (0)41 760 15 85
www.lfersatzteile724.ch
www.lfersatzteile724.mobi
info@lfersatzteile.ch
 -  **LF Spare Parts Ltd. UNITED KINGDOM**
A10a Lakeside Business Park, Broadway Lane
South Cerney, Gloucestershire GL7 5XL
Tel. +44 (0)1285 86 16 25
Fax +44 (0)1285 86 39 49
www.lfspareparts724.co.uk
www.lfspareparts724.mobi
info@lfspareparts.co.uk
 -  **AUSTRALIA AND NEW ZEALAND**
www.lfspareparts724.com
andrea.calvio@lfspareparts.com
 -  **AUSTRIA**
www.lfersatzteile724.at
info@lfersatzteile.at
 -  **BALKAN COUNTRIES**
www.lfspareparts724.com
matijaramov@lfspareparts.com
 -  **BALTIC COUNTRIES**
www.lfspareparts724.com
inara.silina@lfspareparts.com
 -  **CENTRAL AND EASTERN EUROPE**
www.lfspareparts724.cz
jiri.kremla@lfspareparts.cz
 -  **DENMARK**
www.lfspareparts724.dk
michael.leth@lfspareparts.com
 -  **JAPAN**
www.lfspareparts724.jp
hiroshi.ukai@lfspareparts.jp
 -  **SOUTH KOREA**
www.lfspareparts724.com
fabio.doni@lfspareparts.com
 -  **TURKEY**
www.lfyedekparca724.com
basar.ergun@lfyedekparca.com
 -  **USA AND CANADA**
www.lfspareparts724.us
sauro.dallaglio@lfspareparts.us
howard.truitt@lfspareparts.us