




Spare parts for:

Cooking equipment



Suitable for:

SCHÖLLER



This catalogue is automatically generated.
Therefore, the sequence of the items might
not be always shown at best.

Updates will be issued in case of additions
and/or amendments.

Suitable universal spare parts may not be included

Rel. 2013-11182128





Suitable for:

SCHÖLLER



Suitable for:

Lamps

3221349 GLASS F.OVEN RECEPTACLE LAMP ø 72 mm



SCHÖLLER

3221050 LAMP RECEPTACLE WITH LAMP E14 40W 240V

lamp glass ø 72 mm
mounting hole ø 68 mm
max temperature 300°C
for Display cabinet warm (CB) ESP/2 - EV16 - EV24
EV35 - VR12E - VR12G - VR20 - VR24 - VR30
VR36 - VR48 - VR8E



SCHÖLLER