



Spare parts for:
Coffee grinders



Suitable for:

RANCILIO




This catalogue is automatically generated.
Therefore, the sequence of the items might
not be always shown at best.
Updates will be issued in case of additions
and/or amendments.
Suitable universal spare parts may not be included





GRINDER ASSEMBLY MD40

MD40



RAMC01




RANCILIO



Position	LF code no.	Description
1	1080901	COMPLETE COFFEE HOPPER
2	1252523	COFFEE HOPPER LID
4	1348814	S/STEEL COGGED WASHER M4 UNI 8842
8	1252505	COFFEE HOPPER CLOSING SHEET
10	1241906	FILTER HANDLE
15	1252525	DOSER LID
17	1528516	CUT HEAD SCREW M5x12 UNI 6107
21	1252506	DOSER SCRAPER
21	1252507	DOSER SCRAPER
24	1343011	UPPER STAR MD
25	1252511	CLOSING SECTOR MD
26	1343012	MIDDLE STAR MD
27	1250906	STAR SPRING
29	1343013	LOWER STAR MD WITH PIN
30	1250810	LEVER RETURN SPRING \varnothing 10x31/45 mm
33	1225901	DISPENSER LEVER MD
34	1250907	STROKE COUNTER SPRING MD
36	1252514	COUNTER FOR COFFEE GRINDER
38	1252512	DOSER PIN MD
39	1252502	PAWL FOR COFFEE GRINDER MD
41	1186504	STAINLESS STEEL WASHER \varnothing 29x10.6x2 mm
43	1252501	DOSER BOTTOM LID
44	1528001	SCREW M4x10 UNI 6109
45	1528100	CROSS HEAD SCREW M4x12 UNI 7687
47	1385526	COFFEE TAMPER ASSEMBLY MD
53	1252527	ADJUSTMENT RING RETAINER MD40 MD50
57	1250908	MD PIN SPRING
61	1251109	GRINDING BURRS RANCILIO (PAIR) LEFT
62	3528291	CROSS HEAD FLUSH SCREW M4x8 UNI 7688
67	1319215	BLACK BIPOLAR SWITCH 16A 250V
68	3319501	SWITCH PROTECTION CAP
70	3528111	S/S SCREW T.E. M6x10 UNI 5739 DIN 24017
71	1252429	COFFEE COLLECTION TRAY
73	1313901	RUBBER FOOT MD80
75	1528100	CROSS HEAD SCREW M4x12 UNI 7687
80	1348813	HEXAGONAL NORM.NUT M4 ST.STEEL UNI 5588
83	1528030	ST.STEEL HEXAGONAL NUT M6 UNI 5588
88	1348814	S/STEEL COGGED WASHER M4 UNI 8842
90	1241513	BLIND HEXAGONAL NUT M8 UNI 5721



GRINDER ASSEMBLY MD50



RAMC02

Positions without LF code no.: upon request




RANCILIO



Position	LF code no.	Description
1	1080902	COMPLETE COFFEE HOPPER
2	1252524	COFFEE HOPPER LID
4	1348814	S/STEEL COGGED WASHER M4 UNI 8842
8	1252504	COFFEE HOPPER CLOSING SHEET
10	1241906	FILTER HANDLE
15	1252525	DOSER LID
16	1528100	CROSS HEAD SCREW M4x12 UNI 7687
20	1240847	MICROSWITCH 5A 250V
21	1252507	DOSER SCRAPER
22	1252510	DOSING KNOB MD50 MD80
24	1343011	UPPER STAR MD
25	1252511	CLOSING SECTOR MD
26	1343012	MIDDLE STAR MD
27	1250906	STAR SPRING
29	1343013	LOWER STAR MD WITH PIN
30	1250810	LEVER RETURN SPRING \varnothing 10x31/45 mm
33	1225901	DISPENSER LEVER MD
34	1250907	STROKE COUNTER SPRING MD
36	1252514	COUNTER FOR COFFEE GRINDER
38	1252512	DOSER PIN MD
39	1252502	PAWL FOR COFFEE GRINDER MD
41	1186504	STAINLESS STEEL WASHER \varnothing 29x10.6x2 mm
43	1252501	DOSER BOTTOM LID
44	1528001	SCREW M4x10 UNI 6109
45	1528100	CROSS HEAD SCREW M4x12 UNI 7687
47	1385526	COFFEE TAMPER ASSEMBLY MD
54	1252515	HEAD PROTECTOR MD50
56	1252516	DOSER CYLINDER
58	1090906	DISPENSER BODY
59	1240846	MICROSWITCH 13A 250 V
61	1528030	ST.STEEL HEXAGONAL NUT M6 UNI 5588
62	1252526	GRINDER/DOSER HEAD MD 50 WITH OUTLET HOL
63	1251071	GRINDING BURRS RANCILIO-VFA (PAIR) LEFT
65	3528291	CROSS HEAD FLUSH SCREW M4x8 UNI 7688
67	1252527	ADJUSTMENT RING RETAINER MD40 MD50
68	1250908	MD PIN SPRING
72	1348817	STAINLESS STEEL CIRCLIP RA-4 UNI 7437
74	1350901	GRINDING ADJUSTMENT RING MD
75	1324903	GRINDING ADJUSTMENT PIN
77	1240907	MOTOR MD 50 220V ASSEMBLY
78	1348814	S/STEEL COGGED WASHER M4 UNI 8842
79	1348813	HEXAGONAL NORM.NUT M4 ST.STEEL UNI 5588
85	1319916	ORANGE BIPOLAR PUSH-BUTTON 16A 250V
86	3319501	SWITCH PROTECTION CAP
89	1252517	COFFEE COLLECTION TRAY
90	1162901	FILTER HOLDER FORK
91	3528111	S/S SCREW T.E. M6x10 UNI 5739 DIN 24017
96	1313901	RUBBER FOOT MD80
98	1241513	BLIND HEXAGONAL NUT M8 UNI 5721
105	3351605	RELAY 60.63 10A 230V 50/60Hz
106	1252529	CIRCUIT INTERRUPTER MD50 4211 - NEW
109	1528030	ST.STEEL HEXAGONAL NUT M6 UNI 5588
112	1319215	BLACK BIPOLAR SWITCH 16A 250V



GRINDER ASSEMBLY MD80



RAMC03

Positions without LF code no.: upon request



RANCILIO



Position	LF code no.	Description
1	1080903	COMPLETE COFFEE HOPPER
2	1252503	COFFEE HOPPER LID
4	1348814	S/STEEL COGGED WASHER M4 UNI 8842
8	1252504	COFFEE HOPPER CLOSING SHEET
10	1241906	FILTER HANDLE
15	1252525	DOSER LID
16	1528100	CROSS HEAD SCREW M4x12 UNI 7687
20	1240847	MICROSWITCH 5A 250V
21	1252507	DOSER SCRAPER
22	1252510	DOSING KNOB MD50 MD80
24	1343011	UPPER STAR MD
25	1252511	CLOSING SECTOR MD
26	1343012	MIDDLE STAR MD
27	1250906	STAR SPRING
29	1343013	LOWER STAR MD WITH PIN
30	1250810	LEVER RETURN SPRING \varnothing 10x31/45 mm
33	1225901	DISPENSER LEVER MD
34	1250907	STROKE COUNTER SPRING MD
36	1252514	COUNTER FOR COFFEE GRINDER
38	1252512	DOSER PIN MD
39	1252502	PAWL FOR COFFEE GRINDER MD
41	1186504	STAINLESS STEEL WASHER \varnothing 29x10.6x2 mm
43	1252501	DOSER BOTTOM LID
44	1528001	SCREW M4x10 UNI 6109
45	1528100	CROSS HEAD SCREW M4x12 UNI 7687
47	1385526	COFFEE TAMPER ASSEMBLY MD
56	1252519	DOSER CYLINDER
58	1090906	DISPENSER BODY
59	1240846	MICROSWITCH 13A 250 V
61	1528030	ST.STEEL HEXAGONAL NUT M6 UNI 5588
62	1252518	GRINDER HEAD MD 50 WITH OUTLET HOLE
63	1251072	GRINDING BURRS RANCILIO (PAIR) LEFT
67	1252430	RING NUT LOCKING PIN
72	1348817	STAINLESS STEEL CIRCLIP RA-4 UNI 7437
74	1350901	GRINDING ADJUSTMENT RING MD
75	1324903	GRINDING ADJUSTMENT PIN
82	1319215	BLACK BIPOLAR SWITCH 16A 250V
83	1319916	ORANGE BIPOLAR PUSH-BUTTON 16A 250V
84	3319501	SWITCH PROTECTION CAP
86	1252520	COFFEE COLLECTION TRAY
87	1162901	FILTER HOLDER FORK
88	3528111	S/S SCREW T.E. M6x10 UNI 5739 DIN 24017
91	1348814	S/STEEL COGGED WASHER M4 UNI 8842
94	1313901	RUBBER FOOT MD80
103	1528030	ST.STEEL HEXAGONAL NUT M6 UNI 5588
110	1252804	RELAY BASE



Suitable for:

RANCILIO



Suitable for:

Adjustment rings for coffee grinder

1350901 GRINDING ADJUSTMENT RING MD
for Grinder-dispenser (RANCILIO) MD50 - MD80



RANCILIO 38120065

Bearings


1063911 BEARING 6202 2Z
external \varnothing 35 mm-internal \varnothing 15 mm-thickness 11 mm



RANCILIO 44015010

Bodies

1252518 GRINDER HEAD MD 50 WITH OUTLET HOLE



RANCILIO 14701012

1252526 GRINDER/DOSER HEAD MD 50 WITH OUTLET HOLE



RANCILIO 14701011

Capacitors

3068016 CAPACITOR μ F 10 450V 50/60Hz
operating temperature $-25+85^{\circ}\text{C}$
in compliance with EEC 93/68 and 92/31 regulations



RANCILIO 34020003

RANCILIO 65206002

3068019 CAPACITOR μ F 12.5 450V 50/60Hz
operating temperature $-25+85^{\circ}\text{C}$
in compliance with EEC 93/68 and 92/31 regulations



RANCILIO 34020004


3068024 CAPACITOR μ F 16 450V 50/60Hz
operating temperature $-25+85^{\circ}\text{C}$
in compliance with EEC 93/68 and 92/31 regulations



RANCILIO 34020016

RANCILIO 65206004

3068008 CAPACITOR μ F 5 450V 50/60Hz
operating temperature $-25+85^{\circ}\text{C}$
in compliance with EEC 93/68 and EEC 92/31 regulat



RANCILIO 65206010

Suitable for:

Suitable for:

3068010 CAPACITOR μ F 6.3 450V 50/60Hz
 operating temperature $-25+85^{\circ}\text{C}$
 in compliance with EEC 93/68 and EEC 92/31 regulat



RANCILIO 65206002

RANCILIO 65206009

Circlips

1348817 STAINLESS STEEL CIRCLIP RA-4 UNI 7437



RANCILIO 37510400

Coffee measuring spoons

1069001 PLASTIC MEASURING SPOON 20 ml



RANCILIO 38120004


1069002 STAINLESS STEEL MEASURING SPOON 20 ml



RANCILIO


Containers for coffee

1252504 COFFEE HOPPER CLOSING SHEET
 for Grinder-dispenser (RANCILIO) MD50 - MD80




RANCILIO 32329015

1252505 COFFEE HOPPER CLOSING SHEET
 for Grinder-dispenser (RANCILIO) MD40




RANCILIO 32329038

1252503 COFFEE HOPPER LID
 for Grinder-dispenser (RANCILIO) MD80



RANCILIO 38120025

1252523 COFFEE HOPPER LID
 for Grinder-dispenser (RANCILIO) MD40



RANCILIO 38120040



Suitable for:

RANCILIO



1252524 COFFEE HOPPER LID
for Grinder-dispenser (RANCILIO) MD50



RANCILIO 38120012

1080901 COMPLETE COFFEE HOPPER
for Grinder-dispenser (RANCILIO) MD40



RANCILIO 14030005

1080902 COMPLETE COFFEE HOPPER
for Grinder-dispenser (RANCILIO) MD50



RANCILIO 14030001

1080903 COMPLETE COFFEE HOPPER
for Grinder-dispenser (RANCILIO) MD80



RANCILIO 14030011

Counters

1252514 COUNTER FOR COFFEE GRINDER
for Grinder-dispenser (RANCILIO) MD40 - MD50
MD80



RANCILIO 69000085

Dosers for coffee

1090906 DISPENSER BODY
for Grinder-dispenser (RANCILIO) MD50 - MD80



RANCILIO 21204001

1252501 DOSER BOTTOM LID
for RANCILIO MD40-MD50-MD80



RANCILIO 22206501

1252516 DOSER CYLINDER
for Grinder-dispenser (RANCILIO) MD50



RANCILIO 38125008

RANCILIO 38125008A

1252519 DOSER CYLINDER
for Grinder-dispenser (RANCILIO) MD80



RANCILIO 38125009

RANCILIO 38125009A




RANCILIO



Suitable for:

1252525 DOSER LID
for Grinder-dispenser (RANCILIO) MD40 - MD50
MD80



RANCILIO 38120024

Suitable for:

1252506 DOSER SCRAPER
for Grinder-dispenser (RANCILIO) MD40



RANCILIO 38123038

1252507 DOSER SCRAPER
for Grinder-dispenser (RANCILIO) MD40 - MD50
MD80



RANCILIO 38123002

1252515 HEAD PROTECTOR MD50



RANCILIO 38120063

Feet

1313901 RUBBER FOOT MD80



RANCILIO 36310003

RANCILIO 36310005

Forks for portafilter coffee grinder

1162901 FILTER HOLDER FORK
for Grinder-dispenser (RANCILIO) MD50 - MD80



RANCILIO 21210501

Gaskets and seals

1186421 O-RING 02018 EPDM



RANCILIO 36401003



Suitable for:

RANCILIO



Suitable for:

Grinders

1251072 GRINDING BURRS RANCILIO (PAIR) LEFT
 external \varnothing 75 mm - internal \varnothing 43 mm
 thickness 10.5 mm - 3 mounting holes
 for Grinder-dispenser (PROMAC) MD75
 for Grinder-dispenser (RANCILIO) MD80



RANCILIO 69000034

1251109 GRINDING BURRS RANCILIO (PAIR) LEFT
 external \varnothing 50 mm - internal \varnothing 31 mm
 height 8 mm - 3 mounting holes
 for Grinder-dispenser (PROMAC) MDCLUB
 for Grinder-dispenser (RANCILIO) MD40 - ROCKY



RANCILIO 69000032

1251071 GRINDING BURRS RANCILIO-VFA (PAIR) LEFT
 external \varnothing 64 mm - internal \varnothing 38 mm
 thickness 9 mm - 3 mounting holes
 for Grinder-dispenser (PROMAC) MD64
 for Grinder-dispenser (RANCILIO) MD50
 for Grinder-dispenser (VFA EXPRES) AE1464NEW
 AN1464 - E1464 - N1464



RANCILIO 69000033

Ironmongery (screws,nuts,washers)

1241513 BLIND HEXAGONAL NUT M8 UNI 5721



RANCILIO 37320800

3528291 CROSS HEAD FLUSH SCREW M4x8 UNI 7688



RANCILIO 37030407

1528100 CROSS HEAD SCREW M4x12 UNI 7687



RANCILIO 37113913

RANCILIO 37174012

1528516 CUT HEAD SCREW M5x12 UNI 6107



RANCILIO 25124007

RANCILIO 37030511

RANCILIO 37030513

1348813 HEXAGONAL NORM.NUT M4 ST.STEEL UNI 5588



RANCILIO 37310400

3528213 HEXAGONAL NORMAL NUT M5 UNI 5588



RANCILIO 37320501



RANCILIO



Suitable for:

3528111 S/S SCREW T.E. M6x10 UNI 5739 DIN 24017



RANCILIO 37040610

Suitable for:

1348814 S/STEEL COGGED WASHER M4 UNI 8842




RANCILIO 37430400

1528023 S/STEEL CROSS SCREW M5x16 mm UNI 7688



RANCILIO 37060513

3528143 S/STEEL EXAGONAL BLIND NUT M5-200PCS
NF E 27-453



RANCILIO 37370501

1184012 S/STEEL SCREW T.C.C.E.I. M5x10 UNI 5931



RANCILIO 37040510

1528001 SCREW M4x10 UNI 6109



RANCILIO 37184012

1528030 ST. STEEL HEXAGONAL NUT M6 UNI 5588



RANCILIO 37320600

RANCILIO 37320601


1186504 STAINLESS STEEL WASHER \varnothing 29x10.6x2 mm



RANCILIO 39520008


Knobs

1252510 DOSING KNOB MD50 MD80



RANCILIO 21208701

1241906 FILTER HANDLE



RANCILIO 38120010



Suitable for:

RANCILIO



Suitable for:

Lamps

3221095 ORANGE INDICATOR LAMP 230V
head \varnothing 13.5 mm - hole \varnothing 10 mm - 120°C
universal application



RANCILIO 65216018

Levers

1225901 DISPENSER LEVER MD
for Grinder-dispenser (RANCILIO) MD40 - MD50
MD80



RANCILIO 14705015

RANCILIO 22105001

Microswitches

1240846 MICROSWITCH 13A 250 V
for Grinder-dispenser (RANCILIO) MD50 - MD80



RANCILIO 34100004

3240123 MICROSWITCH 16A 250V



RANCILIO 68023055

1240847 MICROSWITCH 5A 250V
for Grinder-dispenser (RANCILIO) MD50 - MD80



RANCILIO 34100003

Motors

1240907 MOTOR MD 50 220V ASSEMBLY



RANCILIO 14000022

RANCILIO 34014022

RANCILIO 34014086

**Pawls for coffee grinder dosers****1252502 PAWL FOR COFFEE GRINDER MD**

RANCILIO 21103000

Pins**1252527 ADJUSTMENT RING RETAINER MD40 MD50**

RANCILIO 22208501

1252512 DOSER PIN MD

RANCILIO 26105005

1252430 RING NUT LOCKING PIN


RANCILIO 38111003

Pull-through brushes**1384001 BRUSH FOR COFFEE SHOWER**

RANCILIO 38120068

Relays**1252529 CIRCUIT INTERRUPTER MD50 4211 - NEW**

RANCILIO 34020109


1252804 RELAY BASE

RANCILIO 34020106



Suitable for:

3351605 RELAY 60.63 10A 230V 50/60Hz
3 switching contacts
for CIMBALI JUNIOR




RANCILIO 34200192

RANCILIO 65229024

RANCILIO 68023190

Suitable for:

3351008 RELAY 62.83 16A 230V 50/60Hz
3 switching contacts
for Grinder-dispenser (CIMBALI) MAGNUM - SPECIAL
6/S - 6/SNEW
for Grinder-dispenser (FAEMA) MD3000



RANCILIO 65229036


Springs

1250810 LEVER RETURN SPRING \varnothing 10x31/45 mm
for RANCILIO MD40-MD50-MD80



RANCILIO 39220010

1250908 MD PIN SPRING



RANCILIO 39120035

1250906 STAR SPRING
for RANCILIO MD40-MD50-MD80



RANCILIO 39120025

1250907 STROKE COUNTER SPRING MD



RANCILIO 39220015


Stars and spare parts

1252511 CLOSING SECTOR MD



RANCILIO 32329014

1324903 GRINDING ADJUSTMENT PIN



RANCILIO 26214010

1343013 LOWER STAR MD WITH PIN




RANCILIO 14701020

1343012 MIDDLE STAR MD



RANCILIO 21206501

1343011 UPPER STAR MD



RANCILIO 21208501


Switches

1319215 BLACK BIPOLAR SWITCH 16A 250V
with orange led indicator light
"flash" screen printing
mounting hole 22x30 mm
for Grinder-dispenser (RANCILIO) MD40 - MD50
MD80



RANCILIO 34030064

1319916 ORANGE BIPOLAR PUSH-BUTTON 16A 250V
mounting hole 30x22 mm
silk-screen printing "START"
for Grinder-dispenser (RANCILIO) MD50 - MD80



RANCILIO 34030050

RANCILIO 34030052

3319501 SWITCH PROTECTION CAP
external dimensions 29x36 mm
for switches with mounting hole 22x30 mm



RANCILIO 34030131

Tampers for coffee

1385526 COFFEE TAMPER ASSEMBLY MD



RANCILIO 14701027

1385002 NYLON COFFEE TAMPER ø 50/57 mm



RANCILIO 38120005

Terminal blocks

3247016 3-POLE TERMINAL BLOCK FV273 40A 450V
for cable max 6 mm²
operating temperature 150°C
nominal voltage 450 V



RANCILIO 34150023



Suitable for:


RANCILIO



Suitable for:


Trays

1252429 COFFEE COLLECTION TRAY
for Grinder-dispenser (RANCILIO) MD40



RANCILIO 38120041

1252517 COFFEE COLLECTION TRAY
for Grinder-dispenser (RANCILIO) MD50



RANCILIO 38120013

1252520 COFFEE COLLECTION TRAY
for Grinder-dispenser (RANCILIO) MD80



RANCILIO 38120026

The data herewith contained may change without notice and LF SpA cannot be held responsible for possible errors stated or resulting by the use of this document. All rights reserved. No part of this publication may be reproduced without written permission by LF SpA.



LF SpA
via Voltri, 80 - 47522 Cesena (FC) ITALIA
Tel. +39 0547 34 11 11 - Fax +39 0547 34 11 10
www.lfricambi724.it - www.lfricambi724.mobi
info@lfricambi.it
Export Dept.: Tel. +39 0547 34 11 50 - Fax: +39 0547 34 11 55
www.lfspareparts724.com - www.lfspareparts724.mobi
export@lfspaceparts.com

FRANCE



EPGC Sas
13, Rue des Forts - 59960 Neuville en Ferrain
Tél. +33 (0)3 20 25 06 21
Fax +33 (0)3 20 25 34 12
www.epgc.com
www.epgc724.mobi
epgc@epgc.com

DEUTSCHLAND



LF GmbH
Junkersstrasse, 1 - D-82178 Puchheim - München
Tel. +49 89 89 45 78 66
Fax +49 89 89 45 78 88
www.lfersatzteile724.de
www.lfersatzteile724.mobi
info@lfersatzteile.de

SCHWEIZ



LF GmbH Verkaufsbüro
Sennweidstrasse, 45 - CH-6312 Steinhausen
Tel. +41 (0)41 760 15 80-1
Fax +41 (0)41 760 15 85
www.lfersatzteile724.ch
www.lfersatzteile724.mobi
info@lfersatzteile.ch

ESPAÑA



LF Repuestos Horeca S.L.U.
Calle Ciudad Real, 10 - 45517 Escalonilla - Toledo
Tif. +34 91 477 91 00
Fax +34 91 477 90 81
www.lfrepuestos724.es
www.lfrepuestos724.mobi
info@lfrepuestos.es

UNITED KINGDOM



LF Spare Parts Ltd.
A10a Lakeside Business Park, Broadway Lane
South Cerney, Gloucestershire GL7 5XL
Tel. +44 (0)1285 86 16 25
Fax +44 (0)1285 86 39 49
www.lfspareparts724.co.uk
www.lfspareparts724.mobi
info@lfspaceparts.co.uk

RUSSIA



OOO LF
ul, Anatoliya Zhivova, 8 - office 1 - 123100 Moscow
Tel. +7 499 259 85 75
Fax +7 495 725 26 53
www.lfspareparts724.ru
www.lfspareparts724.mobi
info@lfspaceparts.ru

CHINA



LF China
Room 102, House 8, Lane 725, Mao Tai Rd.
Changning Dist. - 200336 Shanghai
Tel. +86 (0)21 33 53 66 31
Fax +86 (0)21 33 53 66 32
www.lfspareparts724.com
www.lfspareparts724.mobi
china@lfspaceparts.com