



Spare parts for:

Washing equipment



Suitable for:

ELECTROLUX



This catalogue is automatically generated.
Therefore, the sequence of the items might
not be always shown at best.

Updates will be issued in case of additions
and/or amendments.

Suitable universal spare parts may not be included





Suitable for:



Suitable for:

Air Chambers

3060001 AIR CHAMBER ø 150x65 mm

for Dishwasher (ZANUSSI) ALS540 - LS50 - LS500
LS501 - LS52 - LS540 - LS541 - LS75 - LS96
for Dishwasher hood type (ZANUSSI) LS1080 - LS860
for Pan washing machine (ZANUSSI) LO480 - PLO480



ELECTROLUX 045459

3060011 AIR CHAMBER ø 44x113 mm

for Dishwasher (ZANUSSI) CF314 - LS360 - LS365
LS365F - LS505 - LS510 - ZLS510 - ZLS520
ZLS521
for Dishwasher conveyor type (ZANUSSI) CT142
CT190 - CT191
for Dishwasher hood type (ZANUSSI) HYDRA1000
HYDRA1200 - LS10 - LS12



ELECTROLUX 0H2542

ELECTROLUX 046631

1186255 O-RING 0109 EPDM



ELECTROLUX 068573

3060012 AIR CHAMBER ø 47x59 mm

for Dishwasher (ZANUSSI) LS62 - LS63 - LS64 - LS7
for Dishwasher hood type (ZANUSSI) LS10 - LS12
LS8 - LS9



ELECTROLUX 048308

3060056 LOWER SEAL

for Dishwasher (ZANUSSI) CRYSTAL51 - CRYSTAL52
LS505 - LS510
for Dishwasher hood type (ZANUSSI) LS10 - LS12



ELECTROLUX 067930

3060088 AIR CHAMBER NUT M14

for Dishwasher (ZANUSSI) CRYSTAL51 - CRYSTAL52
LS505 - LS510 - LS62 - LS63 - LS64 - LS7
for Dishwasher hood type (ZANUSSI) LS10 - LS12
LS8 - LS9



ELECTROLUX 049268



ELECTROLUX



Suitable for:

Suitable for:

3186860 OR GASKET 03056 EPDM

EX OR 0118
for Dishwasher (UNIC) FI100 - FI120
for Dishwasher (ZANUSSI) CRYSTAL51 - CRYSTAL52
LS510 - LS62 - LS63 - LS64 - LS7
for Dishwasher hood type (FAGOR) FI-80
for Dishwasher hood type (ZANUSSI) LS10 - LS12
LS8 - LS9



ELECTROLUX 0KK400

ELECTROLUX 068642

3060035 AIR CHAMBER 260x200 mm

for Dishwasher (ZANUSSI) ECOTEMP5 - LS6E



ELECTROLUX 049459

3061023 CAP GASKET

for Dishwasher (ZANUSSI)



ELECTROLUX 048230

3060034 BOILER AIR CHAMBER 230 mm

for Dishwasher (ZANUSSI) LS6AH - WT30H



ELECTROLUX 0L0098

ELECTROLUX 049628

3060037 AIR CHAMBER RING NUT

for Dishwasher (ZANUSSI)



ELECTROLUX 049480

3060038 O-RING GASKET 03212 EPDM

for Dishwasher (ZANUSSI)



ELECTROLUX 049460



Suitable for:

ELECTROLUX



3060601 COMPLETE AIR CHAMBER

complete with fittings, o-ring and retaining bolt
 for Dishwasher (COLGED) BETA250 - BETA253 - BETA50
 BETA53 - ONIX50 - SILVER50
 for Dishwasher (ELETTROBAR) E52
 for Dishwasher (HOBART) GW600
 for Glasswasher/Cupwasher (BONNET) VR1000R
 VR1000RAD - VR1500C - VR1500CAD
 for Glasswasher/Cupwasher (ELETTROBAR) S621 - S624
 S626 - S634 - S636
 for Glasswasher/Cupwasher (HOBART) GW601
 for Glasswasher/Cupwasher (ZANUSSI) CRYSTAL11
 CRYSTAL22 - LTB11 - LTB12 - LTB22



ELECTROLUX 069515

3060602 FITTING FOR AIR CHAMBER

for Dishwasher (HOBART) GW600
 for Glasswasher/Cupwasher (BONNET) VR1000R
 VR1000RAD - VR1500C - VR1500CAD
 for Glasswasher/Cupwasher (HOBART) GW601



ELECTROLUX 069670

1186318 O-RING 03043 EPDM

for Dishwasher (FAGOR) FI-30 - FI-48 - FI-48B
 FI-50 - FI-64 - FI-64B - FI-72
 for Dishwasher (HOBART) GW600
 for Dishwasher (JEMI) GS-8/2 - GS-8/2D - GS-9/2
 GS-9/2D
 for Dishwasher hood type (JEMI) GS-100 - GS-82
 for Glasswasher/Cupwasher (BONNET) VR1000R
 VR1500C
 for Glasswasher/Cupwasher (COLGED) BETA35
 for Glasswasher/Cupwasher (ELETTROBAR) S621 - S636
 for Glasswasher/Cupwasher (FAGOR) - Series LVC
 Series LVR
 for Glasswasher/Cupwasher (HOBART) GW601
 for Glasswasher/Cupwasher (JEMI) GS-3 - GS-3D
 GS-4/2 - GS-4/2D



ELECTROLUX 069644

3060605 FITTING

for Dishwasher (HOBART) GW600
 for Glasswasher/Cupwasher (BONNET) VR1000R
 VR1000RAD - VR1500C - VR1500CAD
 for Glasswasher/Cupwasher (HOBART) GW601



3786668 O-RING 03024 EPDM



3060603 RETAINING BOLT FOR FITTING

for Dishwasher (HOBART) GW600
 for Glasswasher/Cupwasher (BONNET) VR1000R
 VR1000RAD - VR1500C - VR1500CAD
 for Glasswasher/Cupwasher (HOBART) GW601




Bearings

3063113 BEARING 6004 2RSH
outside \varnothing 42 mm - insied \varnothing 20 mm - thickness 12 mm



ELECTROLUX 089921

5009467 BEARING 6007 2RS
extern. \varnothing 62 mm - intern. \varnothing 35 mm - thickness 14 mm



ELECTROLUX 0HD046

3063018 BEARING 6200 2RS1
external \varnothing 30 mm -internal \varnothing 10 mm -thickness 9 mm
for Dishwasher hood type (FAGOR) ECO-120 - FI-100
FI-120 - FI-120W - FI-80 - FI-80W - MF-120



ELECTROLUX 072018

1063005 BEARING 6201 2RS
external \varnothing 32 mm-internal \varnothing 12 mm-thickness 10 mm



ELECTROLUX 0D5346

ELECTROLUX 072019

3063005 BEARING 6202 2RS
external \varnothing 35 mm -internal \varnothing 15 mm-thickness 11 mm
for Dishwasher (ZANUSSI) LS4 - LS50 - LS500



ELECTROLUX 0D0035

ELECTROLUX 072751

9063001 BEARING 6206 2RS
external \varnothing 62 mm -internal \varnothing 30 mm-thickness 16 mm
for Dishwasher (JEMI) - Series MC
for Dishwasher conveyor type (JEMI) - Series MA



ELECTROLUX 0D0006

ELECTROLUX 0KK225

Belts

3062011 TOOTHED BELT T10-610 0702
for transmission pulley
for models RT100-RT140-RT190-RT270
for Dishwasher conveyor type (ZANUSSI) RT100
RT140 - RT190 - RT270



ELECTROLUX 0E5050

ELECTROLUX 0E5188



Suitable for:

ELECTROLUX



Suitable for:

Boilers

3024003 BOILER \varnothing 140x400 mm
for Dishwasher (ZANUSSI) LS360 - LS360F - LS365
LS365F - LS500 - LS500F - LS501 - LS501F
LS540



ELECTROLUX 046294

3024085 BOILER \varnothing 145x405 mm
for Dishwasher (ZANUSSI) FL5 - FL5DP - LS5 - LV5
LV5DP - WT4D - WT46



ELECTROLUX 049958

3024024 BOILER \varnothing 145x430 mm
for Dishwasher (ZANUSSI) LS32 - LS33



ELECTROLUX 049336

3024018 BOILER \varnothing 200x365 mm
3 holes for heating element
for Dishwasher hood type (ZANUSSI) HT1000 - HT1200
LS10 - LS12 - WT60



ELECTROLUX 049632

3024008 BOILER \varnothing 200x410 mm
for Dishwasher (ZANUSSI) ECOTEMP5 - FL610 - FL700
HYDRA700 - LS10F - LS61 - LS7 - LS7F - LS8D
LS8F - LV70
for Dishwasher hood type (ZANUSSI) HT1000 - HT800
HYDRA1000 - HYDRA800 - LS10 - LS8 - Z80



ELECTROLUX 048548

3024021 COMPLETE BOILER \varnothing 200x410 mm
2 holes for heating element
for Dishwasher (ZANUSSI) FL620 - FL630 - LS12D
LS62 - LS62D - LS63 - LS63D - LS7 - Z62 - Z63
Z64
for Dishwasher hood type (ZANUSSI) HT1000 - HT1200
HYDRA1000 - HYDRA1200 - LS10 - LS12 - Z120



ELECTROLUX 0L1639

ELECTROLUX 048484

Capacitors

3068016 CAPACITOR μ F 10 450V 50/60Hz
operating temperature $-25+85^{\circ}\text{C}$
in compliance with EEC 93/68 and 92/31 regulations
for Dishwasher (FAGOR) FI-12D - FI-30 - FI-50
FI-72
for Dishwasher hood type (FAGOR) FI-80



ELECTROLUX 0U0403

ELECTROLUX 056178

3068002 CAPACITOR μ F 2.5 450V 50/60Hz
operating temperature $-25+85^{\circ}\text{C}$
in compliance with EEC 93/68 and EEC 92/31 regulat



ELECTROLUX 0E0174



Suitable for:

Suitable for:

3068027 CAPACITOR μ F 20 450V 50/60Hz
operating temperature $-25+85^{\circ}\text{C}$
in compliance with EEC 93/68 and 92/31 regulations



ELECTROLUX 0H1044

ELECTROLUX 047744

Castors

3346024 COVER LIFTING ROLLER
external \varnothing 49 mm
for LS10-WT60-LS12-HT1000-HT1200-HYDRA 1000-
HYDRA 1200



ELECTROLUX 048260

3346025 ROLLER PIN



ELECTROLUX 048259

3346019 COVER SLIDE ROLLER \varnothing 34 mm
for LS8-WT50-LS10-LS12-WT60-HT800-HYDRA 800-Z80



ELECTROLUX 048657

3324005 HOOD ROLLER PIN



ELECTROLUX 048635

3346020 ROLLER PIN



ELECTROLUX 048656

3346036 HANDLE SLIDE
for LS10-LS12



ELECTROLUX 049597

3346037 HANDLE SLIDE BUSHING
for LS10-LS12



ELECTROLUX 049598



ELECTROLUX



Suitable for:

3346017 ROLLER \varnothing 32x33 mm
for conveyor area
for CT92-CT140-CT141-CT142-CT190-CT191-CT192-
'CT240-CT241



ELECTROLUX 046841

Suitable for:

3346206 ROLLER SET \varnothing 50x71 mm
for DISHWASHER ROLLERS



ELECTROLUX 0K8640

3346007 SLIDING ROLLER
external \varnothing 39 mm
internal \varnothing 15 mm



ELECTROLUX 0K7281

ELECTROLUX 0L2443

3346021 SPACER ROLLER \varnothing 15x13 mm
for lifting cover lever



ELECTROLUX 048654

3346022 SPACER ROLLER BUSHING



ELECTROLUX 048653

3346023 SPACER ROLLER PIN



ELECTROLUX 048652

3346004 TRANSMISSION SHAFT BUSHING
 \varnothing 20x40 mm
for serie RT



ELECTROLUX 0E5043

ELECTROLUX 0K8236

Clamps

3449405 DOUBLE-WIRE CLAMP 9.8-10.4 - 100 PCS
for hoses \varnothing 9.8÷10.4 mm



ELECTROLUX 0E5993

ELECTROLUX 0L0815

3449462 HOSE CLAMP 12-20
for hoses \varnothing 12÷20 mm
made of stainless steel AISI 304
height 9 mm and screw E7
for Glasswasher/Cupwasher (ADLER) DSF101



ELECTROLUX 049888

3449466 HOSE CLAMP 16-27
for hoses \varnothing 16÷27 mm
made of stainless steel AISI 304
height 12 mm and screw E7



ELECTROLUX 0E5120

ELECTROLUX 0E900

3449453 HOSE CLAMP 25-40
for pipes \varnothing 25÷40 mm
made of stainless steel AISI 304
height 9 mm and screw E7



ELECTROLUX 047578

3449456 HOSE CLAMP 50-70
for hoses \varnothing 50÷70 mm
made of stainless steel AISI 304
height 9 mm and screw E7



ELECTROLUX 0E1358

ELECTROLUX 0K8983

ELECTROLUX 046855

3449457 HOSE CLAMP 60-80
for pipes \varnothing 60÷80 mm
made of stainless steel AISI 304
height 9 mm and screw E7



ELECTROLUX 046853

3449461 HOSE CLAMP 8-12
for hoses \varnothing 8÷12 mm
made of stainless steel AISI 304
height 9 mm and screw E7



ELECTROLUX 046946

ELECTROLUX 048224



Suitable for:

ELECTROLUX



Suitable for:

Column faucets

3359682 COLUMN FAUCET 84319

oil bath spindles
spout \varnothing 20x240 mm
connection \varnothing 1/2" M
overall height 555 mm
rod length 435 mm



ELECTROLUX 206158

ELECTROLUX 216036

3359820 SPOUT TYPE S \varnothing 20x250 mm



3359793 OIL BATH TAP WORM

for type Z medium size - type P \varnothing 32 mm knobs
ACTIVE cross type - ACTIVE lever type



3359780 Z TYPE MIDDLE SIZE KNOB



3359140 COLUMN TAP
swivel column
swivel spout 250 mm
fitting \varnothing 3/4" M
height 425 mm
overall height 700 mm
25l/min at 4 bar



ELECTROLUX 927130

3241485 BLACK KNOB
square connection 7x7 mm



Contact thermostats

3443058 BRACKET FOR CONTACT THERMOSTAT
for LB-LS



ELECTROLUX 048987

3443030 CONTACT THERMOSTAT
contact capacity 16(4)A 250V
for LS521



ELECTROLUX 048166

ELECTROLUX 048631



ELECTROLUX



Suitable for:

3444393 CONTACT THERMOSTAT FOR WASH TANK

3 contacts 16A 250V
for LB1-LB2



ELECTROLUX 048804

Suitable for:

3444607 CONTACT THERMOSTAT 110°C

with manual reset
for ELETTOBAR E41-E42-E45-E46-E50-E51-E52
NIAGARA40/51-RIVER50/61-46F-460F-E35H-E40H
for COLGED BETA235/240/245/250/253-SILVER35/40/45
for SAMMIC DISHWASHER SU600S
for ZANUSSI LS3-LS7-LS8-LS12-LS62-LS63-LS64-LO10



ELECTROLUX 048287

ELECTROLUX 048887

3443015 THERMOSTAT GASKET \varnothing 45 mm

internal hole \varnothing 16 mm
external hole \varnothing 45 mm



ELECTROLUX 066717

3443016 YELLOW/BROWN CONTACT THERMOSTAT

NO contact operating temperature $35 \div 46^{\circ}\text{C}$
NC contact operating temperature $52-60^{\circ}\text{C}$
16A 250V
for ZANUSSI LS7/8/10/12/521-HYDRA800/1000/1200
for MARENO MLS30/31/35-MLC50/65
for LASA LS3-LS4-LS35-LC50-LC65



ELECTROLUX 045495

ELECTROLUX 047508

ELECTROLUX 048487

Curtains

3443332 CENTRAL CURTAIN 530x305 mm

for versions before 1986
for Dishwasher conveyor type (ZANUSSI) CT140
CT142 - CT192 - CT92 - CT95



ELECTROLUX 046883

3324030 CURTAIN PIN \varnothing 6x545 mm

for Dishwasher conveyor type (ZANUSSI) WT100
WT150



ELECTROLUX 0E5487

3443331 CURTAIN 545x445 mm

for Dishwasher conveyor type (ZANUSSI) CT140
CT142 - CT192 - CT95 - RT100 - RT140 - RT190
RT270 - WT100 - WT150 - WT90



ELECTROLUX 0E5029

ELECTROLUX 0E5277

3443059 CURTAIN 550x355 mm

for Dishwasher conveyor type (ZANUSSI) CT140
CT142 - CT192 - CT95 - Series RT - WT100
WT150 - WT90



ELECTROLUX 0E5038



Suitable for:

3443021 CURTAIN 550x460 mm
for Dishwasher conveyor type (ZANUSSI) WT100
WT150



ELECTROLUX 0E2728

Suitable for:

3443027 CURTAIN 550x300 mm
for Dishwasher conveyor type (ZANUSSI) WT100
WT150



ELECTROLUX 0E2729

3456025 CURTAIN 580x480 mm
for Dishwasher conveyor type (ZANUSSI) RT100
RT142 - RT190 - RT270 - RT340 - RT480



ELECTROLUX 0E6006

3443300 LATERAL CURTAIN 575x420 mm
for Dishwasher conveyor type (ZANUSSI) CT140
CT190 - CT192 - CT90



ELECTROLUX 046882

3443301 CENTRAL CURTAIN 640x430 mm
for Dishwasher conveyor type (ZANUSSI) CT140
CT190 - CT192 - CT90



ELECTROLUX 048042

3443302 LATERAL CURTAIN 600x450 mm
for Dishwasher conveyor type (ZANUSSI) LSE22
LSE31 - LSE40



ELECTROLUX 068891

Descaling powders for dishwashers

3094005 4 COLUMN SCALE REMOVER

width 165 mm - length 390 mm
 for Dishwasher (ADLER) CF50
 for Dishwasher (COMENDA) FC53 - FC54 - LF320A
 LF323A - LF350A - LF400A - LF450A
 for Dishwasher (ELFRAMO)
 for Dishwasher (KOMEL)
 for Dishwasher (LAMBER)
 for Dishwasher (UNIVERBAR) LOGOSD - MIDI50D
 OMEGAD - SINCROD
 for Glasswasher/Cupwasher (COMENDA) BC25A - BC30A
 BHC25 - BHC30 - BR20A - BR25A - B12T - B14T
 B16T - B19T - FC43A
 for Glasswasher/Cupwasher (MEIKO) ECOSTAR545D
 for Glasswasher/Cupwasher (UNIVERBAR) BET37D
 BET40D - ERGOND - MIDI40D - MINIBETD



3010138 WATER SOFTENER SUPPORT

distance between mounting holes 195 mm
 for Dishwasher (WHIRLPOOL) AGB652 - AGB653
 for Glasswasher/Cupwasher (WHIRLPOOL) AGB643
 AGB644 - AGB647



ELECTROLUX 069476

Door catches

3398001 DOOR CATCH

for DISHWASHER models LS510-LS520-LS521-LS5DS-LS4-
 5CF50B-5CF51B-5CF5-CRYSTAL50-CRYSTAL51-CRYSTAL52B



ELECTROLUX 0A6111

ELECTROLUX 047491

3398002 SPRING FOR DOOR CATCH

for DISHWASHER models LS510-LS520-LS521-LS5DS-LS4-
 5CF50B-5CF51B-5CF52B-CRYSTAL50-CRYSTAL51-CRYSTAL52



ELECTROLUX 047492

3398072 DOOR CATCH

for RT



ELECTROLUX 0E5157

3398601 DOOR CATCH

for DISHWASHER models S521-S623-S624-S626-S631-
 S633-S634-S636S641-S643



ELECTROLUX 069435

3398017 DOOR CATCH 70 mm

for DISHWASHER LS3



ELECTROLUX 049271

3398015 STEEL STRIKE 35x12 mm

for DISHWASHER LS3



ELECTROLUX 049536



Suitable for:

ELECTROLUX



Suitable for:

Door labyrinthes

3222002 PLASTIC FRAME FOR DOOR

for Dishwasher (ZANUSSI) CRYSTAL50 - CRYSTAL51
CRYSTAL52 - LS4 - LS5DS - LS510 - LS520
LS521 - 5CF50B - 5CF51B - 5CF52



ELECTROLUX 047483

3186302 LEFT-HAND GASKET

for Dishwasher (ZANUSSI) CRYSTAL50 - CRYSTAL51
CRYSTAL52 - LS4 - LS5DS - LS510 - LS520
LS521 - ZLS510 - ZLS520 - ZLS521



ELECTROLUX 047454

3186303 RIGHT-HAND GASKET

for Dishwasher (ZANUSSI) CRYSTAL50 - CRYSTAL51
CRYSTAL52 - LS4 - LS510 - LS521



ELECTROLUX 047455

3222001 RETAINING GASKET FOR PLASTIC FRAME

for Dishwasher (ZANUSSI) LS500 - LS501 - LS540
LS541 - 5CF07B - 5CF08B - 5CF09B



ELECTROLUX 045836

Drain assembly

3316010 BRASS DRAIN ASSEMBLY \varnothing 1"1/2

external \varnothing 67 mm - internal \varnothing 40 mm
connection \varnothing 47 mm
for SINKS



ELECTROLUX 0S1310

3448070 OVERFLOW PIPE

of stainless steel
 \varnothing 40 mm - overall height 230 mm
for drain assembly \varnothing 1"1/2



3448071 OVERFLOW PIPE

of stainless steel
 \varnothing 40 mm - overall height 280 mm
for drain assembly \varnothing 1"1/2



3448076 OVERFLOW PIPE

of stainless steel
 \varnothing 40 mm - overall height 320 mm
for drain assembly \varnothing 1"1/2





ELECTROLUX



Suitable for:

3316011 BRASS DRAIN ASSEMBLY \varnothing 2"
external \varnothing 80 mm - internal \varnothing 50 mm
connection \varnothing 59 mm
for SINKS



ELECTROLUX 051317

ELECTROLUX 069317

ELECTROLUX 069654

Suitable for:

3448079 OVERFLOW PIPE
of stainless steel
 \varnothing 50 mm - overall height 300 mm
for drain assembly \varnothing 2"



3448081 OVERFLOW PIPE
of stainless steel
 \varnothing 50 mm - overall height 230 mm
for drain assembly \varnothing 2"



3448082 OVERFLOW PIPE
of stainless steel
 \varnothing 50 mm - overall height 280 mm
for drain assembly \varnothing 2"



3316120 COMPLETE DRAIN ASSEMBLY 1"1/2
for RT



ELECTROLUX 0E0141

ELECTROLUX 0E9141

ELECTROLUX 0L1863

3448106 DRAIN ASSEMBLY
for DISHWASHER models CT92-CT140-CT142



ELECTROLUX 046875

3448108 GASKET DRAIN ASSY
for CT92-CT140-CT142



ELECTROLUX 066088

3448107 RING FOR DRAIN ASSEMBLY
for CT92-CT140-CT142



ELECTROLUX 066079



Suitable for:

3316143 DRAIN ASSEMBLY \varnothing 1"1/2
for DISHWASHER LO250-LO480



ELECTROLUX 075624

3448107 RING FOR DRAIN ASSEMBLY
for CT92-CT140-CT142



ELECTROLUX 066079

3316013 ST. STEEL/PLASTIC DRAIN ASSEMBLY \varnothing 2"
external \varnothing 70 mm - internal \varnothing 50 mm
connection \varnothing 59 mm
for SINKS



ELECTROLUX 0S1319

3448081 OVERFLOW PIPE
of stainless steel
 \varnothing 50 mm - overall height 230 mm
for drain assembly \varnothing 2



Suitable for:

3448108 GASKET DRAIN ASSY
for CT92-CT140-CT142



ELECTROLUX 066088

3448079 OVERFLOW PIPE
of stainless steel
 \varnothing 50 mm - overall height 300 mm
for drain assembly \varnothing 2"



3448082 OVERFLOW PIPE
of stainless steel
 \varnothing 50 mm - overall height 280 mm
for drain assembly \varnothing 2"



3316012 ST. STEEL/PLASTIC DRAIN ASSEMBLY \varnothing 1"1/2
external \varnothing 70 mm - internal \varnothing 50 mm
connection \varnothing 47 mm
for SINKS-DISHWASHERS
for UNIVERBAR DISHWASHER COSMO-COMPACT



ELECTROLUX 0S1318

3316147 DRAIN ASSEMBLY ELBOW \varnothing 1"1/2
for UNIVERBAR DISHWASHER COSMO-COMPACT





ELECTROLUX



Suitable for:

3186606 O-RING 0144 EPDM



ELECTROLUX 047192

3448081 OVERFLOW PIPE
of stainless steel
ø 50 mm - overall height 230 mm
for drain assembly ø 2"



Suitable for:

3448079 OVERFLOW PIPE
of stainless steel
ø 50 mm - overall height 300 mm
for drain assembly ø 2"



3448082 OVERFLOW PIPE
of stainless steel
ø 50 mm - overall height 280 mm
for drain assembly ø 2"



3316017 WASTE FUNNEL
ø superior external 282 mm.
ø superior internal 195 mm.
ø inferior external 230 mm.
ø inferior internal 180 mm.
height 93 mm.



ELECTROLUX 069318

Drain hoses

3450119 DRAIN PIPE



ELECTROLUX 047558

3450131 DRAIN PIPE ø 27x2000 mm
hoses internal ø 28x20 mm



ELECTROLUX 049878

3450130 DRAIN PIPE ø 23x2000 mm
hoses internal ø 28 e 18 mm



ELECTROLUX 048845

3450022 DRAIN PIPE ø 47x1000 mm
muff internal ø 58 mm
temperature max 90°C
for LS500-LS540-LSE720-LSE721-5CF09B-5CF10B



ELECTROLUX 0S0148

ELECTROLUX 047894



Suitable for:

ELECTROLUX



3450034 MANIFOLD CONNECTION PIPE 1100 mm
ø 40x1100 mm
hoses internal ø 35 e 40 mm
max temperature 90°C



ELECTROLUX 0S0149

ELECTROLUX 047465

Suitable for:

3450041 NOZZLE SUPPORT CONNECTING PIPE
length 650 mm
per LS6E-FLE620-ECOTEMP5E



ELECTROLUX 0L0095

3450001 PIPE ø 60x75 mm
rubber pipe with textile reinforcement
for WASHING MACHINE
for DISHWASHER LS500-LS540-LS1080-LSE720



ELECTROLUX 0L0613

ELECTROLUX 045456

3450736 PRESSURE SWITCH PIPE ø 4x8.5 mm - 10 m
black rubber
external ø 8.5 mm
internal ø 4 mm



ELECTROLUX 072393

3450336 PRESSURE SWITCH PIPE ø 4x8.5 mm - 100 m
black rubber
external ø 8.5 mm
internal ø 4 mm



ELECTROLUX 072393

3450622 PRESSURE SWITCH PIPE ø 5x11 mm - 5 m
temperature -30°+110°C
operating pressure 10 bar
burst pressure 40 bar
non-toxic rubber hose
external ø 11 mm
internal ø 5 mm
5-m bundles
for 50-m bundles see 3450652



ELECTROLUX 048225

ELECTROLUX 048226

ELECTROLUX 048883

3450652 PRESSURE SWITCH PIPE ø 5x11 mm - 50 m
temperature -30°+110°C
operating pressure 10 bar
burst pressure 40 bar
non-toxic rubber hose
external ø 11 mm
internal ø 5 mm
50-m bundles
for 5-m bundles see 3450622



ELECTROLUX 048225

ELECTROLUX 048226

ELECTROLUX 048883

Suitable for:

Suitable for:

3450040 PUMP CONNECTING PIPE
 plastic pipe with rubber muffs
 internal \varnothing 45 mm
 connecting pump and wash jets
 for LS500-LS720




ELECTROLUX 046372

3450047 PUMP OUTLET HOSE
 plastic pipe with rubber muffs
 internal \varnothing 60 mm
 connecting pump and wash jets
 for LS860-LS1080



ELECTROLUX 046542

3450176 PVC \varnothing 4x7 mm - 150 m



ELECTROLUX 069480

3450623 PVC PIPE \varnothing 4x7 mm - 10 m
 external \varnothing 7 mm
 internal \varnothing 4 mm



ELECTROLUX 069480

3450297 RUBBER HOSE \varnothing 11x19 mm - 5 m
 temperature $-30^{\circ}+110^{\circ}\text{C}$
 operating pressure 10 bar
 burst pressure 40 bar
 non-toxic rubber hose
 external \varnothing 19 mm
 internal \varnothing 11 mm
 5-m bundles
 for 50-m bundles see 3450197



ELECTROLUX 0E5121

ELECTROLUX 0K8670

ELECTROLUX 048531

3450197 RUBBER HOSE \varnothing 11x19 mm - 50 m
 temperature $-30^{\circ}+110^{\circ}\text{C}$
 operating pressure 10 bar
 burst pressure 40 bar
 non-toxic rubber hose
 external \varnothing 19 mm
 internal \varnothing 11 mm
 50-m bundles
 for 5-m bundles see 3450297



ELECTROLUX 0E5121

ELECTROLUX 0K8670

ELECTROLUX 048531

3450621 RUBBER PIPE 110°C . \varnothing 10x16 mm - 5 m
 temperature $-30^{\circ}+110^{\circ}\text{C}$
 operating pressure 10 bar
 burst pressure 40 bar
 non-toxic rubber hose
 external \varnothing 16 mm
 internal \varnothing 10 mm
 for 40 m rolls see 3450651



ELECTROLUX 0C3165

ELECTROLUX 0C4158

ELECTROLUX 002707

ELECTROLUX 086085

3450651 RUBBER PIPE 110°C . \varnothing 10x16 mm - 40 m
 temperature $-30^{\circ}+110^{\circ}\text{C}$
 operating pressure 10 bar
 burst pressure 40 bar
 non-toxic rubber hose
 external \varnothing 16 mm
 internal \varnothing 10 mm
 40-m rolls
 for 5-m rolls see 3450621



ELECTROLUX 0C3165

ELECTROLUX 0C4158

ELECTROLUX 002707

ELECTROLUX 086085



Suitable for:

3743370 WASH OUTLET TOP PIPE
for LS9-LS10-LS14-LS14AH-LS14W-WT55-WT65-WT65WS



ELECTROLUX 0L0556

ELECTROLUX 0L0556

ELECTROLUX 049595

Suitable for:

3786685 O-RING 06287 EPDM
for Dishwasher hood type (ZANUSSI) HT1200 - LS14
LV1200 - WT65



ELECTROLUX 049593

3450161 RING NUT FOR WASH OUTLET PIPE



ELECTROLUX 0L0557

ELECTROLUX 049596

3450100 WASH OUTLET TUBE
total height 700 mm
for WT4-LB5



ELECTROLUX 0L0125

ELECTROLUX 049291

Drain plugs

3448316 OVERFLOW PIPE
for DISHWASHER LB1-LB2



ELECTROLUX 049195



Suitable for:

Suitable for:

Drain plugs

3448158 OVERFLOW PIPE \varnothing 24x187 mm
made of plastic
for LB1-LB2



ELECTROLUX 049194

1186356 O-RING 03075 EPDM
for Dishwasher (AFI) A600 - A900
for Dishwasher (ANGELO PO) L40 - L40S - L60
for Dishwasher (EUROSYSTEM) PRO400
for Dishwasher (HILTA) S41 - S42
for Dishwasher (NOSEM) C5000 - C5010 - C5020
K602S - NC401
for Dishwasher hood type (AFI) A1000L
for Dishwasher hood type (ANGELO PO) L100 - L80
for Dishwasher hood type (EUROSYSTEM) PRO600
for Dishwasher hood type (HILTA) W13 - W14 - W15
for Dishwasher hood type (NOSEM) K601 - K602
for Glasswasher/Cupwasher (AFI) A35 - A35Z2 - A36
for Glasswasher/Cupwasher (EUROSYSTEM) PRO100
PRO200
for Glasswasher/Cupwasher (HILTA) RB10 - RB22



ELECTROLUX 049036

3160602 OVERFLOW PIPE \varnothing 25x215 mm - GREY



ELECTROLUX 069526

3448103 OVERFLOW PIPE \varnothing 26x277 mm
in plastic
for LS8-LS63-LS64



ELECTROLUX 048842

1186833 O-RING 03100 EPDM
for Dishwasher (ZANUSSI) FL610 - FL620 - LS3
LS61 - LS63 - LS64 - LS7 - WT32 - WT40 - Z62
for Dishwasher hood type (ZANUSSI) LS8



ELECTROLUX 046799

ELECTROLUX 086280

3448102 OVERFLOW PIPE \varnothing 26x280 mm
in plastic
for LS62-LS7



ELECTROLUX 048323

1186833 O-RING 03100 EPDM
for Dishwasher (ZANUSSI) FL610 - FL620 - LS3
LS61 - LS63 - LS64 - LS7 - WT32 - WT40 - Z62
for Dishwasher hood type (ZANUSSI) LS8



ELECTROLUX 046799

ELECTROLUX 086280



Suitable for:

3448100 OVERFLOW PIPE \varnothing 30x210 mm
in plastic
for LS510-LS520-LS521



ELECTROLUX 047460

Suitable for:

1186833 O-RING 03100 EPDM
for Dishwasher (ZANUSSI) FL610 - FL620 - LS3
LS61 - LS63 - LS64 - LS7 - WT32 - WT40 - Z62
for Dishwasher hood type (ZANUSSI) LS8



ELECTROLUX 046799

ELECTROLUX 086280

3448258 OVERFLOW PIPE \varnothing 39x418 mm
plastic made
for LS-LSV



ELECTROLUX 049140

3448105 OVERFLOW PIPE \varnothing 40x270 mm
in chrome plated brass
for CT92-CT140-CT142



ELECTROLUX 047116

3448109 OVERFLOW PIPE \varnothing 40x400 mm
in plastic
for LS10-LS12



ELECTROLUX 048250

3448232 OVERFLOW PIPE \varnothing 40x435 mm



ELECTROLUX 049675

3448257 OVERFLOW PIPE \varnothing 40x80 mm
for RT



ELECTROLUX 0E5149

Electrical gas valves and accessories

3526500 NON-RETURN VALVE
for Dishwasher (ZANUSSI) C51 - C52 - LS510 - LS520
LS62 - LS63 - LS64 - LS7
for Dishwasher hood type (ZANUSSI) LS10 - LS12
LS8



ELECTROLUX 048191



Suitable for:

Suitable for:

Electrical gas valves and accessories

1526503 NON-RETURN VALVE \varnothing 40 mm

ballcock - outlets \varnothing 12 mm
 stainless steel cap
 for Dishwasher (LAMBER) 01F - 040F - 045F - 050F
 075F
 for Dishwasher (SILANOS) N50 - N700
 for Dishwasher (WHIRLPOOL) AGB648 - AGB649
 AGB650 - AGB652 - AGB653 - AGB657 - AGB658
 AGB659
 for Glasswasher/Cupwasher (LAMBER) MINIBAR
 SUPERQS - S200 - S240 - S280 - S510
 for Glasswasher/Cupwasher (MACH) MB630



ELECTROLUX 005762

ELECTROLUX 049332

3786648 RUBBER GASKET \varnothing 27x40x1.5 mm



Electronic printed-circuit boards

3390031 CIRCUIT BOARD

for Dishwasher (ZANUSSI) FL610 - FL620 - FL630
 LS61 - LS62 - Z62



ELECTROLUX 048833

3390032 CIRCUIT BOARD

for Dishwasher (ZANUSSI) FL630 - LS63 - LS64 - Z63
 Z64



ELECTROLUX 048926

3390014 CIRCUIT BOARD 260x130 mm

for Dishwasher (ZANUSSI) LS5 - LS6
 for Dishwasher hood type (ZANUSSI) ECOTEMP12
 HT1000 - HT1200 - LS10 - LS14 - LS9 - WT60
 WT65



ELECTROLUX 0L0045
 ELECTROLUX 0L0705
 ELECTROLUX 0L2583

ELECTROLUX 0L0261
 ELECTROLUX 0L1412
 ELECTROLUX 049910

ELECTROLUX 0L0541
 ELECTROLUX 0L1811

3390376 ELECTRONIC CIRCUIT BOARD

for Dishwasher (ZANUSSI) LS5



ELECTROLUX 0L0046
 ELECTROLUX 0L1236
 ELECTROLUX 0L2582

ELECTROLUX 0L0547
 ELECTROLUX 0L1410

ELECTROLUX 0L0706
 ELECTROLUX 0L1810



Suitable for:

1186803 O-RING 02037 EPDM

for Dishwasher (ADLER) DS400 - DS410
for Dishwasher (BONNET) INO3F
for Dishwasher (COMENDA) F20 - F45 - F50 - F55
F65 - F80
for Dishwasher (WHIRLPOOL) F360 - F650
for Dishwasher (ZANUSSI) LS32 - LS360 - LS365
for Dishwasher hood type (WHIRLPOOL) F1000
F1201A
for Glasswasher/Cupwasher (ADLER) CF35 - CF40
for Glasswasher/Cupwasher (COMENDA) B10 - B15
B15T - B20
for Glasswasher/Cupwasher (ELETTOBAR) E35 - E40
MISTRAL40 - NIAGARA35
for Glasswasher/Cupwasher (HOONVED) CR43 - CR48
C35 - C43 - C43E - C46E - C48



ELECTROLUX 046376

3390374 USER INTERFACE CARD

for Dishwasher (ZANUSSI) - Series ECOTEMP
Series HT - LS5 - LS6 - Series WT
for Dishwasher hood type (ZANUSSI) LS10 - LS9



ELECTROLUX 0L0726
ELECTROLUX 0L1567

ELECTROLUX 0L1241
ELECTROLUX 0L1626

ELECTROLUX 0L1565

ELECTROLUX



Suitable for:

3397004 TEMPERATURE PROBE ø 10 mm -10+100°C



ELECTROLUX 049643

ELECTROLUX 049666

3390375 USER INTERFACE CARD

for Dishwasher (ZANUSSI) - Series HT - LS5 - LS6
for Dishwasher hood type (ZANUSSI) LS10 - LS9



ELECTROLUX 0L0548
ELECTROLUX 0L1237
ELECTROLUX 0L1973
ELECTROLUX 049754

ELECTROLUX 0L0708
ELECTROLUX 0L1240
ELECTROLUX 0L2482
ELECTROLUX 049998

ELECTROLUX 0L0709
ELECTROLUX 0L1627
ELECTROLUX 049623

3390019 ELECTRONIC CIRCUIT BOARD 185x90 mm


for Dishwasher (ZANUSSI) LS3 - WT303



ELECTROLUX 049412

3390208 TIMER BOARD

size 185x90 mm
for Dishwasher (ZANUSSI) LS32 - LS65 - WT35



ELECTROLUX 049411

3390209 USER INTERFACE CARD

sizes 340x44 mm
for Dishwasher (ZANUSSI) LS6



ELECTROLUX 0L0279
ELECTROLUX 0L1242

ELECTROLUX 0L0538
ELECTROLUX 0L1579

ELECTROLUX 0L0707
ELECTROLUX 049897

3390373 USER INTERFACE CARD

dimensions 195x80 mm
for Dishwasher hood type (ZANUSSI) LS9



ELECTROLUX 0L0061
ELECTROLUX 0L1235

ELECTROLUX 0L0550

ELECTROLUX 0L0710



Faucets and mixers

3359474 HORIZONTAL TAP
 spout \varnothing 18x300 mm
 flow rate 25L/min by 4 bar
 connection \varnothing 1/2"M



ELECTROLUX 0C3108

3359805 TAP WORM



3359195 MAXI SINGLE-LEVER MIXER
 mounting hole \varnothing 50 mm
 flowrate 80L/min



ELECTROLUX 0S0130

ELECTROLUX 008000

3359186 TWO-HOLE MIXER
 spout: \varnothing 20 x 250 mm
 fixing hole \varnothing 29 mm



ELECTROLUX 033125

ELECTROLUX 069964

3759083 SPOUT \varnothing 20x250 mm NEW TYPE connection



3359165 WALL MOUNTED HORIZONTAL TAP
 spout: \varnothing 20 x 300 mm
 connection \varnothing 1/2"M



ELECTROLUX 0S0103

3359290 BLUE TAP KNOB



Feet

3313003 STAINLESS STEEL FOOT \varnothing 2" x h 125 mm
 with rectangular flange 100x90 mm



ELECTROLUX 057536

3313001 STAINLESS STEEL FOOT \varnothing 2" HEIGHT 125 mm



ELECTROLUX 053792



Suitable for:

ELECTROLUX



Suitable for:

Filters

3160604 EXTERNAL FILTER \varnothing 135x90 mm - GREY
 for Glasswasher/Cupwasher (BONNET) VR1000R
 VR1000RAD - VR1500C - VR1500CAD
 for Glasswasher/Cupwasher (ELETTROBAR) S621 - S623
 S624 - S626 - S631 - S633 - S634 - S636 - 21F
 21R
 for Glasswasher/Cupwasher (KREFFT) GLX920



ELECTROLUX 069528

3160395 FILTER BASKET
 for Dishwasher hood type (ZANUSSI) LS10 - LS10D
 LS12



ELECTROLUX 048252

3160215 INLET FITTING 1"1/4
 for Dishwasher (ADLER) B40 - B41 - DL240
 for Glasswasher/Cupwasher (ADLER) B101 - CF35
 COMPACT - DSF101 - DSF103 - DS101 - DS103
 DS11 - DS13 - DS201 - DS203 - DS21 - DS23
 for Glasswasher/Cupwasher (WHIRLPOOL) D110 - D111
 D210 - D211 - F30 - F300 - F312 - F35 - F41



ELECTROLUX 070328

3160195 FILTER LOCKING SHAFT \varnothing 6 mm
 length 42 mm
 for Dishwasher (ADLER) DL240
 for Glasswasher/Cupwasher (ADLER) CF35 - CF40
 DSF101 - DSF103
 for Glasswasher/Cupwasher (WHIRLPOOL) F300 - F312
 F35 - F41



3160194 FILTER LOCKING SHAFT 58 mm
 thread \varnothing 6 mm
 for Dishwasher (ADLER) B40 - B41 - CF50
 for Dishwasher (WHIRLPOOL) F360
 for Glasswasher/Cupwasher (ADLER) B101 - COMPACT
 DS101 - DS103 - DS11 - DS13 - DS201 - DS203
 DS21 - DS23
 for Glasswasher/Cupwasher (WHIRLPOOL) D110 - D111
 D210 - D211 - F30



3186238 O-RING 0146 EPDM
 for Dishwasher (CIMBALI) F3E - F6E
 for Dishwasher (HEMERSON) P43E - P60E
 for Glasswasher/Cupwasher (RANCILIO) LT105 - LT205



3160198 RING NUT FOR SUCTION BOSS 1"1/4
 for IRINOX CHILLER LC51
 per LAVASTOVIGLIE KF





Suitable for:

3160605 INTERNAL FILTER \varnothing 136x75 mm - GREY
 for Glasswasher/Cupwasher (BONNET) VR1000R
 VR1000RAD - VR1500C - VR1500CAD
 for Glasswasher/Cupwasher (ELETTROBAR) S621 - S623
 S624 - S626 - S631 - S633 - S634 - S636 - 21F
 21R
 for Glasswasher/Cupwasher (KREFFT) GLX920



ELECTROLUX 069529

Suitable for:

3160606 NUT FOR WASH TANK FILTER
 for Glasswasher/Cupwasher (BONNET) VR1000R
 VR1000RAD - VR1500C - VR1500CAD
 for Glasswasher/Cupwasher (ELETTROBAR) S621 - S623
 S624 - S626 - S631 - S633 - S634 - S636 - 21F
 21R
 for Glasswasher/Cupwasher (KREFFT) GLX920



ELECTROLUX 069530

3160518 PUMP FILTER
 for Dishwasher hood type (WHIRLPOOL) HT1200
 for Dishwasher hood type (ZANUSSI) LS10 - LS12
 LS14 - LS9



ELECTROLUX 049810

3160187 PUMP FILTER \varnothing 124 mm
 for Glasswasher/Cupwasher (ZANUSSI) GW1 - GW2 - LB
 LB2 - WT1 - WT2 - Z1 - Z2



ELECTROLUX 0L2757

ELECTROLUX 049032

3186466 GASKET O-RING 04475 EPDM
 for Glasswasher/Cupwasher (ZANUSSI) GW1 - GW2
 LB1 - LB2 - WT1 - WT2 - Z1 - Z2



ELECTROLUX 049033

3160189 DRAIN MANIFOLD
 for Glasswasher/Cupwasher (ZANUSSI) GW1 - GW2
 LB1 - LB2 - WT1 - WT2 - Z1 - Z2



ELECTROLUX 049035

3160188 RING NUT FOR FILTER
 for Glasswasher/Cupwasher (ZANUSSI) GW1 - GW2
 LB1 - LB2 - WT1 - WT2 - Z1 - Z2



ELECTROLUX 049034

3160331 STAINLESS STEEL FILTER \varnothing 102 mm
 for Dishwasher conveyor type (ZANUSSI) RT100
 RT140 - RT190 - RT270



ELECTROLUX 0E5186

3160400 TANK BOTTOM FILTER
 for Dishwasher hood type (ZANUSSI) LS14EA



ELECTROLUX 048251

ELECTROLUX 049846



Suitable for:

3160190 WASH TANK FILTER \varnothing 495x485 mm
for Dishwasher (ZANUSSI) HYDRA700 - LS3 - LS61
LS62 - LS63 - LS7
for Dishwasher hood type (ZANUSSI) HT800
HYDRA800 - LS8



ELECTROLUX 048331
ELECTROLUX 049537

ELECTROLUX 048332

ELECTROLUX 048584

Suitable for:

3160112 WASH TANK FILTER 460x460 mm
for Dishwasher (ZANUSSI) CRYSTAL51 - CRYSTAL52
LS510 - LS520 - LS521 - ZLS510 - ZLS520
ZLS521



ELECTROLUX 0A6158

ELECTROLUX 047544

3160002 WATER FILTER
for Dishwasher (ZANUSSI) LS500 - LS501 - LS540
LS541
for Dishwasher hood type (ZANUSSI) LS1080 - LS720
LS860 - LS861



ELECTROLUX 045476

ELECTROLUX 068713

3160111 WATER FILTER \varnothing 89 mm
for Dishwasher (ZANUSSI) HYDRA700 - LS3 - LS6
LS61 - LS62 - LS63 - LS64 - LS7 - Z62 - Z63
for Dishwasher hood type (ZANUSSI) HYDRA800 - LS8



ELECTROLUX 048324

3160462 WATER FILTER 1/2"FF



ELECTROLUX 054450

ELECTROLUX 067392

3160007 WATER FILTER 3/4"FF



ELECTROLUX 0C4113

ELECTROLUX 068121

3160109 WATER INLET FILTER
fittings \varnothing 3/4"MF
for Dishwasher hood type (ZANUSSI) HT1200 - LC120
LS10 - LS12



ELECTROLUX 048746

Fittings

1349104 FITTING \varnothing 1/2"M-1/2"M



ELECTROLUX 0K9022

1349115 FITTING \varnothing 1/2"M-3/4"M



ELECTROLUX 0E5431



ELECTROLUX



Suitable for:

3349590 FITTING WITH RING NUT



ELECTROLUX 049652

Suitable for:

3349346 NICHEL-PL.HOSE-END FITTING \varnothing 1/4" M \varnothing 12



ELECTROLUX 0C1626

3349319 NICHEL-PLATED FITTING \varnothing 1/4" M-1/4" M



ELECTROLUX 006350

3349357 NICHEL-PLATED FITTING \varnothing 3/4" M-3/4" M



ELECTROLUX 0W3306

3090616 T-FITTING FOR BOILER
for 621-623-624-626-631-633-634-636



ELECTROLUX 069459

3090608 BOILER OUTLET FITTING



3090617 FITTING FOR BOILER PIPE



ELECTROLUX 069461

Fuses

3049003 DELAY FUSE 5x20 - 10 PCS
250V 100mA



ELECTROLUX 086338

3049012 DELAY FUSE 5x20 - 10 PCS
250V 800mA



ELECTROLUX 0C2301

3049038 QUICK ACTING FUSE 5x20 - 10 PCS
250V 160mA



ELECTROLUX 002820

3049040 QUICK ACTING FUSE 5x20 - 10 PCS
250V 250mA



ELECTROLUX 002920



ELECTROLUX



Suitable for:

3049041 QUICK ACTING FUSE 5x20 - 10 PCS
250V 315mA



ELECTROLUX 0W3499

ELECTROLUX 005032

ELECTROLUX 4005032

Suitable for:

3049042 QUICK ACTING FUSE 5x20 - 10 PCS
250V 400mA



ELECTROLUX 002750

3049044 QUICK ACTING FUSE 5x20 - 10 PCS
250V 630mA



ELECTROLUX 058871

3049049 QUICK ACTING FUSE 5x20 - 10 PCS
250V 2A



ELECTROLUX 0A8438

3049052 QUICK ACTING FUSE 5x20 - 10 PCS
250V 4A



ELECTROLUX 057783

Gaskets and seals

3786550 "U" SHAPED GASKET 700 mm
for mod. LS6-7-61-62-63-64
per mod. LS6-7-61-62-63-64
for Dishwasher (ZANUSSI) LS6 - LS61 - LS62 - LS63
LS64 - LS7



ELECTROLUX 0E5559

ELECTROLUX 047513

3186470 ADHESIVE SPONGE GASKET 4750 mm
profile dimensions 10x2.5 mm
for Dishwasher (ZANUSSI) LS4
for Glasswasher/Cupwasher (ZANUSSI) C50



ELECTROLUX 046583

40L0021 DOOR GASKET 590 mm
profile 24x6mm



ELECTROLUX 0L0021

3786480 GASKET FOR BOTTOM MANIFOLD
for Dishwasher hood type (ZANUSSI) LS1080 - LS720
LS861



ELECTROLUX 047928



ELECTROLUX



Suitable for:

40E0112 GASKET FOR DRAIN ELBOW \varnothing 104 mm
distance between holes 65 mm
for Dishwasher conveyer type (ZANUSSI) D530 - D580
D680
for Dishwasher hood type (ZANUSSI) D48



ELECTROLUX 0E0112

Suitable for:

3786683 GASKET FOR WASH RAMP 78x50x10 mm
for Dishwasher conveyer type (ZANUSSI) RT100
RT190 - RT270 - RT340 - RT480



ELECTROLUX 0E6005

3186108 GASKET FOR 435x30 mm
for Dishwasher hood type (ZANUSSI) LS8 - Z80
for Glasswasher/Cupwasher (ZANUSSI) LB1 - LB2



ELECTROLUX 049017

4049016 GASKET 1000 mm
profile dimensions 9x4 mm
for Glasswasher/Cupwasher (ZANUSSI) - Series GWT1
Series GWT2 - Series LB1 - Series LB2 - Series WT1
Series WT2



ELECTROLUX 049016

3186301 GASKET 565x25 mm
grey colour
for Dishwasher (ZANUSSI) ECOTEMP5 - LS6 - LS61
LS62 - LS63 - LS64 - LS7



ELECTROLUX 0L2561

ELECTROLUX 048248

ELECTROLUX 048306

ELECTROLUX 049248

ELECTROLUX 049892

3186300 GASKET 600x20 mm
black color
for Dishwasher (ZANUSSI) LS360 - LS365 - LS365F
LS367



ELECTROLUX 046394

3186578 INDICATOR LIGHT GASKET



ELECTROLUX 046584

3186136 LOWER BUMPER 36x14 mm
for Dishwasher hood type (ZANUSSI) HYDRA800 - LS10
LS12 - LS14 - LS8 - WT60 - WT65 - Z80



ELECTROLUX 048710



ELECTROLUX



Suitable for:

1186506 O-RING 04125 EPDM



ELECTROLUX 002874

Suitable for:

3786047 O-RING \varnothing 35x29x3 mm
for Dishwasher conveyor type (ZANUSSI) - Series RT
Series WT
for Dishwasher hood type (ZANUSSI) D48 - D480



ELECTROLUX 0E0142

1186231 O-RING GASKET 04106 EPDM



ELECTROLUX 027300

3786202 O-RING OR 03850 EPDM



ELECTROLUX 0KV753

1186014 O-RING 02015 EPDM



ELECTROLUX 059293

1186759 O-RING 03106 EPDM



ELECTROLUX 0L0922

3786008 O-RING 04112 BROWN VITON
for coffee group upper piston



ELECTROLUX 002873

3186314 O-RING 06225 SILICONE \varnothing 67 mm



ELECTROLUX 0L2304

1186990 OR-GASKET 04137 RED SILICONE



ELECTROLUX

1786087 O-RING 02037 RED SILICONE



ELECTROLUX 0L2303

1186693 O-RING 04325 EPDM



ELECTROLUX 0KM726



Suitable for:

ELECTROLUX



Suitable for:

Guides

3189015 ADHESIVE SPONGE GASKET 25x4 mm
sold per meter



ELECTROLUX 0K9154

3189016 DOOR SLIDEWAY
dimensions 900x40x17 mm
for Pan washing machine (ZANUSSI) L0250 - L0480



ELECTROLUX 048576

Handles

3242060 COMPLETE DOOR HANDLE
for DISHWASHER models LS500-LS540



ELECTROLUX 046355

3242061 HANDLE CAP



ELECTROLUX 081727

3242024 DOOR HANDLE 550x75 mm
for LS61-62-63-64



ELECTROLUX 048811

3242062 GREY DOOR HANDLE 170 mm
distance between holes 130 mm
for LS505-LS510-LS520



ELECTROLUX 047481

3242197 HANDLE SIDE PANEL



ELECTROLUX 047479

3242023 HANDLE ROLLER \varnothing 65 mm
for LS10-LS12-ECOTEMP12



ELECTROLUX 048348

3243918 ROLLER PIN \varnothing 6x77 mm
for Dishwasher hood type (ZANUSSI) ECOTEMP12
LS10 - LS12



ELECTROLUX 048349



Suitable for:

ELECTROLUX



Suitable for:

Heating elements

3355601 BOILER HEATING ELEMENT 2400W 220V
 immersed length 200 mm
 flange external \varnothing 63 mm
 with thermostat probe receptacle
 with o-ring \varnothing 58 (3186013)
 for Dishwasher (LUXIA) K400QS - K502QBS - 5P - 5Q
 5R - 5O2 - 7P - 7Q - 7R
 for Glasswasher/Cupwasher (BONNET)
 for Glasswasher/Cupwasher (ELETTROBAR) S621 - S623
 S624 - S626 - S631 - S633 - S634 - S636
 for Glasswasher/Cupwasher (KREFFT) GLX920
 for Glasswasher/Cupwasher (LUXIA) K10QT - K11QS
 K12QS - OCEANO35 - OCEANO40 - T40 - T45



ELECTROLUX 069455

ELECTROLUX 069672

3186013 O-RING GASKET 06187 EPDM \varnothing 58 mm
 for Dishwasher (COMENDA) FC53 - FC533 - FC54
 FC543 - FC544
 for Dishwasher (FAGOR) FI-12D - FI-12S - FI-300
 FI-300B
 for Dishwasher (HOONVED) STS53 - STS60
 for Dishwasher hood type (ADLER) DS1200
 for Dishwasher hood type (BONNET) INO60
 for Dishwasher hood type (COLGED) L51
 for Dishwasher hood type (LINEA BLANCA) LC-3500
 LC-4000
 for Glasswasher/Cupwasher (FAGOR) CI-20 - CI-20D
 for Glasswasher/Cupwasher (HOONVED) STS43 - STS48



ELECTROLUX 046213

ELECTROLUX 067620

ELECTROLUX 069456

3355314 BOILER HEATING ELEMENT 2800W 230V
 immersed length 385 mm
 flange external \varnothing 63 mm
 complete with o-ring \varnothing 58 (3186013)
 for Dishwasher (ZANUSSI) LS5 - WT4



ELECTROLUX 049980

3455335 BOILER HEATING ELEMENT 4000W 230V
 immersed length 465 mm
 flange \varnothing 63 mm
 with bulb sheath
 with O-ring \varnothing 58 (3186013)
 for Dishwasher conveyor type (ZANUSSI) - Series RT
 Series WT



ELECTROLUX 0E5115

ELECTROLUX 0K8250

ELECTROLUX 0L1833

3355312 BOILER HEATING ELEMENT 6000W 230/380V
 immersed length 455 mm
 flange external \varnothing 72 mm
 complete with o-ring \varnothing 67 (3186014)
 for Dishwasher conveyor type (ZANUSSI) WT730
 WT760



ELECTROLUX 0E5114

ELECTROLUX 0K8249

3455428 HEATING ELEMENT BOILER 12000W 230V
 immersed length 440 mm
 complete with O-Ring \varnothing 67 (3186014)
 for Dishwasher conveyor type (ZANUSSI) RT100
 RT140 - RT142 - RT190 - RT270 - RT340



ELECTROLUX 0E5162

ELECTROLUX 0L1861



Suitable for:

Suitable for:

3455427 HEATING ELEMENT F/ BOILER 12000W 230V
length 460 mm
with thermostat probe receptacle
flange \varnothing 72 mm
for Dishwasher conveyor type (ZANUSSI) RT100
RT140 - RT142 - RT190 - RT270



ELECTROLUX 0E5116

ELECTROLUX 0L1837

3355478 HEATING ELEMENT F/ BOILER 4500W 220/380V
immersed length 370 mm
flange external \varnothing 63 mm
with thermostat probe receptacle \varnothing 7 mm
complete with o-ring \varnothing 58 (3186013)
for Dishwasher (DIHR) GASTRO500 - GASTRO750
GASTRO900 - GS45 - GS50
for Dishwasher (KROMO) K50 - K60 - K70 - K80
for Dishwasher hood type (KROMO) K120



ELECTROLUX 002524

ELECTROLUX 026453

ELECTROLUX 049307

ELECTROLUX 057698

3186013 O-RING GASKET 06187 EPDM \varnothing 58 mm
for Dishwasher (COMENDA) FC53 - FC533 - FC54
FC543 - FC544
for Dishwasher (FAGOR) FI-12D - FI-12S - FI-300
FI-300B
for Dishwasher (HOONVED) STS53 - STS60
for Dishwasher hood type (ADLER) DS1200
for Dishwasher hood type (BONNET) INO60
for Dishwasher hood type (COLGED) L51
for Dishwasher hood type (LINEA BLANCA) LC-3500
LC-4000
for Glasswasher/Cupwasher (FAGOR) CI-20 - CI-20D
for Glasswasher/Cupwasher (HOONVED) STS43 - STS48



ELECTROLUX 046213

ELECTROLUX 067620

ELECTROLUX 069456

3455426 HEATING ELEMENT F/ BOILER 8000W 230V
immersed length 465 mm
with thermostat probe receptacle
flange \varnothing 72 mm
for Dishwasher conveyor type (ZANUSSI) RT100
RT140 - RT180 - RT190 - RT250 - RT270 - RT340
RT480



ELECTROLUX 0E5113

ELECTROLUX 0L1835

3455429 HEATING ELEMENT F/ TANK 2000W 230V
width 365 mm - length 72 mm
for Dishwasher (ZANUSSI) LS5 - LS6



ELECTROLUX 0L2109

ELECTROLUX 049954



Suitable for:

3355290 HEATING ELEMENT F/ TANK 2200W 230V
 immersed length 340 mm
 width 75 mm
 complete with gasket (3186190)
 for Dishwasher (ZANUSSI) LS3 - LS6 - LS7
 for Dishwasher hood type (ZANUSSI) LS10 - LS12
 LS8



ELECTROLUX 0L2340

ELECTROLUX 048228

ELECTROLUX 048924

Suitable for:

3186190 GASKET FOR ELEMENT 23x46 mm
 in rubber



ELECTROLUX 048483

3355295 HEATING ELEMENT F/BOILER 3000W 230/400V
 immersed length 170 mm
 flange external \varnothing 63 mm
 complete with o-ring (3186013)
 for Dishwasher (ZANUSSI) LS62 - LS63 - LS64



ELECTROLUX 0L1634

ELECTROLUX 048489

ELECTROLUX 048927

3186013 O-RING GASKET 06187 EPDM \varnothing 58 mm
 for Dishwasher (COMENDA) FC53 - FC533 - FC54
 FC543 - FC544
 for Dishwasher (FAGOR) FI-12D - FI-12S - FI-300
 FI-300B
 for Dishwasher (HOONVED) STS53 - STS60
 for Dishwasher hood type (ADLER) DS1200
 for Dishwasher hood type (BONNET) INO60
 for Dishwasher hood type (COLGED) L51
 for Dishwasher hood type (LINEA BLANCA) LC-3500
 LC-4000
 for Glasswasher/Cupwasher (FAGOR) CI-20 - CI-20D
 for Glasswasher/Cupwasher (HOONVED) STS43 - STS48



ELECTROLUX 046213

ELECTROLUX 067620

ELECTROLUX 069456

3355293 HEATING ELEMENT F/BOILER 4500W 230/400V
 immersed length 370 mm
 flange external \varnothing 63 mm
 complete with o-ring \varnothing 58 mm (3186013)
 for Dishwasher hood type (ZANUSSI) LSE720 - LS1080
 LS720 - LS860



ELECTROLUX 048284

3186013 O-RING GASKET 06187 EPDM \varnothing 58 mm
 for Dishwasher (COMENDA) FC53 - FC533 - FC54
 FC543 - FC544
 for Dishwasher (FAGOR) FI-12D - FI-12S - FI-300
 FI-300B
 for Dishwasher (HOONVED) STS53 - STS60
 for Dishwasher hood type (ADLER) DS1200
 for Dishwasher hood type (BONNET) INO60
 for Dishwasher hood type (COLGED) L51
 for Dishwasher hood type (LINEA BLANCA) LC-3500
 LC-4000
 for Glasswasher/Cupwasher (FAGOR) CI-20 - CI-20D
 for Glasswasher/Cupwasher (HOONVED) STS43 - STS48



ELECTROLUX 046213

ELECTROLUX 067620

ELECTROLUX 069456



Suitable for:

3355294 HEATING ELEMENT F/BOILER 6000W 230/400V
immersed length 370 mm
flange external \varnothing 63 mm
complete with o-ring \varnothing 58 mm (3186013)
for Dishwasher (ZANUSSI) LS7
for Dishwasher hood type (ZANUSSI) LS10 - LS12
LS8



ELECTROLUX 048221

ELECTROLUX 048513

Suitable for:

3186013 O-RING GASKET 06187 EPDM \varnothing 58 mm
for Dishwasher (COMENDA) FC53 - FC533 - FC54
FC543 - FC544
for Dishwasher (FAGOR) FI-12D - FI-12S - FI-300
FI-300B
for Dishwasher (HOONVED) STS53 - STS60
for Dishwasher hood type (ADLER) DS1200
for Dishwasher hood type (BONNET) IN060
for Dishwasher hood type (COLGED) L51
for Dishwasher hood type (LINEA BLANCA) LC-3500
LC-4000
for Glasswasher/Cupwasher (FAGOR) CI-20 - CI-20D
for Glasswasher/Cupwasher (HOONVED) STS43 - STS48



ELECTROLUX 046213

ELECTROLUX 067620

ELECTROLUX 069456

3755057 HEATING ELEMENT FOR BOILER 10000W 230V
immersed length 460 mm
flange external \varnothing 72 mm
with thermostat probe receptacle
complete with o-ring \varnothing 67 (3186014)
for Dishwasher conveyor type (ZANUSSI) - Series RT
RT10 - RT100 - RT190 - RT270 - Series WT



ELECTROLUX 0E5066

ELECTROLUX 0L1836

3755054 HEATING ELEMENT FOR BOILER 2000W 230V
immersed length 325 mm
width 65 mm
flange 82x28 mm
for Dishwasher hood type (ZANUSSI) LS10 - LS12
WT60
for Pan washing machine (ZANUSSI) PW1



ELECTROLUX 049613

ELECTROLUX 049755

3355377 HEATING ELEMENT FOR BOILER 2400W 230V
immersed length 260 mm
complete with gasket (3186191)
for Dishwasher (ADLER) B40 - B41 - DS400 - DS410
for Glasswasher/Cupwasher (ADLER) B100 - B200
CF35 - CF40 - COMPACT - DSF101 - DSF103
DS101 - DS103 - DS201 - DS203
for Glasswasher/Cupwasher (WHIRLPOOL) D110 - D111
D210 - D211 - F30 - F300 - F312 - F35 - F40
F400 - F41 - F410



ELECTROLUX 070307

3186191 VITON GASKET FOR HEATING ELEMENT
sizes 52x41x6 mm
for Dishwasher (ADLER) A350 - A500 - A720 - B300
B40 - B41
for Dishwasher hood type (ADLER) A900
for Glasswasher/Cupwasher (ADLER) B100 - B200



ELECTROLUX 060009

ELECTROLUX 070308



Suitable for:

ELECTROLUX



3755055 HEATING ELEMENT FOR BOILER 2800W 230V

immersed length 320 mm
flange external \varnothing 63 mm
complete with o-ring \varnothing 58 (3186013)
for Dishwasher (ZANUSSI) LS3



ELECTROLUX 049371

Suitable for:

3755052 HEATING ELEMENT FOR BOILER 3000W 230V

immersed length 310 mm
width 65 mm
flange 82x28 mm
for Dishwasher hood type (ZANUSSI) LS10 - LS12
WT60



ELECTROLUX 049614

ELECTROLUX 049756

3755053 HEATING ELEMENT FOR BOILER 3500W 230V

immersed length 310 mm
width 65 mm
flange 82x28 mm
for Dishwasher hood type (ZANUSSI) LS10 - LS12
WT60
for Pan washing machine (ZANUSSI) PW1



ELECTROLUX 049615

ELECTROLUX 049757

3755600 HEATING ELEMENT FOR BOILER 4500W 230V

immersed length 225 mm
flange external \varnothing 63 mm
complete with O-Ring \varnothing 58 (3186013)
for Dishwasher (ZANUSSI) FL610 - LS61 - LS7
for Dishwasher hood type (ZANUSSI) LS10 - LS1080
LS720 - LS8 - LS860



ELECTROLUX 048928

3355604 HEATING ELEMENT FOR TANK 2000W 220V

immersed length 275 mm
width 120 mm - connection \varnothing 10 mm
for Dishwasher (BONNET) VR1000RD
for Dishwasher (HOBART) GW600
for Glasswasher/Cupwasher (BONNET) VR1000R
VR1500C - VR1500CAD
for Glasswasher/Cupwasher (ELETTROBAR) S621 - S623
S624 - S626 - S631 - S633 - S634 - S636 - 11F
11FD - 11R
for Glasswasher/Cupwasher (KREFFT) GLX920



ELECTROLUX 069437

ELECTROLUX 069671

3355031 HEATING ELEMENT FOR WASH TANK 1600W 220V

immersed length 335x78 mm
connection \varnothing 14 mm
for DISHWASHER 400 dishes model old type



ELECTROLUX 067373

3355027 HEATING ELEMENT FOR WASH TANK 1800W 220V

immersed length 410x85 mm
connection \varnothing 14 mm
for Dishwasher (ZANUSSI) LS365 - LS480 - LS500
LS540 - LS750
for Dishwasher hood type (ZANUSSI) LS860



ELECTROLUX

3355030 HEATING ELEMENT FOR WASH TANK 2000W 220V

immersed length 370x100 mm
connection \varnothing 14 mm
for Dishwasher conveyor type (ZANUSSI) LSE22
LSE31 - LSE40



ELECTROLUX 067610



ELECTROLUX



Suitable for:

3355028 HEATING ELEMENT FOR WASH TANK 2200W 220V
 immersed length 410x130 mm
 connection \varnothing 14 mm
 for Dishwasher (ZANUSSI) LS365 - LS480 - LS500
 LS540 - LS750
 for Dishwasher hood type (ZANUSSI) LS860



ELECTROLUX 047484

ELECTROLUX 047506

ELECTROLUX 047848

Suitable for:

3355291 HEATING ELEMENT FOR WASH TANK 2200W 230V
 immersed length 325 mm
 width 80 mm
 connection \varnothing 14 mm
 for Dishwasher (BONNET) IN03F
 for Dishwasher hood type (ZANUSSI) LS1080 - LS720
 LS860



ELECTROLUX 046404

ELECTROLUX 048000

ELECTROLUX 048086

3755056 HEATING ELEMENT FOR WASH TANK 7500W 230V
 immersed length 460 mm
 flange external \varnothing 72 mm
 complete with o-ring \varnothing 67 (3186014)
 upon request nut (3528003) and washer (3528004)
 for Dishwasher conveyor type (ZANUSSI) RT10
 RT100 - RT190 - RT270



ELECTROLUX 0E5161

3355670 FLANGE FOR HEATING ELEMENT
 external \varnothing 100 mm - internal \varnothing 57 mm - 5 holes
 for Dishwasher conveyor type (ZANUSSI) - Series RT



ELECTROLUX 0E5492

3755051 HEATING ELEMENT FOR WASH TANK 800W 230V
 immersed length 155 mm
 width 34 mm
 flange 50x27 mm
 complete with gasket
 for Glasswasher/Cupwasher (ZANUSSI) GW1 - GW2
 LB1 - LB2 - WT1 - WT2 - Z1 - Z2



ELECTROLUX 049059

3355348 HEATING ELEMENT 10500W 230/380V
 immersed length 340 mm
 flange external \varnothing 72 mm
 complete with o-ring \varnothing 67 (3186014)
 for Dishwasher hood type (ZANUSSI) ECOTEMP12
 HT1000 - HT1200 - LS10 - LS14



ELECTROLUX 0L1772

ELECTROLUX 049997

3755964 HEATING ELEMENT 10500W 230V
 immersed length 380 mm
 flange external \varnothing 63 mm
 with bulb sheath
 complete with O-Ring \varnothing 58 (3186013)
 for Dishwasher conveyor type (ZANUSSI) RT10



ELECTROLUX 0E5953

ELECTROLUX 0L1852

3755952 HEATING ELEMENT 12000W 220V
 immersed length 460 mm
 flange external \varnothing 72 mm.
 with bulb sheath
 complete with O-Ring \varnothing 67 (3186014)
 upon demand nut (3528003) and washer (3528004)
 for Dishwasher conveyor type (ZANUSSI) RT190
 RT270 - WTF3



ELECTROLUX 0E5213

ELECTROLUX 0K7530



Suitable for:

Suitable for:

3355289 HEATING ELEMENT 1375W 230V

width 370 mm
height 170 mm
for Dishwasher conveyor type (ZANUSSI) - Series RT
Series WT



ELECTROLUX 0E5126

ELECTROLUX 0E5253

3186073 HEATING ELEMENT GASKET



ELECTROLUX 0K7154

3755171 HEATING ELEMENT 17000W 230V

immersed depth 590 mm
flange external \varnothing 63 mm
with bulb sheath
complete with O-RING



ELECTROLUX 0C5336

ELECTROLUX 0F0095

ELECTROLUX 058995

ELECTROLUX 059003

3755572 BRACKET FOR HEATING ELEMENT

external \varnothing 90 mm - internal \varnothing 50 mm
thickness 2.5 mm - distance between holes 63 mm



ELECTROLUX 003362

ELECTROLUX 065558

3186013 O-RING GASKET 06187 EPDM \varnothing 58 mm

for Dishwasher (COMENDA) FC53 - FC533 - FC54
FC543 - FC544
for Dishwasher (FAGOR) FI-12D - FI-12S - FI-300
FI-300B
for Dishwasher (HOONVED) STS53 - STS60
for Dishwasher hood type (ADLER) DS1200
for Dishwasher hood type (BONNET) INO60
for Dishwasher hood type (COLGED) L51
for Dishwasher hood type (LINEA BLANCA) LC-3500
LC-4000
for Glasswasher/Cupwasher (FAGOR) CI-20 - CI-20D
for Glasswasher/Cupwasher (HOONVED) STS43 - STS48



ELECTROLUX 046213

ELECTROLUX 067620

ELECTROLUX 069456



Suitable for:

3355018 HEATING ELEMENT 1800W 220V
immersed length 360x50 mm
flange external dimensions 66x30 mm
for Dishwasher (ZANUSSI) LS32 - LS4 - LS50



ELECTROLUX 060715

3186007 HEATING ELEMENT SHAFT GASKET
in rubber



ELECTROLUX 060717

3755273 HEATING ELEMENT 1800W 220V
submersed length 330 mm
width 90 mm
fittings \varnothing 1/4"
for Dishwasher (ZANUSSI) LS4 - LS510 - LS521



ELECTROLUX 047507

3355024 HEATING ELEMENT 3000W 220/380V
for wash tank and boiler
immersed length 260 mm
flange external \varnothing 63 mm
complete with o-ring \varnothing 58 mm (3186013)



ELECTROLUX 066109

Suitable for:

3186008 HEATING ELEMENT GASKET
in rubber
for Dishwasher (FAGOR) FI-300B - FI-300R - FI-650R
for Dishwasher hood type (FAGOR) ECO-1200
FI-1200 - FI-900
for Glasswasher/Cupwasher (FAGOR) LVC-12 - LVC-15
LVC-15D - LVC-21 - LVC-21B - LVC-21D - LVR-10
LVR-14 - LVR-14D - LVR-20 - LVR-20B - LVR-20D



ELECTROLUX 060716

3355250 SHAFT FOR HEATING ELEMENT



ELECTROLUX 060718

40E2326 HEATING ELEMENT 2000W 220V
immersed length 350 mm
flange 60x26 mm with gasket



ELECTROLUX 0E2326

3186013 O-RING GASKET 06187 EPDM \varnothing 58 mm
for Dishwasher (COMENDA) FC53 - FC533 - FC54
FC543 - FC544
for Dishwasher (FAGOR) FI-12D - FI-12S - FI-300
FI-300B
for Dishwasher (HOONVED) STS53 - STS60
for Dishwasher hood type (ADLER) DS1200
for Dishwasher hood type (BONNET) INO60
for Dishwasher hood type (COLGED) L51
for Dishwasher hood type (LINEA BLANCA) LC-3500
LC-4000
for Glasswasher/Cupwasher (FAGOR) CI-20 - CI-20D
for Glasswasher/Cupwasher (HOONVED) STS43 - STS48



ELECTROLUX 046213

ELECTROLUX 067620

ELECTROLUX 069456



Suitable for:

3355022 HEATING ELEMENT 3000W 220V
 for wash tank and boiler
 immersed length 380x65 mm
 connections \varnothing 14 mm
 for Dishwasher conveyor type (ZANUSSI) - Series LN
 Series LSE



ELECTROLUX 067608

3355033 HEATING ELEMENT 4200W 220/380V
 for tank and boiler
 immersed length 335 mm
 flange external \varnothing 63 mm
 with thermostat probe receptacle
 with o-ring
 upon request nut and washer
 for Dishwasher hood type (ZANUSSI) LSE720



ELECTROLUX 046622

ELECTROLUX 046623

3528004 HEXAGONAL SCREW WASHER M4 - 100 PCS
 \varnothing 7.7x4.4x0.5 mm
 for Dishwasher (ZANUSSI) LS62/F



Suitable for:

3355313 HEATING ELEMENT 3000W 230V
 length 355 mm
 width 75 mm
 flange 50x27 mm
 for Dishwasher hood type (ZANUSSI) HT900 - LS9



ELECTROLUX 0L1870

ELECTROLUX 048491

3528003 BRASS NUT M4 - 100 PIECES
 for Dishwasher (ZANUSSI) LS62/F



3186013 O-RING GASKET 06187 EPDM \varnothing 58 mm
 for Dishwasher (COMENDA) FC53 - FC533 - FC54
 FC543 - FC544
 for Dishwasher (FAGOR) FI-12D - FI-12S - FI-300
 FI-300B
 for Dishwasher (HOONVED) STS53 - STS60
 for Dishwasher hood type (ADLER) DS1200
 for Dishwasher hood type (BONNET) INO60
 for Dishwasher hood type (COLGED) L51
 for Dishwasher hood type (LINEA BLANCA) LC-3500
 LC-4000
 for Glasswasher/Cupwasher (FAGOR) CI-20 - CI-20D
 for Glasswasher/Cupwasher (HOONVED) STS43 - STS48



ELECTROLUX 046213

ELECTROLUX 067620

ELECTROLUX 069456



Suitable for:

3355025 HEATING ELEMENT 4500W 220/380V
 for wash tank and boiler
 immersed length 395 mm
 flange external \varnothing 63 mm
 complete with o-ring \varnothing 58 mm (3186013)
 for Dishwasher (ZANUSSI) LS360
 for Dishwasher hood type (ZANUSSI) LS860



ELECTROLUX 002523

ELECTROLUX 065557

Suitable for:

3186013 O-RING GASKET 06187 EPDM \varnothing 58 mm
 for Dishwasher (COMENDA) FC53 - FC533 - FC54
 FC543 - FC544
 for Dishwasher (FAGOR) FI-12D - FI-12S - FI-300
 FI-300B
 for Dishwasher (HOONVED) STS53 - STS60
 for Dishwasher hood type (ADLER) DS1200
 for Dishwasher hood type (BONNET) INO60
 for Dishwasher hood type (COLGED) L51
 for Dishwasher hood type (LINEA BLANCA) LC-3500
 LC-4000
 for Glasswasher/Cupwasher (FAGOR) CI-20 - CI-20D
 for Glasswasher/Cupwasher (HOONVED) STS43 - STS48



ELECTROLUX 046213

ELECTROLUX 067620

ELECTROLUX 069456

3355292 HEATING ELEMENT 4500W 220/380V
 immersed length 320 mm
 flange external \varnothing 63 mm
 with thermostat probe receptacle
 complete with OR \varnothing 58 (3186013)
 for Dishwasher (UNIVERBAR) BRAMA - OMEGA - OMEGAD
 for Dishwasher (ZANUSSI) LS4 - LS6
 for Dishwasher hood type (ZANUSSI) LS8



ELECTROLUX 047847

3186013 O-RING GASKET 06187 EPDM \varnothing 58 mm
 for Dishwasher (COMENDA) FC53 - FC533 - FC54
 FC543 - FC544
 for Dishwasher (FAGOR) FI-12D - FI-12S - FI-300
 FI-300B
 for Dishwasher (HOONVED) STS53 - STS60
 for Dishwasher hood type (ADLER) DS1200
 for Dishwasher hood type (BONNET) INO60
 for Dishwasher hood type (COLGED) L51
 for Dishwasher hood type (LINEA BLANCA) LC-3500
 LC-4000
 for Glasswasher/Cupwasher (FAGOR) CI-20 - CI-20D
 for Glasswasher/Cupwasher (HOONVED) STS43 - STS48



ELECTROLUX 046213

ELECTROLUX 067620

ELECTROLUX 069456

3755211 HEATING ELEMENT 4500W 230V
 immersed length 320 mm
 flange external \varnothing 63 mm
 with thermostat probe receptacle
 with O-ring
 for Dishwasher hood type (ZANUSSI) LSE720 - LS860



ELECTROLUX 046627

3186013 O-RING GASKET 06187 EPDM \varnothing 58 mm
 for Dishwasher (COMENDA) FC53 - FC533 - FC54
 FC543 - FC544
 for Dishwasher (FAGOR) FI-12D - FI-12S - FI-300
 FI-300B
 for Dishwasher (HOONVED) STS53 - STS60
 for Dishwasher hood type (ADLER) DS1200
 for Dishwasher hood type (BONNET) INO60
 for Dishwasher hood type (COLGED) L51
 for Dishwasher hood type (LINEA BLANCA) LC-3500
 LC-4000
 for Glasswasher/Cupwasher (FAGOR) CI-20 - CI-20D
 for Glasswasher/Cupwasher (HOONVED) STS43 - STS48



ELECTROLUX 046213

ELECTROLUX 067620

ELECTROLUX 069456



Suitable for:

ELECTROLUX



Suitable for:

3755951 HEATING ELEMENT 4500W 230V
 immersed length 265 mm
 flange \varnothing 63 mm
 with O-Ring \varnothing 58 (3186013)
 for Dishwasher (ZANUSSI) EUC1 - EUC3 - LS5 - WT4



ELECTROLUX 0L2129

ELECTROLUX 0L2652

ELECTROLUX 049955

3355026 HEATING ELEMENT 6000W 220/380V
 for wash tank and boiler
 immersed length 495 mm
 flange external \varnothing 63 mm
 complete with o-ring \varnothing 58 mm (3186013)



ELECTROLUX 058012

ELECTROLUX 066110

ELECTROLUX 076035

3355046 HEATING ELEMENT 6000W 220/380V
 immersed length 490 mm
 flange external \varnothing 63 mm
 with thermostat probe receptacle
 with O-ring
 for Dishwasher conveyor type (ZANUSSI) CT92



ELECTROLUX 051632

3186013 O-RING GASKET 06187 EPDM \varnothing 58 mm
 for Dishwasher (COMENDA) FC53 - FC533 - FC54
 FC543 - FC544
 for Dishwasher (FAGOR) FI-12D - FI-12S - FI-300
 FI-300B
 for Dishwasher (HOONVED) STS53 - STS60
 for Dishwasher hood type (ADLER) DS1200
 for Dishwasher hood type (BONNET) INO60
 for Dishwasher hood type (COLGED) L51
 for Dishwasher hood type (LINEA BLANCA) LC-3500
 LC-4000
 for Glasswasher/Cupwasher (FAGOR) CI-20 - CI-20D
 for Glasswasher/Cupwasher (HOONVED) STS43 - STS48



ELECTROLUX 046213

ELECTROLUX 067620

ELECTROLUX 069456

3186013 O-RING GASKET 06187 EPDM \varnothing 58 mm
 for Dishwasher (COMENDA) FC53 - FC533 - FC54
 FC543 - FC544
 for Dishwasher (FAGOR) FI-12D - FI-12S - FI-300
 FI-300B
 for Dishwasher (HOONVED) STS53 - STS60
 for Dishwasher hood type (ADLER) DS1200
 for Dishwasher hood type (BONNET) INO60
 for Dishwasher hood type (COLGED) L51
 for Dishwasher hood type (LINEA BLANCA) LC-3500
 LC-4000
 for Glasswasher/Cupwasher (FAGOR) CI-20 - CI-20D
 for Glasswasher/Cupwasher (HOONVED) STS43 - STS48



ELECTROLUX 046213

ELECTROLUX 067620

ELECTROLUX 069456



Suitable for:

3355106 HEATING ELEMENT 6000W 230/400V
for wash tank and boiler
immersed length 350 mm
flange external \varnothing 72 mm
with thermostat probe receptacle
with O-ring
upon request nut and washer
for Dishwasher (ANGELO PO) AL75 - AL90 - AP9
for Dishwasher (ZANUSSI) LS62/F
for Dishwasher hood type (ANGELO PO) L100 - L80



ELECTROLUX 049898

3528004 HEXAGONAL SCREW WASHER M4 - 100 PCS
 \varnothing 7.7x4.4x0.5 mm
for Dishwasher (ZANUSSI) LS62/F



Suitable for:

3528003 BRASS NUT M4 - 100 PIECES
for Dishwasher (ZANUSSI) LS62/F



3186014 O-RING GASKET 06225 EPDM \varnothing 67 mm
for Dishwasher (ZANUSSI) LS62/F



ELECTROLUX 0E5037
ELECTROLUX 049909

ELECTROLUX 007029

ELECTROLUX 047156

3755963 HEATING ELEMENT 6000W 230V
immersed length 300 mm
flange external \varnothing 63 mm
complete with O-Ring \varnothing 58 (3186013)
for Pan washing machine (ZANUSSI)



ELECTROLUX 0L1878

ELECTROLUX 049116

3355307 HEATING ELEMENT 9000W 230V
immersed length 440 mm
external flange 72 mm
complete with o-ring \varnothing 67 (3186014)
upon request nut (3528003) and washer (3528004)
for Dishwasher conveyor type (ZANUSSI) - Series RT



ELECTROLUX 0E5163

3355670 FLANGE FOR HEATING ELEMENT
external \varnothing 100 mm - internal \varnothing 57 mm - 5 holes
for Dishwasher conveyor type (ZANUSSI) - Series RT



ELECTROLUX 0E5492



Suitable for:

3755270 HEATING ELEMENT 9000W 230V
 submersed length 345 mm
 flange external \varnothing 72 mm
 complete with O-ring \varnothing 67 (3186014)
 upon request nut (3528003) and washer (3528004)
 for Dishwasher (ZANUSSI) LU7
 for Dishwasher hood type (ZANUSSI) HT1200 - LS10E
 LS14ROW - LS9 - WT55



ELECTROLUX 0L1630

ELECTROLUX 0L2653

ELECTROLUX 049992

Suitable for:

3355336 SILICONE HEATING ELEMENT 1000W 240V
 length 400 mm - width 290 mm
 complete with thermostat 150°C automatic reset



ELECTROLUX 032094

3455336 TANK HEATING ELEMENT 3x5000W 230V
 immersed length 445 mm
 flange \varnothing 72 mm
 with O-RING \varnothing 67 (3186014)
 for Dishwasher conveyor type (ZANUSSI) WTF2 - WTF3
 WTF4



ELECTROLUX 0K8505

3455425 TANK HEATING ELEMENT 7500W 230V
 immersed length 325 mm
 flange \varnothing 72 mm
 with O-Ring \varnothing 67 (3186014)
 with bulb sheath
 for Pan washing machine (ZANUSSI) LV100M - LV200M



ELECTROLUX 0H2277

Hinges

3053049 CLASP
 for Dishwasher (ZANUSSI) LS50 - LS51 - LS52




ELECTROLUX 045446

3053325 DOOR LEVER
 for Pan washing machine (ZANUSSI) - Series PW
 Series WT



ELECTROLUX 049731

3250052 DOOR SPRING \varnothing 16x186 mm
 for Glasswasher/Cupwasher (ZANUSSI) GW1 - LB1
 WT1 - WT2 - Z1



ELECTROLUX 049200

3250068 DOOR SPRING \varnothing 16x198 mm
 for Glasswasher/Cupwasher (ZANUSSI) GW2 - LB2 - Z2



ELECTROLUX 049086



Suitable for:

Suitable for:

3053324 DOOR TIE ROD \varnothing 12x605 mm
for Pan washing machine (ZANUSSI) - Series PW
Series WT



ELECTROLUX 049730

3053210 DOOR TIE ROD 255 mm
for Dishwasher (ZANUSSI) C32 - C33 - C55 - FL32
FL33 - FL5 - LS32 - LS33 - LS5 - LV32 - LV5
WT302 - WT303 - WT4 - Z32



ELECTROLUX 049282

3053209 DOOR TIE ROD RETAINER
for Dishwasher (ZANUSSI) C32 - C33 - C55 - FL32
FL33 - FL5 - LS32 - LS33 - LS5 - LV32 - LV5
WT302 - WT303 - WT4 - Z32



ELECTROLUX 049286

1348817 STAINLESS STEEL CIRCLIP RA-4 UNI 7437



ELECTROLUX 049284

3053021 LEFTHAND STEEL DOOR HINGE
for Dishwasher (ZANUSSI) LS50 - LS51 - LS52



ELECTROLUX 045480

ELECTROLUX 045483

3398018 DOOR LOCKING PLATE 64x16 mm
for Dishwasher (ZANUSSI) C32 - C33 - C55 - FL32
FL33 - FL5 - LS32 - LS33 - LS5 - LV32 - LV5
WT302 - WT303 - WT4 - Z32



ELECTROLUX 049285

3528062 NUT FOR DOOR TIE ROD
for Dishwasher (ZANUSSI) C32 - C33 - C55 - FL32
FL33 - FL5 - LS32 - LS33 - LS5 - LV32 - LV5
WT302 - WT303 - WT4 - Z32



ELECTROLUX 049372

3053208 TIE ROD PIN
for Dishwasher (ZANUSSI) C32 - C33 - C55 - FL32
FL33 - FL5 - LS32 - LS33 - LS5 - LV32 - LV5
WT302 - WT303 - WT4 - Z32



ELECTROLUX 049283



Suitable for:

3053062 LEVER FOR LEFTHAND DOOR HINGE
for Dishwasher (ZANUSSI) ECOTEMP5 - LS62 - LS63
LS64



ELECTROLUX 0L0718

ELECTROLUX 048814

Suitable for:

3053063 BUSH FOR LEVER
for Dishwasher (ZANUSSI) ECOTEMP5 - LS62 - LS63
LS64



ELECTROLUX 048812

3053064 RETURN SPRING FOR DOOR
for Dishwasher (ZANUSSI) ECOTEMP5 - LS62 - LS63
LS64



ELECTROLUX 048815

3053061 LEVER FOR RIGHTHAND DOOR HINGE
for Dishwasher (ZANUSSI) ECOTEMP5 - LS62 - LS63
LS64



ELECTROLUX 0L0717

ELECTROLUX 048813

3053063 BUSH FOR LEVER
for Dishwasher (ZANUSSI) ECOTEMP5 - LS62 - LS63
LS64



ELECTROLUX 048812

3053064 RETURN SPRING FOR DOOR
for Dishwasher (ZANUSSI) ECOTEMP5 - LS62 - LS63
LS64



ELECTROLUX 048815

3053079 PIN FOR HINGE SPRING \varnothing 11x280 mm
for Dishwasher (ZANUSSI) LS360 - LS365 - LS500



ELECTROLUX 048581



ELECTROLUX



Suitable for:

3053130 RIGHTHAND HINGE
for Dishwasher (ZANUSSI) LS7



ELECTROLUX 048582

Suitable for:

3053133 LEFTHAND HINGE
for Dishwasher (ZANUSSI) LS7



ELECTROLUX 048583

3053058 RIGHTHAND/LEFTHAND DOOR HINGE
for Dishwasher (ZANUSSI) - Series LS



ELECTROLUX 048161

3053059 HINGE PIN
for Dishwasher (ZANUSSI) - Series LS



ELECTROLUX 047478

3053078 SAFETY PIN 95 mm



ELECTROLUX 048297

3250047 SAFETY SPRING \varnothing 9x26 mm
for LS8-LS10-HT1000-HT1200-HYDRA 1200-LS12-HT800-
HYDRA 800-HYDRA 1000



ELECTROLUX 048298

3250048 SPRING FOR HOOD LIFTING
dimensions \varnothing 39x495 mm
for LS10-WT60-LS12-HT1000-HT1200-HYDRA 1000-
HYDRA 1200-Z100-Z120



ELECTROLUX 048258

3053052 SPRING FOR LEFTHAND DOOR HINGE
for Dishwasher (ZANUSSI) LS360 - LS365 - LS500



ELECTROLUX 046268

3053053 SPRING FOR RIGHTHAND DOOR HINGE
for Dishwasher (ZANUSSI) LS360 - LS365 - LS500



ELECTROLUX 046269



Suitable for:

ELECTROLUX



3053240 TIE-ROD GUIDE PIN

for Pan washing machine (ZANUSSI) PW1 - PW100
PW2 - PW200 - WT830



ELECTROLUX 049685

Suitable for:

3053239 LEFT DOOR LOCK

for Pan washing machine (ZANUSSI) PW1 - PW100
PW2 - PW200 - WT830



ELECTROLUX 049711

3053241 RIGHT DOOR LOCK

for Pan washing machine (ZANUSSI) PW1 - PW100
PW2 - PW200 - WT830



ELECTROLUX 049693

Hose reels

3359553 WALL MOUNTED WASHING UNIT MINIREEL

stainless steel case aisi 304
with automatic retractor
EPDM hose \varnothing 13 mm
pull-out hose length 1600 mm
complete with shower ECO/F
for mounting to any machine



ELECTROLUX 0T1747

ELECTROLUX 006696


3359610 BLACK SHOWER CASE ECO \varnothing 1/2" M

with coupling 3/8" M x 1/2" M



ELECTROLUX 003175

3359611 SPRAY CUP WITH FILTER





Suitable for:

ELECTROLUX

Suitable for:



Hose-end fittings

3315023 Y-SHAPED FITTING
fittings outer \varnothing 14 mm
for Dishwasher (ZANUSSI) LS5 - LS6 - LS7
for Dishwasher hood type (ZANUSSI) LS14



ELECTROLUX 0L0365

3315106 3-WAY HOSE END RUBBER FITTING \varnothing 10 mm
for Dishwasher (DIHR) DS35 - DS37 - DS40
ELECTRON400 - ELECTRON400CLEAN - GASTRO450
GS37 - GS40 - G35 - LINEAR - TEKNO4
for Dishwasher (UNIVERBAR) SINCRO - SINCROD - TOP
for Dishwasher conveyor type (DIHR) BX300
for Glasswasher/Cupwasher (DIHR) DERBY - STAR
for Glasswasher/Cupwasher (UNIVERBAR) BET37
BET37D - BET40 - BET40D - MINIBET - MINIBETD
MIX



ELECTROLUX 047431

3315107 3-WAYS HOSE END RUBBER FITTING \varnothing 12



ELECTROLUX 048195

Inlet hoses

3449007 ELBOW INLET HOSE 3/4" 150 cm
rubber hose with textile reinforcement
external \varnothing 20 mm
internal \varnothing 13 mm
with elbow of thermoplastic material
metal ring nuts \varnothing 3/4" F
max temperature 90°C
max pressure 15 bar




ELECTROLUX 0S0153

ELECTROLUX 047605

ELECTROLUX 066463

3449026 FLAT EPDM GASKET \varnothing 24x12x2 mm
for pipes \varnothing 3/4"



ELECTROLUX 046925

3449025 INLET HOSE STAINLESS STEEL FILTER \varnothing 3/4"
for all models
for Dishwasher (MACH)





Suitable for:

3449001 INLET ELBOW HOSE \varnothing 3/4" FF 150 cm
 pipe \varnothing 10x16 mm
 nylon fittings \varnothing 3/4" with gaskets
 max temperature 90°C
 max pressure 10 bar



ELECTROLUX 0S0150

ELECTROLUX 053789

Suitable for:

3449026 FLAT EPDM GASKET \varnothing 24x12x2 mm
 for pipes \varnothing 3/4"



ELECTROLUX 046925

3449025 INLET HOSE STAINLESS STEEL FILTER \varnothing 3/4"
 for all models
 for Dishwasher (MACH)



3449056 INLET ELBOW PIPE \varnothing 3/4" FF 200 cm
 thermoplastic pipe \varnothing 13x19 mm
 brass fittings \varnothing 3/4" with gaskets
 max temperature 90°C
 max pressure 10 bar
 with WRAS approval



ELECTROLUX 0L1887

ELECTROLUX 048816

3449034 INLET ELBOW PIPE \varnothing 3/4" 150 cm
 made of EPDM covered in stainless steel \varnothing 17x12 mm
 elbow and ring nuts \varnothing 3/4" F
 max temperature 93°C
 max pressure 20 bar
 WRAS approved



ELECTROLUX 0S0151

ELECTROLUX 069571

3449035 INLET ELBOW PIPE \varnothing 3/4" 200 cm
 made of EPDM covered in stainless steel \varnothing 17x12 mm
 elbow and ring nuts \varnothing 3/4" F
 max temperature 93°C
 max pressure 20 bar
 WRAS approved



ELECTROLUX 049540



ELECTROLUX



Suitable for:

3449003 STRAIGHT INLET HOSE \varnothing 3/4" 150 cm
rubber hose with textile reinforcement
external \varnothing 20 mm
internal \varnothing 13 mm
with metal ring nuts \varnothing 3/4"
max temperature 90°C
max pressure 15 bar



ELECTROLUX 0S0152

ELECTROLUX 060933

Suitable for:

3449026 FLAT EPDM GASKET \varnothing 24x12x2 mm
for pipes \varnothing 3/4"



ELECTROLUX 046925

3449025 INLET HOSE STAINLESS STEEL FILTER \varnothing 3/4"
for all models
for Dishwasher (MACH)



Interference suppression filters

3160099 INTERFERENCE SUPPRESSION FILTER 0,47 μ F



ELECTROLUX 046217

3160394 TRAP FILTER RFI 230V



ELECTROLUX 046226

Ironmongery (screws,nuts,washers)

1349504 NUT FOR TAP \varnothing 1/2"



ELECTROLUX 003035

3528094 S.ST.SCREW T.E. M8x12 UNI 5739 DIN 24017



ELECTROLUX 0KE147

Knobs

3241200 KNOB \varnothing 40 mm
D shaft hole 6x4.6 mm
for Dishwasher (ZANUSSI) LS360 - LS4 - LS510
LS520 - LS521



ELECTROLUX 047842

3241201 ALLEN SCREW FOR KNOB M4X6



ELECTROLUX 046258

ELECTROLUX 047846



Suitable for:

3241202 KNOB \varnothing 42 mm
D-shaped hole 4.6x6 mm
for Dishwasher (ZANUSSI) LS360 - LS365



ELECTROLUX 047693

Suitable for:

3241201 ALLEN SCREW FOR KNOB M4X6



ELECTROLUX 046258

ELECTROLUX 047846

3241204 PROGRAM SWITCH KNOB \varnothing 40 mm
D shaft hole 6x4.6 mm
for Dishwasher (ZANUSSI) LS521



ELECTROLUX 048153

Lamps

3221132 GREEN INDICATOR LAMP 230V
head \varnothing 13.5 mm - hole \varnothing 10 mm - 120°C
universal application



ELECTROLUX 004169

ELECTROLUX 058544

3221164 GREEN INDICATOR LAMP 230V
head \varnothing 7 mm - hole \varnothing 6 mm - 120°C
dashboard mounting
for Dishwasher (COLGED) E78



ELECTROLUX 054150+054151

3221045 GREEN LAMP CAP \varnothing 7 mm



ELECTROLUX 054151

3221034 GREEN INDICATOR LAMP 400V
head \varnothing 13.5 mm - hole \varnothing 10 mm - 120°C
universal application



ELECTROLUX 004157

3221430 ORANGE INDICATOR LAMP 400V
head \varnothing 15.5 mm - hole \varnothing 10 mm
universal application





ELECTROLUX



Suitable for:

Suitable for:

3221035 RED INDICATOR LAMP 400V
head \varnothing 13.5 mm - hole \varnothing 10 mm - 120°C
universal application



3221008 GREEN LAMP RECEPTACLE
head \varnothing 15 mm - hole \varnothing 12.5 mm
universal application



ELECTROLUX 075096

3221126 INDICATOR LAMP 24V
head \varnothing 8 mm



ELECTROLUX 075110

3221097 NEUTRAL INDICATOR LAMP 220V
head \varnothing 8 mm - 120°C



ELECTROLUX 004895

ELECTROLUX 046241

ELECTROLUX 048488

ELECTROLUX 048832

3221098 GREEN LAMP RECEPTACLE
for DS11/13/101/103-CF35-CF40/235/1000-DL240-DS600



ELECTROLUX 0HA054

3221378 GREEN LAMP RECEPTACLE
for LO250



ELECTROLUX 075605

3221011 ORANGE INDICATOR LAMP 230V
head \varnothing 13.5 mm - hole \varnothing 10 mm - 120°C
universal application



ELECTROLUX 0A2225

3221032 GREEN INDICATOR LAMP 230V
head \varnothing 13.5 mm - hole \varnothing 10 mm - 120°C
universal application



ELECTROLUX 0A2224

ELECTROLUX 058544



Suitable for:

3221033 RED INDICATOR LAMP 230V
head \varnothing 13.5 mm - hole \varnothing 10 mm - 120°C
universal application



ELECTROLUX 0A2408

3221094 ORANGE INDICATOR LAMP 230V
head \varnothing 14.5 mm - hole \varnothing 11.5 mm - 120°C
for C33-C44-C66-CW650-BD11/13/14/22-LP60/130-D30
D40-D80F-D120



ELECTROLUX 0H6618

3221007 ORANGE LAMP RECEPTACLE
head \varnothing 15 mm - hole \varnothing 12.5 mm
universal application



ELECTROLUX 075095

3221097 NEUTRAL INDICATOR LAMP 220V
head \varnothing 8 mm - 120°C



ELECTROLUX 004895

ELECTROLUX 046241

ELECTROLUX 048488

3221004 RED INDICATOR LAMP 220/380V
head 16x16 mm - hole \varnothing 12 mm - 120°C
universal application



ELECTROLUX 053153

ELECTROLUX



Suitable for:

3221095 ORANGE INDICATOR LAMP 230V
head \varnothing 13.5 mm - hole \varnothing 10 mm - 120°C
universal application



ELECTROLUX 005215

ELECTROLUX 058522

3221126 INDICATOR LAMP 24V
head \varnothing 8 mm



ELECTROLUX 075110

3221005 GREEN INDICATOR LAMP 220/380V
head 16x16 mm - hole \varnothing 12 mm - 120°C
universal application



ELECTROLUX 026456

ELECTROLUX 053148

ELECTROLUX 053154



ELECTROLUX



Suitable for:

Suitable for:

3221006 ORANGE INDICATOR LAMP 220/380V
head 16x16 mm - hole \varnothing 12 mm - 120°C
universal application



ELECTROLUX 045272

ELECTROLUX 053149

ELECTROLUX 053155

3221009 RED INDICATOR LAMP 220V
head 17x17 mm - \varnothing hole 13 mm - 120°C
universal application



ELECTROLUX 057294

3221379 RED LAMP RECEPTACLE
for L0250



ELECTROLUX 075604

3221593 WHITE INDICATOR LIGHT 24V
hole \varnothing 12 mm



ELECTROLUX 0E5134

3221380 WHITE LAMP RECEPTACLE
for L0250



ELECTROLUX 075603

3221605 YELLOW INDICATOR LIGHT 24V
hole \varnothing 12 mm



ELECTROLUX 0E5195


Lever mixers

3359178 SINGLE-HOLE LEVER MIXER
mounting hole \varnothing 52 mm
spout \varnothing 20x300 mm



ELECTROLUX 0S1244

3359300 BLACK LEVER FOR MIXER
length 255 mm
connection 10x10 mm





Suitable for:

3359297 MIXER CARTRIDGE (BIG TYPE)



ELECTROLUX



Suitable for:

3359252 SPOUT \varnothing 20x320x200 mm



3359181 TWO-HOLE SINGLE LEVER MIXER
connections \varnothing 3/4"MM
distance between holes 155 mm
spout 250 mm




ELECTROLUX 0S1457

ELECTROLUX 069965

ELECTROLUX 850021

3359298 MIXER CARTRIDGE (SMALL TYPE)



ELECTROLUX 0S1340

ELECTROLUX 069958

3359269 SPOUT 250 mm



ELECTROLUX 0S1404

ELECTROLUX 069962

3359443 TWO-HOLE SINGLE LEVER MIXER
spout 250 mm
flow rate 22 L/min by 4 bar
distance between holes 155 mm
connections \varnothing 3/4"MM
mounting hole \varnothing 27/28 mm



ELECTROLUX 0S0341

3359409 BLUE LEVER FOR MIXER
length 345 mm
fitting 7x8 mm



3359408 BLACK LEVER FOR MIXER
length 310 mm
connection 7x8 mm



ELECTROLUX 0S0343

3359461 MIXER CARTRIDGE



ELECTROLUX 0S0346



Suitable for:

3359823 SPOUT 250 mm



ELECTROLUX 050344

ELECTROLUX



Suitable for:

Manifolds for dishwashers

3061012 COMPLETE FILTER HOLDER MANIFOLD SET
for Dishwasher (ZANUSSI) LS62 - LS63 - LS64 - LS7
for Dishwasher hood type (ZANUSSI) LS8



ELECTROLUX 0L1629

ELECTROLUX 048325

3061015 CAP GASKET
for Dishwasher (ZANUSSI) LS62 - LS63 - LS64 - LS7
for Dishwasher hood type (ZANUSSI) LS8



ELECTROLUX 046595

3061016 EPDM O-RING GASKET 04437
for Dishwasher (ZANUSSI) LS62 - LS63 - LS64 - LS7
for Dishwasher hood type (ZANUSSI) LS8



ELECTROLUX 048327

3061017 UPPER RING NUT FOR MANIFOLD
for Dishwasher (ZANUSSI) LS62 - LS63 - LS64 - LS7
for Dishwasher hood type (ZANUSSI) LS8



ELECTROLUX 048326

3061014 CAP FOR MANIFOLD
for Dishwasher (ZANUSSI) LS62 - LS63 - LS64 - LS7
for Dishwasher hood type (ZANUSSI) LS8



ELECTROLUX 046596

3061020 CLAMP FOR MANIFOLD
for Dishwasher (ZANUSSI) LS63 - LS64



ELECTROLUX 046878

3786686 GASKET



ELECTROLUX 049828



Suitable for:

ELECTROLUX



Suitable for:

3061019 DRAIN MANIFOLD KIT
 for Dishwasher (ZANUSSI) CRISTAL50 - CRISTAL51
 CRISTAL52 - LS360 - LS4 - LS520 - LS54 - LS540
 LS550



ELECTROLUX 0L1638

ELECTROLUX 047456

ELECTROLUX 047457

3061026 MANIFOLD OUTLET



ELECTROLUX 046594

3061008 CAP GASKET



ELECTROLUX 046593

3061007 O-RING 04362 EPDM
 for Dishwasher hood type (WINTERHALTER) GS502



ELECTROLUX 045462

3061013 WASH PUMP FILTER MANIFOLD
 for Dishwasher (ZANUSSI) LS505



ELECTROLUX 047554

3061014 CAP FOR MANIFOLD
 for Dishwasher (ZANUSSI) LS62 - LS63 - LS64 - LS7
 for Dishwasher hood type (ZANUSSI) LS8



ELECTROLUX 046596

3061015 CAP GASKET
 for Dishwasher (ZANUSSI) LS62 - LS63 - LS64 - LS7
 for Dishwasher hood type (ZANUSSI) LS8



ELECTROLUX 046595

3061011 O-RING SEAL 04375 EPDM
 for Dishwasher (ZANUSSI) CRYSTAL50 - CRYSTAL51
 CRYSTAL52 - LS36 - LS4 - LS505 - LS510 - LS520
 LS54



ELECTROLUX 047458



ELECTROLUX



Suitable for:

3061021 WASH PUMP FILTER MANIFOLD
for Dishwasher hood type (ZANUSSI) LS10 - LS12



ELECTROLUX 048430 ELECTROLUX 049600

3061023 CAP GASKET
for Dishwasher (ZANUSSI)



ELECTROLUX 048230

3450032 DRAIN PIPE ø 38x2000 mm
muffs internal ø 31 and 40 mm
max temperature 90°C



ELECTROLUX 049748

3061025 WASH PUMP FILTER MANIFOLD
for Dishwasher hood type (ZANUSSI) LS1080 - LS860



ELECTROLUX 046525

Suitable for:

3061022 CAP FOR MANIFOLD
for Dishwasher hood type (ZANUSSI) LS10 - LS12



ELECTROLUX 048231

3450031 DRAIN PIPE ø 38x1500 mm
muffs internal ø 31 and 40 mm
max temperature 90°C



ELECTROLUX 048818 ELECTROLUX 049856

3786181 O-RING 0150 EPDM



ELECTROLUX 048229

Microswitches

40E5835 ACTOVATOR FOR MICROSWITCH
for DISHWASHER RT10-RT180-Z18-WT90



ELECTROLUX 0E5835

3240605 DOOR MICROSWITCH M1AX20 10A 250V



ELECTROLUX 002785 ELECTROLUX 046063



Suitable for:

ELECTROLUX



3240465 LEVEL MICROSENSOR FOR BOILER
contact NA
for Dishwasher hood type (ZANUSSI) LS10 - LS8



ELECTROLUX 049309

ELECTROLUX 049478

3240167 LEVER FOR MICROSWITCH
for Dishwasher (ZANUSSI) LS365 - LS367 - LS540
LS541 - 5CF06B - 5CF09B



ELECTROLUX 046279

3240471 MAGNET FOR MICROSWITCH 23x16x18 mm
for Dishwasher conveyor type (ZANUSSI) - Series RT



ELECTROLUX 0E0102

ELECTROLUX 088361

3240461 MAGNETIC MICRO SWITCH
bulb \varnothing 6x30 mm - cable 350 mm.
for Dishwasher (ZANUSSI)
since 1/01/94
till 1/01/94
LS7 - WT40



ELECTROLUX 048893

3240467 MAGNETIC MICROSWITCH
for rinsing area
1400 mm cable
bulb \varnothing 9x30 mm
contacts normally closed
for Dishwasher conveyor type (ZANUSSI) RT100
RT140 - RT190



ELECTROLUX 0E0006

ELECTROLUX 0E2321

ELECTROLUX 049970

3240463 MAGNETIC MICROSWITCH \varnothing 6x30 mm
0.01A 250V - contact NO
with cable length 290 mm
for Dishwasher (ZANUSSI) LS61 - LS62 - LS63 - LS64
Z62 - Z63 - Z64
for Dishwasher hood type (ZANUSSI) LS10 - LS8



ELECTROLUX 048831

3240464 MICROSWITCH MAGNET \varnothing 6x29 mm
for Dishwasher hood type (ZANUSSI) HT1000 - HT1200
HYDRA1000 - HYDRA1200 - LS10 - LS12 - LS8
Z100 - Z120



ELECTROLUX 048667



Suitable for:

3240466 MAGNETIC MICROSWITCH \varnothing 6x30 mm
 0.5A 250V - contact NO
 with cable length 460 mm
 for Dishwasher hood type (ZANUSSI) ECOTEMP12
 HT1000 - HT1200 - HT800 - HYDRA1000
 HYDRA1200 - HYDRA800 - LS10 - LS12 - LS8
 for Glasswasher/Cupwasher (ZANUSSI) GW1 - GW2
 LB1 - LB2 - WT1 - WT2 - Z1 - Z2



ELECTROLUX 048268

ELECTROLUX 048486

3240462 MAGNETIC MICROSWITCH E5111B
 0.01A 250V - contact NO - head 32x13x8 mm
 with cable length 290 mm
 for Dishwasher (ZANUSSI) LS3 - LS6



ELECTROLUX 049226

3240469 MAGNETIC MICROSWITCH E7101B
 50VA 250V - NO contact - head 50x19 mm
 for Dishwasher hood type (ZANUSSI) LS10 - LS12
 WT60
 for Pan washing machine (ZANUSSI)
 since 1/01/99
 till 1/01/99
 PW1M - PW2M



ELECTROLUX 049621

Suitable for:

3240137 MAGNET PROTECTION
 for Dishwasher hood type (ZANUSSI) ECOTEMP12
 HYDRA1000 - HYDRA1200 - LS10 - LS12



ELECTROLUX 049535

3240468 MAGNETIC MICROSWITCH E591-1U
 230V 3A 60W
 1600 mm cable
 for Dishwasher conveyor type (ZANUSSI) LN - RT10
 RT100 - RT140 - RT190 - RT270



ELECTROLUX 0E0003

ELECTROLUX 049966

3240148 MICROSWITCH MAGNET 63x19x11 mm
 for Dishwasher (ANGELO PO) F60P - F60PR - F60T
 F80P - F80PR
 for Dishwasher (SILANOS) N50 - N700
 for Dishwasher (WHIRLPOOL) AGB648 - AGB650
 AGB651 - AGB652 - AGB657 - AGB658 - AGB659
 AGB660 - AGB663
 for Dishwasher hood type (SILANOS) N1000
 for Dishwasher hood type (ZANUSSI) LS10 - LS12
 for Glasswasher/Cupwasher (SILANOS) N22 - R20
 O20 - O30
 for Glasswasher/Cupwasher (WHIRLPOOL) AGB641
 AGB642 - AGB643 - AGB645 - AGB646 - AGB647
 AGB782 - AGB783 - AGB784



ELECTROLUX 049627



Suitable for:

ELECTROLUX



3240098 MAGNETIC MICROSWITCH 36x26 mm
 cable length 2500 mm
 for Dishwasher conveyor type (ZANUSSI) RT10



ELECTROLUX 0E5854

ELECTROLUX 049969

3240407 MECHANICAL MICROSWITCH KIT 16A 250V
 3 locking positions
 the kit includes 5 levers:
 lever 75 mm - lever 27 mm - lever 15 mm
 lever 15 mm with wheels - lever 27 mm with wheels
 for Dishwasher (DIHR) GASTRO450 - GASTRO500
 GASTRO750 - GASTRO900 - GS100 - TEKNO4
 for Dishwasher (KROMO) K40LUX - K60 - K70 - K80
 for Dishwasher (OLIS) OLDS35 - OLDS37 - OLDS50
 for Dishwasher (UNIVERBAR) BRAMA - CASTA - COSMO
 LOGOS - LOGOSD - MIDI50 - MIDI50D - OMEGA
 OMEGAD - SINCRO - SINCROD - TOP - UBF850/2R
 for Dishwasher hood type (UNIVERBAR) COMPACT
 for Glasswasher/Cupwasher (DIHR) DERBYCF
 LINEARCF - LINEARLS - STARCF - STARLS
 for Glasswasher/Cupwasher (UNIVERBAR) BET37



ELECTROLUX 069484

3803063 MICRO SWITCH WITH CABLE 1700 mm
 for Dishwasher conveyor type (ZANUSSI) D530 - D580
 D680 - RT100 - RT140 - RT180 - RT190 - RT250
 RT270 - RT340 - RT480
 for Dishwasher hood type (ZANUSSI) D48 - D480
 for Pan washing machine (ZANUSSI) D820 - D840



ELECTROLUX 0E5185

ELECTROLUX 0K7171

3240927 MICRO SWITCH XGG2 88 S21 16A 250V
 lever with roller \varnothing 4.8 mm
 length 25.9 mm - 6.6 mm width



ELECTROLUX

3240410 MICRO SWITCH 16A 250V
 for ANGELO PO OLD OVENS FC-FCV
 for ANGELO PO OVEN FC611G-FC611E-FC1011G-FC1011E
 FC1211G-FC1211E
 for ANGELO PO FRYER 030FE1-030FE1B-70FE
 70FE1-70FE1B-70FES-70FES2-71FE-71FE2-71FE2B-30FES
 30FES2-30FES2B-091FE28
 for IMESA DRYER ES10-ES55-ES75
 for IMESA WASHING MACHINE
 LM30-LM40-LM55-LM70-LM85
 RC30-RC40-RC55-RC70
 for SIRMAN CUTTER C4-C6-C6VV-C9
 for GRANDIMPIANTI DRYER EMS10-EMS15
 for FAGOR CALENDER PE30/140-PE30/160-PE30/200
 for FOINOX OVEN JO0611E-JO0611G-JO1011E-JO1011G
 JO1021E-JO1021G-JO2011E-JO2011G-JO2021E-JO2021G
 for IPSO CALENDER RI1600/30-RI1600/30AV



ELECTROLUX

3240449 BRACKET MICRO F300-45-55-65





ELECTROLUX



Suitable for:

3240203 DOOR MICROSWITCH BUSHING
external \varnothing 10x15 mm



Suitable for:

3240236 LIMIT SWITCH CONTROL



3240234 LIMIT SWITCH PIN



3240233 MICROSWITCH FITTING M16x1.5 mm



3250071 MICROSWITCH SPRING \varnothing 13x25 mm



3240235 RING NUT M16x1.5 mm



3240155 MICROSWITCH FR530A 3A 400V
for COLD ROOMS DOORS
for Dishwasher conveyor type (ZANUSSI) CT140
CT190 - CT192 - CT92
for Dishwasher hood type (MARENO) MLC50 - MLC65



ELECTROLUX 046884

3240601 MICROSWITCH N16 250V
contact capacity 16A 250V
for Dishwasher (ELETTROBAR) R509 - R511 - R651
R704 - R706 - R708 - S641 - S643 - S651 - S653
S654 - S655 - S815 - S830 - S835
for Glasswasher/Cupwasher (BONNET) VR1000R
VR1000RAD - VR1500C - VR1500CAD
for Glasswasher/Cupwasher (ELETTROBAR) R501 - R503
R505 - R507 - S621 - S623 - S624 - S626 - S631
S633 - S634 - S636 - 44F
for Glasswasher/Cupwasher (ZANUSSI) LTB12



3240206 PUSH ROD FOR MICRO



ELECTROLUX



Suitable for:

3240144 MICROWITCH S16 16A 250V
 for Dishwasher (ELFRAMO) D40 - D80
 for Dishwasher (KOMEL) F94 - F98
 for Glasswasher/Cupwasher (ELFRAMO) BD14
 for Glasswasher/Cupwasher (KOMEL) F91



ELECTROLUX 0W2466

Suitable for:

3240406 MICROWITCH 10A 250V



ELECTROLUX 0H6597

3240472 MICROWITCH 16(4)A/250V
 for Dishwasher hood type (ZANUSSI) LS1080



ELECTROLUX 060722

3240123 MICROWITCH 16A 250V



ELECTROLUX 0KI505

3240151 MICROWITCH 16A 250V
 for ZANUSSI TRAINO RT
 for BIANCHI LEVEL TANK
 for Dishwasher (LASA) LS3 - LS30 - LS31 - LS35
 for Dishwasher (MARENO) MLS30 - MLS31 - MLS35
 for Dishwasher (ZANUSSI) CRYSTAL50 - CRYSTAL52
 LS360 - LS4 - LS510 - LS520 - LS521 - LS540
 for Dishwasher conveyor type (ZANUSSI) - Series RT



ELECTROLUX 0E0209

ELECTROLUX 004904

ELECTROLUX 047485

3240152 BUSHING FOR MICROWITCH
 for Dishwasher (ZANUSSI) CRYSTAL50 - CRYSTAL52
 LS360 - LS4 - LS510 - LS520 - LS521



ELECTROLUX 047487

3240473 GASKET FOR BUSHING



ELECTROLUX 047490

3240153 ROD FOR MICROWITCH
 for Dishwasher (ZANUSSI) CRYSTAL50 - CRYSTAL52
 LS360 - LS4 - LS510 - LS520 - LS521



ELECTROLUX 047488

3240154 SPRING FOR MICROWITCH ROD
 for Dishwasher (ZANUSSI) CRYSTAL50 - CRYSTAL52
 LS360 - LS4 - LS510 - LS520 - LS521



ELECTROLUX 047489

Suitable for:

Suitable for:

3240332 MICROSWITCH 16A 250V



ELECTROLUX 0D6615

ELECTROLUX 0KQ309

3240820 MICROSWITCH 16A 250V
for Dishwasher (ZANUSSI) CF314 - LS500 - LS540



ELECTROLUX 0KB678

ELECTROLUX 046286

ELECTROLUX 047485

5035454 MICRO SUPPORT
for WASHING MACHINE LF25



3240401 ACTUATOR FOR MICROSWITCH
for OVEN



ELECTROLUX 054902

3240166 MOUNTING PLATE FOR MICROSWITCH
external dimensions 46x26 mm
for Dishwasher (ZANUSSI) LS365 - LS367 - LS540
LS541



ELECTROLUX 045404

ELECTROLUX 45404

3240156 MICROSWITCH 5A 250V
for Dishwasher conveyor type (ZANUSSI) CT140
CT190 - CT192 - CT92
for Pan washing machine (ZANUSSI) L0250 - L0480



ELECTROLUX 046322

3240178 SPRING FOR LEVER
for Dishwasher conveyor type (ZANUSSI) CT140
CT190 - CT192 - CT90
for Pan washing machine (ZANUSSI) L0250 - L0480



ELECTROLUX 075633

3240177 LEVER FOR MICROSWITCH
for Dishwasher conveyor type (ZANUSSI) CT140
CT190 - CT192 - CT90
for Pan washing machine (ZANUSSI) L0250 - L0480



ELECTROLUX 075626



Suitable for:

ELECTROLUX



Suitable for:

3240884 RECTANGULAR MAGNET 63x19x7 mm
 for Dishwasher (KRUPPS) KORAL500 - KORAL600
 KORAL800
 for Glasswasher/Cupwasher (KRUPPS) KORAL205
 KORAL206 - KORAL207 - KORAL208 - KORAL209
 KORAL210



ELECTROLUX 0L2534

Motors

3240501 AXIAL VENTILATOR SUNON 120x120x38 mm
 ball bearings
 22W 230V 50/60Hz 2850 Rpm
 DP200A 2123XBT.GN



ELECTROLUX 0C1478
 ELECTROLUX 0E2261
 ELECTROLUX 058855

ELECTROLUX 0C4106
 ELECTROLUX 002656

ELECTROLUX 0C4423
 ELECTROLUX 002690

3340102 GERMOTOR DP71 4-6 0.27/0.16Kw
 380/420V 50/60Hz
 for Dishwasher conveyor type (ZANUSSI) RT190
 RT270 - RT3400 - RT4800 - WT100 - WT150 - Z340
 Z480



ELECTROLUX 0E5352


3340103 MOTOR AM90L BAG 1.7HP 230/400V
 shaft \varnothing 24x50 mm - feather 8x40 mm
 for Dishwasher conveyor type (ZANUSSI) WTM140ERA



ELECTROLUX 0E5616

ELECTROLUX 0E5798

3240014 MOTOR F.604130 130W



ELECTROLUX 057437

3340104 MOTOR FAN S2E200-CE31-10
 58W 230V 50/60Hz 2750 rpm
 for Dishwasher conveyor type (ZANUSSI) D530ESD
 D580ESD - D680EDS - FT36 - FT50 - FT72 - LN34
 LN46 - LN72 - RT100 - RT140 - RT142 - RT1800
 RT190 - RT2500 - RT270 - RT3400 - RT4800
 WT100 - WT150 - WT190 - WT200 - WT270 - WT730
 WT760 - WT790 - WT95



ELECTROLUX 0K7494

3340109 MOTOR K21R 71K4 0.4HP 230/400V
 shaft \varnothing 14x30 mm - feather 5x15 mm
 for Dishwasher conveyor type (ZANUSSI)



ELECTROLUX 0K8531



Suitable for:

Suitable for:

3340108 MOTOR LAFERT AM717 AA4 0.25/0.29Kw
220-240V/380-415V 50/60Hz
shaft \varnothing 14x30 mm - feather 5x20 mm
for Dishwasher conveyor type (ZANUSSI)



ELECTROLUX 0E5800

Outlet siphons

3395026 PIPE SIPHON \varnothing 1"1/2



ELECTROLUX 069404

Pegs

3389005 CONVEYOR FINGER
for Dishwasher conveyor type (ZANUSSI) - Series FT
Series WT



ELECTROLUX 0K8238


3389011 CONVEYOR FINGER
for Dishwasher conveyor type (ZANUSSI) RT100
RT140 - RT190 - RT270



ELECTROLUX 0E5007

ELECTROLUX 0K8166

3389010 CONVEYOR FINGER 71 mm
for corner conveyor
for Dishwasher conveyor type (ZANUSSI) - Series RT



ELECTROLUX 0E2896

ELECTROLUX 0K8637

ELECTROLUX 046842

3389012 CONVEYOR FINGER FASTENING SCREW
 \varnothing 6 mm
for Dishwasher conveyor type (ZANUSSI) - Series RT



ELECTROLUX 0K8636

ELECTROLUX 046843

3389016 PIN GUIDE
for Dishwasher conveyor type (ZANUSSI) - Series RT



ELECTROLUX 0E5006



Suitable for:

ELECTROLUX



Suitable for:

Pre-rinse units

3359028 BLUE SPRAY HEAD NEW TYPE \varnothing 1/2" M



ELECTROLUX 069973

3359209 SINGLE-HOLE MIXER
with pre-wash set
mixer with basin connections
with non-return valves
connection \varnothing 3/4" M



ELECTROLUX 069570

ELECTROLUX 069968

ELECTROLUX 855315

3359364 HOSE \varnothing 1/2" F x 1/2" M 1200 mm



3359360 MIXER SPRAY HEAD \varnothing 1/2" M



ELECTROLUX 0L0640

ELECTROLUX 0S1075

ELECTROLUX 069569

3359029 SPRAY HEAD \varnothing 1/2" M



ELECTROLUX 069973

3359290 BLUE TAP KNOB



3359236 HOSE \varnothing 1/2" FF 1200 mm
stainless steel 18/10 double braid
with transparent PVC coating
swivel nickel-plated brass coupling \varnothing 1/2" F



ELECTROLUX 0L0644

ELECTROLUX 0S1094

ELECTROLUX 069568

3359237 SHOWER SPRING



ELECTROLUX 0S1086

ELECTROLUX 069975

1186316 EPDM FLAT GASKET \varnothing 15x4x4 mm 60 SH





Suitable for:

Suitable for:

3359347 STAINLESS STEEL HOSE \varnothing 1/2" FF 100 cm

stainless steel 18/10 double braid
nickel plated brass coupling \varnothing 1/2"F



ELECTROLUX 0D2999

3359271 TWO-HOLE SINGLE LEVER MIXER

with pre-wash unit
with upstand single-lever mixer
connections \varnothing 3/4"MM
distance between mounting holes 155 mm
spout 280 mm



ELECTROLUX 0S1461

ELECTROLUX 069966

ELECTROLUX 850011

3359236 HOSE \varnothing 1/2" FF 1200 mm

stainless steel 18/10 double braid
with transparent PVC coating
swivel nickel-plated brass coupling \varnothing 1/2"F



ELECTROLUX 0L0644

ELECTROLUX 0S1094

3359360 MIXER SPRAY HEAD \varnothing 1/2" M



ELECTROLUX 0L0640

ELECTROLUX 0S1075

3359269 SPOUT 250 mm




ELECTROLUX 0S1404

ELECTROLUX 069962

3359364 HOSE \varnothing 1/2" Fx1/2" M 1200 mm



3359298 MIXER CARTRIDGE (SMALL TYPE)



ELECTROLUX 0S1340

ELECTROLUX 069958

3359237 SHOWER SPRING



ELECTROLUX 0S1086

ELECTROLUX 069975



Suitable for:

ELECTROLUX



3359455 TWO-HOLE SINGLE LEVER MIXER
 with pre-wash unit
 with upstanding single lever mixer
 connections \varnothing 3/4"MM
 spout 250 mm
 flow rate 22L/min by 4 bar
 distance between holes 155 mm
 mounting hole \varnothing 27/28 mm



ELECTROLUX 0S0105

3359409 BLUE LEVER FOR MIXER
 length 345 mm
 fitting 7x8 mm



3359915 HANDLE 1/4 TURN FOR SWITCH



3359461 MIXER CARTRIDGE



ELECTROLUX 0S0346

3359496 SHOWER UNIT FIXING BRACKET
 \varnothing internal 20 mm



3359408 BLACK LEVER FOR MIXER
 length 310 mm
 connection 7x8 mm



ELECTROLUX 0S0343

3359119 CONTROL SCREW 1/4 TURN
 for cold water



3359465 HOSE \varnothing 1/2" FF 1100 mm



3359237 SHOWER SPRING



ELECTROLUX 0S1086

ELECTROLUX 069975

3359823 SPOUT 250 mm



ELECTROLUX 0S0344



Suitable for:

3359463 SPRAY HEAD \varnothing 1/2" M



3359426 STAINLESS STEEL HOSE \varnothing 1/2" FF 110 cm
for showers STAR
stainless steel 18/10 double braid
coated with transparent PVC
nickel-plated brass coupling \varnothing 1/2" F



ELECTROLUX



Suitable for:

3359460 SPRAY HEAD LUXI \varnothing 1/2" M WHITE




3359198 STEEL HOSE \varnothing 1/2" FF 106cm
for shower units with hose spout



ELECTROLUX 0KC217

ELECTROLUX 0L0641

3359605 WHITE SHOWER HEAD NEW \varnothing 1/2" F



ELECTROLUX 003167

3359606 WHITE SPRAY CUP WITH FILTER



ELECTROLUX 003164


Pressure switches

3320003 "Y" CONNECTOR
for fitting with two pressure switches



ELECTROLUX 069195

3320206 PRESSURE SWITCH SET 60-20/110-85
for LS5DI-LS521-LS521D-LD521F



ELECTROLUX 048752

3320025 PRESSURE SWITCH 105/60 mm 250V 16A
1 level
max operating temperature 85°C
for LS720-LS860-LS1020



ELECTROLUX 046601

3320093 PRESSURE SWITCH 110/55 mm 1 LEVEL
16(4)A/250V
for LB1-LB2



ELECTROLUX 049058



Suitable for:

ELECTROLUX



3320150 **PRESSURE SWITCH 110/80 60/20 mm**
for LS32-LS33



ELECTROLUX 0L0508

ELECTROLUX 049361

Suitable for:

3320060 **PRESSURE SWITCH 110/80-60/20 mm 250V 16A**
2 levels
max operating temperature 85°C
for DISHWASHERS



ELECTROLUX 048826

3320016 **PRESSURE SWITCH 130/240 mm 250V 16A**
1 level
max operating temperature 85°C
for LS10-LS12



ELECTROLUX 048267

3320026 **PRESSURE SWITCH 160/80 mm 250V 16A**
1 level
max operating temperature 85°C
for LS75-LS95-CT92



ELECTROLUX 046653

3320094 **PRESSURE SWITCH 165/135-110/55 mm**
16(4)A/250V
for LB1/WSWP-LB1/TOP-LB2/WP-LB2/TOP



ELECTROLUX 049081

3320043 **PRESSURE SWITCH 180/310 mm**
1 level
16(4)A 250V
for LO250E-LO480E



ELECTROLUX 075660

3320241 **PRESSURE SWITCH 2 LEVELS**
for DISHWASHER LS10/DP-LS12/DP




ELECTROLUX 049142

3320092 **PRESSURE SWITCH 250/130 mm**
16(4) 250V
for LS10-LS12-WT60-PW1 (new versions)



ELECTROLUX 049620

3320095 **PRESSURE SWITCH 40/15-55/35 mm**
16(4)A/250V
for CONVEYOR DISHWASHER series TR



ELECTROLUX 0E0014

ELECTROLUX 0E2501

ELECTROLUX 0E3731

ELECTROLUX 0K8562

3320029 **PRESSURE SWITCH 40/20 mm 250V 16A**
1 level
max operating temperature 85°C
for DISHWASHER



ELECTROLUX 070324



ELECTROLUX



Suitable for:

3320091 PRESSURE SWITCH 46/26 mm 1 LEVEL
16(4)A/250V
for BD11-13-22/B15/D30-40-80F



ELECTROLUX 046503

Suitable for:

3320022 PRESSURE SWITCH 50/10 mm 250V 16A
1 - level
max operating temperature 85°C
for DISHWASHER



ELECTROLUX 046444

3320019 PRESSURE SWITCH 55/35 mm 250V 16A
1 level
max operating temperature 85°C
for LTB11-LTB12-LTB22



ELECTROLUX 069434

3320023 PRESSURE SWITCH 60/20 mm 250V 16A
1 - level
max operating temperature 85°C
for LS4-LS8-LS32-LS36-LS45-LS54-LS360
LS365-LS500-LS510-LS520-LS540-CRYSTAL51-CRYSTAL52
for Dishwasher hood type (ELFRAMO) C66



ELECTROLUX 046352
ELECTROLUX 049485

ELECTROLUX 048723
ELECTROLUX 065545

ELECTROLUX 049305

3320242 PRESSURE SWITCH 60/20-110 15A 250V
for WASHER-EXTRACTOR LVA70-LVA100
for DISHWASHER EUC1-EUC3-NUC1-NUC3-EUCAI



ELECTROLUX 049881

3320240 PRESSURE SWITCH 60/35



ELECTROLUX 0KZ786

Probes

3397110 BOILER TEMPERATURE PROBE
bulb \varnothing 6x50 mm
for LS5-LS6



ELECTROLUX 049884

ELECTROLUX 149884

3444215 GLAND FOR THERMOSTAT 12x1
for Dishwasher (ZANUSSI) LS50 - LS500 - LS52
LS540 - LS7
for Dishwasher conveyor type (ZANUSSI) CT92
for Dishwasher hood type (ZANUSSI) LS1080 - LS720
LS8 - LS860



ELECTROLUX 067899



Suitable for:

3243139 O-RING 02025 EPDM

for Dishwasher (BONNET) INO3F
for Dishwasher (ZANUSSI) LS32 - LS360 - LS365
LS500 - LS540 - LS7
for Dishwasher conveyor type (ZANUSSI) CT92
for Dishwasher hood type (ZANUSSI) LS1080 - LS720
LS8 - LS860



ELECTROLUX 067898

ELECTROLUX 086109

ELECTROLUX



Suitable for:

Pumps

3122262 DRAIN ELECTRO-PUMP 30W 230V 50Hz

inlet external \varnothing 30 mm - outlet external \varnothing 35 mm
for Dishwasher (ZANUSSI) LS5 - LS63 - LS64



ELECTROLUX 0L0692

ELECTROLUX 048844

3122412 PUMP HOUSING

inlet external \varnothing 30 mm - outlet external \varnothing 35 mm



3122260 DRAIN ELECTRO-PUMP 90W 240V 50Hz

inlet external \varnothing 25 mm - outlet external \varnothing 23 mm
for Dishwasher (ZANUSSI) CRYSTAL51 - CRYSTAL52
CRYSTAL54 - LS36 - LS510 - LS520



ELECTROLUX 046647

ELECTROLUX 047562

3122015 ELECTR.PUMP AP 05803SX 0.75HP 230V 50Hz

inlet external \varnothing 45 mm - outlet external \varnothing 40 mm
motor revolutions 2850 - flowrate 270 L/min
0.75Hp 230V 4A - capacitor 16 μ f
for old model SOLE
for Dishwasher (ZANUSSI) LS360



ELECTROLUX 046370

3122524 GASKET FOR PUMP HOUSING



ELECTROLUX 048630

ELECTROLUX 048984



Suitable for:

3122530 LOWER IMPELLER ø 102 mm



ELECTROLUX 048982

ELECTROLUX 049451

3122569 PUMP HOUSING
inlet external ø 45 mm
outlet external ø 42 mm



ELECTROLUX 048981

3122695 ELECTR.PUMP AP 42133DX 0.15HP 230V 50Hz
inlet external ø 28 mm - outlet external ø 28 mm
for Dishwasher (ZANUSSI) LS6
for Dishwasher hood type (ZANUSSI) LS9



ELECTROLUX

3122058 MECHANICAL SEAL ø 11mm INNER SURFACE 8mm



3122506 PUMP HOUSING
inlet external ø 28 mm
outlet external ø 28 mm



ELECTROLUX



Suitable for:

3122058 MECHANICAL SEAL ø 11mm INNER SURFACE 8mm



3122503 IMPELLER ø 72 mm



1186237 O-RING 03300 EPDM
for Glasswasher/Cupwasher (ELFRAMO) BD14 - B14
B15





Suitable for:

ELECTROLUX



Suitable for:

3122854 ELECTR.PUMP LGB ZFCI121DX 0.47HP
 inlet \varnothing 28 mm - outlet \varnothing 26 mm
 0.47HP 220/240V 50Hz
 for Glasswasher/Cupwasher (ZANUSSI) GW1 - GW2
 LB1 - LB2 - WT1 - WT2 - Z1 - Z2



ELECTROLUX 0L0571

3122853 ELECTR.PUMP LGB ZF523VSX 1.34HP
 inlet \varnothing 63 mm - outlet \varnothing 48 mm
 1.34HP 230/400V 50Hz
 for Dishwasher hood type (ZANUSSI) HT1000 - HT1200
 HT900 - LS10EA - LS14EA - LS9P - WT55 - WT60



ELECTROLUX 0L0060

ELECTROLUX 0L0564

3122855 IMPELLER \varnothing 110 mm



ELECTROLUX 0L0819

ELECTROLUX 0L1978

ELECTROLUX 0L1987

3122856 ELECTR.PUMP ZF340SX 0.94HP 230V 50Hz
 inlet \varnothing 45 mm - outlet \varnothing 38 mm
 0.94HP 230V 50Hz
 complete with bracket
 for Dishwasher (ZANUSSI) LS3 - LS6 - LS61 - LS62
 LS63 - LS64 - LS7
 for Dishwasher hood type (ZANUSSI) LS8



ELECTROLUX 0L0126

3122362 ELECTR/PUMP FIR B257SX 1HP 220/240V
 inlet external \varnothing 45 mm - outlet external \varnothing 42 mm
 motor revolutions 2800
 1HP 220/240V 3.5A - capacitor 16 μ F
 for Dishwasher (ZANUSSI) LS5 - LS6



ELECTROLUX 049876

3122297 GASKET 4247





ELECTROLUX



Suitable for:

3122024 MECHANICAL SEAL \varnothing 12mm INNER SURFACE 8mm
for Dishwasher (ELFRAMO)



ELECTROLUX 048983

ELECTROLUX 049171

Suitable for:

3122315 PUMP HOUSING
inlet external \varnothing 45 mm
outlet external \varnothing 40 mm



3122761 ELECTRIC PUMP FIR 1246 HP 0.1 230V 50HZ
inlet and outlet external \varnothing 28 mm
for Dishwasher conveyor type (WHIRLPOOL)
for Dishwasher conveyor type (ZANUSSI) D530ESD
D580ESD - D680ESD - RT100 - RT140 - RT190
RT270



ELECTROLUX 0K7482

3122007 ELECTRIC PUMP GRE 604215
WITH TEFLON ROTATING MECHANICAL SEAL WITH BASIS
OF ALUMINUM
100W 230V 50Hz
connections \varnothing 24 mm
for old models
for Dishwasher (ADLER) CF50DP
for Dishwasher (WHIRLPOOL) F360DP



ELECTROLUX 0KM595

ELECTROLUX 0U1035

3122002 ELECTROPUMP ROTATING SEAL
outlet \varnothing 24 mm
ceramic part internal \varnothing 10 mm
part with spring internal \varnothing 6 mm



3122841 ELECTRIC PUMP LGB ZF522V SX 0.94HP
inlet external \varnothing 62 mm - outlet external \varnothing 50 mm
motor revolutions 2800
0.94HP 230V 50Hz - capacitor 16 μ f
for Dishwasher (TEIKOS) TS983SP
for Dishwasher hood type (TEIKOS) TS103



ELECTROLUX 0L0092

6926275 IMPELLER FOR PUMP ZF522 \varnothing 110 mm





Suitable for:

3122024 MECHANICAL SEAL \varnothing 12mm INNER SURFACE 8mm
for Dishwasher (ELFRAMO)



ELECTROLUX 048983

ELECTROLUX 049171

ELECTROLUX



Suitable for:

3122679 ELECTRO-PUMP AP C58711SX 1.5HP 220/380V
inlet external \varnothing 70 mm - outlet external \varnothing 62 mm
1.5HP 220/380V 50Hz
for Dishwasher hood type (ZANUSSI) LS1080 - LS860



ELECTROLUX

3122565 IMPELLER \varnothing 110 mm



3122518 GASKET



3122024 MECHANICAL SEAL \varnothing 12mm INNER SURFACE 8mm
for Dishwasher (ELFRAMO)



ELECTROLUX 048983

ELECTROLUX 049171

3122532 ELECTRO-PUMP AP 1021SX 0.75HP 230V 50Hz
inlet external \varnothing 45 mm - outlet external \varnothing 40 mm
motor revolutions 2850 - flowrate 320 L/min
0.75Hp 230V 4A - capacitor 16 μ f
for Pan washing machine (MACH) MLP60 - MLP60E



ELECTROLUX

3122024 MECHANICAL SEAL \varnothing 12mm INNER SURFACE 8mm
for Dishwasher (ELFRAMO)



ELECTROLUX 048983

ELECTROLUX 049171

3122524 GASKET FOR PUMP HOUSING



ELECTROLUX 048630

ELECTROLUX 048984

3122538 PUMP HOUSING
inlet external \varnothing 45 mm
outlet external \varnothing 40 mm



ELECTROLUX 049526



ELECTROLUX



Suitable for:

3122554 TOP IMPELLER ø 102 mm



Suitable for:

3122537 ELECTRO-PUMP AP 1022SX 1.2HP 230V 50Hz
inlet external ø 45 mm - outlet external ø 40 mm
motor revolutions 2850 - flowrate 400 L/min
1.2Hp 230V 6A - capacitor 16 µf



ELECTROLUX

3122024 MECHANICAL SEAL ø 12mm INNER SURFACE 8mm
for Dishwasher (ELFRAMO)



ELECTROLUX 048983

ELECTROLUX 049171

3122554 TOP IMPELLER ø 102 mm



3122524 GASKET FOR PUMP HOUSING



ELECTROLUX 048630

ELECTROLUX 048984

3122538 PUMP HOUSING
inlet external ø 45 mm
outlet external ø 40 mm



ELECTROLUX 049526

3122558 ELECTRO-PUMP AP 2701SX 2HP 230/400V 50Hz
inlet external ø 72 mm - outlet external ø 61 mm
motor revolutions 2800 - flowrate 500 L/min
2HP 230/400V 50Hz 5.8/3.4A
for Dishwasher hood type (ZANUSSI) HT1000 - HT1200
HYDRA1000 - HYDRA1200 - LS10 - LS12



ELECTROLUX

3122518 GASKET





Suitable for:

3122565 IMPELLER ø 110 mm



ELECTROLUX



Suitable for:

3122024 MECHANICAL SEAL ø 12mm INNER SURFACE 8mm
for Dishwasher (ELFRAMO)



ELECTROLUX 048983

ELECTROLUX 049171

3122311 ELECTRO-PUMP AP 3100SX 1HP 220/380V 50Hz
inlet external ø 45 mm - outlet external ø 40 mm
motor revolutions 2830
1HP 220/380V 50Hz 2.8/1.6A
for Dishwasher (ZANUSSI) HYDRA700 - LS3 - LS6
LS7 - WT30 - WT40
for Dishwasher hood type (ZANUSSI) HYDRA800 - LS8



ELECTROLUX 048304

3122524 GASKET FOR PUMP HOUSING



ELECTROLUX 048630

ELECTROLUX 048984

3122024 MECHANICAL SEAL ø 12mm INNER SURFACE 8mm
for Dishwasher (ELFRAMO)



ELECTROLUX 048983

ELECTROLUX 049171

3122538 PUMP HOUSING
inlet external ø 45 mm
outlet external ø 40 mm



ELECTROLUX 049526

3122554 TOP IMPELLER ø 102 mm



3122310 ELECTRO-PUMP AP 5800SX 1HP 220/240V 50Hz
inlet external ø 45 mm - outlet external ø 40 mm
motor revolutions 2850 - flowrate 340 L/min
1HP 220/240V 50Hz 4.5A - capacitor 16 µf
for Dishwasher (ZANUSSI) LS3 - LS6 - LS61 - LS62
LS63 - LS64 - LS7 - WT30 - WT40 - WT50
for Dishwasher hood type (ZANUSSI) LS8



ELECTROLUX 048885

3122524 GASKET FOR PUMP HOUSING



ELECTROLUX 048630

ELECTROLUX 048984



ELECTROLUX



Suitable for:

3122024 MECHANICAL SEAL \varnothing 12mm INNER SURFACE 8mm
for Dishwasher (ELFRAMO)



ELECTROLUX 048983

ELECTROLUX 049171

3122554 TOP IMPELLER \varnothing 102 mm



Suitable for:

3122538 PUMP HOUSING
inlet external \varnothing 45 mm
outlet external \varnothing 40 mm



ELECTROLUX 049526

3122678 ELECTRO-PUMP AP 59632SX 0.75HP 220/380V
inlet external \varnothing 63 mm - outlet external \varnothing 48 mm
motor revolutions 2800
0.75HP 220/380V 50Hz 2.5/1.45A
for Dishwasher (ZANUSSI) LS540
for Dishwasher hood type (THIRODE) VSL900
VSL900P
for Dishwasher hood type (ZANUSSI) LS720



ELECTROLUX

3122565 IMPELLER \varnothing 110 mm



3122518 GASKET



3122024 MECHANICAL SEAL \varnothing 12mm INNER SURFACE 8mm
for Dishwasher (ELFRAMO)



ELECTROLUX 048983

ELECTROLUX 049171

3122517 PUMP HOUSING
inlet external \varnothing 63 mm
outlet external \varnothing 50 mm





Suitable for:

Suitable for:

3122391 ELECTRO-PUMP AP 6300DX 0.37HP 220/240V
 inlet external \varnothing 32 mm - outlet external \varnothing 32 mm
 motor revolutions 2850
 0.37HP 220/240V 50Hz - capacitor 6.3 μ f
 for Glasswasher/Cupwasher (ZANUSSI) GW1 - GW2
 LB1 - LB2 - WT1 - WT2 - Z1 - Z2

3122286 IMPELLER \varnothing 78 mm



ELECTROLUX 0L0406

ELECTROLUX 049057

ELECTROLUX 049187

3122058 MECHANICAL SEAL \varnothing 11mm INNER SURFACE 8mm

3122287 O-RING FOR PUMP HOUSING \varnothing 81x2 mm



ELECTROLUX 049188

3122288 PUMP HOUSING
 inlet and outlet \varnothing 32 mm



ELECTROLUX 049186

3122185 ELECTRO-PUMP FIR 1204DX 2HP 240/415V
 inlet external \varnothing 63 mm - outlet external \varnothing 54 mm
 motor revolutions 2800 - flowrate 500 L/min
 2Hp 240/415V 50Hz 5.9/3.4A
 for Dishwasher (BONNET) INO20
 for Dishwasher conveyor type (COMENDA) - Series AC
 Series ACS
 for Dishwasher hood type (COMENDA) C140 - C33
 C34
 for Dishwasher hood type (DIHR) GASTRO1200 - G12S
 for Dishwasher hood type (SILANOS) 1300
 for Pan washing machine (COMENDA) GE100 - GE115
 GE60 - GE65

3122247 IMPELLER \varnothing 116 mm



ELECTROLUX 0K7245

ELECTROLUX 0K7250



ELECTROLUX



Suitable for:

3122024 MECHANICAL SEAL \varnothing 12mm INNER SURFACE 8mm
for Dishwasher (ELFRAMO)



ELECTROLUX 048983

ELECTROLUX 049171

3122026 PUMP HOUSING SEAL



Suitable for:

3122047 PUMP HOUSING
inlet external \varnothing 63 mm
outlet external \varnothing 54 mm



3122028 ELECTRO-PUMP FIR 1211SX 0.75HP 220/415V
inlet external \varnothing 63 mm - outlet external \varnothing 48 mm
motor revolutions 2800 - flowrate 360 L/min
0.75HP 220/415V 50Hz 2.1/1.2A
for Dishwasher (ZANUSSI) LS540
for Dishwasher hood type (THIRODE) VSL900
VSL900P
for Dishwasher hood type (ZANUSSI) LS720



ELECTROLUX 046346

ELECTROLUX 047195

ELECTROLUX 068710

3122025 IMPELLER \varnothing 103 mm



ELECTROLUX 048464

ELECTROLUX 049174

ELECTROLUX 069170

3122024 MECHANICAL SEAL \varnothing 12mm INNER SURFACE 8mm
for Dishwasher (ELFRAMO)



ELECTROLUX 048983

ELECTROLUX 049171

3122026 PUMP HOUSING SEAL



3122027 PUMP HOUSING
inlet external \varnothing 63 mm
outlet external \varnothing 48 mm



ELECTROLUX 0L0305



Suitable for:

Suitable for:

3122023 ELECTRO-PUMP FIR 1214SX 0.75HP 230/415V
 inlet external \varnothing 63 mm - outlet external \varnothing 48 mm
 motor revolutions 2800 - flowrate 360 L/min
 0.75HP 230/415V 50Hz 2.1/1.2A
 for Dishwasher (ZANUSSI) LS540
 for Dishwasher hood type (ZANUSSI) LS720



ELECTROLUX 046574

3122025 IMPELLER \varnothing 103 mm



ELECTROLUX 048464

ELECTROLUX 049174

ELECTROLUX 069170

3122024 MECHANICAL SEAL \varnothing 12mm INNER SURFACE 8mm
 for Dishwasher (ELFRAMO)



ELECTROLUX 048983

ELECTROLUX 049171

3122027 PUMP HOUSING
 inlet external \varnothing 63 mm
 outlet external \varnothing 48 mm



ELECTROLUX 0L0305

3122026 PUMP HOUSING SEAL



3122765 ELECTRO-PUMP FIR 1293SX 0.75HP 230V 50Hz
 inlet external \varnothing 63 mm outlet external \varnothing 48 mm
 for Dishwasher conveyor type (ZANUSSI) RT190
 RT270



ELECTROLUX 0L0581

3122312 ELECTRO-PUMP FIR 2254/SSX 2HP 230/400V
 inlet external \varnothing 69 mm - outlet external \varnothing 61 mm
 motor revolutions 2800 - flowrate 500 L/min
 2HP 230/400V 50Hz 5.9/3.4A
 for Dishwasher hood type (ZANUSSI) HT1000 - HT1200
 HYDRA1000 - HYDRA1200 - LS10 - LS12



ELECTROLUX 048216

3315040 HOSE-END FITTING FOR ELECTRO-PUMP



ELECTROLUX 049561



Suitable for:

3122035 IMPELLER ø 111 mm
altezza 35 mm



ELECTROLUX



Suitable for:

3122024 MECHANICAL SEAL ø 12mm INNER SURFACE 8mm
for Dishwasher (ELFRAMO)



ELECTROLUX 048983

ELECTROLUX 049171

3122314 PUMP HOUSING
inlet external ø 70 mm
outlet external ø 61 mm



3122026 PUMP HOUSING SEAL



ELECTROLUX 0L0496

3122022 ELECTRO-PUMP FIR 2254SX 1.5HP 220/380V
inlet external ø 70 mm - outlet external ø 61 mm
motor revolutions 2800 - flowrate 550 L/min
1.5HP 220/380V 50Hz 4.8/2.8A
for Dishwasher hood type (ZANUSSI) LS1080 - LS860



3122313 IMPELLER ø 100 mm



ELECTROLUX 047708

ELECTROLUX 048624

3122024 MECHANICAL SEAL ø 12mm INNER SURFACE 8mm
for Dishwasher (ELFRAMO)



3122314 PUMP HOUSING
inlet external ø 70 mm
outlet external ø 61 mm



ELECTROLUX 048983

ELECTROLUX 049171

ELECTROLUX 0L0496

3122026 PUMP HOUSING SEAL





Suitable for:

ELECTROLUX



3122719 ELECTRO-PUMP FIR 2275SX 3.6HP 220/380V
inlet external \varnothing 63 mm - outlet external \varnothing 63 mm
motor revolutions 2800
3.6HP 220/380V 50Hz 10/5.8A



ELECTROLUX 049669

3122660 PUMP CASE FIR 2274-2275
inlet - outlet \varnothing 63 mm



Suitable for:

3122174 IMPELLER FOR PUMP FIR 2275 3.7HP \varnothing 135mm



ELECTROLUX 0E1305

3786468 PUMP GASKET FIR 2275 3.6HP



ELECTROLUX 049769

3453026 ROTATING SEAL AND BACKING ELEMENT FIR
for PUMPS 2275 and 2274



3122316 ELECTRO-PUMP FIR 4213DX 0.37HP 220/240V
inlet external \varnothing 28 mm - outlet external \varnothing 28 mm
motor revolutions 2800
0.37HP 220/240V 50Hz 1.5A - capacitor 6.3 μ F
for Dishwasher (ZANUSSI) LS6
for Dishwasher hood type (ZANUSSI) LS9



ELECTROLUX 049310

3122147 PUMP HOUSING
inlet external \varnothing 28 mm
outlet external \varnothing 28 mm



3122764 ELECTRO-PUMP FIR 4290 2HP 230/400 50HZ
inlet and outlet external \varnothing 63 mm
for Dishwasher conveyor type (ZANUSSI) RT100
RT140 - RT142 - RT190 - RT270



ELECTROLUX 0E5365

ELECTROLUX 0L0037

3122762 ELECTRO-PUMP FIR 4290SX 2HP 230/400V
inlet external \varnothing 63 mm - outlet external \varnothing 63 mm
motor revolutions 2800
for Dishwasher conveyor type (ZANUSSI) - Series RT



ELECTROLUX 0L0039

Suitable for:

Suitable for:

3122763 ELECTRO-PUMP FIR 5213DX 220/240V 50Hz
 inlet external \varnothing 30 mm - outlet external \varnothing 28 mm
 motor revolutions 2800
 for Dishwasher conveyor type (ZANUSSI) - Series RT
 Series WT



ELECTROLUX 0E2746

ELECTROLUX 0L0149

3122615 ELECTRO-PUMP OP T.30 0.40HP 220/240V
 inlet external \varnothing 45 mm - outlet external \varnothing 32 mm
 overflow outlet 24 mm
 2700 revolutions - flowrate 160 L/min
 0,40HP 220/240V 50Hz - capacitor 8 μ f
 for Glasswasher/Cupwasher (ELETTRORBAR) S621 - S623
 S624 - S626 - S631 - S633 - S634 - S636



ELECTROLUX 069540

3122024 MECHANICAL SEAL \varnothing 12mm INNER SURFACE 8mm
 for Dishwasher (ELFRAMO)



ELECTROLUX 048983


ELECTROLUX 049171

3122616 IMPELLER \varnothing 90 mm



ELECTROLUX 069545

3122365 O-RING 02475 EPDM
 for Dishwasher (ELFRAMO) D30 - D40 - D80 - ES400
 MRS400 - SQT80 - SQ60 - SQ885
 for Glasswasher/Cupwasher (ELFRAMO) SQ42 - SQ42E
 SQ48 - SQ48E - SQ55



3122153 ELECTRO-PUMP TM61E 0,45HP 220V
 for pressure boost
 inlet \varnothing 1" F - outlet \varnothing 1" F
 motor revolutions 2900 - flow rate 38 l/min
 max pressure 6 ATM max temperature 90°C
 0.45HP 220V 50Hz 2.3A - capacitor 10 μ f
 for Dishwasher (OLIS) OLDS40 - OLDS50 - OLG540
 OLG550 - OLG585
 for Dishwasher hood type (DIHR) G12S
 for Dishwasher hood type (KROMO) K100
 for Dishwasher hood type (OLIS) OLG11S - OLHT11D
 OLHT12



ELECTROLUX 048437

ELECTROLUX 048668

3122158 COMPLETE ROTATING SEAL \varnothing 21x12 mm





Suitable for:

3349039 FITTING \varnothing 1"x 3/4"



ELECTROLUX



Suitable for:

3122396 IMPELLER \varnothing 91 mm



ELECTROLUX 049525

3122805 PRESSURE PUMP PS45DX 230V 50Hz
for Pan washing machine (MACH) MLP50 - MLP60
MLP60E



ELECTROLUX 049229

Rating-plates

3399076 CONTROL PANEL WT30 560 mm
for Dishwasher (ZANUSSI) LS62 - LS63 - LS64 - LS65
WT32 - WT33 - WT34 - WT35



ELECTROLUX 048905

3399077 CONTROL PLATE LS3 IN ABS 560 mm



ELECTROLUX 049313

3399020 CONTROL PLATE 308x158 mm
for Dishwasher hood type (ZANUSSI) LS8



ELECTROLUX 048648

3186468 CONTROL PANEL GASKET



ELECTROLUX 048274

3399005 CONTROL PLATE 435x65 mm
for Glasswasher/Cupwasher (ZANUSSI) LB1 - LB2



ELECTROLUX 049061

3399018 CONTROL PLATE 560x75 mm
for Dishwasher (ZANUSSI) LS6 - LS60 - LS61 - LS62



ELECTROLUX 048827

ELECTROLUX 049128



ELECTROLUX



Suitable for:

3399016 CONTROL PLATE 590x70 mm
for Dishwasher (ZANUSSI) LS7



ELECTROLUX 048339

Suitable for:

3399017 CONTROL PLATE 590x70 mm
for Dishwasher (ZANUSSI) LS520




ELECTROLUX 047545

ELECTROLUX 047561

ELECTROLUX 047633


Relays

3351158 BASE UNDECAL ES11 10A 400V
11 poles



ELECTROLUX 049236

3351037 MINI RELAY 40.52 8A 230V 50/60Hz
2 switching contacts



ELECTROLUX 0E5849

3351020 POWER RELAY REP 200
16A 230V 50Hz
2 contacts NO
for LS-CF




ELECTROLUX

3351003 RELAY A9230AA 230V 16A
contacts 16A
coil 250V
for LS62 - LS63 - LS64




ELECTROLUX 048888

3351601 RELAY B1-3 16A 230V 50/60Hz
3 NO contacts




ELECTROLUX 046380

3351900 RELAY B2-3 250V 16A
tripolar changeover switch



ELECTROLUX 046001

3351005 RELAY 56.34 250V 12A
230V 50/60Hz
tetrapolar change over switch
for LS8 - LS10 - LS12



ELECTROLUX 048611

3351004 RELAY 56.32 12A 230V 50/60Hz
2 switching contacts
for ZANUSSI DISHWASHER LS7-LV70-Z70-LB1-LB2
for LINEA BLANCA DISHWASHER LC80-LC140-LC1000
LC1500-LC1700-LC2000-LC2300-LC2300TR-LC2600-LC2800
LC3800-LC4200
for NUOVA SIMONELLI SUPERAUTOMATIC MASTER



ELECTROLUX 048438



Suitable for:

3351901 RELAY 60.62 10A 230V 50/60Hz
2 switching contacts




ELECTROLUX 0D0013
ELECTROLUX 083215

ELECTROLUX 058857

ELECTROLUX 069882

Suitable for:

3351605 RELAY 60.63 10A 230V 50/60Hz
3 switching contacts
for CIMBALI JUNIOR



ELECTROLUX 056446
ELECTROLUX 085296

ELECTROLUX 056466
ELECTROLUX 086214


ELECTROLUX 056510

3351021 RELAY 62.82 16A 230V 50/60Hz
2 switching contacts



ELECTROLUX 0PE302

3351008 RELAY 62.83 16A 230V 50/60Hz
3 switching contacts
for CIMBALI MAGNUM-SPECIAL-6/S-6/SNEW
for FAEMA MD3000
for SILANOS 030A-N50/90/700-E1000



ELECTROLUX 0A9596
ELECTROLUX 088197

ELECTROLUX 005033

ELECTROLUX 005034

3351602 RELAY 65.31 30A 250V
1 cut-off contact
coil 230V 50/60Hz



ELECTROLUX 085647


3351010 3 CONTACTS 24V RELAY
for series RT



ELECTROLUX 0E5170

Remote control switches

3454068 CONTACTOR BENEDIKT/JAGER K3-10ND10
10A 400V 4Kw
coil 220/240V 50/60Hz
3 normally open contacts
1 normally open auxiliary contact
for Dishwasher (ZANUSSI)



ELECTROLUX 082986

ELECTROLUX 088477

3446510 CONTACTOR BENEDIKT/JAGER K3-14A1024
coil 14A 24V 50/60Hz 5.5Kw
3 normally open contacts
1 normally open auxiliary contact



ELECTROLUX 0E0020

ELECTROLUX 0L0360

ELECTROLUX 046994



ELECTROLUX



Suitable for:

3454001 CONTACTOR K3-10A01 220/240V 25A

3 NO contacts
1 NC contact



ELECTROLUX 0E3757
ELECTROLUX 048825


ELECTROLUX 0L0285

ELECTROLUX 047048

Suitable for:

3446561 CONTACTOR LOVATO BF0910A

9A 400V 4.2Kw
coil 230V 50/60Hz
3 normally open contacts
for Dishwasher (ADLER) DS400 - DS410 - DS600
for Dishwasher (WHIRLPOOL) F650
for Glasswasher/Cupwasher (WHIRLPOOL) F400 - F410



ELECTROLUX 003027

ELECTROLUX 004206

3446552 CONTACTOR LOVATO BG0610A

coil 6A 230V 50/60Hz 2.2Kw
3 normally open contacts
1 normally open auxiliary contact
for Glasswasher/Cupwasher (ADLER) CF40 - COMPACT
for Glasswasher/Cupwasher (WHIRLPOOL) F30 - F41



ELECTROLUX 086215

3446556 CONTACTOR LOVATO BG0910A

coil 9A 230V 50/60Hz 4Kw
3 normally open contacts
1 normally open auxiliary contact
for Dishwasher (MACH) MGL500 - MS350 - MS351
MS400B - MS400T - MS450 - MS451 - MS453
MS500B - MS800
for Dishwasher conveyor type (SILANOS) T1650
T2000
for Dishwasher conveyor type (WHIRLPOOL) AGB676
AGB678 - AGB682
for Dishwasher hood type (MACH) MS1100 - MS1300
MS900
for Dishwasher hood type (SILANOS) E1000 - N1000
for Dishwasher hood type (WHIRLPOOL) AGB664
AGB668 - AGB669 - AGB671



ELECTROLUX 048519

ELECTROLUX 075796

5009239 CONTACTOR SCHNEIDER LC1K0910P7

9A 4Kw coil 220V 50/60Hz
3 normally open contacts
1 normally open auxiliary contact
for Dishwasher (LINEA BLANCA) LC-1500 - LC-1700
LC-2000 - LC-2300 - LC-2300TR - LC-2600
LC-2800
for Glasswasher/Cupwasher (LINEA BLANCA) LC-1000
LC-140 - LC-80



ELECTROLUX 0KQ438



Suitable for:

ELECTROLUX



Suitable for:

Rinse aid containers and accessories

3066001 RINSE AID CONTAINER
for Dishwasher (ZANUSSI) LS3 - LS5DS - LS510
LS520 - LS521 - LS61 - LS62 - LS63 - LS64
LV62 - LV63 - LV64



ELECTROLUX 047549

3066003 CONTAINER FRONT COVER
for Dishwasher (ZANUSSI) LS3 - LS5DS - LS510
LS520 - LS521 - LS61 - LS62 - LS63 - LS64
LV62 - LV63 - LV64



ELECTROLUX 047547

3066002 CONTAINER LID
for Dishwasher (ZANUSSI) LS3 - LS5DS - LS510
LS520 - LS521 - LS61 - LS62 - LS63 - LS64
LV62 - LV63 - LV64



ELECTROLUX 047551

3066006 GASKET FOR TRAY
for Dishwasher (ZANUSSI) LS3 - LS5DS - LS510
LS520 - LS521 - LS61 - LS62 - LS63 - LS64
LV62 - LV63 - LV64



ELECTROLUX 030186

3528040 NUT
for Dishwasher (ZANUSSI) LS3 - LS5DS - LS510
LS520 - LS521 - LS61 - LS62 - LS63 - LS64
LV62 - LV63 - LV64



ELECTROLUX 047550

3066005 RINSE AID INLET TUBE
for Dishwasher (ZANUSSI) LS3 - LS5DS - LS510
LS520 - LS521 - LS61 - LS62 - LS63 - LS64
LV62 - LV63 - LV64



ELECTROLUX 047552

3066004 RINSE AID PIPE
for Dishwasher (ZANUSSI) LS3 - LS5DS - LS510
LS520 - LS521 - LS61 - LS62 - LS63 - LS64
LV62 - LV63 - LV64



ELECTROLUX 047548

3066049 RINSE AID CONTAINER
for Glasswasher/Cupwasher (ZANUSSI) LB1 - LB2



ELECTROLUX 049024

3786684 GASKET Ø 3/4"



ELECTROLUX 049201



Suitable for:

3066050 HOSE END FOR CONTAINER \varnothing 3/8"
for Glasswasher/Cupwasher (ZANUSSI) LB1 - LB2



ELECTROLUX 049026

ELECTROLUX



Suitable for:

3066051 RINSE AID CONTAINER
for Dishwasher (ZANUSSI) LS32 - LS33 - LS5



ELECTROLUX 049975

3066602 RINSE AID CONTAINER ASSEMBLY
FRONT mounting
with various connectors



ELECTROLUX 069647

Rinse aid pumps and accessories

3090300 DETERGENT PERISTALTIC PUMP PG-3
fixed flowrate: 3 L/h
santoprene tube
3W 230V 50Hz
complete with assembly kit



ELECTROLUX 0S0705


ELECTROLUX 049624

3090351 SANTOPRENE DIAPHRAGM-TUBE
with connections



ELECTROLUX 049419

3090154 FOOT FILTER WITH 4 m PVC PIPE



ELECTROLUX 049359

3090203 GREY HOSE 2660 mm
external \varnothing 6 mm - internal \varnothing 4 mm



ELECTROLUX 0L1163



Suitable for:

Suitable for:

3090022 HYDRAULIC RINSE AID INJECTOR MODEL 1000
 for rinse aid
 delivery connector for boiler, olive connection,
 pipe \varnothing 4x6 mm
 stainless steel ball
 stainless steel spring for diaphragm, wire \varnothing 1 mm
 silicon valve
 silicon diaphragm
 pump connection fitting, olive connection,
 pipe \varnothing 6x8 mm
 inlet fitting with connection
 for flexible pipe \varnothing 4x6 mm
 for Dishwasher (WHIRLPOOL) F650
 for Glasswasher/Cupwasher (WHIRLPOOL) D110 - D111
 D210 - D211 - D310 - D311 - F300 - F312 - F35
 F40 - F400 - F41 - F410

3090055 DIAPHRAGM MOD. DA 1011



ELECTROLUX

ELECTROLUX

3090221 SILICONE VALVE F/DISPENSER MOD.1000



3090025 HYDRAULIC RINSE AID INJECTOR MODEL 1000
 for rinse aid
 delivery connector for boiler, olive connection,
 pipe \varnothing 4x6 mm
 teflon ball
 stainless steel spring for diaphragm, wire \varnothing 1 mm
 silicon valve
 silicon diaphragm
 pump connection fitting, olive connection,
 pipe \varnothing 6x8 mm
 inlet fitting with connection
 for flexible pipe \varnothing 4x6 mm

3090055 DIAPHRAGM MOD. DA 1011



ELECTROLUX 0HA055

ELECTROLUX

3090221 SILICONE VALVE F/DISPENSER MOD.1000





Suitable for:

Suitable for:

3090016 HYDRAULIC RINSE AID INJECTOR MODEL 3000

for rinse aid
with inspectionable filter
for Dishwasher (ADLER) DS400 - DS410 - DS600
for Dishwasher (WHIRLPOOL) F650
for Glasswasher/Cupwasher (ADLER) CF35 - CF40
DSF101 - DSF103 - DS101 - DS103 - DS201
DS203
for Glasswasher/Cupwasher (NOSEM) NA400
for Glasswasher/Cupwasher (WHIRLPOOL) D110 - D111
D210 - D211 - D310 - D311 - F300 - F312 - F35
F40 - F400 - F41 - F410



ELECTROLUX 0HA056

3090017 INLET FILTER MODEL 3000



3090018 T-FITTING BLACK



3090356 NON-RETURN VALVE AISI 316 STAINL.STEEL

stainless steel aisi 316
for rinse aid injection 1/8" G.M.
(FPM valve)



ELECTROLUX 049358

3090056 DIAPHRAGM MOD. DA 3010



3090003 INLET VALVE FOR RINSE AID INJECTOR

for Dishwasher (BONNET) IN08
for Dishwasher (COMENDA) F20 - F45
for Dishwasher (JEMI) GS-8/2 - GS-8/2D - GS-9/2
GS-9/2D
for Dishwasher hood type (JEMI) GS-100 - GS-83
for Glasswasher/Cupwasher (BONNET) IN07F - VR1000R
for Glasswasher/Cupwasher (COMENDA) B11T
for Glasswasher/Cupwasher (ELETTROBAR) S621 - S636





ELECTROLUX



Suitable for:

3090029 PERISTALTIC DETERGENT PUMP G200 230V50Hz
 detergent flow rate 0.777 gr per second
 max flow rate 2 l/hour (equivalent to 2000 cm3)
 for DISHWASHER (500 DISHES PER HOUR)



ELECTROLUX 0U1032

3090033 FOOT VALVE WITH NON RETURN
 with filter and STAINLESS steel ring



Suitable for:

3090032 ELBOW FOR TANK INLET
 complete
 for Dishwasher (ELFRAMO) D30 - D40 - D80
 for Dishwasher hood type (ELFRAMO) C44 - C66
 for Dishwasher hood type (KOMEL) K8044 - K8066
 for Glasswasher/Cupwasher (ELFRAMO) BD14 - B11
 B14 - B15
 for Pan washing machine (ELFRAMO) LP60 - LP70



3090017 INLET FILTER MODEL 3000



3090018 T-FITTING BLACK



3090057 THERMOPLASTIC PIPE 5x8 mm 55SH
 replacement for pumps G200-G250-G252-G40-D25-G8
 G82-G15-G40-G40D-G50D-G600
 complete with connectors new version



3090301 PERISTALTIC DETERGENT PUMP PG-0.4
 fixed flow rate: 0.4 l per h
 pressure: 3 bar
 sekob Brill pipe
 230V 50Hz
 complete with mounting kit



3090350 SEKOBRILL PIPE



ELECTROLUX 0L0697
ELECTROLUX 049625

ELECTROLUX 0S0704

ELECTROLUX 049311

ELECTROLUX 049418



Suitable for:

3090303 PERISTALTIC DETERGENT PUMP PR-4

fixed flow rate: 0.6÷4 l per h
pressure: 0.1 bar
santoprene pipe
230V 50Hz
complete with mounting kit



ELECTROLUX 050669

Suitable for:

3090351 SANTOPRENE DIAPHRAGM-TUBE

with connections



ELECTROLUX 049419

3090019 RINSE AID DISPENSER N6 E 05 G4G4

with EPDM diaphragm
minimum pressure 0.5 bar
inlet side 4 mm hose fitting
outlet side 4 mm hose fitting



ELECTROLUX 048496

3090084 RINSE AID DISPENSER N6 W4W4

with EPDM diaphragm
minimum pressure 0,5 bar
inlet side hose fitting 4 mm
pressure side hose fitting 4 mm



ELECTROLUX

3090130 RINSE AID HYDRAULIC DISPENSER

setting from 0 to 3 cm³/cycle



ELECTROLUX 0L0094

ELECTROLUX 048715

ELECTROLUX 049484

3090038 RINSE AID INJECTOR DB2

power supply 220/240V 50Hz
screw for flow rate regulation
for Dishwasher (BONNET) IN08
for Dishwasher (THIRODE) LT1000 - LT140 - LT1500
LT90 - VSL450 - VSL650 - VSL800
for Dishwasher hood type (THIRODE) VSL900
for Glasswasher/Cupwasher (BONNET) IN07F - VR1000R
for Glasswasher/Cupwasher (ELETTROBAR) S621 - S636
for Glasswasher/Cupwasher (SAN MARCO) PROTOS
ROTOR



ELECTROLUX 069921

3090039 COIL 220/240V 50Hz

for Dishwasher (BONNET) IN08
for Dishwasher (THIRODE) LT1000 - LT140 - LT1500
LT90 - VSL450 - VSL650 - VSL800
for Dishwasher hood type (THIRODE) VSL900
for Glasswasher/Cupwasher (BONNET) IN07F - VR1000R
for Glasswasher/Cupwasher (ELETTROBAR) S621 - S636
for Glasswasher/Cupwasher (SAN MARCO) PROTOS
ROTOR



ELECTROLUX



Suitable for:

3090003 INLET VALVE FOR RINSE AID INJECTOR

for Dishwasher (BONNET) IN08
 for Dishwasher (COMENDA) F20 - F45
 for Dishwasher (JEMI) GS-8/2 - GS-8/2D - GS-9/2
 GS-9/2D
 for Dishwasher hood type (JEMI) GS-100 - GS-83
 for Glasswasher/Cupwasher (BONNET) IN07F - VR1000R
 for Glasswasher/Cupwasher (COMENDA) B11T
 for Glasswasher/Cupwasher (ELETTROBAR) S621 - S636



ELECTROLUX



Suitable for:

3090190 WASHING PRODUCT DISPENSER

mod. RS20RNIP - Ext.size. 160 x 80 x 85 mm
 220/240 V - 50 Hz
 flowrate 0.28L /hour - 2.80L/hour



3090196 NORPRENE PIPE



ELECTROLUX

Rotary switches

3057050 CONNECTING BRACKET

connecting thermostat and switch



ELECTROLUX 0A2205

ELECTROLUX 0KT779

ELECTROLUX 006712

ELECTROLUX 054376

3059055 CYCLE SELECTOR SWITCH

D spindle \varnothing 6x4.6 mm
 for Dishwasher (ZANUSSI) LS60 - LS61 - LS62 - LS63
 LS64



ELECTROLUX 048829

3241205 KNOB \varnothing 44 mm

D shaft hole 6x4.6 mm
 for Dishwasher (ZANUSSI) LS60 - LS61 - LS62 - LS63
 LS64



ELECTROLUX 048830



ELECTROLUX



Suitable for:

3059056 CYCLE SELECTOR SWITCH 16A 250V
 D spindle \varnothing 6x4.6 mm
 for Dishwasher (ZANUSSI) HYDRA700 - LS7
 for Dishwasher hood type (ZANUSSI) HT1000 - HT1200
 HYDRA1000 - HYDRA1200 - HYDRA800 - LS10 - LS12
 LS8



ELECTROLUX 048270

Suitable for:


3241206 KNOB \varnothing 40 mm
 D shaft hole 6x4.6 mm
 for Dishwasher (ZANUSSI) LS7



ELECTROLUX 047849

ELECTROLUX 048340+047846

3241207 KNOB \varnothing 44 mm
 D shaft hole 6x4.6 mm
 for Dishwasher hood type (ZANUSSI) LS10 - LS12
 LS8



ELECTROLUX 048402

3059058 CYCLE SELECTOR SWITCH 16A 250V
 D spindle \varnothing 6x4.6 mm
 for Dishwasher hood type (ZANUSSI) HYDRA800 - LS8



ELECTROLUX 048524

3241207 KNOB \varnothing 44 mm
 D shaft hole 6x4.6 mm
 for Dishwasher hood type (ZANUSSI) LS10 - LS12
 LS8



ELECTROLUX 048402

3059059 CYCLE SELECTOR SWITCH 16A 250V
 D spindle \varnothing 6x4.6 mm
 for Dishwasher (ZANUSSI) LS500 - LS540 - LS541



ELECTROLUX 046350

3241208 KNOB \varnothing 40 mm
 D shaft hole 6x4.6 mm
 for Dishwasher (ZANUSSI) LS500 - LS540 - LS541



ELECTROLUX 046356

ELECTROLUX 048340

ELECTROLUX 048527



Suitable for:

ELECTROLUX



3059054 ON/OFF SELECTOR SWITCH
 contact capacity 16A 250V
 D spindle \varnothing 6x4.6 mm
 for Dishwasher (ZANUSSI) LS60 - LS61 - LS62 - LS63
 LS64



ELECTROLUX 048828

Suitable for:
3241205 KNOB \varnothing 44 mm
 D shaft hole 6x4.6 mm
 for Dishwasher (ZANUSSI) LS60 - LS61 - LS62 - LS63
 LS64



ELECTROLUX 048830


3057332 PROGRAM SELECTOR SWITCH



ELECTROLUX 005079


ELECTROLUX 059051

3057331 PROGRAM SELECTOR SWITCH 4 CAMS
 for Dishwasher (ZANUSSI) LS7DP
 for Dishwasher hood type (ZANUSSI) LS10DP - LS12DP
 LS8DP



ELECTROLUX 049145

3059057 SELECTOR SWITCH 0-1 POSITIONS
 ON-OFF-START
 16A 250V - max 150°C
 D-shaped pin \varnothing 6x4.6 mm
 for Dishwasher (ZANUSSI) HYDRA700 - LS7



ELECTROLUX 048271

3057048 SELECTOR SWITCH 3 POLES AND BUTTON
 16A 250V
 for Dishwasher conveyor type (ZANUSSI) RT100
 RT140 - RT190 - RT270



ELECTROLUX 0E5132

3057049 SELECTOR SWITCH 4 POLES 16A 250V
 for Dishwasher conveyor type (ZANUSSI) RT100
 RT140 - RT190 - RT270



ELECTROLUX 0E5131

3057046 SELECTOR SWITCH 6 POSITIONS
 for Dishwasher conveyor type (ZANUSSI) RT100
 RT140 - RT190 - RT270



ELECTROLUX 0E5222

ELECTROLUX 0K8266

3057291 SELECTOR SWITCH 6 POSITIONS
 6 positions 16A 250V
 for Dishwasher hood type (ZANUSSI) HT1200
 HYDRA1200 - LS12 - WT60



ELECTROLUX 048286



Suitable for:

ELECTROLUX



Suitable for:

Salt container and accessories

3067603 CAP FOR SALT CONTAINER



ELECTROLUX 069472

3067604 RETAINING NUT FOR CAP



ELECTROLUX 069552

3067001 SALT CONTAINER



ELECTROLUX 010370

3067002 GASKET FOR CONTAINER

external \varnothing 82 mm
internal \varnothing 64 mm
thickness 3 mm



ELECTROLUX 069470

3067002 GASKET FOR CONTAINER

external \varnothing 82 mm
internal \varnothing 64 mm
thickness 3 mm



ELECTROLUX 069470

3067016 FUNNEL FOR SALT INTAKE

external \varnothing 93 mm hole \varnothing 27 mm



3067198 O-RING 04162 EPDM

for Dishwasher (AFI) A600
for Dishwasher (EUROSYSTEM) PRO400
for Dishwasher (HILTA) S41 - S42
for Dishwasher (IME OMNIWASH) 4Q82
for Dishwasher (LAMBER) 040F - 045F
for Dishwasher (NOSEM) C5000 - C5010 - NC501
for Dishwasher (NUOVA SIMONELLI) KIARA6
for Dishwasher (SAB ITALIA) C50H
for Dishwasher (SO.WE.BO.)
for Dishwasher (SOTAL) F600
for Glasswasher/Cupwasher (AFI) A35Z2
for Glasswasher/Cupwasher (ELETTROBAR) 35F - 350F
40F - 400F
for Glasswasher/Cupwasher (IME OMNIWASH) JA40
JA41 - UNO





Suitable for:

3067007 SALT CONTAINER CAP



ELECTROLUX

3067602 SALT CONTAINER ASSEMBLY 85x100 mm
new model
for E35/40/41/42/45/46/50/51/55-MISTRAL40/51
NIAGARA35/40/45/51-RIVER48/50/61



ELECTROLUX 069680

ELECTROLUX



Suitable for:

3067005 SALT CONTAINER RING NUT



3067300 SALT CONTAINER GROUP ASSY
total height 125 mm - external \varnothing 122 mm
for MACH DISHWASHER MB520K-MB530K-930K
for COMENDA DISHWASHER BC-BHC
for JEMI DISHWASHER GS2-GS3-GS4/2-GS4/2AF-GS6
GS6AF-GS7-GS8/2-GS9-GS18-GS19-GS20



ELECTROLUX 049075

Sleeves

3248606 INLET HOSE
internal \varnothing 45 mm
length 60 mm
for Glasswasher/Cupwasher (ELETTROBAR) S621 - S623
S631 - S633



ELECTROLUX 069537

3450103 INLET HOSE
internal \varnothing 63 mm - length 70 mm
for Dishwasher conveyor type (ZANUSSI) RT



ELECTROLUX 0E5023

3450104 OUTLET HOSE
internal \varnothing 53 mm



ELECTROLUX 0E2970



Suitable for:

Suitable for:

3248170 PUMP HOSE INTERNAL \varnothing 64x110 mm
for Dishwasher conveyor type (ZANUSSI) CT192
for Dishwasher hood type (ZANUSSI) LS1080



ELECTROLUX 046565

3450017 PUMP OUTLET PIPE
rubber pipe with textile reinforcement
internal \varnothing 54 mm
internal \varnothing 43 mm
length 430 mm
for Dishwasher (ZANUSSI) LS500 - LS501



ELECTROLUX 046257

ELECTROLUX 065531

3450042 MANICOTTO MANDATA
rubber pipe with textile reinforcement
internal \varnothing 45 mm
length 285 mm
for tank pump inlet hose
for Dishwasher (ZANUSSI) LS4 - LS500 - LS521



ELECTROLUX 045768

3450048 PUMP OUTLET PIPE
for Dishwasher hood type (ZANUSSI) HT1000 - HT1200
HYDRA1000 - HYDRA1200 - LS10 - LS12



ELECTROLUX 048241

3450065 INLET HOSE
external \varnothing 78 mm
height 50 mm
for Dishwasher hood type (ZANUSSI) HT1000 - HT1200
HYDRA1000 - HYDRA1200 - LS10 - LS12



ELECTROLUX 048242

Solenoid valves

3120292 FLOWRATE ADJUSTER \varnothing 1.45 mm



ELECTROLUX 002091



Suitable for:

ELECTROLUX



Suitable for:

Solenoid valves

3120261 MULLER SOLENOID VALVE 230V \varnothing 12 mm
 solenoid valve 180° - 220/230V 50/60Hz - max 90°C
 3/4" inlet - \varnothing 12 mm outlet



ELECTROLUX 0G2196

3120271 MULLER COIL 220/240V 50/60Hz
 temperature 90°C



3120111 SOLENOID VALVE L145R4 \varnothing 3/4" FF 220V
 for steam
 normally closed (ex L142 M2)
 max. temperature 175°C
 max. pressure differential 12 bar
 coil 220V 50Hz



ELECTROLUX 065297

3120115 COIL SIRAI Z534A 230V 50Hz
 for solenoid valve fitting 3/4" - 1"



3120034 CONNECTOR FEMALE LARGE
 for coils



3120118 DIAPHRAGM FOR VALVE \varnothing 3/4"



3120210 SOLENOID VALVE L153D7 \varnothing 3/4" FF 220V
 for steam
 normally closed
 coil 220V. 50Hz
 max. temperature 175°C
 max. pressure differential 12 bar



ELECTROLUX 0E5974

3120213 COIL SIRAI Z134A 230V 50Hz
 for solenoid valves L153 DA \varnothing 3/4"



3120034 CONNECTOR FEMALE LARGE
 for coils





Suitable for:

3120510 SOLENOID VALVE L153D7 3/4" FF 24V
 for steam
 normally closed
 max. temperature 175°C
 max. pressure differential 12 bar
 coil 24V 50Hz



ELECTROLUX 0E2200

3120034 CONNECTOR FEMALE LARGE
 for coils



Suitable for:

3120214 COIL SIRAI Z134A 24V 50Hz
 for solenoid valves L153 DA ø 3/4"



3120057 SOLENOID VALVE L182B31 ø 1/2" FF 220V
 previous L180
 for water
 normally closed
 max. temperature 100°C
 max. pressure differential 16 bar
 coil 220V 50Hz



ELECTROLUX 0H2412

ELECTROLUX 067356

3120042 COIL SIRAI Z610A 6W 230V 50/60Hz
 width 25 mm - height 33 mm
 depth 33 mm



ELECTROLUX 0KG317

ELECTROLUX 067609

3120105 DIAPHRAGM FOR VALVES



ELECTROLUX 069017

3120347 COIL SIRAI ZB10A 230V 4W 50/60Hz
 width 22 mm - height 30 mm
 depth 28 mm



3120044 CONNECTOR FEMALE SMALL
 for coils



3120123 DIAPHRAGM FOR VALVES
 NEW TYPE





ELECTROLUX



Suitable for:

3120557 SOLENOID VALVE L182B31 1/2" FF 24V
 EX L180
 for water
 normally closed
 max temperature 100°C
 max differential pressure 16 bar
 coil 24V 50Hz
 for Dishwasher conveyor type (DIHR) - Series AX
 Series BX
 for Dishwasher conveyor type (KROMO) - Series KP



ELECTROLUX 068464

3120043 COIL SIRAI Z610A 24V 50/60Hz



Suitable for:

3120348 COIL SIRAI ZB10A 24V 4W 50/60Hz
 width 22 mm - height 30 mm
 depth 28 mm



3120044 CONNECTOR FEMALE SMALL
 for coils



3120105 DIAPHRAGM FOR VALVES



ELECTROLUX 069017

3120563 SOLENOID VALVE 1 OUTLET 180° 14 mm
 220/240V 50/60Hz
 for Dishwasher (ZANUSSI) LS62 - LS63 - LS64 - LS7
 for Dishwasher hood type (ZANUSSI) LS8



ELECTROLUX 0L0566

ELECTROLUX 0L0568

3120562 SOLENOID VALVE 180° 230V 50/60Hz ø 10 mm
 for Glasswasher/Cupwasher (WINTERHALTER) GS202
 GS402



ELECTROLUX 0E1575

3120255 SOLENOID VALVE 220/240V ø 10 mm
 solenoid valve 180° - 220/240V 50/60Hz - max 90°C
 inlet 3/4" - two outlets ø 10 mm
 with red flowrate reducer at the outlet



ELECTROLUX 047579

3120404 SOLENOID VALVE 230V ø 10.5 mm
 solenoid valve 90° - 230V 50/60Hz - max 90°C
 3/4" inlet - 1 outlet ø 10.5 mm



ELECTROLUX 0C0688

ELECTROLUX 0C4984

ELECTROLUX 056350



Suitable for:

Suitable for:

3120406 SOLENOID VALVE 230V \varnothing 10.5 mm
solenoid valve 90° - 230V 50/60Hz - max 90°C
inlet 3/4" - 2 outlets \varnothing 10.5 mm



ELECTROLUX 069295

3120013 SOLENOID VALVE 263 220/240V \varnothing 10 mm
solenoid valve 90° - 220/240V 50/60Hz - max 90°C
inlet 3/4" - triple outlet \varnothing 10 mm



ELECTROLUX 047539

ELECTROLUX 047540

ELECTROLUX 049077

ELECTROLUX 069296

3120000 FILTER FOR INLET SOLENOID VALVE ELBI



3120021 INLET PRESSURE REDUCER 12 L/min BLACK



3120022 INLET PRESSURE REDUCER 16 L/min BLACK



3120019 INLET PRESSURE REDUCER 5.5 L/min BLACK



3120037 OUTLET REDUCER ELBI 0.25 L/min GREEN
for ELBI solenoid valve
face value +/- 25%



3120202 OUTLET REDUCER ELBI 0.35 L/min YELLOW
for ELBI solenoid valve
face value +/- 25%



3120015 OUTLET REDUCER ELBI 0.5 L/min RED
for ELBI solenoid valve
face value +/- 25%





Suitable for:

3120016 OUTLET REDUCER ELBI 1.2 L/min NEUTRAL
for ELBI solenoid valve
face value +/- 25%



ELECTROLUX 0L0166

3120017 OUTLET REDUCER ELBI 2.5 L/min ORANGE
for ELBI solenoid valve
face value +/- 25%



3120204 OUTLET REDUCER ELBI 5.5 L/min BROWN
for ELBI solenoid valve
face value +/- 25%



ELECTROLUX 0W2908

3120014 SOLENOID VALVE 264 220/240V ø 10 mm
solenoid valve 180° - 220/240V 50/60Hz - max 90°C
inlet 3/4" - triple outlet ø 10 mm



ELECTROLUX 0E0330

ELECTROLUX 047538

ELECTROLUX 069464

3120021 INLET PRESSURE REDUCER 12 L/min BLACK



ELECTROLUX



Suitable for:

3120203 OUTLET REDUCER ELBI 2 L/min WHITE
for ELBI solenoid valve
face value +/- 25%



3120201 OUTLET REDUCER ELBI 4.7 L/min GREY
for ELBI solenoid valve
face value +/- 25%



3120000 FILTER FOR INLET SOLENOID VALVE ELBI



3120022 INLET PRESSURE REDUCER 16 L/min BLACK





Suitable for:

3120019 INLET PRESSURE REDUCER 5.5 L/min BLACK



3120202 OUTLET REDUCER ELBI 0.35 L/min YELLOW
for ELBI solenoid valve
face value +/- 25%



3120016 OUTLET REDUCER ELBI 1.2 L/min NEUTRAL
for ELBI solenoid valve
face value +/- 25%



ELECTROLUX 0L0166

3120017 OUTLET REDUCER ELBI 2.5 L/min ORANGE
for ELBI solenoid valve
face value +/- 25%



3120204 OUTLET REDUCER ELBI 5.5 L/min BROWN
for ELBI solenoid valve
face value +/- 25%



ELECTROLUX 0W2908

ELECTROLUX



Suitable for:

3120037 OUTLET REDUCER ELBI 0.25 L/min GREEN
for ELBI solenoid valve
face value +/- 25%



3120015 OUTLET REDUCER ELBI 0.5 L/min RED
for ELBI solenoid valve
face value +/- 25%



3120203 OUTLET REDUCER ELBI 2 L/min WHITE
for ELBI solenoid valve
face value +/- 25%



3120201 OUTLET REDUCER ELBI 4.7 L/min GREY
for ELBI solenoid valve
face value +/- 25%





Suitable for:

Suitable for:

3120004 SOLENOID VALVE 319 220/240V \varnothing 10 mm
 solenoid valve 90° - 220/240V 50/60Hz - max 90°C
 inlet 3/4" - outlet \varnothing 10 mm



ELECTROLUX 0A2064
 ELECTROLUX 047531

ELECTROLUX 0KM766
 ELECTROLUX 055350

ELECTROLUX 002613

3120000 FILTER FOR INLET SOLENOID VALVE ELBI



3120021 INLET PRESSURE REDUCER 12 L/min BLACK



3120022 INLET PRESSURE REDUCER 16 L/min BLACK



3120019 INLET PRESSURE REDUCER 5.5 L/min BLACK



3120037 OUTLET REDUCER ELBI 0.25 L/min GREEN
 for ELBI solenoid valve
 face value +/- 25%



3120202 OUTLET REDUCER ELBI 0.35 L/min YELLOW
 for ELBI solenoid valve
 face value +/- 25%



3120015 OUTLET REDUCER ELBI 0.5 L/min RED
 for ELBI solenoid valve
 face value +/- 25%



3120016 OUTLET REDUCER ELBI 1.2 L/min NEUTRAL
 for ELBI solenoid valve
 face value +/- 25%



3120203 OUTLET REDUCER ELBI 2 L/min WHITE
 for ELBI solenoid valve
 face value +/- 25%



ELECTROLUX 0L0166



Suitable for:

3120017 OUTLET REDUCER ELBI 2.5 L/min ORANGE
for ELBI solenoid valve
face value +/- 25%



ELECTROLUX



Suitable for:

3120201 OUTLET REDUCER ELBI 4.7 L/min GREY
for ELBI solenoid valve
face value +/- 25%



3120204 OUTLET REDUCER ELBI 5.5 L/min BROWN
for ELBI solenoid valve
face value +/- 25%



ELECTROLUX 0W2908

3120005 SOLENOID VALVE 329 220/240V ø 10 mm
solenoid valve 180° - 220/240V 50/60Hz - max 90°C
inlet 3/4" - outlet ø 10 mm



3120000 FILTER FOR INLET SOLENOID VALVE ELBI



ELECTROLUX 002753
ELECTROLUX 055132

ELECTROLUX 047756
ELECTROLUX 086014

ELECTROLUX 048894

3120021 INLET PRESSURE REDUCER 12 L/min BLACK



3120022 INLET PRESSURE REDUCER 16 L/min BLACK



3120019 INLET PRESSURE REDUCER 5.5 L/min BLACK



3120037 OUTLET REDUCER ELBI 0.25 L/min GREEN
for ELBI solenoid valve
face value +/- 25%





Suitable for:

3120202 **OUTLET REDUCER ELBI 0.35 L/min YELLOW**
for ELBI solenoid valve
face value +/- 25%



3120016 **OUTLET REDUCER ELBI 1.2 L/min NEUTRAL**
for ELBI solenoid valve
face value +/- 25%



ELECTROLUX 0L0166

3120017 **OUTLET REDUCER ELBI 2.5 L/min ORANGE**
for ELBI solenoid valve
face value +/- 25%



3120204 **OUTLET REDUCER ELBI 5.5 L/min BROWN**
for ELBI solenoid valve
face value +/- 25%



ELECTROLUX 0W2908

3120505 **SOLENOID VALVE 329 24V ø 10 mm**
solenoid valve 180° - 24V 50Hz - max 90°C
inlet 3/4" - outlet ø 10 mm



ELECTROLUX 058996

ELECTROLUX



Suitable for:

3120015 **OUTLET REDUCER ELBI 0.5 L/min RED**
for ELBI solenoid valve
face value +/- 25%



3120203 **OUTLET REDUCER ELBI 2 L/min WHITE**
for ELBI solenoid valve
face value +/- 25%



3120201 **OUTLET REDUCER ELBI 4.7 L/min GREY**
for ELBI solenoid valve
face value +/- 25%



3120000 **FILTER FOR INLET SOLENOID VALVE ELBI**





Suitable for:

3120021 INLET PRESSURE REDUCER 12 L/min BLACK



3120019 INLET PRESSURE REDUCER 5.5 L/min BLACK



3120202 OUTLET REDUCER ELBI 0.35 L/min YELLOW
for ELBI solenoid valve
face value +/- 25%



3120016 OUTLET REDUCER ELBI 1.2 L/min NEUTRAL
for ELBI solenoid valve
face value +/- 25%



3120017 OUTLET REDUCER ELBI 2.5 L/min ORANGE
for ELBI solenoid valve
face value +/- 25%



3120204 OUTLET REDUCER ELBI 5.5 L/min BROWN
for ELBI solenoid valve
face value +/- 25%



ELECTROLUX 0W2908

ELECTROLUX



Suitable for:

3120022 INLET PRESSURE REDUCER 16 L/min BLACK



3120037 OUTLET REDUCER ELBI 0.25 L/min GREEN
for ELBI solenoid valve
face value +/- 25%



3120015 OUTLET REDUCER ELBI 0.5 L/min RED
for ELBI solenoid valve
face value +/- 25%



3120203 OUTLET REDUCER ELBI 2 L/min WHITE
for ELBI solenoid valve
face value +/- 25%



3120201 OUTLET REDUCER ELBI 4.7 L/min GREY
for ELBI solenoid valve
face value +/- 25%





ELECTROLUX



Suitable for:

Suitable for:

3120006 SOLENOID VALVE 339 220/240V ø 10 mm
 solenoid valve 90° - 220/240V 50/60Hz - max 90°C
 inlet 3/4" - dual outlet ø 10 mm



ELECTROLUX 055444

ELECTROLUX 056872

3120021 INLET PRESSURE REDUCER 12 L/min BLACK



3120000 FILTER FOR INLET SOLENOID VALVE ELBI



3120022 INLET PRESSURE REDUCER 16 L/min BLACK



3120019 INLET PRESSURE REDUCER 5.5 L/min BLACK



3120037 OUTLET REDUCER ELBI 0.25 L/min GREEN
for ELBI solenoid valve
face value +/- 25%



3120202 OUTLET REDUCER ELBI 0.35 L/min YELLOW
for ELBI solenoid valve
face value +/- 25%



3120015 OUTLET REDUCER ELBI 0.5 L/min RED
for ELBI solenoid valve
face value +/- 25%



3120016 OUTLET REDUCER ELBI 1.2 L/min NEUTRAL
for ELBI solenoid valve
face value +/- 25%



3120203 OUTLET REDUCER ELBI 2 L/min WHITE
for ELBI solenoid valve
face value +/- 25%



ELECTROLUX 0L0166

3120017 OUTLET REDUCER ELBI 2.5 L/min ORANGE
for ELBI solenoid valve
face value +/- 25%



3120201 OUTLET REDUCER ELBI 4.7 L/min GREY
for ELBI solenoid valve
face value +/- 25%





Suitable for:

3120204 OUTLET REDUCER ELBI 5.5 L/min BROWN
for ELBI solenoid valve
face value +/- 25%



ELECTROLUX



Suitable for:

ELECTROLUX 0W2908

3120007 SOLENOID VALVE 349 220/240V ø 10 mm
solenoid valve 180° - 220/240V 50/60Hz - max 90°C
inlet 3/4" - dual outlet ø 10 mm



ELECTROLUX 0K5389

ELECTROLUX 045631

ELECTROLUX 046427

ELECTROLUX 047536

ELECTROLUX 069463

3120021 INLET PRESSURE REDUCER 12 L/min BLACK



3120000 FILTER FOR INLET SOLENOID VALVE ELBI



3120022 INLET PRESSURE REDUCER 16 L/min BLACK



3120019 INLET PRESSURE REDUCER 5.5 L/min BLACK



3120037 OUTLET REDUCER ELBI 0.25 L/min GREEN
for ELBI solenoid valve
face value +/- 25%



3120202 OUTLET REDUCER ELBI 0.35 L/min YELLOW
for ELBI solenoid valve
face value +/- 25%



3120015 OUTLET REDUCER ELBI 0.5 L/min RED
for ELBI solenoid valve
face value +/- 25%





Suitable for:

3120016 OUTLET REDUCER ELBI 1.2 L/min NEUTRAL
for ELBI solenoid valve
face value +/- 25%



ELECTROLUX 0L0166

3120017 OUTLET REDUCER ELBI 2.5 L/min ORANGE
for ELBI solenoid valve
face value +/- 25%



3120204 OUTLET REDUCER ELBI 5.5 L/min BROWN
for ELBI solenoid valve
face value +/- 25%



ELECTROLUX 0W2908

3120507 SOLENOID VALVE 349 24V ø 10 mm
solenoid valve 180° - 24V 50Hz - max 90°C
inlet 3/4" - dual outlet ø 10 mm



ELECTROLUX 046796

ELECTROLUX 048180

3120021 INLET PRESSURE REDUCER 12 L/min BLACK



ELECTROLUX



Suitable for:

3120203 OUTLET REDUCER ELBI 2 L/min WHITE
for ELBI solenoid valve
face value +/- 25%



3120201 OUTLET REDUCER ELBI 4.7 L/min GREY
for ELBI solenoid valve
face value +/- 25%



3120000 FILTER FOR INLET SOLENOID VALVE ELBI



3120022 INLET PRESSURE REDUCER 16 L/min BLACK





Suitable for:

3120019 INLET PRESSURE REDUCER 5.5 L/min BLACK



3120202 OUTLET REDUCER ELBI 0.35 L/min YELLOW
for ELBI solenoid valve
face value +/- 25%



3120016 OUTLET REDUCER ELBI 1.2 L/min NEUTRAL
for ELBI solenoid valve
face value +/- 25%



ELECTROLUX 0L0166

3120017 OUTLET REDUCER ELBI 2.5 L/min ORANGE
for ELBI solenoid valve
face value +/- 25%



3120204 OUTLET REDUCER ELBI 5.5 L/min BROWN
for ELBI solenoid valve
face value +/- 25%



ELECTROLUX 0W2908

ELECTROLUX



Suitable for:

3120037 OUTLET REDUCER ELBI 0.25 L/min GREEN
for ELBI solenoid valve
face value +/- 25%



3120015 OUTLET REDUCER ELBI 0.5 L/min RED
for ELBI solenoid valve
face value +/- 25%



3120203 OUTLET REDUCER ELBI 2 L/min WHITE
for ELBI solenoid valve
face value +/- 25%



3120201 OUTLET REDUCER ELBI 4.7 L/min GREY
for ELBI solenoid valve
face value +/- 25%





Suitable for:

Suitable for:

3120008 SOLENOID VALVE 350 220/240V \varnothing 14 mm
 solenoid valve 90° - 220/240V 50/60Hz - max 90°C
 inlet 3/4" - outlet \varnothing 14 mm



ELECTROLUX 047529
 ELECTROLUX 048898

ELECTROLUX 047532
 ELECTROLUX 069179

ELECTROLUX 048178

3120000 FILTER FOR INLET SOLENOID VALVE ELBI



3120021 INLET PRESSURE REDUCER 12 L/min BLACK



3120022 INLET PRESSURE REDUCER 16 L/min BLACK



3120019 INLET PRESSURE REDUCER 5.5 L/min BLACK



3120037 OUTLET REDUCER ELBI 0.25 L/min GREEN
 for ELBI solenoid valve
 face value +/- 25%



3120202 OUTLET REDUCER ELBI 0.35 L/min YELLOW
 for ELBI solenoid valve
 face value +/- 25%



3120015 OUTLET REDUCER ELBI 0.5 L/min RED
 for ELBI solenoid valve
 face value +/- 25%



3120016 OUTLET REDUCER ELBI 1.2 L/min NEUTRAL
 for ELBI solenoid valve
 face value +/- 25%



3120203 OUTLET REDUCER ELBI 2 L/min WHITE
 for ELBI solenoid valve
 face value +/- 25%



ELECTROLUX 0L0166



Suitable for:

3120017 OUTLET REDUCER ELBI 2.5 L/min ORANGE
for ELBI solenoid valve
face value +/- 25%



3120204 OUTLET REDUCER ELBI 5.5 L/min BROWN
for ELBI solenoid valve
face value +/- 25%



ELECTROLUX



Suitable for:

3120201 OUTLET REDUCER ELBI 4.7 L/min GREY
for ELBI solenoid valve
face value +/- 25%



ELECTROLUX 0W2908

3120511 SOLENOID VALVE 350 24V ø 14 mm
solenoid valve 90° - 24V 50Hz - max 90°C
3/4" inlet - ø 14 mm outlet



ELECTROLUX 0H2513

ELECTROLUX 0L0175

3120009 SOLENOID VALVE 351 220/240V ø 14 mm
solenoid valve 180° - 220/240V 50/60Hz - max 90°C
inlet 3/4" - outlet ø 14 mm



3120000 FILTER FOR INLET SOLENOID VALVE ELBI



ELECTROLUX 072282

3120021 INLET PRESSURE REDUCER 12 L/min BLACK



3120022 INLET PRESSURE REDUCER 16 L/min BLACK





Suitable for:

3120019 INLET PRESSURE REDUCER 5.5 L/min BLACK



3120202 OUTLET REDUCER ELBI 0.35 L/min YELLOW
for ELBI solenoid valve
face value +/- 25%



3120016 OUTLET REDUCER ELBI 1.2 L/min NEUTRAL
for ELBI solenoid valve
face value +/- 25%



ELECTROLUX 0L0166

3120017 OUTLET REDUCER ELBI 2.5 L/min ORANGE
for ELBI solenoid valve
face value +/- 25%



3120204 OUTLET REDUCER ELBI 5.5 L/min BROWN
for ELBI solenoid valve
face value +/- 25%



ELECTROLUX 0W2908

ELECTROLUX



Suitable for:

3120037 OUTLET REDUCER ELBI 0.25 L/min GREEN
for ELBI solenoid valve
face value +/- 25%



3120015 OUTLET REDUCER ELBI 0.5 L/min RED
for ELBI solenoid valve
face value +/- 25%



3120203 OUTLET REDUCER ELBI 2 L/min WHITE
for ELBI solenoid valve
face value +/- 25%



3120201 OUTLET REDUCER ELBI 4.7 L/min GREY
for ELBI solenoid valve
face value +/- 25%





Suitable for:

Suitable for:

3120512 SOLENOID VALVE 351 24V \varnothing 14 mm
solenoid valve 180° - 24V 50Hz - max 90°C
3/4" inlet - \varnothing 14 mm outlet



ELECTROLUX 0E5070

3120010 SOLENOID VALVE 352 220/240V \varnothing 14 mm
solenoid valve 90° - 220/240V 50/60Hz - max 90°C
inlet 3/4" - dual outlet \varnothing 14 mm



3120000 FILTER FOR INLET SOLENOID VALVE ELBI



ELECTROLUX 049056

3120021 INLET PRESSURE REDUCER 12 L/min BLACK



3120022 INLET PRESSURE REDUCER 16 L/min BLACK



3120019 INLET PRESSURE REDUCER 5.5 L/min BLACK



3120037 OUTLET REDUCER ELBI 0.25 L/min GREEN
for ELBI solenoid valve
face value +/- 25%



3120202 OUTLET REDUCER ELBI 0.35 L/min YELLOW
for ELBI solenoid valve
face value +/- 25%



3120015 OUTLET REDUCER ELBI 0.5 L/min RED
for ELBI solenoid valve
face value +/- 25%





Suitable for:

3120016 OUTLET REDUCER ELBI 1.2 L/min NEUTRAL
for ELBI solenoid valve
face value +/- 25%



ELECTROLUX 0L0166

3120017 OUTLET REDUCER ELBI 2.5 L/min ORANGE
for ELBI solenoid valve
face value +/- 25%



3120204 OUTLET REDUCER ELBI 5.5 L/min BROWN
for ELBI solenoid valve
face value +/- 25%



ELECTROLUX 0W2908

3120011 SOLENOID VALVE 353 220/240V ø 14 mm
solenoid valve 180° - 220/240V 50/60Hz - max 90°C
inlet 3/4" - dual outlet ø 14 mm



ELECTROLUX 069262

ELECTROLUX 072364

3120021 INLET PRESSURE REDUCER 12 L/min BLACK



ELECTROLUX



Suitable for:

3120203 OUTLET REDUCER ELBI 2 L/min WHITE
for ELBI solenoid valve
face value +/- 25%



3120201 OUTLET REDUCER ELBI 4.7 L/min GREY
for ELBI solenoid valve
face value +/- 25%



3120000 FILTER FOR INLET SOLENOID VALVE ELBI



3120022 INLET PRESSURE REDUCER 16 L/min BLACK





Suitable for:

3120019 INLET PRESSURE REDUCER 5.5 L/min BLACK



3120202 OUTLET REDUCER ELBI 0.35 L/min YELLOW
for ELBI solenoid valve
face value +/- 25%



3120016 OUTLET REDUCER ELBI 1.2 L/min NEUTRAL
for ELBI solenoid valve
face value +/- 25%



ELECTROLUX 0L0166

3120017 OUTLET REDUCER ELBI 2.5 L/min ORANGE
for ELBI solenoid valve
face value +/- 25%



3120204 OUTLET REDUCER ELBI 5.5 L/min BROWN
for ELBI solenoid valve
face value +/- 25%



ELECTROLUX 0W2908

ELECTROLUX



Suitable for:

3120037 OUTLET REDUCER ELBI 0.25 L/min GREEN
for ELBI solenoid valve
face value +/- 25%



3120015 OUTLET REDUCER ELBI 0.5 L/min RED
for ELBI solenoid valve
face value +/- 25%



3120203 OUTLET REDUCER ELBI 2 L/min WHITE
for ELBI solenoid valve
face value +/- 25%



3120201 OUTLET REDUCER ELBI 4.7 L/min GREY
for ELBI solenoid valve
face value +/- 25%





Suitable for:

Suitable for:

3120514 SOLENOID VALVE 353 24V \varnothing 14 mm
 solenoid valve 180° - 24V 50Hz - max 90°C
 inlet 3/4" - two outlets \varnothing 14 mm



ELECTROLUX 0KZ810

3120231 SOLENOID VALVE 7321BAN00 1/2" 220V



ELECTROLUX 047137

1120332 COIL LUCIFER/PARKER 220/240V 9W 50Hz
 width 32 mm - height 38 mm
 depth 43 mm



3120732 SOLENOID VALVE 7321BCN00 3/4" 24V



ELECTROLUX 046900

ELECTROLUX 075736

1120333 COIL LUCIFER 483510P0 24V 9W 50/60Hz
 width 32 mm - height 37 mm
 depth 43 mm



3120034 CONNECTOR FEMALE LARGE
 for coils



3120069 DIAPHRAGM PM7321 CN/DN \varnothing 3/4"-1"
 formerly PM133



3120104 SOLENOID-VALVE 319 220/240V \varnothing 14 mm
 solenoid valve 90° - 220/240V 50/60Hz - max 90°C
 inlet 3/4" - outlet \varnothing 14mm



ELECTROLUX 048817

ELECTROLUX 049626

3120564 1-WAY SOLENOID VALVE 230V
 flowrate 5.5 L
 inlet 3/4" - outlet \varnothing 14 mm
 for Dishwasher (ZANUSSI) LS6
 for Dishwasher hood type (ZANUSSI) LS10 - LS12
 LS14



ELECTROLUX 088194

ELECTROLUX 049452



ELECTROLUX



Suitable for:

3120400 1-WAY SOLENOID VALVE 90° 12V
inlet 3/4" - outlet \varnothing 13.5 mm
max. temperature 90°C - flow rate 1.2 m³/h
operating pressure from 0.2 to 10 bars



ELECTROLUX

Suitable for:

3120399 1-WAY WATER SOLENOID VALVE 180°-12V
inlet 3/4" - outlet \varnothing 10.5 mm
max temperature 90°C
operating pressure from 0.2 to 10 bar



ELECTROLUX

Splash guards

3315050 SPLASH GUARD 59.5 cm
for Dishwasher (ZANUSSI) LS500 - LS501 - 5CF07B
5CF08B



ELECTROLUX 047453

ELECTROLUX 047855

3315051 GASKET FOR SPLASH GUARD
for DISHWASHER models LS510-LS520-LS521-LS4-LS5DS
CRYSTAL50-CRYSTAL51-CRYSTAL52



ELECTROLUX 046256

Springs

3250100 LIFTING SPRING
overall length 360 mm
body \varnothing 51 mm
for DISHWASHER 750/1080 WITH HOOD



ELECTROLUX 066398

3250050 SPRING FOR DOOR LIFTING
external \varnothing 45x26 mm
for CONVEYOR DISHWASHER series RT



ELECTROLUX 0E5158

ELECTROLUX 0K8168

3250030 SPRING PULLEY
external \varnothing 30 mm
internal \varnothing 11 mm
for models RT



ELECTROLUX 0E5001

ELECTROLUX 0K8167



Suitable for:

3250051 SPRING FOR DOOR LIFTING
external \varnothing 45x39 mm
for CONVEYOR DISHWASHER series RT



ELECTROLUX 0E5167

3250094 SPRING LOCK



ELECTROLUX 0E2898

3250046 SPRING FOR HOOD LIFTING
dimensions \varnothing 38.5x380 mm
for Dishwasher hood type (ZANUSSI) HT800
HYDRA800 - LS8



ELECTROLUX 048655

Suitable for:

3250093 SPACER FOR SPRING



ELECTROLUX 0E5454

ELECTROLUX 0K7600

3250030 SPRING PULLEY
external \varnothing 30 mm
internal \varnothing 11 mm
for models RT



ELECTROLUX 0E5001

ELECTROLUX 0K8167

3250049 SPRING FOR HOOD LIFTING
dimensions \varnothing 39x755 mm
for LS10-LS12-WT60 (versions from 1999 on)



ELECTROLUX 049582

Supports

3391015 LONG ROLLER SUPPORT
for Dishwasher conveyor type (ZANUSSI)



ELECTROLUX 0E3530

Switches

3319920 BLACK TWO-POLE SWITCH 16A 250V
for Dishwasher (DIHR) GASTRO500 - GASTRO750 - G600



ELECTROLUX 0A8754

3319923 BLACK/RED CAM



ELECTROLUX 0A8272



Suitable for:

3319646 GREEN/ORANGE CAM

for Dishwasher (KROMO) K35 - K37 - K40 - K45 - K50
K80 - K90
for Dishwasher hood type (KROMO) K100



Suitable for:

3319627 DOUBLE CHANGE OVER SWITCH 16A 250V

for Dishwasher (CONTI) CM5000
for Dishwasher (ELETTROBAR) E50 - E51 - E52
for Dishwasher (EUROSYSTEM) A600
for Dishwasher (SAB ITALIA) K5.2P - K6.1P
for Dishwasher (SOTAL) C13001P
for Dishwasher (UNIC) A61A
for Dishwasher hood type (AFI) A1000L
for Dishwasher hood type (HILTA) W13 - W15
for Dishwasher hood type (IME OMNIWASH) SEI1P
SEI2P
for Dishwasher hood type (NOSEM) K601 - K602
for Dishwasher hood type (NUOVA SIMONELLI) LTM1500
for Dishwasher hood type (SO.WE.BO.) 6.1P - 6.2PB
for Dishwasher hood type (SOTAL) C1300
for Dishwasher hood type (UNIC) A61



3319170 BLACK ELLIPTICAL PUSH-BUTTON



ELECTROLUX 003766

3319164 BLACK ELLIPTICAL PUSH-BUTTON BODY



3319633 BUTTON FOR SWITCH BLOCK

for Dishwasher (CONTI) CM5000
for Dishwasher (ELETTROBAR) E50 - E51 - E52
for Glasswasher/Cupwasher (ELETTROBAR) E35 - E40
E45 - E46



3319482 CHROMIUM-PLATED ELLIPTIC KEY

for Dishwasher (COLGED) STEEL51



3319481 ELLIPTIC GREY SWITCH BLOCK

for Dishwasher (COLGED) STEEL51





Suitable for:

3319177 ELLIPTICAL PUSH-BUTTON INSERT
for Dishwasher (ELETTROBAR) PLUVIA280



3319636 RECTANGULAR CAP
mounting hole 34x24 mm
for Dishwasher (CONTI) CM5000
for Dishwasher (ELETTROBAR) E50 - E51 - E52
for Glasswasher/Cupwasher (ELETTROBAR) E35 - E40
E45 - E46



3319658 ROUND RED KEY 0-1



3319632 SQUARE SWITCH BLOCK W/HOLE FOR IND.LAMP
for Dishwasher (CONTI) CM5000
for Dishwasher (ELETTROBAR) E50 - E51 - E52
for Glasswasher/Cupwasher (ELETTROBAR) E35 - E40
E45 - E46



ELECTROLUX



Suitable for:

3221096 ORANGE INDICATOR LAMP 230V
head \varnothing 7 mm - hole \varnothing 6 mm
wire connection length 210 mm
for ANGELO PO OVEN FC101-FC101E-FC241-FC241E
FC241G-FC61-FC61E-FC611G-FC611E-FC1011G-FC1011E
FC1221G-FC1221E
for Dishwasher (COLGED) STEELTECH340



3319659 ROUND GREY KEY



3319635 SQUARE CAP
for Dishwasher (CONTI) CM5000
for Dishwasher (ELETTROBAR) E50 - E51 - E52
for Glasswasher/Cupwasher (ELETTROBAR) E35 - E40
E45 - E46



3319634 START SWITCH
for Dishwasher (CONTI) CM5000
for Dishwasher (ELETTROBAR) E50 - E51 - E52
for Glasswasher/Cupwasher (ELETTROBAR) E35 - E40
E45 - E46





Suitable for:

3319749 EMERGENCY BUTTON
for Dishwasher conveyor type (ZANUSSI)



ELECTROLUX 0E5305

ELECTROLUX 0K8450

Suitable for:

3319012 GREEN BIPOLAR SWITCH 16A 250V
with indicator light and switch cover
screen printing 0 - I
max temperature 120°C
mounting hole 22x30 mm
for Dishwasher (DIHR) DERBY CF - GASTRO450
GASTRO500 - GASTRO750 - GASTRO900 - TURBOCF/LS
for Dishwasher (UNIVERBAR)
for Dishwasher hood type (DIHR) GASTRO11S
GASTRO1200S



ELECTROLUX 053810

3319013 GREEN BIPOLAR SWITCH 16A 250V
with indicator lamp and switch cover
"0 - II" symbol screenprinted
max temperature 120°C
mounting hole 22x30 mm



ELECTROLUX 053837

3319928 GREEN BIPOLAR SWITCH 16A 250V
with indicator lamp
max.temperature 120°C
mounting hole \varnothing 25 mm
for Dishwasher (LINEA BLANCA) LC-1500 - LC-1700
LC-2000 - LC-2300 - LC-2300TR - LC-2600
LC-2800
for Dishwasher hood type (LINEA BLANCA) LC-3500
for Glasswasher/Cupwasher (LINEA BLANCA) LC-1000
LC-80



ELECTROLUX 054518

3319151 SWITCH PROTECTION CAP
 \varnothing external 34 mm
for push-buttons with mounting hole \varnothing 25 mm



ELECTROLUX 053979



Suitable for:

3319944 GREEN BIPOLAR SWITCH 16A 250V

with indicator light
0-I silk-screen printing
temperature max 120°C
mounting hole 22x30 mm



ELECTROLUX 056703

Suitable for:

3319951 GREEN BIPOLAR SWITCH 16A 250V

with indicator lamp
max temperature 125°C
lead connector 6.35x0.8 mm
mounting hole 25x27 mm
for Dishwasher (JEMI) GS-8/2 - GS-9
for Dishwasher hood type (JEMI) GS-100 - GS-82
for Glasswasher/Cupwasher (JEMI) GS-3 - GS-4/2



ELECTROLUX 085987

ELECTROLUX 099274

3319175 GREEN CHANGE OVER SWITCH 16A 24V

with indicator lamp
max temperature 120°C
mounting hole 22x30 mm
for Dishwasher hood type (IME OMNIWASH) SEI2P
for Dishwasher hood type (STORME) L502



ELECTROLUX 004158

1319202 GREEN TWO-POLE SWITCH 16A 250V

with indicator lamp
silk-screen printing 0 - I
temperature max 120°C
mounting hole 22x30 mm



ELECTROLUX 056703

ELECTROLUX 081680

3319415 KEY SUPPORTING BODY

for all models



ELECTROLUX 083050

3319088 ORANGE BIPOLAR SWITCH 250V 16A

with indicator lamp and push-button cover
temperature max 120°C
mounting hole 22x30 mm
for Dishwasher (SAMMIC) E-300
for Glasswasher/Cupwasher (SAMMIC) E-19 - LVT-18
LVT-18A - LVT-18H - S-20



ELECTROLUX 056878

ELECTROLUX 056879

ELECTROLUX 056880

3319145 ORANGE PUSH-BUTTON

for Pan washing machine (ZANUSSI) L0250 - L0480



ELECTROLUX 0L1243

ELECTROLUX 075600

ELECTROLUX 075656

3221057 INDICATOR LAMP 2W 30V

dimensions \varnothing 10x28 mm
for POT WASHER L0250



ELECTROLUX 075026



Suitable for:

3221089 SNAP-IN LAMP RECEPTACLE
for LO250-LO480



ELECTROLUX 0L1244

ELECTROLUX 075602

Suitable for:

3319011 RED TWO-POLE PUSH-BUTTON 16A 250V
normally closed
with indicator lamp and push-button cap
max temperature 120°C
mounting hole 22x30 mm



ELECTROLUX 054547

ELECTROLUX 055014

3319015 RED BIPOLAR PUSH BUTTON 16A 250V
with indicator lamp
silk-screen print 0 - I
max temperature 120°C
mounting hole 22x30 mm



ELECTROLUX 005899

3319922 SINGLE POLE CHANGEOVER SWITCH
lead connector 6.35x0.8 mm



ELECTROLUX 0A8273

3319923 BLACK/RED CAM



ELECTROLUX 0A8272

3319024 START PUSH-BUTTON PANEL
bipolar switch NO
for Dishwasher (ZANUSSI) LS500 - LS540
for Dishwasher hood type (ZANUSSI) LS1080



ELECTROLUX 046340

ELECTROLUX 048445+048575

3319080 SWITCH SUPPORT



ELECTROLUX 085609

3319211 SWITCH 16(4)A 250V
for Glasswasher/Cupwasher (ZANUSSI) GW1 - GW2
LB1 - LB2 - WT1 - WT2 - Z1 - Z2



ELECTROLUX 049063

3319212 GREY BUTTON ø 23 mm
for Glasswasher/Cupwasher (ZANUSSI) GW1 - GW2
LB1 - LB2 - Z1 - Z2



ELECTROLUX 049062



ELECTROLUX



Suitable for:

3319213 SWITCH 16(4)A 250V
for Glasswasher/Cupwasher (ZANUSSI) GW1 - GW2
LB1 - LB2 - WT1 - WT2 - Z1 - Z2



ELECTROLUX 049068

3319214 YELLOW BUTTON ø 23 mm
for Glasswasher/Cupwasher (ZANUSSI) GW1 - GW2
LB1 - LB2 - Z1 - Z2



ELECTROLUX 049065

3319127 THREE-POLE SWITCH
for Dishwasher (ZANUSSI) LS3



ELECTROLUX 049316

3319129 PUSH-BUTTON
for Dishwasher (ZANUSSI) LS3



ELECTROLUX 049315

3319142 SCREENPRINTED BUTTON ø 23 mm
for Dishwasher (ZANUSSI) LS3



ELECTROLUX 049383

Suitable for:

3319215 GREEN BUTTON ø 23 mm
for Glasswasher/Cupwasher (ZANUSSI) GW1 - GW2
LB1 - LB2 - Z1 - Z2



ELECTROLUX 049091

3319570 DRAIN GREY KEY



ELECTROLUX 049325

3319138 SCREENPRINTED BUTTON ø 23 mm
for Dishwasher (ZANUSSI) LS3



ELECTROLUX 049318

3319143 SCREENPRINTED BUTTON 23 mm
for Dishwasher (ZANUSSI) LS3



ELECTROLUX 049317



Suitable for:

3319128 THREE-POLE SWITCH
for Dishwasher (ZANUSSI) LS3



ELECTROLUX 049326

3319256 WHITE BIPOLAR SWITCH 16A 250V
with light



ELECTROLUX

Telethermometers

3394354 ELECTRONIC THERMOMETER LAE LTS12PTI-2
complete with 2-wire probe length 3000 mm
multiprobe: PT100(-100+600°C) - PTC(-50+150°C)
power supply 24 Vac 3W
mounting hole distance 70x28 mm
for Dishwasher (ZANUSSI) - Series WT



ELECTROLUX 0E5030

ELECTROLUX 049943

3394355 ELECTRONIC THERMOMETER LAE LTS12PTI-2
complete with 2-wire probe length 5000 mm
multiprobe: PT100(-100+600°C) - PTC(-50+150°C)
power supply 24 Vac 3W
mounting hole distance 70x28 mm
for Dishwasher conveyor type (ZANUSSI) RT100
RT140 - RT190 - RT270



ELECTROLUX 049944

3441033 TELETHERMOMETER 56x25 mm 0-120°C
plastic body
white dial
PVC covered capillary length 3000 mm
bulb with spring \varnothing 6x20 mm
for Dishwasher (ELFRAMO) - Series EN
for Dishwasher hood type (ZANUSSI) LS8



ELECTROLUX 048544

3441043 THERMOMETER 0-120°C 48x48 mm
covered capillary 2900 mm
bulb \varnothing 6x36 mm
for Dishwasher (ZANUSSI) LS65 - WT35



ELECTROLUX 0E5545

ELECTROLUX 048525



Suitable for:

ELECTROLUX



Suitable for:

3441006 WHITE TELETHERMOMETER \varnothing 52 mm 0-120°C
 metal case
 PVC covered capillary 1500 mm
 spring bulb \varnothing 8x32 mm
 bulb fitting M10x1
 for Dishwasher (LASA)
 for Dishwasher (MARENO) MLS30 - MLS31 - MLS35
 for Dishwasher hood type (MARENO) MLC50 - MLC65



ELECTROLUX 032085

ELECTROLUX 034075

3441013 WHITE TELETHERMOMETER 56x25 mm 0-110°C
 plastic case
 PVC covered capillary 2000 mm
 bulb with seal \varnothing 8.4 mm
 with swivel fitting \varnothing 14x1 mm
 for Dishwasher (ZANUSSI) LC100 - LC1000
 for Dishwasher hood type (ZANUSSI) LS10 - LS1080
 LS12



ELECTROLUX 048553

ELECTROLUX 048084

ELECTROLUX 048272

ELECTROLUX 066350

ELECTROLUX 067336

3186135 THERMOMETER GASKET 60x30 mm



ELECTROLUX 048070

3441015 WHITE TELETHERMOMETER 56x25 mm 0-120°C
 plastic case
 PVC covered capillary 3000 mm
 spring bulb \varnothing 8.4 mm
 fitting \varnothing M10x1 mm
 for Dishwasher (ZANUSSI) LC100
 for Dishwasher hood type (ZANUSSI) HT1000 - HT1200
 HYDRA1000 - LS10 - LS12



ELECTROLUX 047211

ELECTROLUX 047784

ELECTROLUX 048065

ELECTROLUX 075671

ELECTROLUX 076048

3441044 WHITE THERMOMETER \varnothing 52 mm 0-120°C
 plastic case
 covered capillary 2500 mm
 bulb \varnothing 6x36 mm
 for Dishwasher (ZANUSSI) FL700 - HYDRA700 - LS7
 LV70 - Z70



ELECTROLUX 048564



Suitable for:

ELECTROLUX



Suitable for:

Terminal blocks

3247039 MAIN TERMINAL BLOCK 145x145 mm
for Dishwasher (ZANUSSI) LB5G - LS5 - LS5WS - LS6
LS6AH - LS6WS - WT30WS - WT37 - WT38 - WT4
WT4G - WT4WS - WT5S
for Dishwasher hood type (ZANUSSI) LS10 - LS12
LS14 - LS14AH - LS14WS - LS9 - WT60 - WT65
WT65WS



ELECTROLUX 0L0111

ELECTROLUX 049618

3247015 12-POLE BRASS TERMINAL BLOCK
for cable max 4 mm²
operating temperature 150°C
nominal voltage 450 V



ELECTROLUX 0W3543

3247006 2-POLE CERAMIC TERMINAL BLOCK
for cable max 6 mm²
operating temperature 300°C
nominal voltage 450V
dimensions 25x22x21 mm



ELECTROLUX 053805

3247016 3-POLE TERMINAL BLOCK FV273 40A 450V
for cable max 6 mm²
operating temperature 150°C
nominal voltage 450 V
for Glasswasher/Cupwasher (SILANOS) R20 - 020
030
for Glasswasher/Cupwasher (WHIRLPOOL) AGB641
AGB642 - AGB643 - AGB647 - AGB782



ELECTROLUX 046357

3247005 4-POLE CERAMIC TERMINAL BLOCK
for cable max 2.5 mm²
operating temperature 300°C
nominal voltage 450V
dimensions 40x18x16 mm



ELECTROLUX 054042

3247011 6-POLE TERMINAL BLOCK FV122 40A 600V
for cable max 6 mm²
operating temperature 150°C
nominal voltage 450 V



ELECTROLUX 046347

3247009 6-POLE TERMINAL BLOCK FV122/B 40A 600V
for cable max 6 mm²
operating temperature 150°C
nominal voltage 450 V



ELECTROLUX 005420

ELECTROLUX 058613



Suitable for:

ELECTROLUX



Suitable for:

Thermostats

3444121 MILLED GLAND FOR THERMOSTAT 9x1



ELECTROLUX 027061

3444072 SAFETY THERMOSTAT 126°C

manual reset
covered capillary 1730 mm
bulb \varnothing 6x129 mm
16A 250V
for Dishwasher conveyor type (ZANUSSI) - Series RT



ELECTROLUX 0E5086

3444396 SINGLE-PHASE SAFETY THERMOSTAT +130°C

covered capillary length 800 mm
bulb \varnothing 6x70 mm
for Dishwasher (ZANUSSI) LS3 - LS6
for Dishwasher conveyor type (ZANUSSI) CT92
for Dishwasher hood type (ZANUSSI) LS8



ELECTROLUX 046816

3444602 SINGLE-PHASE THERMOSTAT 0-85°C

for tank
covered capillary 600 mm
button bulb \varnothing 14x31 mm
16A 250V
D shaft \varnothing 6x4.6 mm
for Glasswasher/Cupwasher (ELETTRORBAR) S621 - S623
S624 - S626 - S631 - S633 - S634
for Glasswasher/Cupwasher (ZANUSSI) CRYSTAL11
CRYSTAL22 - LTB11 - LTB12 - LTB22



ELECTROLUX 069423

3444014 SINGLE-PHASE THERMOSTAT 30-90°C

capillary 1250 mm
bulb \varnothing 6x110 mm
16A 250V
for Dishwasher (ZANUSSI) LS50 - LS500 - LS52
LS75 - LS96
for Dishwasher hood type (ZANUSSI) LS1080 - LS720
LS860



ELECTROLUX 0L1633

ELECTROLUX 068012

ELECTROLUX 048266

ELECTROLUX 068582

ELECTROLUX 049243

3444215 GLAND FOR THERMOSTAT 12x1

for Dishwasher (ZANUSSI) LS50 - LS500 - LS52
LS540 - LS7
for Dishwasher conveyor type (ZANUSSI) CT92
for Dishwasher hood type (ZANUSSI) LS1080 - LS720
LS8 - LS860



ELECTROLUX 067899



Suitable for:

Suitable for:

3243139 O-RING 02025 EPDM

for Dishwasher (BONNET) INO3F
for Dishwasher (ZANUSSI) LS32 - LS360 - LS365
LS500 - LS540 - LS7
for Dishwasher conveyor type (ZANUSSI) CT92
for Dishwasher hood type (ZANUSSI) LS1080 - LS720
LS8 - LS860




ELECTROLUX 067898

ELECTROLUX 086109

3444018 SINGLE-PHASE THERMOSTAT 30-90°C

complete with auxiliary selector switch
D-shaped pin \varnothing 6x4.6 mm
covered capillary length 1000 mm - 16A 250V
bulb \varnothing 6x175 mm



ELECTROLUX 051142

3444754 SINGLE-PHASE THERMOSTAT 50-98°C

D-shaped pin 6x4.6 mm
covered capillary length 2400 mm - 16A 230V
bulb \varnothing 3x335 mm - with stuffing gland M9x1



ELECTROLUX 0H6440

3444395 SINGLE-PHASE THERMOSTAT 82°C

capillary 900 mm
bulb \varnothing 6x150 mm
15A 400V
for Glasswasher/Cupwasher (ZANUSSI) WT1 - WT2



ELECTROLUX 0L2122

ELECTROLUX 049255

3444215 GLAND FOR THERMOSTAT 12x1

for Dishwasher (ZANUSSI) LS50 - LS500 - LS52
LS540 - LS7
for Dishwasher conveyor type (ZANUSSI) CT92
for Dishwasher hood type (ZANUSSI) LS1080 - LS720
LS8 - LS860



ELECTROLUX 067899

3243139 O-RING 02025 EPDM

for Dishwasher (BONNET) INO3F
for Dishwasher (ZANUSSI) LS32 - LS360 - LS365
LS500 - LS540 - LS7
for Dishwasher conveyor type (ZANUSSI) CT92
for Dishwasher hood type (ZANUSSI) LS1080 - LS720
LS8 - LS860



ELECTROLUX 067898

ELECTROLUX 086109



Suitable for:

ELECTROLUX



Suitable for:

3444065 THERMOSTAT 30°-110°C
for Dishwasher conveyor type (ZANUSSI) - Series RT



ELECTROLUX 0E5032

ELECTROLUX 0K7035

3444330 THREE-PHASE THERMOSTAT 0-90°C
for tank
covered capillary 1000 mm
bulb \varnothing 6x220 mm
10A 400V
with adjusting screw
for Dishwasher (MARENO) MLS30 - MLS31
for Glasswasher/Cupwasher (ZANUSSI) LB1 - LB2



ELECTROLUX 049191

3243139 O-RING 02025 EPDM
for Dishwasher (BONNET) INO3F
for Dishwasher (ZANUSSI) LS32 - LS360 - LS365
LS500 - LS540 - LS7
for Dishwasher conveyor type (ZANUSSI) CT92
for Dishwasher hood type (ZANUSSI) LS1080 - LS720
LS8 - LS860



ELECTROLUX 067898

ELECTROLUX 086109

3444780 THREE-PHASE THERMOSTAT 30-95°C
covered capillary 900 mm
bulb \varnothing 6x200 mm
16A 230V
D shaft \varnothing 6x4.6 mm
for Dishwasher (ZANUSSI) LS360



ELECTROLUX 046413

3444215 GLAND FOR THERMOSTAT 12x1
for Dishwasher (ZANUSSI) LS50 - LS500 - LS52
LS540 - LS7
for Dishwasher conveyor type (ZANUSSI) CT92
for Dishwasher hood type (ZANUSSI) LS1080 - LS720
LS8 - LS860



ELECTROLUX 067899

3444331 THREE-PHASE THERMOSTAT +140°C
with manual reset
covered capillary 1000 mm
bulb \varnothing 6x90 mm
10A 400V
for boiler



ELECTROLUX 004862

ELECTROLUX 059079



Suitable for:

3444221 THREE-PHASE THERMOSTAT 140°C
 with manual reset
 covered capillary length 1000 mm - 10A 400V
 bulb \varnothing 6x175 mm
 for Dishwasher (ZANUSSI) LS7
 for Dishwasher hood type (ZANUSSI) LS1080 - LS860



ELECTROLUX 051644

Suitable for:

3444016 THREE-PHASE THERMOSTAT 30-90°C
 capillary 900 mm
 bulb \varnothing 6x215 mm
 10A 400V
 with temperature adjusting screw
 for Dishwasher (ZANUSSI) LS360 - LS365 - LS4
 LS510 - LS520 - LS521



ELECTROLUX 0C5345

ELECTROLUX 045169

Timers

3322194 CONTROLLER D94 3 CAMS
 for rinsing
 cycle 240 seconds
 rinse 18 seconds
 230V 50/60HZ
 D-shaped pin \varnothing 6x4.6 mm
 for Dishwasher (ADLER) A350 - F1000 - F1201 - F350
 F650
 for Dishwasher (WHIRLPOOL) F360 - F650
 for Dishwasher hood type (ADLER) A1080
 for Dishwasher hood type (WHIRLPOOL) F1000 - F1201



ELECTROLUX 0R0015

3241350 BLACK KNOB \varnothing 45 mm
 D shaft hole 6x4.6 mm
 for Dishwasher (ADLER) DS41
 for Glasswasher/Cupwasher (ADLER) CF40 - DSF103



3250215 TIMER KNOB SPRING



3322605 CONTROLLER 9449 1 CAM
 cycle 40 seconds
 230V 50HZ
 without shaft
 for Dishwasher (ELETTROBAR) S653
 for Glasswasher/Cupwasher (BONNET) VR1000R
 VR1000RAD - VR1500C - VR1500CAD
 for Glasswasher/Cupwasher (ELETTROBAR) S623 - S626
 S633 - S636 - 11FD - 11RD
 for Glasswasher/Cupwasher (ZANUSSI) CRYSTAL11
 CRYSTAL22 - LTB11 - LTB12 - LTB22



ELECTROLUX 069420

3322115 REGENERATION CONTROLLER 1 CAM
 cycle 40 seconds- 230V 50HZ
 for Glasswasher/Cupwasher (ELETTROBAR) E35 - E40
 E41 - E42 - E45





Suitable for:

ELECTROLUX



Suitable for:

3322322 PROGRAMMER 11904 F1 4 CAMS 15 MIN.

230V 50/60Hz
without pin
for Dishwasher



ELECTROLUX 085329

3322034 PROGRAMMER 9444 3 CAMS

cycle 120 seconds
rinse 14 seconds
220V 50/60HZ
clockwise rotation
D shaft \varnothing 6x4.6 mm
for Glasswasher/Cupwasher (ADLER) B100 - B101
B102 - B103 - B201 - B203 - CF35 - CF40
COMPACT - DSF101 - DSF103 - DS101 - DS103
DS201 - DS203
for Glasswasher/Cupwasher (WHIRLPOOL) D110 - D111
D210 - D211 - F30 - F300 - F312 - F35 - F40
F41



ELECTROLUX 070310

3446208 CONTROLLER SHAFT

for Glasswasher/Cupwasher (ADLER) CF40 - DSF103



3241350 BLACK KNOB \varnothing 45 mm

D shaft hole 6x4.6 mm
for Dishwasher (ADLER) DS41
for Glasswasher/Cupwasher (ADLER) CF40 - DSF103



3250215 TIMER KNOB SPRING



3322069 TIMER D94 4 CAMS

cycle 180 seconds
240V 50/60Hz
D-shaft \varnothing 6x4,6 mm
for Dishwasher (ZANUSSI) LS4 - LS510 - LS520
LS521



ELECTROLUX 047497

ELECTROLUX 048881

3322609 TIMER PWE5 3 CAMS

without shaft
previous model 600/636/5200
for Dishwasher (COLGED) STEEL 41
for Dishwasher (ELETTROBAR) S651 - S653 - S655
for Glasswasher/Cupwasher (ELETTROBAR) E35 - S621
S623 - S624 - S626 - S631 - S633 - S634 - S636
11F - 11FD - 11R - 11RD
for Glasswasher/Cupwasher (ZANUSSI) CRYSTAL11
CRYSTAL22 - LTB11 - LTB12 - LTB22



ELECTROLUX 069419

ELECTROLUX 069669

ELECTROLUX 069926



ELECTROLUX



Suitable for:

3322171 **TIMER P25 5 CAMS**
1st cycle 180 seconds
2nd cycle 6 seconds
230V 50/60HZ
for Dishwasher (ZANUSSI) LS7 - WT40



ELECTROLUX 048303

Suitable for:

3322173 **TIMER P25 5 CAMS**
1st cycle 120 seconds
2nd cycle 6 seconds
230V 50/60HZ
for Dishwasher hood type (ZANUSSI) HT800
HYDRA800 - LS8



ELECTROLUX 048647

3322174 **TIMER P25 6 CAMS**
1st cycle 2 minutes
2nd cycle 6 seconds
230V 50/60HZ
for Dishwasher hood type (ZANUSSI) LS10 - LS12



ELECTROLUX 048264

ELECTROLUX 048591

3322238 **TIMER P25 7 CAMS**
2 motors 230V 50/60Hz
cycle: 6" - 6'
for Glasswasher/Cupwasher (ZANUSSI) GW1 - GW2
LB1 - LB2 - Z1 - Z2



ELECTROLUX 049054

3446040 **TIMER T23 24V 50Hz**
electronic multiscale timer
programmable time scale 120h-12h-120'-12'-
120"-12"
2 changeover relays contact capacity 6(4)A 250V
for LP480



ELECTROLUX 075659

3322353 **TIMER 7 CAMS 230V 50Hz**
for Glasswasher/Cupwasher (ZANUSSI) LB1 - LB2



ELECTROLUX 049256

3446022 **TIMER 900-904-1114**
for LS360-LS365



ELECTROLUX 068671



Suitable for:

ELECTROLUX



Suitable for:

Tools and equipment

3394952 DIGITAL THERMOMETER PDT300/1C

probe protected by its case
range -50+150°C/-58+300°F
resolution 0,1° - precision \pm 1°C
auto power-off
memory button - ON/OFF button



ELECTROLUX 0S2040

Vibration insulators for motors

3046028 VIBRATION BUFFER \varnothing 25x20 M6

for Dishwasher (COMENDA) FC3E - FC3M - FC4E - FC4M
for Dishwasher conveyor type (COMENDA) ACS181
ACS182 - ACS201 - ACS202 - ACS241 - ACS242
Series NL
for Dishwasher hood type (COMENDA) C1000E - C1300E
LC1200 - LC412 - LC700 - LC900



ELECTROLUX 0KI589

Wash and rinse arms and accessories

3243150 ARM ASSEMBLY BOSS

wash and rinse
for Dishwasher (ZANUSSI) CRYSTAL51 - CRYSTAL52
LS505 - LS510 - LS520 - LS521



ELECTROLUX 047990

3243157 LOCKING SCREW RETAINER FOR BOSS



ELECTROLUX 047991

3243179 END CAP

for Dishwasher (ZANUSSI) LS3 - LS5



ELECTROLUX 0A6109

ELECTROLUX 047471

ELECTROLUX 049296

3060608 O-RING 03050 EPDM





ELECTROLUX



Suitable for:

1186223 O-RING 02056 EPDM

for Dishwasher (ADLER) CF50 - DS400 - DS410
DS600
for Dishwasher (WHIRLPOOL) F360 - F650
for Dishwasher hood type (ADLER) CF1000 - CF1201A
DS1200
for Dishwasher hood type (WHIRLPOOL) F1000
F1201A
for Glasswasher/Cupwasher (ADLER) CF35 - CF40
for Glasswasher/Cupwasher (WHIRLPOOL) F30 - F35
F40 - F400 - F41 - F410



ELECTROLUX 046223

ELECTROLUX 047473

ELECTROLUX 070346

3243896 RINSING NOZZLE 210 mm

for Dishwasher (ZANUSSI) CRYSTAL51 - CRYSTAL52
LS3 - LS5 - LS510 - LS520 - LS521



ELECTROLUX 0A6159

ELECTROLUX 048142

ELECTROLUX 049298

3243151 WASH ARM

for Dishwasher (ZANUSSI) CRYSTAL51 - CRYSTAL52
LS505 - LS510 - LS520 - LS521



ELECTROLUX 047470

3743368 ARM COUPLING SLEEVE

for Dishwasher conveyor type (ZANUSSI) - Series RT
Series WT




ELECTROLUX 0E5507

ELECTROLUX 0KL044

Suitable for:

3243154 RINSE ARM END CAP



ELECTROLUX 0A6160

ELECTROLUX 047475

3243879 RINSING NOZZLE 220 mm

for Dishwasher (ZANUSSI) LS3 - LS5



ELECTROLUX 047989

ELECTROLUX 049297

3743847 BOTTOM JET SUPPORT

for Dishwasher (ZANUSSI) C32 - C33 - C55A - LS32
LS33 - LV32 - LV33



ELECTROLUX 049290



Suitable for:

3243651 COMPLETE RINSE ARM

for Glasswasher/Cupwasher (ELETTROBAR) S621 - S623
S624 - S626 - S631 - S633 - S634 - 11F - 11FD



ELECTROLUX 069577

3243653 LEFTHAND RINSE ARM



3243608 RINSE JET

for Dishwasher (ELETTROBAR) S651 - S654 - S830
S835
for Glasswasher/Cupwasher (BONNET) VR1000R
VR1000RAD - VR1500C - VR1500CAD - VR1500D
for Glasswasher/Cupwasher (ELETTROBAR) S624 - S626
S634 - S636 - 10F - 11F - 11FD - 11R - 11RD
22F - 40F - 44F



ELECTROLUX 069451

3243600 COMPLETE WASH AND RINSE ARM

for Glasswasher/Cupwasher (ELETTROBAR) 10F - 11F
11FD



ELECTROLUX 069576

Suitable for:

3186605 CAP GASKET

for Glasswasher/Cupwasher (ELETTROBAR) E35 - E40
NIAGARA35 - NIAGARA40



3243607 RING NUT FOR RINSE JET

for Dishwasher (ELETTROBAR) S651 - S835
for Dishwasher hood type (ELETTROBAR) S850 - 66
for Glasswasher/Cupwasher (BONNET) VR1000R
VR1000RAD - VR1500C - VR1500CAD - VR1500D
for Glasswasher/Cupwasher (ELETTROBAR) E35 - E40
S621 - S623 - S624 - S626 - S631 - S633 - S634
S636 - 10F - 11F - 11FD - 11R - 11RD - 22F
40F - 44F



ELECTROLUX 069450

3243612 CENTER CONDUIT

for Glasswasher/Cupwasher (ELETTROBAR) 10F - 11F
11FD





ELECTROLUX



Suitable for:

3243609 GASKET CENTER CONDUIT
for Glasswasher/Cupwasher (ELETTROBAR) 10F - 11F
11FD



Suitable for:

3243602 LEFTHAND WASH ARM
for Glasswasher/Cupwasher (BONNET) VR1500C
VR1500CAD
for Glasswasher/Cupwasher (ELETTROBAR) S621 - S623
S631 - S633 - 10F - 11F - 11FD



3243638 LOWER WASH ARM ASSEMBLY BOSS
for Glasswasher/Cupwasher (BONNET) VR1500C
VR1500CAD
for Glasswasher/Cupwasher (ELETTROBAR) E45 - E46
S621 - S623 - S631 - S633 - 10F - 11F - 11FD
45F - 45FD - 460F - 460FD



3243616 LOWER WASH ARM ASSY MANIFOLD WITH HOLES



ELECTROLUX 069452

3243642 LOWER WASH WHEEL MANIFOLD (CLOSED)



1186803 O-RING 02037 EPDM
for Dishwasher (ADLER) DS400 - DS410
for Dishwasher (BONNET) INO3F
for Dishwasher (COMENDA) F20 - F45 - F50 - F55
F65 - F80
for Dishwasher (WHIRLPOOL) F360 - F650
for Dishwasher (ZANUSSI) LS32 - LS360 - LS365
for Dishwasher hood type (WHIRLPOOL) F1000
F1201A
for Glasswasher/Cupwasher (ADLER) CF35 - CF40
for Glasswasher/Cupwasher (COMENDA) B10 - B15
B15T - B20
for Glasswasher/Cupwasher (ELETTROBAR) E35 - E40
MISTRAL40 - NIAGARA35
for Glasswasher/Cupwasher (HOONVED) CR43 - CR48
C35 - C43 - C43E - C46E - C48



ELECTROLUX 046376



Suitable for:

3243607 RING NUT FOR RINSE JET

for Dishwasher (ELETTROBAR) S651 - S835
for Dishwasher hood type (ELETTROBAR) S850 - 66
for Glasswasher/Cupwasher (BONNET) VR1000R
VR1000RAD - VR1500C - VR1500CAD - VR1500D
for Glasswasher/Cupwasher (ELETTROBAR) E35 - E40
S621 - S623 - S624 - S626 - S631 - S633 - S634
S636 - 10F - 11F - 11FD - 11R - 11RD - 22F
40F - 44F



ELECTROLUX 069450

3243608 RINSE JET

for Dishwasher (ELETTROBAR) S651 - S654 - S830
S835
for Glasswasher/Cupwasher (BONNET) VR1000R
VR1000RAD - VR1500C - VR1500CAD - VR1500D
for Glasswasher/Cupwasher (ELETTROBAR) S624 - S626
S634 - S636 - 10F - 11F - 11FD - 11R - 11RD
22F - 40F - 44F



ELECTROLUX 069451

3243610 WASH ARM ASSEMBLY LOWER BOSS SPINDLE

for Dishwasher (HOBART) ECOMAX501A
for Glasswasher/Cupwasher (BONNET) VR1500C
VR1500CAD
for Glasswasher/Cupwasher (ELETTROBAR) E45 - E46
S621 - S623 - S631 - S633 - 10F - 11F - 11FD
45F - 45FD - 460F - 460FD



ELECTROLUX 069445

ELECTROLUX



Suitable for:

3243605 RING NUT FOR WASH JET

for Dishwasher (ELETTROBAR) S651 - S653 - S654
S655 - S810 - S815 - S830 - S835
for Glasswasher/Cupwasher (BONNET) VR1000R
VR1000RAD - VR1500C - VR1500CDA
for Glasswasher/Cupwasher (ELETTROBAR) E35 - E40
E40H - E45 - E46 - R499 - R501 - R503 - S621
S623 - S624 - S626 - S631 - S633 - S634 - S636
10F - 11F - 11FD - 11R - 11RD - 45F - 45FD
460F - 460FD



ELECTROLUX 069448

3243615 SPINDLE FOR MANIFOLD



3243606 WASH JET

for Glasswasher/Cupwasher (BONNET) VR1000R
VR1000RAD - VR1500C - VR1500CAD
for Glasswasher/Cupwasher (ELETTROBAR) E35 - E40
E40H - E45 - E46 - NIAGARA40 - 10F - 11F
11FD - 45F - 45FD - 460F - 460FD





Suitable for:

3743127 COMPLETE WASH/RINSE ARM ASSEMBLY
length 380 mm
for Dishwasher (ADLER) CF235 - DL240 - DS401
DS412
for Glasswasher/Cupwasher (ADLER) CF35 - CF40
COMPACT
for Glasswasher/Cupwasher (WHIRLPOOL) F30 - F35
F40 - F400 - F41 - F410



ELECTROLUX 070349

Suitable for:

3743119 ARM ASSEMBLY RING NUT
for Dishwasher (ADLER) CF50 - DL240 - DS401
DS412 - DS600
for Dishwasher (WHIRLPOOL) F360 - F650
for Dishwasher hood type (ADLER) CF1000 - CF1201A
DS1200
for Dishwasher hood type (WHIRLPOOL) F1000
F1201A
for Glasswasher/Cupwasher (ADLER) CF35 - CF40
COMPACT
for Glasswasher/Cupwasher (WHIRLPOOL) F30 - F35
F40 - F400 - F41 - F410



3315006 FLANGE WATER SPREADING
for Dishwasher (ZANUSSI) LS500 - LS540 - LS541
for Dishwasher hood type (ZANUSSI) LSE720 - LSE721
652120Z



ELECTROLUX 045492

ELECTROLUX 046543

3315008 END CAP FOR FLANGE
for Dishwasher (ZANUSSI) LS500 - LS540 - LS541
for Dishwasher hood type (ZANUSSI) LSE720 - LSE721
652120Z



ELECTROLUX 066038

3315009 GASKET FOR FLANGE
for Dishwasher (ZANUSSI) LS500 - LS540 - LS541
for Dishwasher hood type (ZANUSSI) LSE720 - LSE721
652120Z



ELECTROLUX 061488

3501063 GASKET FOR NOZZLE



ELECTROLUX 046271



Suitable for:

ELECTROLUX



3243181 LOWER RINSE ARM



ELECTROLUX 048133

3243182 RINSE JET



ELECTROLUX 048135

3243165 LOWER WASH ARM ASSEMBLY SUPPORT
for Dishwasher (ZANUSSI) CRYSTAL51 - CRYSTAL52
LS505 - LS510 - LS520 - LS521



ELECTROLUX 048145

Suitable for:

1186352 O-RING 02050 EPDM
for Dishwasher (AFI) A600
for Dishwasher (DIHR) C40CF - GASTRO450
GASTRO500 - GASTRO750 - GASTRO900 - GS45
GS50
for Dishwasher (EUROSYSTEM) PRO400
for Dishwasher (FAEMA) 1201
for Dishwasher (HILTA) S41 - S42
for Dishwasher (IME OMNIWASH) 4Q82
for Dishwasher (KROMO) K35 - K37
for Dishwasher (NOSEM) C5000 - C5010 - C5020
NC501
for Dishwasher (NUOVA SIMONELLI) KIARA6
for Dishwasher (OLIS) OLG550 - OLG585
for Dishwasher (SAB ITALIA) C50H - 1200
for Dishwasher (SILANOS) 200 - 300 - 400 - 600



ELECTROLUX 047986

3243166 EPDM O-RING GASKET 03237



ELECTROLUX 047462



ELECTROLUX



Suitable for:

3243069 O-RING OR 02068 EPDM

for Dishwasher (COMENDA) F20 - F45 - F50 - F55
 F65 - F80
 for Glasswasher/Cupwasher (COMENDA) BC15 - B15T
 for Glasswasher/Cupwasher (HOONVED) C35 - C43
 C43E - C46E - C48
 for Pan washing machine (COMENDA) LP360



ELECTROLUX 047987

1186352 O-RING 02050 EPDM

for Dishwasher (AFI) A600
 for Dishwasher (DIHR) C40CF - GASTRO450
 GASTRO500 - GASTRO750 - GASTRO900 - GS45
 GS50
 for Dishwasher (EUROSYSTEM) PRO400
 for Dishwasher (FAEMA) 1201
 for Dishwasher (HILTA) S41 - S42
 for Dishwasher (IME OMNIWASH) 4Q82
 for Dishwasher (KROMO) K35 - K37
 for Dishwasher (NOSEM) C5000 - C5010 - C5020
 NC501
 for Dishwasher (NUOVA SIMONELLI) KIARA6
 for Dishwasher (OLIS) OLG550 - OLG585
 for Dishwasher (SAB ITALIA) C50H - 1200
 for Dishwasher (SILANOS) 200 - 300 - 400 - 600



ELECTROLUX 047986

3243162 SPINDLE FOR ARM

for Dishwasher (ZANUSSI) CRYSTAL51 - CRYSTAL52
 LS505 - LS510 - LS520 - LS521



ELECTROLUX 047464

Suitable for:

1186803 O-RING 02037 EPDM

for Dishwasher (ADLER) DS400 - DS410
 for Dishwasher (BONNET) INO3F
 for Dishwasher (COMENDA) F20 - F45 - F50 - F55
 F65 - F80
 for Dishwasher (WHIRLPOOL) F360 - F650
 for Dishwasher (ZANUSSI) LS32 - LS360 - LS365
 for Dishwasher hood type (WHIRLPOOL) F1000
 F1201A
 for Glasswasher/Cupwasher (ADLER) CF35 - CF40
 for Glasswasher/Cupwasher (COMENDA) B10 - B15
 B15T - B20
 for Glasswasher/Cupwasher (ELETTOBAR) E35 - E40
 MISTRAL40 - NIAGARA35
 for Glasswasher/Cupwasher (HOONVED) CR43 - CR48
 C35 - C43 - C43E - C46E - C48



ELECTROLUX 046376

3061007 O-RING 04362 EPDM

for Dishwasher hood type (WINTERHALTER) GS502



ELECTROLUX 045462

3243136 WASHER



ELECTROLUX 047282



Suitable for:

3243192 LOWER WASH ARM ASSEMBLY SUPPORT
for Dishwasher (ZANUSSI) LS62 - LS63 - LS64 - LS7
for Dishwasher hood type (ZANUSSI) LS8



ELECTROLUX 0L1628 ELECTROLUX 048329 ELECTROLUX 048819

3243194 LOCKING NUT
for Dishwasher (ZANUSSI) LS62 - LS63 - LS64 - LS7
for Dishwasher hood type (ZANUSSI) LS8



ELECTROLUX 048330

Suitable for:

3243195 GASKET FOR JET SUPPORT
for Dishwasher (ZANUSSI) LS62 - LS63 - LS64 - LS7
for Dishwasher hood type (ZANUSSI) HT1000 - HT1200
LS10 - LS12 - LS8 - WT60



ELECTROLUX 048236

3243193 SHUTTER FOR ARM
for Dishwasher (ZANUSSI) LS62 - LS63 - LS64 - LS7
for Dishwasher hood type (ZANUSSI) LS10 - LS12
LS8



ELECTROLUX 048820

3243199 LOWER WASH ARM ASSEMBLY SUPPORT
for Dishwasher hood type (ZANUSSI) LS10 - LS12
LS8



ELECTROLUX 048235

3243193 SHUTTER FOR ARM
for Dishwasher (ZANUSSI) LS62 - LS63 - LS64 - LS7
for Dishwasher hood type (ZANUSSI) LS10 - LS12
LS8



ELECTROLUX 048820

3243195 GASKET FOR JET SUPPORT
for Dishwasher (ZANUSSI) LS62 - LS63 - LS64 - LS7
for Dishwasher hood type (ZANUSSI) HT1000 - HT1200
LS10 - LS12 - LS8 - WT60



ELECTROLUX 048236

3243202 SUPPORT LOCKING NUT
for Dishwasher hood type (ZANUSSI) HT1000 - HT1200
LS10 - LS12 - WT60



ELECTROLUX 048237

3243878 NOZZLE BOSS
for Dishwasher (ZANUSSI) LS3 - LS5



ELECTROLUX 049293

3243179 END CAP
for Dishwasher (ZANUSSI) LS3 - LS5



ELECTROLUX 0A6109

ELECTROLUX 047471

ELECTROLUX 049296



ELECTROLUX



Suitable for:

3243195 GASKET FOR JET SUPPORT

for Dishwasher (ZANUSSI) LS62 - LS63 - LS64 - LS7
for Dishwasher hood type (ZANUSSI) HT1000 - HT1200
LS10 - LS12 - LS8 - WT60



ELECTROLUX 048236

1186223 O-RING 02056 EPDM

for Dishwasher (ADLER) CF50 - DS400 - DS410
DS600
for Dishwasher (WHIRLPOOL) F360 - F650
for Dishwasher hood type (ADLER) CF1000 - CF1201A
DS1200
for Dishwasher hood type (WHIRLPOOL) F1000
F1201A
for Glasswasher/Cupwasher (ADLER) CF35 - CF40
for Glasswasher/Cupwasher (WHIRLPOOL) F30 - F35
F40 - F400 - F41 - F410



ELECTROLUX 046223

ELECTROLUX 047473

ELECTROLUX 070346

3243896 RINSING NOZZLE 210 mm

for Dishwasher (ZANUSSI) CRYSTAL51 - CRYSTAL52
LS3 - LS5 - LS510 - LS520 - LS521



ELECTROLUX 0A6159

ELECTROLUX 048142

ELECTROLUX 049298

3243193 SHUTTER FOR ARM

for Dishwasher (ZANUSSI) LS62 - LS63 - LS64 - LS7
for Dishwasher hood type (ZANUSSI) LS10 - LS12
LS8



ELECTROLUX 048820

Suitable for:

3243194 LOCKING NUT

for Dishwasher (ZANUSSI) LS62 - LS63 - LS64 - LS7
for Dishwasher hood type (ZANUSSI) LS8



ELECTROLUX 048330

3243919 RINSE NOZZLE END CAP Ø 3/8"

for Dishwasher (ZANUSSI) LS3 - LS5



ELECTROLUX 049299

3243879 RINSING NOZZLE 220 mm

for Dishwasher (ZANUSSI) LS3 - LS5



ELECTROLUX 047989

ELECTROLUX 049297

3528021 STAINLESS STEEL CIRCLIP A-17 UNI 7435

for Dishwasher (ZANUSSI) LS62 - LS63 - LS7
for Dishwasher hood type (ZANUSSI) LS8



ELECTROLUX 048979



Suitable for:

3243136 WASHER



ELECTROLUX 047282

3243880 WASHING NOZZLE 195 mm
for Dishwasher (ZANUSSI) LS3 - LS5



ELECTROLUX 049295

3743207 PLUG FOR WASH/RINSE ARM ASSY



ELECTROLUX 066396

3743188 RINSE ARM
overall length 534 mm
for Dishwasher conveyor type (ZANUSSI) - Series RT
Series WT



ELECTROLUX 0E5506

3243885 RINSE ARM ASSEMBLY 400 mm
for Glasswasher/Cupwasher (ZANUSSI) GW1 - GW2
LB1 - LB2 - WT1 - WT2 - Z1 - Z2



ELECTROLUX 0L2096

ELECTROLUX 049049

ELECTROLUX



Suitable for:

3743509 WASHER PROTECTION
for Dishwasher (ZANUSSI) LS3 - LS5 - WT302 - WT303



ELECTROLUX 049294

3743367 RING NUT FOR WASH ARM ASSEMBLY BOSS
for Pan washing machine (ZANUSSI) LO/E250
LO/E480 - LO480Z - PLO250E - PLO480/E
PLO480V



ELECTROLUX 075627

3743189 RINSE NOZZLE TYPE 9504
for Dishwasher conveyor type (ZANUSSI) - Series RT
Series WT



ELECTROLUX 0E5148

3243886 RINSE ARM ASSEMBLY CAP
for Glasswasher/Cupwasher (ZANUSSI) GW1 - GW2
LB1 - LB2 - WT1 - WT2 - Z1 - Z2



ELECTROLUX 049048



ELECTROLUX



Suitable for:

3243887 RINSE ARM ASSEMBLY SPINDLE
for Glasswasher/Cupwasher (ZANUSSI) GW1 - GW2
LB1 - LB2 - WT1 - WT2 - Z1 - Z2



ELECTROLUX 049046

Suitable for:

3243888 WASHER FOR SPINDLE
for Glasswasher/Cupwasher (ZANUSSI) GW1 - GW2
LB1 - LB2 - WT1 - WT2 - Z1 - Z2



ELECTROLUX 049047

3243206 RINSE ARM ASSEMBLY 475 mm
for Dishwasher (ZANUSSI) LS62 - LS63 - LS64 - LS7
for Dishwasher hood type (ZANUSSI) LS8



ELECTROLUX 0L2095

ELECTROLUX 048542

ELECTROLUX 048716

3243159 HOSE-END ELBOW \varnothing 1/4"
for Dishwasher (ZANUSSI) CRYSTAL51 - CRYSTAL52
LS505 - LS510 - LS520 - LS521



ELECTROLUX 046375

3743846 RINSE ARM ASSEMBLY
for Dishwasher (ZANUSSI) LS61 - LS62 - LS63 - LS64
LS7
for Dishwasher hood type (ZANUSSI) LS10 - LS12
LS8



ELECTROLUX 049152

3243118 SPINDLE FOR UPPER WASH ARM ASSEMBLY
for Dishwasher (ZANUSSI) HYDRA700 - LS7 - WT40
for Dishwasher hood type (ZANUSSI) HT800
HYDRA800 - LS8



ELECTROLUX 048333

3243207 END CAP
for Dishwasher (ZANUSSI) LS62 - LS63 - LS64 - LS7
for Dishwasher hood type (ZANUSSI) HT1000 - LS10
LS12 - LS8 - LV1200 - WT60



ELECTROLUX 048714

3243160 O-RING 0174 EPDM



ELECTROLUX 046366

3243209 SPINDLE FOR ARM
for Dishwasher (ZANUSSI) LS62 - LS63 - LS64 - LS7
for Dishwasher hood type (ZANUSSI) HT1000 - HT1200
LS10 - LS12 - LS8 - WT60



ELECTROLUX 048290

3243158 SUPPORT FOR ARM
for Dishwasher (ZANUSSI) CRYSTAL51 - CRYSTAL52
LS360 - LS505 - LS510 - LS520 - LS521 - LS540
LS7
for Dishwasher hood type (ZANUSSI) LS8



ELECTROLUX 0L0695

ELECTROLUX 046368



Suitable for:

3243119 UPPER RING NUT

for Dishwasher (ZANUSSI) LS7 - WT40
for Dishwasher hood type (ZANUSSI) HT800
HYDRA800 - LS8



ELECTROLUX 048650

ELECTROLUX



Suitable for:

3243208 WASHER FOR ARM

for Dishwasher (ZANUSSI) LS62 - LS63 - LS64 - LS7
for Dishwasher hood type (ZANUSSI) LS8



ELECTROLUX 048632

3243137 RINSE JET

for Dishwasher (BONNET) INO3F
for Dishwasher (ZANUSSI) LS32 - LS360 - LS365
LS367 - LS540
for Dishwasher hood type (ZANUSSI) LSE720 - LS1080
LS860



ELECTROLUX 046272

3243190 RINSE JET


for Dishwasher conveyor type (ZANUSSI) CT140
CT190 - CT192 - CT92



ELECTROLUX 046860

3243191 O-RING 02125 EPDM

for Dishwasher conveyor type (ZANUSSI) CT140
CT190 - CT192 - CT92



ELECTROLUX 046861

3243138 RINSE JET COUNTER FLANGE

5CF11B-CT92-CT140-CT141-CT142-CT190-CT191
for Dishwasher (BONNET) INO3F
for Dishwasher (ZANUSSI) LS32 - LS360 - LS365
LS367 - LS540
for Dishwasher hood type (ZANUSSI) LSE720 - LS1080
LS860



ELECTROLUX 046273

3743315 RINSE ROD

for Dishwasher (ADLER) D111
for Glasswasher/Cupwasher (ADLER) B100 - B101
B102 - B103 - DS101 - DS103 - DS11 - DS13
for Glasswasher/Cupwasher (WHIRLPOOL) D110



ELECTROLUX 0HA043



Suitable for:

Suitable for:

3243131 SPINDLE FOR WASH ARM ASSEMBLY
for Dishwasher (ZANUSSI) LS360 - LS365 - LS540
for Dishwasher hood type (ZANUSSI) LSE720




ELECTROLUX 046363

3243145 SUPPORT FOR ARM
for Dishwasher hood type (ZANUSSI) LS1080 - LS860



ELECTROLUX 046547

3743204 THREADED PLUG FEMALE 1"
for Dishwasher conveyor type (ZANUSSI) - Series RT



ELECTROLUX 0E5016

3743205 UPPER JETS SUPPORT
for Dishwasher (ZANUSSI) LS360 - LS365 - LS540
for Dishwasher hood type (ZANUSSI) LSE720



ELECTROLUX 0L0901

3315001 WASH ARM
for Dishwasher (ZANUSSI) LS500 - LS501



ELECTROLUX 065502

3243159 HOSE-END ELBOW \varnothing 1/4"
for Dishwasher (ZANUSSI) CRYSTAL51 - CRYSTAL52
LS505 - LS510 - LS520 - LS521



ELECTROLUX 046375

3743673 TOP WASH ARM ASSEMBLY SUPPORT
for Dishwasher hood type (ZANUSSI) LS9 - WT55



ELECTROLUX 0L0051

3243185 UPPER WASH ARM ASSEMBLY SUPPORT



ELECTROLUX 048128

3186184 EPDM O-RING GASKET 0147
for Glasswasher/Cupwasher (MACH) MB235LI - MB240LI
MB510E - MB510ER - MB520 - MB530 - MB535
MB630 - MB920E - MB920ER - MB930 - MGL40



ELECTROLUX 065506



Suitable for:

3315004 WASH JET
for Dishwasher (ZANUSSI) LS500 - LS501



ELECTROLUX 065507

3743369 WASH ARM
for Glasswasher/Cupwasher (ZANUSSI) GW1 - GW2
LB1 - LB2



ELECTROLUX 049087

ELECTROLUX 049946

3743316 WASH ARM ASSEMBLY CAP
for Dishwasher (ZANUSSI) LS7
for Dishwasher hood type (ZANUSSI) LS10 - LS8



ELECTROLUX 048289

3243881 WASH ARM ASSEMBLY 410 mm
for Glasswasher/Cupwasher (ZANUSSI) GW1 - GW2
LB1 - LB2 - WT1 - WT2 - Z1 - Z2



ELECTROLUX 049044

3186433 FLAT GASKET ø 50 mm



ELECTROLUX 049038

ELECTROLUX



Suitable for:

3315005 WASH JET SPINNER
for Dishwasher (ZANUSSI) LS500 - LS501



ELECTROLUX 066896

3743849 WASH COLUMN
for Glasswasher/Cupwasher (ZANUSSI) GW1 - GW2
LB1 - LB2



ELECTROLUX 049945

3243135 WASH ARM ASSEMBLY END CAP
for Dishwasher (BONNET) INO3F
for Dishwasher (ZANUSSI) LS360 - LS365 - LS540



ELECTROLUX 046266

3243882 BUSHING FOR WASH ARM ASSEMBLY



ELECTROLUX 049042

3243884 LOCKING RING NUT



ELECTROLUX 049039



Suitable for:

3243883 RING NUT FOR BUSHING



ELECTROLUX 049043

3243117 WASH ARM ASSEMBLY 480 mm
for Dishwasher (ZANUSSI) HT1000 - HT1200
HYDRA1000 - HYDRA1200 - LS10 - LS12 - WT60



ELECTROLUX 0L0597

3243195 GASKET FOR JET SUPPORT
for Dishwasher (ZANUSSI) LS62 - LS63 - LS64 - LS7
for Dishwasher hood type (ZANUSSI) HT1000 - HT1200
LS10 - LS12 - LS8 - WT60



ELECTROLUX 048236

3243209 SPINDLE FOR ARM
for Dishwasher (ZANUSSI) LS62 - LS63 - LS64 - LS7
for Dishwasher hood type (ZANUSSI) HT1000 - HT1200
LS10 - LS12 - LS8 - WT60



ELECTROLUX 048290

3243200 WASH ARM ASSEMBLY BOSS
for Dishwasher (ZANUSSI) LS62 - LS63 - LS64 - LS7
for Dishwasher hood type (ZANUSSI) HT1000 - HT1200
LS10 - LS12 - LS8 - WT60



ELECTROLUX 048401

Suitable for:

3243207 END CAP
for Dishwasher (ZANUSSI) LS62 - LS63 - LS64 - LS7
for Dishwasher hood type (ZANUSSI) HT1000 - LS10
LS12 - LS8 - LV1200 - WT60



ELECTROLUX 048714

3243197 SPACER
for Dishwasher hood type (ZANUSSI) LS8



ELECTROLUX 048238

ELECTROLUX 048645

ELECTROLUX 048931

3243202 SUPPORT LOCKING NUT
for Dishwasher hood type (ZANUSSI) HT1000 - HT1200
LS10 - LS12 - WT60



ELECTROLUX 048237

3243208 WASHER FOR ARM
for Dishwasher (ZANUSSI) LS62 - LS63 - LS64 - LS7
for Dishwasher hood type (ZANUSSI) LS8



ELECTROLUX 048632



Suitable for:

3243203 WASH ARM ASSEMBLY 485 mm
 for Dishwasher (ZANUSSI) LS62 - LS63 - LS64 - LS7
 for Dishwasher hood type (ZANUSSI) LS8



ELECTROLUX 0L0598

ELECTROLUX 048821

1186352 O-RING 02050 EPDM
 for Dishwasher (AFI) A600
 for Dishwasher (DIHR) C40CF - GASTRO450
 GASTRO500 - GASTRO750 - GASTRO900 - GS45
 GS50
 for Dishwasher (EUROSYSTEM) PRO400
 for Dishwasher (FAEMA) 1201
 for Dishwasher (HILTA) S41 - S42
 for Dishwasher (IME OMNIWASH) 4Q82
 for Dishwasher (KROMO) K35 - K37
 for Dishwasher (NOSEM) C5000 - C5010 - C5020
 NC501
 for Dishwasher (NUOVA SIMONELLI) KIARA6
 for Dishwasher (OLIS) OLG550 - OLG585
 for Dishwasher (SAB ITALIA) C50H - 1200
 for Dishwasher (SILANOS) 200 - 300 - 400 - 600



ELECTROLUX 047986

3243200 WASH ARM ASSEMBLY BOSS
 for Dishwasher (ZANUSSI) LS62 - LS63 - LS64 - LS7
 for Dishwasher hood type (ZANUSSI) HT1000 - HT1200
 LS10 - LS12 - LS8 - WT60



ELECTROLUX 048401

3243201 WASH ARM ASSEMBLY SPINDLE
 for Dishwasher (ZANUSSI) LS7
 for Dishwasher hood type (ZANUSSI) LS8



ELECTROLUX 048239

Suitable for:

3243204 GASKET FOR WASH ARM ASSEMBLY
 for Dishwasher (ZANUSSI) LS62 - LS63 - LS64



ELECTROLUX 048823

3743848 PIN FOR JET SUPPORT
 for Dishwasher (ZANUSSI) C32 - C33 - C55A - LS32
 LS33 - LS5



ELECTROLUX 049292

3243205 WASH ARM ASSEMBLY RING NUT
 for Dishwasher (ZANUSSI) LS62 - LS63 - LS64



ELECTROLUX 048824



Suitable for:

Suitable for:

3743845 WASH ARM CAP

for Dishwasher conveyor type (ZANUSSI) RT100
RT140 - RT142 - RT190 - RT270 - RT340 - RT480



ELECTROLUX 0E5997

3243188 WASH JET

for Dishwasher conveyor type (ZANUSSI) CT140
CT190 - CT192 - CT92



ELECTROLUX 046867

3243189 O-RING 02137 EPDM

for Dishwasher conveyor type (ZANUSSI) CT140
CT190 - CT192 - CT92



ELECTROLUX 046868

3243169 WASH MANIFOLD

for Dishwasher (ZANUSSI) CRYSTAL51 - CRYSTAL52
LS505 - LS510 - LS520 - LS521



ELECTROLUX 047461

3243171 DELIVERY TUBE




ELECTROLUX 047467

3243166 EPDM O-RING GASKET 03237



ELECTROLUX 047462

3243170 NUT FOR JET SPREADING



ELECTROLUX 046634

3243069 O-RING OR 02068 EPDM

for Dishwasher (COMENDA) F20 - F45 - F50 - F55
F65 - F80
for Glasswasher/Cupwasher (COMENDA) BC15 - B15T
for Glasswasher/Cupwasher (HOONVED) C35 - C43
C43E - C46E - C48
for Pan washing machine (COMENDA) LP360



ELECTROLUX 047987

3061007 O-RING 04362 EPDM

for Dishwasher hood type (WINTERHALTER) GS502



ELECTROLUX 045462



Suitable for:

3020082 OLIVE FOR 12 mm ø PIPE



ELECTROLUX 027478

ELECTROLUX 050682

ELECTROLUX 054979

ELECTROLUX



Suitable for:

3243897 WASH NOZZLE
for Dishwasher conveyor type (ZANUSSI) CT140



ELECTROLUX 047147

3243900 WASHING NOZZLE FASTENING CLAMP
for Dishwasher conveyor type (ZANUSSI) CT140



ELECTROLUX 047220

3243905 WASH NOZZLE
for Dishwasher conveyor type (ZANUSSI) CT140



ELECTROLUX 048061

3243917 FASTENING CLAMP
for Dishwasher conveyor type (ZANUSSI) CT140



ELECTROLUX 047221

Wash jets and accessories

3501092 COMPLETE RINSE JET
for Dishwasher (ADLER) B300
for Glasswasher/Cupwasher (ADLER) B100 - B101
B200 - DS101 - DS103 - DS201 - DS203
for Glasswasher/Cupwasher (WHIRLPOOL) D110 - D111
D210 - D211 - D310 - D311



ELECTROLUX 0HA048

ELECTROLUX 0HA129

3501091 COMPLETE WASH JET
for Dishwasher (ADLER) B300



ELECTROLUX 0HA132



Suitable for:

3501097 COMPLETE WASH JET
for Dishwasher (ADLER) A350
for Dishwasher hood type (ADLER) A1080



ELECTROLUX

Suitable for:

3501099 EXTERNAL RINSE JET
for Dishwasher (LAMBER)
till 31/12/96
01F - 040F - 045F - 050F - 075F
for Dishwasher hood type (LAMBER)
till 31/12/96
L25 - 015/24L
for Glasswasher/Cupwasher (LAMBER)
till 31/12/96
GS4 - GS5 - MINIBAR - SUPERQS - S200 - S240 - S280
S510



ELECTROLUX 005428

3501060 RINSE JET \varnothing 1/8"
for Pan washing machine (ZANUSSI) L0250 - L0480



ELECTROLUX 045753

3501094 WASH JET DEFLECTOR
for Dishwasher (ADLER) B40 - B41
for Glasswasher/Cupwasher (ADLER) B101F - B103F



ELECTROLUX 0HA102

Washing baskets and accessories

3055556 BASKET F/VARIOUS OBJECTS 500x500x100 mm
bottom with small holes
in plastic
useful internal height when stacked 76 mm



ELECTROLUX 048797

3055053 CUTLERY INSERT RACK 113x113x130 mm



ELECTROLUX 049070

3055004 CUTLERY RACK 110x110x124 mm
of yellow plastic



ELECTROLUX 0L1813(1PZ)

ELECTROLUX 069956

ELECTROLUX 865574

3055612 GLASS INSERT RACK - 10 Pcs
of plastic
modular plastic grid 385x385 mm



ELECTROLUX 069572

ELECTROLUX 960455



ELECTROLUX



Suitable for:

3055228 GLASS RACK \varnothing 345x345x120 mm
in plastic covered iron
for Glasswasher/Cupwasher (ELFRAMO) BD11 - SQ42



ELECTROLUX 0HA029

3055238 GLASS RACK 400x400x135 mm
in plastic covered wire



ELECTROLUX 0U1033

3055401 MISCELLANEOUS BASKET 500x500x100 mm
bottom with large holes
inner useful stacking height 80 mm



ELECTROLUX 048796

3055636 PLATE RACK 500x500x110 mm
for 12 SOUP PLATES \varnothing 240 mm
for 18 SHALLOW PLATES \varnothing 240 mm



ELECTROLUX 048795

ELECTROLUX 068692


3055615 RACK 382x382x95 mm
for GLASSES and DIFFERENT WARE
in plastic covered wire
for Dishwasher (ELETTROBAR) S611 - S613
for Glasswasher/Cupwasher (ELETTROBAR) S621 - S623
S631 - S633



ELECTROLUX 069563

Suitable for:

3055003 GLASS RACK \varnothing 520 mm
in plastic covered wire
for models LS50 - LS500 old series



ELECTROLUX 045098

ELECTROLUX 865566

3055010 GLASS RACK 500x500x120 mm
in plastic covered wire



ELECTROLUX 0S0058

3055002 PLATE RACK \varnothing 520 mm
in plastic covered wire
for Dishwasher (ZANUSSI) LS50 - LS500



ELECTROLUX 065565

ELECTROLUX 865565

3055616 RACK 382x382x200 mm
for GLASSES and DIFFERENT WARE
in plastic covered wire
for Dishwasher (ELETTROBAR) S611 - S613
for Glasswasher/Cupwasher (ELETTROBAR) S621 - S623
S631 - S633



ELECTROLUX 069564

3055638 RACK 500x500x110 mm
for 8 TRAYS 530x370 mm




ELECTROLUX 048890



Suitable for:

3055611 SAUCER RACK INSERT 320 mm
of plastic covered wire



ELECTROLUX 069562


Suitable for:

3055610 TEASPOON INSERT 105x105x135 mm
of plastic



ELECTROLUX 069561

3055011 22-PLATE RACK 500x500x100 mm
in plastic covered wire
for Dishwasher (ELFRAMO) MRS400 - MR1100 - MR800
MR904 - MR908 - SQT80 - SQ160 - SQ885



ELECTROLUX 0S0057

Water softeners and accessories

3010061 MANUAL WATER SOFTENER 12 L \varnothing 3/4"
stainless steel cylinder capacity 12 L
connection fittings 3/4"
dimensions: height 500 mm - \varnothing 185 mm
resin content 9 L
regeneration salt (NaCl-table salt) 1.5 Kg
for average dishwashers and dispensers
for 3-group coffee machines



ELECTROLUX 0S0330

3010018 GASKET FOR WATER SOFTENER LID
OR \varnothing 74x6.5 mm



3010019 LID HANDLE
for DVA models



3010023 BLACK BASE FOR GS WATER SOFTENER



3010021 INLET FILTER
for DVA models



3010022 OUTLET FILTER
for DVA models





Suitable for:

3010014 PIPE FITTING \varnothing 3/8" F x 3/4" M
for DVA models



3010015 PLASTIC TAP HANDLE
for DVA models



3010011 WATER INLET TAP \varnothing 3/8"
for DVA models



3010102 MANUAL WATER SOFTENER 12 L \varnothing 3/4"
plasma welding
STAINLESS STEEL cylinder capacity 12 L
connection fitting 3/4"
dimensions: height 500 mm - \varnothing 185 mm
resin content 9 L
regeneration salt(NaCl-table salt)1.5 Kg
inlet water max temperature 60°C
for average dishwashers and dispensers,
for 3-group coffee machines



ELECTROLUX 0S0330

3010018 GASKET FOR WATER SOFTENER LID
OR \varnothing 74x6.5 mm



ELECTROLUX



Suitable for:

3010016 PLASTIC JET M6
for DVA models



3010012 TAP \varnothing 3/4"
for models DVA
for DISHWASHERS



3010080 WATER SOFTENER LID ASSEMBLY
for DVA models



3010123 BASIS FOR WATER SOFTNER GS



3010016 PLASTIC JET M6
for DVA models





Suitable for:

3010015 PLASTIC TAP HANDLE
for DVA models



3010111 TAP Ø 3/4"
for GS models



3010006 MANUAL WATER SOFTENER 12 L WITH BY-PASS
stainless steel cylinder capacity 12 L
connection fittings 3/8"
dimensions: height 500 mm - Ø 185 mm
resin content 9 L
regeneration salt (NaCl-table salt) 1.5 Kg
for average dishwashers and dispensers
for 3-group coffee machines



ELECTROLUX 0S0579

3010080 WATER SOFTENER LID ASSEMBLY
for DVA models



3010063 MANUAL WATER SOFTENER 20 L Ø 3/4"
stainless steel cylinder capacity 20 L
connection fittings 3/4"
dimensions: height 900 mm - Ø 185 mm
resin content 15 L
regeneration salt (NaCl-table salt) 3 Kg
for dishwashers, large automatic dispensers
for 4-group coffee machines



ELECTROLUX 0S0329

ELECTROLUX



Suitable for:

3010112 RESIN 5 L
5 litre bag



3010114 WATER SOFTENER S/STEEL LID ASSEMBLY
for GS models



3010023 BLACK BASE FOR GS WATER SOFTENER



3010023 BLACK BASE FOR GS WATER SOFTENER





Suitable for:

3010018 GASKET FOR WATER SOFTENER LID
OR \varnothing 74x6.5 mm



3010019 LID HANDLE
for DVA models



3010014 PIPE FITTING \varnothing 3/8" F x 3/4" M
for DVA models



3010015 PLASTIC TAP HANDLE
for DVA models



3010011 WATER INLET TAP \varnothing 3/8"
for DVA models



ELECTROLUX



Suitable for:

3010021 INLET FILTER
for DVA models



3010022 OUTLET FILTER
for DVA models



3010016 PLASTIC JET M6
for DVA models



3010012 TAP \varnothing 3/4"
for models DVA
for DISHWASHERS





Suitable for:

Suitable for:

3010104 MANUAL WATER SOFTENER 20 L \varnothing 3/4"
plasma welding
STAINLESS STEEL cylinder capacity 20 L
connection fitting 3/4"
dimensions: height 900 mm - \varnothing 185 mm
resin content 15 L
regeneration salt(NaCl-table salt)3 Kg
inlet water max temperature 60°C
for dishwashers, large dispensers,
for 4-group coffee machines



3010123 BASIS FOR WATER SOFTNER GS



ELECTROLUX 860430

3010018 GASKET FOR WATER SOFTENER LID
OR \varnothing 74x6.5 mm



3010016 PLASTIC JET M6
for DVA models



3010015 PLASTIC TAP HANDLE
for DVA models



3010112 RESIN 5 L
5 litre bag



3010111 TAP \varnothing 3/4"
for GS models



3010114 WATER SOFTENER S/STEEL LID ASSEMBLY
for GS models



3010060 MANUAL WATER SOFTENER 8 L \varnothing 3/4"
stainless steel cylinder capacity 8 L
connection fittings 3/4"
dimensions: height 400 mm - \varnothing 185 mm
resin content 5.8 L
regeneration salt(NaCl-table salt)1 Kg
for cup washers, small automatic dispensers
for 2-group coffee machines



3010023 BLACK BASE FOR GS WATER SOFTENER



ELECTROLUX 0C1903



Suitable for:

3010018 GASKET FOR WATER SOFTENER LID
OR \varnothing 74x6.5 mm



3010019 LID HANDLE
for DVA models



3010014 PIPE FITTING \varnothing 3/8" F x 3/4" M
for DVA models



3010015 PLASTIC TAP HANDLE
for DVA models



3010011 WATER INLET TAP \varnothing 3/8"
for DVA models



ELECTROLUX



Suitable for:

3010021 INLET FILTER
for DVA models



3010022 OUTLET FILTER
for DVA models



3010016 PLASTIC JET M6
for DVA models



3010012 TAP \varnothing 3/4"
for models DVA
for DISHWASHERS



3010080 WATER SOFTENER LID ASSEMBLY
for DVA models





Suitable for:

Suitable for:

3010101 MANUAL WATER SOFTENER 8 L \varnothing 3/4"
plasma welding
STAINLESS STEEL cylinder capacity 8 L
connection fitting 3/4"
dimensions: height 400 mm - \varnothing 185 mm
resin content 5.8 L
regeneration salt(NaCl-table salt)1 Kg
inlet water max temperature 60°C
for cup washers, small automatic dispensers
for 2-group coffee machines

3010123 BASIS FOR WATER SOFTNER GS



ELECTROLUX 0C1903

3010018 GASKET FOR WATER SOFTENER LID
OR \varnothing 74x6.5 mm

3010016 PLASTIC JET M6
for DVA models



3010015 PLASTIC TAP HANDLE
for DVA models

3010112 RESIN 5 L
5 litre bag



3010111 TAP \varnothing 3/4"
for GS models

3010114 WATER SOFTENER S/STEEL LID ASSEMBLY
for GS models



3010005 MANUAL WATER SOFTENER 8 L WITH BY-PASS
stainless steel cylinder capacity 8 L
connection fittings 3/8"
dimensions: height 400 mm - \varnothing 185 mm
resin content 5.8 L
regeneration salt(NaCl-table salt)1 Kg
for cup washers, small automatic dispensers
for 2-group coffee machines

3010023 BLACK BASE FOR GS WATER SOFTENER



ELECTROLUX 0S0578



Suitable for:

3010080 WATER SOFTENER LID ASSEMBLY
for DVA models



ELECTROLUX



Suitable for:

3010601 PURITY CLEAN EXTRA 1200
water softener suitable for DISHWASHERS
specific for WARM WATER
adjustable by-pass
capacity at 10°KH 3100 L
flow rate 300 L/h
max pressure 6 bar
min pressure 2 bar
operating temperature 4°C/60°C
pressure loss at flow rate 0.45 bar
size: height 550 mm - ø 255 mm
weight: empty 18 Kg - full 24 kg
fittings: inlet ø 1" M - outlet ø 3/4" M
horizontal or vertical mounting



3010611 CARTRIDGE PURITY CLEAN EXTRA 1200



ELECTROLUX 0S0803

3010600 PURITY CLEAN 1200
water softener suitable for DISHWASHERS
specific for WARM WATER
adjustable by-pass
capacity at 10°KH 12000 L
flow rate 300 L/h
max pressure 6 bar
min pressure 2 bar
operating temperature 4°C/60°C
pressure loss at flow rate 0.45 bar
size: height 550 mm - ø 255 mm
weight: empty 18 Kg - full 24 kg
fittings: inlet ø 1" M - outlet ø 3/4" M
horizontal or vertical mounting



3010610 CARTRIDGE PURITY CLEAN 1200



ELECTROLUX 0S0801



Suitable for:

Suitable for:

3010604 PURITY ST 1200

water softener suitable COFFEE MACHINES-DISPENSERS
OVENS - ICE MAKERS
specific for ODOR REMOVAL
adjustable by-pass
capacity at 10°KH 13187 L
flow rate 200 L/h
max pressure 6.9 bar
min pressure 2 bar
operating temperature 4°C/30°C
pressure loss at flow rate 1.05 bar
dimensions: height 550 mm - ø 288 mm
weight: empty 18 Kg - full 24 kg
fittings: inlet ø 3/8"M - outlet ø 3/8"M
horizontal or vertical mounting



3010614 PURITY CARTRIDGE ST 1200



ELECTROLUX OS0682

3010094 WATER SOFTENER" Matic 12" 12 L ø 3/4"

AUTOTROL chronometric head 255/440i
230V 50Hz
time programmer mod.440 (weekly)
operating temperature 2°÷35°C
cylinder capacity 11.8 L - resin content 8 L
salt container 30 kg
regeneration salt(NaCl-table salt)1.5 Kg
inlet/outlet fittings 3/4"
dimensions: width 260 mm - depth 480 mm
height without head 435 - overall height 650 mm
We recommend to use always a mechanical filter
before the softener in order to remove
impurities from the water



3010121 AUTOTROL HEAD DIAPHRAGM SET 255/440i

for Autotrol head 255/440i



ELECTROLUX OS0332

3010120 AUTOTROL O-RING SET 255/440i

for Autotrol head 255/440i



3010046 CAM FOR AUTOTROL HEAD 255/440i

for head AUTOTROL 255/440i





Suitable for:

3010043 COMPLETE BOWL FOR AUTOTROL 255/440i
for AUTOTROL head 255/440i



3010125 LOWER FILTER ø 27 mm
for AUTOTROL head 255/440i



3010127 STANDARD LID
for AUTOTROL head 255/440i



3010200 TRANSFORMER 220/12V
for WATER SOFTENER



ELECTROLUX



Suitable for:

3010126 ELECTRONIC CHLORINATOR
for Autotrol valve 255/400i-450
composed by:
- control box with double adhesive label
- electrode holder cell with two flowrate adjuster
- brine-drawing pipe with filter
- micro-switch with connection cable



3010112 RESIN 5 L
5 litre bag



3010034 TIMER FOR AUTOTROL HEAD 255/440i
for AUTOTROL head 255/440i





Suitable for:

Suitable for:

3010074 WATER SOFTENER "MATIC 8" 8 L ø 3/4"
AUTOTROL chrometric head 255/440i
230V 50Hz
time programmer mod.440 (weekly)
operating temperature 2°÷35°C
cylinder capacity 8.5 L - resin content 5.4 L
salt container 20 kg
regeneration salt(NaCl-table salt)1 Kg
inlet/outlet fittings 3/4"
dimensions: width 200 mm - depth 430 mm
height without head 335 - overall height 550 mm
We recommend to use always a mechanical filter
before the softener in order to remove
impurities from the water



3010121 AUTOTROL HEAD DIAPHRAGM SET 255/440i
for Autotrol head 255/440i



ELECTROLUX 050716

3010120 AUTOTROL O-RING SET 255/440i
for Autotrol head 255/440i



3010046 CAM FOR AUTOTROL HEAD 255/440i
for head AUTOTROL 255/440i



3010043 COMPLETE BOWL FOR AUTOTROL 255/440i
for AUTOTROL head 255/440i



3010126 ELECTRONIC CHLORINATOR
for Autotrol valve 255/400i-450
composed by:
- control box with double adhesive label
- electrode holder cell with two flowrate adjuster
- brine-drawing pipe with filter
- micro-switch with connection cable



3010125 LOWER FILTER ø 27 mm
for AUTOTROL head 255/440i



3010112 RESIN 5 L
5 litre bag





Suitable for:

3010034 **TIMER FOR AUTOTROL HEAD 255/440i**
for AUTOTROL head 255/440i



ELECTROLUX



Suitable for:

3010200 **TRANSFORMER 220/12V**
for WATER SOFTENER

