



Spare parts for:

## Warewashing equipment



Suitable for:

# MEIKO



This catalogue is automatically generated.  
Therefore, the sequence of the items might  
not be always shown at best.

Updates will be issued in case of additions  
and/or amendments.

*Suitable universal spare parts may not be included*





Suitable for:


# MEIKO



Suitable for:

## Air Chambers

**3060063 AIR CHAMBER**  
 height 56 mm  
 width 52 mm  
 for Dishwasher (MEIKO) FV40  
 for Dishwasher hood type (MEIKO) DV120 - DV80  
 for Pan/utensilwashing machines (MEIKO) FV130



MEIKO 9515955


**3060087 BRASS NUT  $\varnothing$  3/8"**  
 for Dishwasher (SILANOS) E50 - N50 - N700 - N90  
 800 - 900  
 for Dishwasher (WHIRLPOOL) AGB648 - AGB649  
 AGB650 - AGB651 - AGB652 - AGB653 - AGB657  
 AGB658 - AGB660 - AGB663  
 for Dishwasher hood type (SILANOS) 1000 - 1300  
 1300S  
 for Glasswasher/Cupwasher (MACH) MB235LI - MB240LI  
 MB920  
 for Glasswasher/Cupwasher (SILANOS) F19 - F22  
 F27 - N22 - R20 - R29 - 020 - 030  
 for Glasswasher/Cupwasher (WHIRLPOOL) AGB641  
 AGB642 - AGB643 - AGB644 - AGB645 - AGB646  
 AGB647 - AGB782 - AGB783 - AGB784 - AGB785



MEIKO 0360211

MEIKO 9515957

**3060064 AIR CHAMBER  $\varnothing$  33 mm**  
 height 38 mm  
 for Dishwasher (MEIKO) ECOSTAR530F  
 for Dishwasher hood type (MEIKO) DV120T - DV80T  
 for Glasswasher/Cupwasher (MEIKO) ECOSTAR430F  
 FV28G  
 for Pan/utensilwashing machines (MEIKO) DV270  
 FV250



MEIKO 0620244

**3186304 GASKET FOR AIR CHAMBER**



MEIKO 0650001

## Boilers

**3024042 BOILER  $\varnothing$  117x260 mm**  
 for Glasswasher/Cupwasher (MEIKO) FR30G - FV25G



MEIKO 8400122

**3024043 BOILER  $\varnothing$  150x260 mm**  
 for Glasswasher/Cupwasher (MEIKO) FV28G



MEIKO 8400280



## Capacitors

- 3068010 CAPACITOR  $\mu$ F 6.3 450V 50/60Hz**  
 operating temperature  $-25+85^{\circ}\text{C}$   
 in compliance with EEC 93/68 and EEC 92/31 regulat  
 for Dishwasher (FAGOR) FI-12D - FI-12S - FI-18D  
 FI-18S - FI-30 - FI-48 - FI-48B - FI-50  
 FI-64 - FI-64B - FI-72  
 for Dishwasher hood type (FAGOR) FI-1200 - FI-900  
 for Glasswasher/Cupwasher (FAGOR) LVC-12 - LVC-15  
 LVC-15D - LVC-21 - LVC-21B - LVC-21D - LVR-10  
 LVR-14 - LVR-14D - LVR-20 - LVR-20B - LVR-20D



MEIKO 0501173

## Castors

- 3346140 HANDLE SLIDING ROLLER**  
 for Dishwasher hood type (MEIKO) DV40




MEIKO 0620451

- 3346142 HANDLE SUPPORT**  
 for Dishwasher hood type (MEIKO) DV40



MEIKO 0620445

- 3346139 HANDLE SUPPORT**  
 for Dishwasher hood type (MEIKO) DV40



MEIKO 0620449

- 3346143 ROLLER PIN**  
 for Dishwasher hood type (MEIKO) DV40



MEIKO 8000230

## Clamps

- 3449402 DOUBLE-WIRE CLAMP 7.8-8.3 - 100 PCS**  
 for hoses  $\varnothing$  7.8÷8.3 mm



MEIKO 9500044

- 3449404 DOUBLE-WIRE CLAMP 8.8-9.3 - 100 PCS**  
 for hoses  $\varnothing$  8.8÷9.3 mm



MEIKO 9500045



Suitable for:

# MEIKO



Suitable for:

**3449143 SCREW HOSE CLAMP  $\varnothing$  9/12 mm**



MEIKO 0233056

## Contact thermostats

**3443034 BOILER SAFETY THERMOSTAT 105°C**  
with manual reset  
for FV28G-FV250-DV80T-DV120T-DV270



MEIKO 0108038

**3443062 CONTACT THERMOSTAT 110°C**  
for DISHWASHER FV40-FV70



MEIKO 0108043

**3443060 CONTACT THERMOSTAT 50°C 10A 250V**  
universal



MEIKO 0108053

**3443057 CONTACT THERMOSTAT 56°C**  
universal



MEIKO 0108047

## Descaling powders for dishwashers

**3094005 4 COLUMN SCALE REMOVER**  
width 165 mm - length 390 mm  
for Dishwasher (ADLER) CF50  
for Dishwasher (COMENDA) FC53 - FC54 - LF320A  
LF323A - LF350A - LF400A - LF450A  
for Dishwasher (ELFRAMO)  
for Dishwasher (KOMEL)  
for Dishwasher (LAMBER)  
for Dishwasher (UNIVERBAR) LOGOSD - MIDI50D  
OMEGAD - SINCROD  
for Glasswasher/Cupwasher (COMENDA) BC25A - BC30A  
BHC25 - BHC30 - BR20A - BR25A - B12T - B14T  
B16T - B19T - FC43A  
for Glasswasher/Cupwasher (MEIKO) ECOSTAR545D  
for Glasswasher/Cupwasher (UNIVERBAR) BET37D  
BET40D - ERGOND - MIDI40D - MINIBETD



MEIKO 0270064

**3010057 8-ELEMENT SCALE REMOVER**  
for Dishwasher (MEIKO) ECOSTAR530F - ECOSTAR530M  
FV40T



MEIKO 0270062

MEIKO 8003601



**Drain assembly**

**3316144 DRAIN ASSEMBLY  $\varnothing$  1"1/2**



MEIKO 8002887

**Drain hoses**

**3450209 RUBBER PIPE  $\varnothing$  13x20 mm - 40 m**  
operating temperature -40+100°C



MEIKO 0640012

MEIKO 9608600

**3450109 RUBBER PIPE  $\varnothing$  13x20 mm - 5 m**  
operating temperature -40+100°C



MEIKO 0640012

MEIKO 9608600

**Drain plugs**

**3448210 OVERFLOW PIPE  $\varnothing$  33x140 mm**  
made of plastic  
for FV28G-ECOSTAR 430F/530F




MEIKO 0620347

**3448222 OVERFLOW PIPE  $\varnothing$  33x175 mm**  
made of plastic  
for ECOSTAR 430F/530F



MEIKO 0620348


**3448256 OVERFLOW PIPE  $\varnothing$  33x215 mm**  
plastic made  
for DV40N-DV120N



MEIKO 0620447

MEIKO 8070117

**3448205 OVERFLOW PIPE  $\varnothing$  33x255 mm**  
made of plastic  
for DV80T-DV120T



MEIKO 0620457

**3448252 OVERFLOW PIPE  $\varnothing$  40x100 mm**  
plastic made  
for FV25G-FR30G-FR40G



MEIKO 0620600

**3448253 OVERFLOW PIPE  $\varnothing$  40x120 mm**  
plastic made  
for FV30GS-FV40-FV60



MEIKO 0620601



Suitable for:

**3448254 OVERFLOW PIPE  $\varnothing$  40x130 mm**  
plastic made  
for OR50H



MEIKO 0620602

# MEIKO



Suitable for:

**3448220 OVERFLOW PIPE  $\varnothing$  40x140 mm**  
made of plastic  
for DV40-DV80-DV120-DV160-DV240



MEIKO 0620603


**3448255 OVERFLOW PIPE  $\varnothing$  40x195 mm**  
STAINLESS steel made  
for FV130B



MEIKO 8650009


## Electrical gas valves and accessories

**3526198 BACKFLOW CHECK VALVE- LARGE**



MEIKO 0620349


**3526199 BACKFLOW CHECK VALVE- SMALL**



MEIKO 0620334

## Electronic printed-circuit boards

**3390202 CONTROL BOARD**  
size 153x56 mm  
for Glasswasher/Cupwasher (MEIKO) FV28G



MEIKO 0124092

**3390199 POWER BOARD**  
size 128x130 mm  
for Glasswasher/Cupwasher (MEIKO) FV28G



MEIKO 0124093

MEIKO 9500251

**3390201 POWER BOARD**  
size 130x128 mm  
for Glasswasher/Cupwasher (MEIKO) FV28G




MEIKO 0124091

MEIKO 9500250

Suitable for:


**3390200 CPU BOARD**  
 size 120x58 mm  
 for Dishwasher (MEIKO) - Series FV30 - FV40T  
 for Glasswasher/Cupwasher (MEIKO) FV20N  
 Series FV25



MEIKO 0124186


Suitable for:

**3390205 POWER BOARD**  
 size 180x85 mm  
 for Dishwasher (MEIKO) ECOSTAR530F  
 for Glasswasher/Cupwasher (MEIKO) ECOSTAR430F




MEIKO 0124187

**3390204 CPU BOARD**  
 size 125x57 mm  
 for Dishwasher (MEIKO) DV40T - FV40T - FV60E  
 FV70T



MEIKO 0124196

**3390203 CONTROL BOARD**  
 size 240x85 mm  
 for Dishwasher (MEIKO) DV40T - FV40T - FV60E  
 FV70T



MEIKO 0124190

**3390207 PROCESSOR EPROM MSPL6-P-FA**  
 for Dishwasher (MEIKO) FV40TFA



MEIKO 0124124

**3390198 TIMER BOARD**  
 size 60x65 mm  
 for Dishwasher hood type (MEIKO) DV120B



MEIKO 0125035

**3390111 TIMER CIRCUIT BOARD**



MEIKO 0124123

MEIKO 9534803


## Filters

**3160225 DRAIN FILTER SUPPORT**



MEIKO 0620430

**3160226 DRAIN FILTER WITH OVERFLOW HOUSING**



MEIKO 0620431




Suitable for:

# MEIKO



**3160337 FILTER  $\varnothing$  133x45 mm**  
for Dishwasher (MEIKO) FV40  
for Glasswasher/Cupwasher (MEIKO) FV25G - FV30



MEIKO 0620500

**3160334 FILTER SUPPORT  $\varnothing$  125 mm**  
for Dishwasher (MEIKO) FV40



MEIKO 8000032

**3160338 FILTER  $\varnothing$  133x75 mm**  
for Pan/utensilwashing machines (MEIKO) FV120  
FV130



MEIKO 0620501

**3160339 FILTER SUPPORT  $\varnothing$  125 mm**  
for Pan/utensilwashing machines (MEIKO) FV130



MEIKO 8000855

**3160330 FILTER  $\varnothing$  195 mm**  
for Dishwasher conveyor type (MEIKO) K337



MEIKO 0620346

MEIKO 06203465

Suitable for:

**3160333 FILTER SUPPORT  $\varnothing$  125 mm**  
for Glasswasher/Cupwasher (MEIKO) FV30



MEIKO 8002176

**3160335 FILTER SUPPORT  $\varnothing$  125 mm**  
for Glasswasher/Cupwasher (MEIKO) FV25G



MEIKO 8000194

MEIKO 8001008

**3160336 FILTER SUPPORT  $\varnothing$  125 mm**  
for Dishwasher hood type (MEIKO) DV160 - DV80  
for Pan/utensilwashing machines (MEIKO) FV120  
FV120B - FV240 - FV240B



MEIKO 8000076

MEIKO 8000082





## Fittings

**3349614 PIPE SIMPLE COUPLING**  
for DISHWASHER DV80



MEIKO 0620342

**3315022 T-FITTING  $\varnothing$  11 mm**  
for FV40-DV80-DV120



MEIKO 9534819

## Fuses

**3049011 DELAY FUSE 5x20 - 10 PCS**  
250V 630mA



MEIKO 0145049

**3049013 DELAY FUSE 5x20 - 10 PCS**  
250V 1A



MEIKO 0145045

**3049014 DELAY FUSE 5x20 - 10 PCS**  
250V 1.25A



MEIKO 0145048

**3049015 DELAY FUSE 5x20 - 10 PCS**  
250V 1.6A



MEIKO 0145046

**3049016 DELAY FUSE 5x20 - 10 PCS**  
250V 2A



MEIKO 0145047

**3049020 DELAY FUSE 5x20 - 10 PCS**  
250V 6.3A



MEIKO 0145001

**3049021 DELAY FUSE 5x20 - 10 PCS**  
250V 8A



MEIKO 0145002

**3049022 DELAY FUSE 5x20 - 10 PCS**  
250V 10A



MEIKO 0145000



Suitable for:

Suitable for:

**3049057 DELAY FUSE 6.3x32 - 10 PCS**  
250V 1A



MEIKO 0145013


## Gaskets and seals

**5024107 FLAT RUBBER GASKET  $\varnothing$  37x28x1.5 mm**



MEIKO 0408226

**5034378 HEATING ELEMENT GASKET 102x144x3 mm EPDM**  
for Dishwasher conveyor type (MEIKO) K200 - K400



MEIKO 0408229

**3090132 O-RING GASKET 03050 VITON**



MEIKO 0260013

## Heating elements

**3755107 BOILER HEATING ELEM. 230/240V 3000/3265W**  
immersed length 185 mm  
flange external  $\varnothing$  63 mm  
with bulb sheath  
complete with 'O' ring  $\varnothing$  58 (3186013)  
for Dishwasher (MEIKO) FV40



MEIKO 9519586

**3755117 BOILER HEATING ELEM. 230/240V 6000/6533W**  
for boiler and tank  
immersed length 335 mm  
flange external  $\varnothing$  63 mm  
with bulb sheath  
complete with 'O' ring  $\varnothing$  58 (3186013)  
for Dishwasher (MEIKO) FV40  
for Pan/utensilwashing machines (MEIKO) FV130



MEIKO 9519588

Suitable for:

**3755115 BOILER HEATING ELEM .230/240V 7500/8166W**

immersed length 415 mm  
flange external  $\varnothing$  63 mm  
with bulb sheath  
complete with 'O' ring  $\varnothing$  58 (3186013)  
for Dishwasher hood type (MEIKO) DV80  
for DV80



MEIKO 9519590

**3755110 BOILER HEATING ELEMENT 230V 3000W**

immersed length 220 mm  
flange external  $\varnothing$  63 mm  
with double bulb sheath  
complete with 'O' ring  $\varnothing$  58 (3186013)  
for Dishwasher (MEIKO) ECOSTAR530F  
for Glasswasher/Cupwasher (MEIKO) ECOSTAR430F  
FV28G



MEIKO 0101150

MEIKO 9504228

**3755956 BOILER HEATING ELEMENT 6000W 230V**


immersed length 400 mm  
threaded coupling 1"1/2  
for FV120B-FV240B-DV120B  
for Dishwasher hood type (MEIKO) DV120B  
for Pan/utensilwashing machines (MEIKO) FV120B  
FV240B



MEIKO 0101146

MEIKO 9502870

**3455418 BRACKET FOR HEATING ELEMENT**



MEIKO 0101183

Suitable for:

**3755104 BOILER HEATING ELEM .230/240V 9000/9800W**

immersed length 485 mm  
flange external  $\varnothing$  63 mm  
with bulb sheath  
complete with 'O' ring  $\varnothing$  58 (3186013)  
for Dishwasher hood type (MEIKO) DV120



MEIKO 9519591

**3755954 BOILER HEATING ELEMENT 4500W 230V**

immersed length 350 mm  
flange external  $\varnothing$  63 mm  
with O-Ring  $\varnothing$  58 (3186013)  
with two bulb sheaths  
for Dishwasher (MEIKO) FV70  
for Dishwasher hood type (MEIKO) DV120B  
for Glasswasher/Cupwasher (MEIKO) FV20




MEIKO 0101163

MEIKO 9504234

**3755072 BOILER HEATING ELEMENT 7500W 230/400V**

immersed length 420 mm  
flange external  $\varnothing$  63 mm  
with bulb sheath  
complete with O-Ring  $\varnothing$  58 (3186013)



MEIKO 0101167

MEIKO 9504237

**3455422 HEATING ELEMENT F/ BOILER 36000W 415V**

flange  $\varnothing$  151 mm  
immersed length 425 mm  
for Dishwasher conveyor type (MEIKO)  
Series B-TRONIC



MEIKO 0101184



Suitable for:

# MEIKO



**3455421 HEATING ELEMENT 11000W 240V**  
 immersed length 505 mm  
 flange external  $\varnothing$  72 mm  
 complete with O-Ring  $\varnothing$  67 (5028504)  
 for Dishwasher conveyor type (MEIKO)  
 Series K-TRONIC



MEIKO 0101186

**3455419 HEATING ELEMENT 2000W 230V**  
 for drying zone  
 length 175 mm - width 295 mm  
 for Dishwasher conveyor type (MEIKO)  
 Series B-TRONIC



MEIKO 0101136

**3755401 HEATING ELEMENT 2000W 230V**  
 length 270 mm - height 25 mm  
 for Dishwasher (MEIKO) ECOSTAR530F - FV40  
 for Dishwasher hood type (MEIKO) DV120T - DV80T  
 for Glasswasher/Cupwasher (MEIKO) ECOSTAR430F  
 FV28G



MEIKO 0101152


MEIKO 0101153

**3786678 GASKET FOR HEATING ELEMENT**



MEIKO 0101175

**3455420 HEATING ELEMENT 3000W 230V**  
 for drying  
 length 172 mm - width 310 mm  
 for Dishwasher conveyor type (MEIKO)  
 Series B-TRONIC



MEIKO 0101135

**3755960 HEATING ELEMENT 3000W 230V**  
 immersed length 230 mm  
 threaded coupling 1"1/2  
 with bulb sheath  
 for Dishwasher (MEIKO) FV40N  
 for Dishwasher hood type (MEIKO) DV40  
 for Glasswasher/Cupwasher (MEIKO) FR30G - FV25G



MEIKO 0101140

MEIKO 9502869

**3755961 HEATING ELEMENT 4500W 240V**  
 immersed length 380 mm  
 threaded coupling 1"1/2  
 for Dishwasher (MEIKO) FV40N  
 for Dishwasher hood type (MEIKO) DV120B



MEIKO 0101142

**3755402 HEATING ELEMENT 6000W 230V**  
 immersed depth 420 mm  
 flange external  $\varnothing$  63 mm  
 with 2 bulb sheathes  
 complete with o-ring (3186013)  
 for Dishwasher (MEIKO) FV70  
 for Dishwasher hood type (MEIKO) DV120B - DV40BIS  
 for Glasswasher/Cupwasher (MEIKO) FV20BIS  
 for Pan/utensilwashing machines (MEIKO) FV130B



MEIKO 0101143

MEIKO 9504236

Suitable for:

Suitable for:

**3755958 HEATING ELEMENT 6000W 230V**

immersed length 400 mm  
threaded coupling 1"1/2



MEIKO 0101145

**3755962 HEATING ELEMENT 6000W 230V**

immersed length 420 mm  
threaded coupling 1"1/2  
for FV120B-FV130B-DV40



MEIKO 0101144

**3755959 HEATING ELEMENT 9000W 320V**

immersed length 400 mm  
threaded coupling 1"1/2



MEIKO 0101149

**3755955 TANK HEATING ELEMENT 3000W 230V**

immersed length 360 mm  
flange external  $\varnothing$  60 mm  
with counter flange and gasket  
for Dishwasher hood type (MEIKO) DV120 - DV40  
DV80



MEIKO 0101151

**3755995 PROTECTION KIT FOR HEATING ELEMENT**



MEIKO 9528040

**3755118 TANK HEATING ELEMENT 200/250V 1000/1500W**

complete with nuts and 'O' ring  
immersed length 185 mm  
width 130 mm  
fittings  $\varnothing$  14 mm  
for Dishwasher (MEIKO) FV40  
for Dishwasher hood type (MEIKO) DV120 - DV80



MEIKO 9546104

**3755957 TANK HEATING ELEMENT 6000W 230V**

immersed length 360 mm  
flange external  $\varnothing$  60 mm  
with counter flange and gasket  
for Dishwasher (MEIKO) FV70  
for Pan/utensilwashing machines (MEIKO) FV120



MEIKO 0101158



Suitable for:

# MEIKO



**3755112 TANK HEATING ELEMENT 9000W 230V**  
 immersed length 485 mm  
 flange external ø 63 mm  
 with double bulb sheath  
 complete with 'O' ring ø 58 (3186013)  
 for Pan/utensilwashing machines (MEIKO) FV250



MEIKO 0101166

MEIKO 9504240

Suitable for:

**3755105 TANK/BOILER HEATING ELEM .230V 9000W**  
 immersed length 485 mm  
 fitting ø 1"1/2 (48 mm)  
 with bulb sheath  
 complete with gasket (3186011)  
 for Pan/utensilwashing machines (MEIKO) DV270



MEIKO 0101148

MEIKO 9502872

## Hinges


**3053333 HINGE BUSHING**



MEIKO 0621084


MEIKO 8003677

**3053334 HINGE FOR DOOR LH**  
 for Dishwasher (MEIKO) ECOSTAR530G - FV110G  
 FV40T - FV40TFA - FV70T - FV70TD  
 for Glasswasher/Cupwasher (MEIKO) FV20N



MEIKO 8003681

**3053335 HINGE FOR DOOR RH**  
 for Dishwasher (MEIKO) ECOSTAR530G - FV110G  
 FV40T - FV40TFA - FV70T - FV70TD  
 for Glasswasher/Cupwasher (MEIKO) FV20N




MEIKO 8003600

**3053329 HINGE RH**  
 for Glasswasher/Cupwasher (MEIKO) FV28G



MEIKO 8004426

**3053331 HINGE BUSHING**



MEIKO 0621085

MEIKO 8003675

**3053332 HINGE BUSHING**



MEIKO 0620398

**3053328 HINGE CABLE**




MEIKO 0435151

**3250162 HINGE CLAMP SPRING**



MEIKO 0435150

**3053330 HINGE LH**



MEIKO 8003985



**Hose-end fittings**

**3315100 "T" HOSE-END FITTING  $\varnothing$  13 mm**

for Dishwasher (ZANUSSI) CRYSTAL50 - CRYSTAL51  
CRYSTAL52 - LS4 - LS5DS - LS510 - LS520  
LS521  
for Dishwasher hood type (JEMI) GS-102 - GS-83  
for Glasswasher/Cupwasher (JEMI) GS-2 - GS-6  
GS-6AF  
for Pan/utensilwashing machines (JEMI) GSP-45



MEIKO 0621035

**3315033 HOSE-END FITTING  $\varnothing$  6.5 mm**



MEIKO 0260049

**3315106 3-WAY HOSE END RUBBER FITTING  $\varnothing$  10 mm**

for Dishwasher (DIHR) DS35 - DS37 - DS40  
ELECTRON400 - ELECTRON400CLEAN - GASTRO450  
GS37 - GS40 - G35 - LINEAR - TEKNO4  
for Dishwasher (UNIVERBAR) SINCRO - SINCROD - TOP  
for Dishwasher conveyor type (DIHR) BX300  
for Glasswasher/Cupwasher (DIHR) DERBY - STAR  
for Glasswasher/Cupwasher (UNIVERBAR) BET37  
BET37D - BET40 - BET40D - MINIBET - MINIBETD  
MIX



MEIKO 0621040

**3315107 3-WAYS HOSE END RUBBER FITTING  $\varnothing$  12**



MEIKO 0621036

**Inlet hoses**

**3450217 PIPE RAGNO PU  $\varnothing$  13/19 mm - 30 m**

pressure 20÷60 bar  
temperature -15+60°C  
alimentary



MEIKO 0640026

**3450117 PIPE RAGNO PU  $\varnothing$  13/19 mm - 5 m**

pressure 20÷60 bar  
temperature -15+60°C  
alimentary



MEIKO 0640026



Suitable for:

**3090734** PVC HOSE  $\varnothing$  5x8 mm - 10 m  
food-safe



MEIKO 0260006

Suitable for:

**3090234** PVC HOSE  $\varnothing$  5x8 mm - 100 m  
food-safe



MEIKO 0260006

**3450115** PVC PIPE  $\varnothing$  6/9 mm - 10 mt  
alimentary



MEIKO 0260007


**3450215** PVC PIPE  $\varnothing$  6/9 mm - 100 m  
alimentary



MEIKO 0260007

### Ironmongery (screws,nuts,washers)

**3528143** S/STEEL EXAGONAL BLIND NUT M5-200PCS  
NF E 27-453



MEIKO 0336050

### Knobs

**3241662** KNOB  $\varnothing$  42 mm  
hole for D-shaped pin 6x4.6 mm



MEIKO 0108018






## Microswitches

### 3240407 MECHANICAL MICROSWITCH KIT 16A 250V

3 locking positions  
 the kit includes 5 levers:  
 lever 75 mm - lever 27 mm - lever 15 mm  
 lever 15 mm with wheels - lever 27 mm with wheels  
 for Dishwasher (DIHR) GASTRO450 - GASTRO500  
 GASTRO750 - GASTRO900 - GS100 - TEKNO4  
 for Dishwasher (KROMO) K40LUX - K60 - K70 - K80  
 for Dishwasher (OLIS) OLDS35 - OLDS37 - OLDS50  
 for Dishwasher (UNIVERBAR) BRAMA - CASTA - COSMO  
 LOGOS - LOGOSD - MIDI50 - MIDI50D - OMEGA  
 OMEGAD - SINCRO - SINCROD - TOP - UBF850/2R  
 for Dishwasher hood type (UNIVERBAR) COMPACT  
 for Glasswasher/Cupwasher (DIHR) DERBYCF  
 LINEARCF - LINEARLS - STARCF - STARLS  
 for Glasswasher/Cupwasher (UNIVERBAR) BET37



MEIKO 0122105

MEIKO 0122106


### 3240475 MICROINTERRUTTORE L 132



MEIKO 0130028

MEIKO 9526211

### 3240674 MICROSWITCH GROUP 250V



MEIKO 9519033

MEIKO 9622898

MEIKO 9683764

### 3240332 MICROSWITCH 16A 250V



MEIKO 0122105

MEIKO 9544800

## Motors

### 3240501 AXIAL VENTILATOR SUNON 120x120x38 mm

ball bearings  
 22W 230V 50/60Hz 2850 Rpm  
 DP200A 2123XBT.GN



MEIKO 0190032



Suitable for:

# MEIKO



Suitable for:

## Pressure switches

### 3320044 PRESSURE SWITCH 0/30 mBAR


1 level  
for Dishwasher (MEIKO) FV40  
for Dishwasher hood type (MEIKO) DV120 - DV80  
for Dishwasher hood type (MIELE) G8072  
for Pan/utensilwashing machines (MEIKO) FV130



MEIKO 9537961

### 3320089 PRESSURE SWITCH 40/15 mm


1 level 250V 16A  
back connection  
for Dishwasher (MEIKO) ECOSTAR530F - FV40  
for Dishwasher hood type (MEIKO) DV120 - DV80  
for Glasswasher/Cupwasher (MEIKO) ECOSTAR430F  
FV28G



MEIKO 0130026

### 3320071 PRESSURE SWITCH 55/30 mm 250V 16A

1 level  
max operating temperature 85°C  
for UNIVERBAR DISHWASHER ALL MODELS  
for Dishwasher (UNIVERBAR)  
for Glasswasher/Cupwasher (ATA) AL20 - AL21 - AL25  
AL26  
for Glasswasher/Cupwasher (UNIVERBAR)




MEIKO 0130009

MEIKO 0130019

### 3320090 PRESSURE SWITCH 62/30 mm

1 level 250V 16A  
back connection  
for Pan/utensilwashing machines (MEIKO) DV270  
FV250




MEIKO 0130006

MEIKO 0130008

### 3320088 PRESSURE SWITCH 90/25 mm

1 level 250V 16A  
back connection  
for Dishwasher hood type (MEIKO) DV120T - DV80T



MEIKO 0130027

## Probes

### 3397112 TEMPERATURE PROBE

bulb  $\varnothing$  6x40 mm - capillary 2100 mm  
for FV28GFH-FU40T




MEIKO 0180683

MEIKO 9500236



## Pumps

**3122402 DRAIN ELECTRO-PUMP 80W 230V 50Hz**  
inlet external  $\varnothing$  24 mm - outlet external  $\varnothing$  24 mm



MEIKO 0535502

**3122845 DRAIN PUMP 0.07KW 200/240V 50Hz**



MEIKO 9544233


**3122847 ELECTR.PUMP B242C2700**  
200/240V-346/415V 50Hz  
for Dishwasher conveyor type (MEIKO) K200VAPCSSTOP



MEIKO 9500488

MEIKO 9621799

**3122849 ELECTR.PUMP UP60-389 460V 60Hz**



MEIKO 9638043

**3122452 ELECTR.PUMP UP60-393 200/240V 50Hz 1.1A**  
inlet external  $\varnothing$  28 mm - outlet external  $\varnothing$  24 mm  
capacitor 5  $\mu$ F



MEIKO 9517934

MEIKO 9638047

**3122848 ELECTR.PUMP 0.55KW 200/240-346/415V**  
0.55KW 200/240-346/415V 50Hz motor rev.2800  
inlet  $\varnothing$  45 mm - outlet  $\varnothing$  42 mm



MEIKO 0501088

**3122688 ELECTRO-PUMP AP 12410DX 1.5HP 220/380V**  
inlet external  $\varnothing$  63 mm - outlet external  $\varnothing$  53 mm  
for Dishwasher (CAPIC) M600 - M950S  
for Dishwasher (ELETTROBAR) S870  
for Dishwasher conveyor type (COMENDA) - Series AC  
Series ACR  
for Dishwasher hood type (HOONVED) CAP10  
for Dishwasher hood type (MACH) MS1300 - MS1300E  
for Pan/utensilwashing machines (HOONVED) ED650



MEIKO

**3122024 MECHANICAL SEAL  $\varnothing$  12mm INNER SURFACE 8mm**  
for Dishwasher (ELFRAMO)



MEIKO 0501095




Suitable for:

# MEIKO



**3122546 ELECTRO-PUMP AP 2012DX 1.5HP 230/400V**  
 inlet external  $\varnothing$  63 mm - outlet external  $\varnothing$  54 mm  
 motor revolutions 2850 - flowrate 650 L/min  
 1.5HP 230/400V 50Hz 4.5/2.7A




MEIKO

Suitable for:  
**3122024 MECHANICAL SEAL  $\varnothing$  12mm INNER SURFACE 8mm**  
 for Dishwasher (ELFRAMO)



MEIKO 0501095

**3122245 ELECTRO-PUMP FIR 1205DX 2.7HP 220/380V**  
 inlet external  $\varnothing$  63 mm - outlet external  $\varnothing$  54 mm  
 motor revolutions 2800 - flowrate 600 L/min  
 2.7Hp 220/380V 7/4A  
 for Dishwasher (CAPIC) M1300 - M2200  
 for Dishwasher hood type (MACH) MS1100P - MS1300P  
 for Dishwasher hood type (WINTERHALTER) GS72



MEIKO 0501032

MEIKO 0501086

**3122024 MECHANICAL SEAL  $\varnothing$  12mm INNER SURFACE 8mm**  
 for Dishwasher (ELFRAMO)




MEIKO 0501095

**3122047 PUMP HOUSING**  
 inlet external  $\varnothing$  63 mm  
 outlet external  $\varnothing$  54 mm



MEIKO 0501097

**3122026 PUMP HOUSING SEAL**



MEIKO 0501101

**3122322 ELECTRO-PUMP FIR 1241DX 1.5HP 220/380V**  
 inlet external  $\varnothing$  63 mm - outlet external  $\varnothing$  54 mm  
 motor revolutions 2800 - flowrate 625 L/min  
 1.5HP 220/380V 50Hz 4.8/2.8A  
 for Dishwasher hood type (LAMBER)  
 till 1/01/99



MEIKO 0501129

MEIKO 0501131

MEIKO 0501146

**3122024 MECHANICAL SEAL  $\varnothing$  12mm INNER SURFACE 8mm**  
 for Dishwasher (ELFRAMO)



MEIKO 0501095



Suitable for:

**3122047 PUMP HOUSING**  
inlet external  $\varnothing$  63 mm  
outlet external  $\varnothing$  54 mm



MEIKO 0501097

**3122188 ELECTRO-PUMP FIR 1295SX 1,2HP 230/400V**  
inlet external  $\varnothing$  63 mm - outlet external  $\varnothing$  48 mm  
motor revolutions 2800 - flowrate 300 L/min  
1.2HP 230/400V 50Hz 3.8/2.2A  
for Dishwasher hood type (MACH) MS900 - MS900E



MEIKO 0501084

MEIKO 0501089

MEIKO 0501118

**3122027 PUMP HOUSING**  
inlet external  $\varnothing$  63 mm  
outlet external  $\varnothing$  48 mm



MEIKO 0501103

**3122447 ELECTRO-PUMP FIR 2256TSX 1HP 250V 50Hz**  
inlet external  $\varnothing$  45 mm - outlet external  $\varnothing$  40 mm  
motor revolutions 2750  
1HP 250V 50Hz 4.8A - capacitor 20  $\mu$ f  
for Pan/utensilwashing machines (MEIKO) FV250B



MEIKO 0501135

MEIKO 9604594

MEIKO 9621706

**3122021 PUMP HOUSING**  
inlet external  $\varnothing$  45 mm  
outlet external  $\varnothing$  40 mm



MEIKO 0501091

# MEIKO



Suitable for:

**3122026 PUMP HOUSING SEAL**




MEIKO 0501101

**3122024 MECHANICAL SEAL  $\varnothing$  12mm INNER SURFACE 8mm**  
for Dishwasher (ELFRAMO)



MEIKO 0501095

**3122026 PUMP HOUSING SEAL**




MEIKO 0501101

**3122024 MECHANICAL SEAL  $\varnothing$  12mm INNER SURFACE 8mm**  
for Dishwasher (ELFRAMO)



MEIKO 0501095

**3122020 PUMP HOUSING SEAL**



MEIKO 0501094

MEIKO 0501157




Suitable for:

# MEIKO




**3122001 ELECTRO-PUMP GRE 1001DX**  
 190W 230V 50Hz  
 inlet external  $\varnothing$  24 mm - outlet external  $\varnothing$  24 mm



MEIKO 0535509

**3122153 ELECTRO-PUMP TM 61E 0,45HP 220V**  
 for pressure boost  
 inlet  $\varnothing$  1" F - outlet  $\varnothing$  1" F  
 motor revolutions 2900 - flow rate 38 l/min  
 max pressure 6 ATM max temperature 90°C  
 0.45HP 220V 50Hz 2.3A - capacitor 10  $\mu$ f  
 for Dishwasher (OLIS) OLDS40 - OLDS50 - OLG540  
 OLG550 - OLG85  
 for Dishwasher hood type (DIHR) G12S  
 for Dishwasher hood type (KROMO) K100  
 for Dishwasher hood type (OLIS) OLG11S - OLHT11D  
 OLHT12



MEIKO 0535056

**3122458 ELECTRO-PUMP 0221/A 0.20HP 230V 50Hz**  
 inlet external  $\varnothing$  33 mm - outlet external  $\varnothing$  31 mm  
 motor revolutions 2800  
 0.20HP 230V 50Hz 1.5A - capacitor 6.3  $\mu$ f  
 for Dishwasher (MEIKO) FV40 - FV60  
 for Glasswasher/Cupwasher (MEIKO) FV20



MEIKO 0501166

MEIKO 9534806


**3122461 ELECTRO-PUMP 3911 0.75HP 230V 50Hz**  
 inlet external  $\varnothing$  45 mm - outlet external  $\varnothing$  40 mm  
 motor revolutions 2800 - flowrate 270 L/min  
 0.75HP 230V 50Hz 4A - capacitor 12.5  $\mu$ f



MEIKO 0501085

MEIKO 9623861

**3122297 GASKET 4247**



MEIKO 9500310

**3122493 IMPELLER FOR PUMP  $\varnothing$  96 mm - RYTON**



MEIKO 0501092

MEIKO 0501137

**3122024 MECHANICAL SEAL  $\varnothing$  12mm INNER SURFACE 8mm**  
 for Dishwasher (ELFRAMO)




MEIKO 0501095



Suitable for:

Suitable for:

**3122846 PUMP UP60-386 200/240V 50Hz**  
 inlet  $\varnothing$  28 mm - outlet  $\varnothing$  24 mm  
 capacitor 5  $\mu$ f



MEIKO 9544228

MEIKO 9638029

## Rating-plates

**3399073 CONTROL PLATE**  
 size 200x52 mm  
 for Pan/utensilwashing machines (MEIKO) FV130



MEIKO 0467249

**3399074 CONTROL PLATE**  
 size 200x52 mm  
 for Dishwasher (MEIKO) FV40 - FV70  
 for Dishwasher hood type (MEIKO) DV80



MEIKO 0467210

**3399075 CONTROL PLATE**  
 size 200x52 mm  
 for Dishwasher (MEIKO) DV40N - FV40T  
 for Dishwasher hood type (MEIKO) DV40 - DV80  
 for Glasswasher/Cupwasher (MEIKO) FR30G - FV20T  
 FV20V - FV25G - FV30GS



MEIKO 0467221

## Remote control switches


**3454002 CONTACTOR B7-30-1 220/240V**  
 universal



MEIKO 0135209

MEIKO 9540220

**3446562 CONTACTOR LOVATO BF0901A**  
 coil 9A 230V 50/60Hz 4.2Kw  
 3 normally open contacts  
 1 normally closed auxiliary contact



MEIKO 0135200




Suitable for:

# MEIKO




**3446555 CONTACTOR LOVATO BF0910A**  
 coil 9A 400V 50/60Hz 4.2Kw  
 3 normally open contacts  
 1 normally open auxiliary contact



MEIKO 0135209


**3446561 CONTACTOR LOVATO BF0910A**  
 coil 9A 230V 50/60Hz 4.2Kw  
 3 normally open contacts  
 1 normally open auxiliary contact  
 for Dishwasher (ADLER) DS400 - DS410 - DS600  
 for Dishwasher (WHIRLPOOL) F650  
 for Glasswasher/Cupwasher (WHIRLPOOL) F400 - F410



MEIKO 0135204

MEIKO 9520025


**3446583 CONTACTOR LOVATO BF18T4A**  
 coil 18A 230V 50/60Hz 8Kw  
 4 normally open contacts  
 no auxiliary contact



MEIKO 0135208

MEIKO 9518558

**3446582 CONTACTOR LOVATO BF1810A**  
 coil 18A 230V 50/60Hz 7.5Kw  
 3 normally open contacts  
 1 normally open auxiliary contact



MEIKO 0135202

MEIKO 0135207

MEIKO 9520023

**3446556 CONTACTOR LOVATO BG0910A**  
 coil 9A 230V 50/60Hz 4Kw  
 3 normally open contacts  
 1 normally open auxiliary contact  
 for Dishwasher (MACH) MGL500 - MS350 - MS351  
 MS400B - MS400T - MS450 - MS451 - MS453  
 MS500B - MS800  
 for Dishwasher conveyor type (SILANOS) T1650  
 T2000  
 for Dishwasher conveyor type (WHIRLPOOL) AGB676  
 AGB678 - AGB682  
 for Dishwasher hood type (MACH) MS1100 - MS1300  
 MS900  
 for Dishwasher hood type (SILANOS) E1000 - N1000  
 for Dishwasher hood type (WHIRLPOOL) AGB664  
 AGB668 - AGB669 - AGB671



MEIKO 0135200





## Rinse aid pumps and accessories

**3090157 DETERGENT DOSING PUMP PP 7 L/h 24V**



MEIKO 9544292

**3090165 DETERGENT INJECTOR 230V 50Hz**  
for Pan/utensilwashing machines (HOBART) UW135  
UW135H



MEIKO 0260024

**3090112 DETERGENT PERISTALTIC PUMP PR-7**  
adjustable flow rate 1.5 - 7 L/h  
santoprene tube  
pressure 0.1 bar  
230V 50Hz  
with assembly kit



MEIKO 9504802

MEIKO 9533323

**3090201 DETERGENT PERISTALTIC PUMP PR-7**  
adjustable flow rate 1.5 - 7 L/h  
santoprene tube with clamp connections 8x12 mm  
pressure 0.1 bar  
230V 50Hz  
with assembly kit



MEIKO 9511667

**3090229 DETERGENT PUMP 10 L/h 230V 50Hz**



MEIKO 9531928

**3090233 DISPENSER F/DETERGENT 12V 4 L/h SR10/50**



MEIKO 0535682

**3090235 PIPE  $\varnothing$  2x1.6x190 mm**  
for doser 4 L/h



MEIKO 0535694

**3090232 DOSING PUMP 24V 1.25 L/h 3.0 bar**



MEIKO 9625978

**3090304 PERISTALTIC DETERGENT PUMP PR-1**  
fixed flow rate: 0.3÷1 l per h  
pressure: 3 bar  
sekobrill pipe  
230V 50Hz  
complete with mounting kit



MEIKO 9503331



Suitable for:

# MEIKO



## 3090142 PERISTALTIC PUMP KONSTA PS10M

set flowrate 1,5 L/h  
PLASTO-Mj pipe for rinse aid  
4,5W 230V 50Hz  
complete with assembly kit



MEIKO

Suitable for:


## 3090230 PIPE COUPLING M10x25 FOR DOSER



MEIKO 8000013

## 3090084 RINSE AID DISPENSER N6 W4W4


with EPDM diaphragm  
minimum pressure 0,5 bar  
inlet side hose fitting 4 mm  
pressure side hose fitting 4 mm



MEIKO 0260070

## 3090155 RINSE-AID DISPENSER PG0.4 230V

230V 50/60Hz - 0.4 Lt/h



MEIKO 9518514

## 3090190 WASHING PRODUCT DISPENSER

mod. RS20RNIP - Ext.size. 160 x 80 x 85 mm  
220/240 V - 50 Hz  
flowrate 0.28L/hour - 2.80L/hour



MEIKO

## Rotary switches

### 3057200 SELECTOR SWITCH 0-1 POSITIONS 20A 600V for Dishwasher hood type (COMENDA) DV40



MEIKO 0123271

### 3057209 SELECTOR SWITCH 0-1 POSITIONS 20A 600V for Dishwasher (MEIKO) FV40 for Dishwasher hood type (MEIKO) DV40



MEIKO 0123261

MEIKO 0123272

**3057210** **SELECTOR SWITCH 0-2 POSITIONS**  
20A 600V  
for Glasswasher/Cupwasher (MEIKO) FR30G - FV25G



MEIKO 0123262

MEIKO 0123270




**3057199** **SELECTOR SWITCH 0-2 POSITIONS 20A 600V**  
for Dishwasher hood type (MEIKO) DV120



MEIKO 0123273

**3053327** **SELECTOR SWITCH 0-3 POSITIONS**  
16A 415V - pin 5x3 mm  
for Pan/utensilwashing machines (MEIKO) FV120



MEIKO 0123001

## Salt container and accessories

**3067001** **SALT CONTAINER**



MEIKO 0270106

## Shock absorbers

**3007008** **SHOCK ABSORBER 150N**  
for Pan/utensilwashing machines (MEIKO) FV250B



MEIKO 0431040

**3007007** **SHOCK ABSORBER 75N**  
for Pan/utensilwashing machines (MEIKO) FV130B



MEIKO 0431041

## Solenoid valves

**3120273** **MULLER COIL 230V 60HZ FOR DISPENSER**  
temperature 90°C



MEIKO 0113256



Suitable for:

# MEIKO



Suitable for:

## Solenoid valves

**3120164 MULLER SOLENOID VALVE 220/240V ø 14 mm**  
solenoid valve 90° - 220/240V 50/60Hz - max 90°C  
inlet ø 3/4" - dual outlet ø 14 mm



MEIKO

**3120271 MULLER COIL 220/240V 50/60Hz**  
temperature 90°C



MEIKO 0113223

**3120161 SOLENOID VALVE MULLER 220/240V ø 14 mm**  
solenoid valve 180°-220/240V 50/60Hz - max 90°C  
inlet ø 3/4" - outlet ø 14 mm



MEIKO 0113202

**3120271 MULLER COIL 220/240V 50/60Hz**  
temperature 90°C



MEIKO 0113223

**3120162 SOLENOID VALVE MULLER 220/240V ø 14 mm**  
solenoid valve 180°-220/240V 50/60Hz - max 90°C  
inlet ø 3/4" - dual outlet ø 14 mm



MEIKO

**3120271 MULLER COIL 220/240V 50/60Hz**  
temperature 90°C



MEIKO 0113223

**3120163 SOLENOID VALVE MULLER 220/240V ø 14 mm**  
solenoid valve 90°-22/2400V 50/60Hz - max 90°C  
inlet 3/4" - outlet ø 14 mm



MEIKO 0113001

MEIKO 0113200

**3120271 MULLER COIL 220/240V 50/60Hz**  
temperature 90°C



MEIKO 0113223

**3120560 SOLENOID VALVE 1/2"x1/2" 230V 50Hz**  
for Dishwasher conveyor type (MEIKO) K200



MEIKO 9500227


**3120404 SOLENOID VALVE 230V ø 10.5 mm**  
solenoid valve 90° - 230V 50/60Hz - max 90°C  
3/4" inlet - 1 outlet ø 10.5 mm



MEIKO 9005869

Suitable for:

**3120561 SOLENOID VALVE 3/4"x3/4" 220V 50Hz**  
for Pan/utensilwashing machines (MEIKO) FV120  
FV130 - FV240 - FV250



MEIKO 0113222

Suitable for:

**3120271 MULLER COIL 220/240V 50/60Hz**  
temperature 90°C




MEIKO 0113223

**3120505 SOLENOID VALVE 329 24V ø 10 mm**  
solenoid valve 180° - 24V 50Hz - max 90°C  
inlet 3/4" - outlet ø 10 mm



MEIKO 9623108

**3120000 FILTER FOR INLET SOLENOID VALVE ELBI**




MEIKO 9506228

**3120511 SOLENOID VALVE 350 24V ø 14 mm**  
solenoid valve 90° - 24V 50Hz - max 90°C  
3/4" inlet - ø 14 mm outlet



MEIKO 9623762

**3120009 SOLENOID VALVE 351 220/240V ø 14 mm**  
solenoid valve 180° - 220/240V 50/60Hz - max 90°C  
inlet 3/4" - outlet ø 14 mm




MEIKO 9505869

**3120000 FILTER FOR INLET SOLENOID VALVE ELBI**



MEIKO 9506228

**3120512 SOLENOID VALVE 351 24V ø 14 mm**  
solenoid valve 180° - 24V 50Hz - max 90°C  
3/4" inlet - ø 14 mm outlet



MEIKO

**3120513 SOLENOID VALVE 352 24V ø 14 mm**  
solenoid valve 90° - 24V 50Hz - max 90°C  
3/4" inlet - ø 14 mm outlet



MEIKO 9623793



Suitable for:

# MEIKO



Suitable for:

**3120399 1-WAY WATER SOLENOID VALVE 180°-12V**  
inlet 3/4" - outlet  $\varnothing$  10.5 mm  
max temperature 90°C  
operating pressure from 0.2 to 10 bar



MEIKO


## Springs

**3250095 DOOR SPRING**  
 $\varnothing$  21 mm - length 110 mm  
for FV40



MEIKO 9521764

**3250164 DOOR SPRING 40 mm 70N**



MEIKO 0431071

**3250163 SPRING  $\varnothing$  14.5x80 mm**  
for FV28G-ECO STAR-430G



MEIKO 0430025

**3250242 SPRING SUPPORT ROD  $\varnothing$  8x78 mm**  
for DISHWASHER K TRONIK




MEIKO 8100910

**3250246 SPRING FOR 50N 080170 5-2**  
dimensions 50x970x40x36 mm



MEIKO 0431073

**3250247 SPRING FOR PER 70N 080171 7-2**  
dimensions 70x970x40x36 mm



MEIKO 0431074

**3250245 SPRING FOR 90N 080172 9-2**  
dimensions 90x970x40x36 mm



MEIKO 0431075




Suitable for:

**3250243 SPRING SUPPORT**  
for DISHWASHER K TRONIK



MEIKO 0620284

**3250248 SPRING 50x920x40x36 mm**



MEIKO 9504017

**3250244 SPRING 70x920x40x36 mm**



MEIKO 9504018

## MEIKO


Suitable for:

**3250250 SPRING 50x1085x40x36 mm**




MEIKO 0431088

**3250251 SPRING 70x1085x40x35 mm**



MEIKO 0431089

**3250249 SPRING 90x1085x40x36 mm**




MEIKO 0431090



## Thermostats

**3444245 BOILER SINGLE-PHASE THERMOSTAT 0-95°C**  
covered capillary 470 mm  
bulb  $\varnothing$  6x148 mm  
screw adjustment  
for Glasswasher/Cupwasher (MEIKO) FV28G



MEIKO 0108037

**3444718 GASKET FOR THERMOSTAT BOILER**  
universal



MEIKO 0108040

**3444720 SINGLE-PHASE THERMOSTAT 0-100°C**  
bulb  $\varnothing$  8x285 mm  
model ATH-1 B603021  
for Dishwasher hood type (MEIKO) DV120B  
for Pan/utensilwashing machines (MEIKO) FV120B  
FV240B



MEIKO 0108004

MEIKO 9539518

**3444802 SINGLE-PHASE THERMOSTAT 0-120°C**  
for Pan/utensilwashing machines (MEIKO) FV120  
FV240



MEIKO 9521606




Suitable for:

# MEIKO



Suitable for:


**3444247 THREE-PHASE THERMOSTAT 120°C**  
 with manual reset  
 covered capillary 540 mm  
 bulb  $\varnothing$  6x94 mm  
 for Dishwasher (MEIKO) ECOSTAR530F  
 for Glasswasher/Cupwasher (MEIKO) ECOSTAR430F  
 for Pan/utensilwashing machines (MEIKO) FV250



MEIKO 9502526


## Timers

**3322267 PROGRAMMER 220V 50/60Hz**  
 cycle 120"  
 for Glasswasher/Cupwasher (MEIKO) FR30G - FV25G




MEIKO 0124080

**3322268 PROGRAMMER 3 CAMS**  
 230V 50Hz - cycle 162"  
 for Dishwasher (MEIKO) FV40N  
 for Dishwasher hood type (MEIKO) DV40




MEIKO 0124036

**3322270 PROGRAMMER 3 CAMS**  
 320V 50Hz - cycle 56"  
 for Dishwasher hood type (MEIKO) DV120B



MEIKO 0124039


**3322266 PROGRAMMER 3 CAMS 220V 50Hz**  
 for Dishwasher hood type (MEIKO) DV80



MEIKO 0124040

MEIKO 0124090

**3322269 PROGRAMMER 4 CAMS**  
 230V 50Hz - cycle 480"  
 pin 5x3 mm  
 for Pan/utensilwashing machines (MEIKO) FV120B  
 FV240B



MEIKO 0124045





## Wash and rinse arms and accessories

### 3743325 ARM ASSEMBLY BOSS



MEIKO 0620286

### 3743329 ARM ASSEMBLY SUPPORT

for Dishwasher (MEIKO) FV40  
for Glasswasher/Cupwasher (MEIKO) FV20 - FV30



MEIKO 0620383


### 3743360 ARM ASSEMBLY SUPPORT

for Glasswasher/Cupwasher (MEIKO) FV25G



MEIKO 0620382

### 3786045 O-RING $\varnothing$ 50x1,5 mm EPDM



MEIKO 0401030

### 3743161 COMPLETE RINSE ARM

length 495 mm  
for Dishwasher (MEIKO) FV40  
for Dishwasher hood type (MEIKO) DV120 - DV80



MEIKO 9547257

### 3743324 ARM ASSEMBLY SHAFT SUPPORT



MEIKO 0620288

### 3743333 ARM ASSEMBLY SUPPORT



MEIKO 8000190



Suitable for:

# MEIKO



**3743160 COMPLETE WASH ARM**  
 length 500 mm  
 for Dishwasher (MEIKO) FV40  
 for Dishwasher hood type (MEIKO) DV120 - DV80



MEIKO 9517391

Suitable for:  
**3743824 ARM ASSEMBLY SPACER**  
 for Dishwasher hood type (MEIKO) DV80



MEIKO 9604483

**3743346 COMPLETE WASH ARM ASSEMBLY**  
 for Dishwasher (MEIKO) FV40N - FV60E  
 for Glasswasher/Cupwasher (MEIKO) FV20N



MEIKO 8001814

**3743827 LONG WASH ARM SUPPORT**  
 for Dishwasher (MEIKO) ECOSTAR580F - FV110 - FV40  
 FV60 - FV70  
 for Dishwasher conveyor type (MEIKO) K207/3  
 for Glasswasher/Cupwasher (MEIKO) FV20 - FV30



MEIKO 0620285

**3743326 RING NUT FOR ARM ASSEMBLY BOSS**



MEIKO 8000049

**3743327 RING NUT FOR ARM ASSEMBLY BOSS**



MEIKO 8000048

**3743176 RINSE ARM ASSEMBLY BODY**  
 for Dishwasher (MEIKO) ECOSTAR530F - FV40T  
 for Glasswasher/Cupwasher (MEIKO) ECOSTAR430F  
 FV28G



MEIKO 0620394

**3743162 FASTENING SCREW**  
 for Dishwasher (MEIKO) ECOSTAR530F - FV40T  
 for Glasswasher/Cupwasher (MEIKO) ECOSTAR430F  
 FV28G



MEIKO 0310010

**3743830 RINSE ARM SUPPORT**  
 for Dishwasher hood type (MEIKO) DV40  
 for Glasswasher/Cupwasher (MEIKO) ECOSTAR430F  
 for Pan/utensilwashing machines (MEIKO) FV130B  
 FV250B



MEIKO 0620235

**3743181 RINSE ARM 111 mm**  
 for Dishwasher (MEIKO) ECOSTAR530F  
 for Glasswasher/Cupwasher (MEIKO) ECOSTAR430F  
 FV28G



MEIKO 0620391



Suitable for:

**3743170 RINSE ARM 155 mm**  
for Dishwasher (MEIKO) ECOSTAR530F - FV40T  
for Glasswasher/Cupwasher (MEIKO) ECOSTAR430F  
FV28G



MEIKO 0620390

**3743165 RINSE PROPELLER**  
for Dishwasher (MEIKO) ECOSTAR530F - FV40T  
for Glasswasher/Cupwasher (MEIKO) ECOSTAR430F  
FV28G



MEIKO 0620121

**3743823 WASH ARM ASSEMBLY BOSS**  
for Dishwasher hood type (MEIKO) DV120-2



MEIKO 9517397

MEIKO 9671628

**3743336 RINSE ARM ASSEMBLY 295 mm**  
for Glasswasher/Cupwasher (MEIKO) F28G



MEIKO 8003886

**3743334 RINSE ARM ASSEMBLY 366 mm**  
for Dishwasher (MEIKO) F25G




MEIKO 8000191

# MEIKO



Suitable for:

**3743168 RINSE JET**  
for Dishwasher (MEIKO) ECOSTAR530F - FV40T  
for Glasswasher/Cupwasher (MEIKO) ECOSTAR430F  
FV28G



MEIKO 0620157

**3743179 SPINDLE FOR WASH/RINSE ARM ASSY**



MEIKO 8003957

MEIKO 8004008

**3743343 RINSE ARM ASSEMBLY 365 mm**  
for Dishwasher (MEIKO) F25G



MEIKO 8000192

**3743342 RINSE ARM ASSEMBLY 400 mm**  
for Dishwasher (MEIKO) FV110G



MEIKO 8003968



Suitable for:

# MEIKO



**3743337 RINSE ARM ASSEMBLY 470 mm**  
for Dishwasher (MEIKO) FV40N  
for Dishwasher hood type (MEIKO) DV120B - DV40  
DV80



MEIKO 8000047

MEIKO 9542558

**3743829 WASH ARM SUPPORT**  
for Dishwasher hood type (MEIKO) DV80T  
for Pan/utensilwashing machines (MEIKO) FV250B



MEIKO 8002880

**3743335 RINSE ARM ASSEMBLY 475 mm**  
for Dishwasher (MEIKO) FV40N  
for Dishwasher hood type (MEIKO) DV120B - DV40  
DV80



MEIKO 8000046

MEIKO 9542559

**3743341 RINSE ARM ASSEMBLY 535 mm**  
for Pan/utensilwashing machines (MEIKO) FV120B  
FV240B - FV250B



MEIKO 8000096

MEIKO 9542573

**3743372 RINSE ARM ASSEMBLY 535 mm**  
for Pan/utensilwashing machines (MEIKO) FV120B  
FV130B - FV240B



MEIKO 8000097

MEIKO 9542572

**3743328 RINSE ARM BOSS**



MEIKO 8000231

**3743371 HALF DISK**  
for Dishwasher hood type (MEIKO) DV120 - DV80



MEIKO 0620211

**3743166 RINSE JET**  
for Pan/utensilwashing machines (MEIKO) FV250



MEIKO 9517406


**3743345 RINSE PIPE**  
for Dishwasher (MEIKO) FR40G  
for Glasswasher/Cupwasher (MEIKO) FR30G



MEIKO 8000023

Suitable for:

**3743314 SUPPORT FOR ARM ASSEMBLY**  
for Dishwasher (MEIKO) DV120T - DV80T  
DV80TFA



MEIKO 0620506

Suitable for:

**3786679 O-RING 21x2 mm EPDM**



MEIKO 0401016

**3743338 WASH ARM ASSEMBLY**  
for Glasswasher/Cupwasher (MEIKO) ECOSTAR430F




MEIKO 8004683

**3743339 WASH ARM ASSEMBLY**  
for Glasswasher/Cupwasher (MEIKO) FV25G



MEIKO 8000187

**3743174 WASH ARM ASSEMBLY BODY**  
for Dishwasher (MEIKO) ECOSTAR530F - FV40T  
for Glasswasher/Cupwasher (MEIKO) ECOSTAR430F  
FV28G



MEIKO 0620380

MEIKO 8004635

**3743162 FASTENING SCREW**  
for Dishwasher (MEIKO) ECOSTAR530F - FV40T  
for Glasswasher/Cupwasher (MEIKO) ECOSTAR430F  
FV28G




MEIKO 0310010

**3743181 RINSE ARM 111 mm**  
for Dishwasher (MEIKO) ECOSTAR530F  
for Glasswasher/Cupwasher (MEIKO) ECOSTAR430F  
FV28G



MEIKO 0620391

**3743170 RINSE ARM 155 mm**  
for Dishwasher (MEIKO) ECOSTAR530F - FV40T  
for Glasswasher/Cupwasher (MEIKO) ECOSTAR430F  
FV28G



MEIKO 0620390

**3743171 RINSE ARM 212 mm**  
for Dishwasher (MEIKO) ECOSTAR530F - FV40T  
for Glasswasher/Cupwasher (MEIKO) ECOSTAR430F  
FV28G



MEIKO 0620389

**3743168 RINSE JET**  
for Dishwasher (MEIKO) ECOSTAR530F - FV40T  
for Glasswasher/Cupwasher (MEIKO) ECOSTAR430F  
FV28G



MEIKO 0620157



Suitable for:

**3743165 RINSE PROPELLER**

for Dishwasher (MEIKO) ECOSTAR530F - FV40T  
for Glasswasher/Cupwasher (MEIKO) ECOSTAR430F FV28G



MEIKO 0620121

**3743180 SHORT WASH ARM**

for Dishwasher (MEIKO) ECOSTAR530F - FV40T  
for Glasswasher/Cupwasher (MEIKO) ECOSTAR430F FV28G



MEIKO 0620388

**3743177 SPINDLE FOR WASH/RINSE ARM ASSY SUPPORT**

for Dishwasher (MEIKO) ECOSTAR530F - FV40T  
for Glasswasher/Cupwasher (MEIKO) ECOSTAR430F FV28G



MEIKO 0620381

MEIKO 8004195

**3743175 WASH ARM**

for Dishwasher (MEIKO) ECOSTAR530F - FV40T  
for Glasswasher/Cupwasher (MEIKO) ECOSTAR430F FV28G



MEIKO 0620386

**3743825 WASH ARM ASSEMBLY SUPPORT**

for Glasswasher/Cupwasher (MEIKO) FV28G



MEIKO 0620432

# MEIKO



Suitable for:

**3743178 SCREW RING NUT**

for Dishwasher (MEIKO) ECOSTAR530F - FV40T  
for Glasswasher/Cupwasher (MEIKO) ECOSTAR430F FV28G



MEIKO 0620384

**3743182 SHORT WASH ARM**

for Dishwasher (MEIKO) ECOSTAR530F  
for Glasswasher/Cupwasher (MEIKO) ECOSTAR430F FV28G



MEIKO 0620387

**3743172 WASH ARM**

for Dishwasher (MEIKO) ECOSTAR530F - FV40T  
for Glasswasher/Cupwasher (MEIKO) ECOSTAR430F FV28G



MEIKO 0620385

**3743823 WASH ARM ASSEMBLY BOSS**

for Dishwasher hood type (MEIKO) DV120-2



MEIKO 9517397

MEIKO 9671628




# MEIKO



Suitable for:

**3743340 WASH ARM ASSEMBLY 500 mm**  
for Dishwasher hood type (MEIKO) DV120 - DV160 DV80



MEIKO 8000147

Suitable for:

**3743348 WASH ARM ASSEMBLY 550 mm**  
for Pan/utensilwashing machines (MEIKO) FV130B FV250B



MEIKO 8000678

MEIKO 9525861


**3743347 WASH ARM ASSEMBLY 590 mm**  
for Pan/utensilwashing machines (MEIKO) FV130B FV250B



MEIKO 8000677


MEIKO 9525862

**3743330 WASH ARM BOTTOM BOSS**  
for Pan/utensilwashing machines (MEIKO) FV130B FV250B



MEIKO 0620281

**3743331 WASH ARM TOP BOSS**  
for Pan/utensilwashing machines (MEIKO) FV130B FV250B



MEIKO 0620282

**3743344 WASH ARM 385 mm**  
for Glasswasher/Cupwasher (MEIKO) ECOSTAR430F FV28G



MEIKO 0620429

**3060087 BRASS NUT  $\varnothing$  3/8"**  
for Dishwasher (SILANOS) E50 - N50 - N700 - N90 800 - 900  
for Dishwasher (WHIRLPOOL) AGB648 - AGB649 AGB650 - AGB651 - AGB652 - AGB653 - AGB657 AGB658 - AGB660 - AGB663  
for Dishwasher hood type (SILANOS) 1000 - 1300 1300S  
for Glasswasher/Cupwasher (MACH) MB235LI - MB240LI MB920  
for Glasswasher/Cupwasher (SILANOS) F19 - F22 F27 - N22 - R20 - R29 - 020 - 030  
for Glasswasher/Cupwasher (WHIRLPOOL) AGB641 AGB642 - AGB643 - AGB644 - AGB645 - AGB646 AGB647 - AGB782 - AGB783 - AGB784 - AGB785



MEIKO 0360211

MEIKO 9515957



Suitable for:

**3186299** **FLAT GASKET** ø 24x18x2 mm



MEIKO 0217433

**3743164** **WASH JET SPINNER**  
for Glasswasher/Cupwasher (MEIKO) FV28G




MEIKO 0620436

**3743826** **WASH END CUP**  
for Dishwasher conveyor type (MEIKO) K201



MEIKO 0620422

**3743173** **2 WAYS WASHING BOSS**  
for Dishwasher (MEIKO)  
till 31/12/91  
FV40N  
for Dishwasher hood type (MEIKO)  
till 31/12/91  
DV120 - DV40 - DV80



MEIKO 8000045

**3743332** **WASH ARM CAP**  
for Dishwasher hood type (MEIKO) DV80



MEIKO 0620163

# MEIKO

Suitable for:

**3743167** **WASH JET**  
for Glasswasher/Cupwasher (MEIKO) FV28G



MEIKO 0620435

**3743828** **WASH SYSTEM CAP**  
for Dishwasher conveyor type (MEIKO) K140 - K160  
K200 - K400



MEIKO 9500040

**3743349** **WASH ARM ASSEMBLY BOSS - 2 WAYS**



MEIKO 8000044

**3743351** **WASH ARM 220 mm**



MEIKO 8000043







Suitable for:

**3743358 WASH ARM 220 mm**




MEIKO 8000052

**3743350 WASH ARM 222 mm**



MEIKO 8000042

**3743169 3 WAYS WASHING BOSS**  
for Glasswasher/Cupwasher (MEIKO) FV25G  
for Pan/utensilwashing machines (MEIKO) FV120B  
FV240B



MEIKO 8000093

**3743332 WASH ARM CAP**  
for Dishwasher hood type (MEIKO) DV80



MEIKO 0620163

**3743355 WASH ARM 267 mm**



MEIKO 8000088

**3743357 WASH ARM 267 mm**




MEIKO 8000090

# MEIKO

Suitable for:

**3743359 WASH ARM 220 mm**



MEIKO 8000053

**3743352 WASH ARM ASSEMBLY BOSS - 3 WAYS**



MEIKO 8000094

**3743354 WASH ARM 267 mm**



MEIKO 8000092

**3743356 WASH ARM 267 mm**



MEIKO 8000089

**3743353 WASH ARM 268 mm**



MEIKO 8000091



*The data herewith contained may change without notice and LF SpA cannot be held responsible for possible errors stated or resulting by the use of this document. All rights reserved. No part of this publication may be reproduced without written permission by LF SpA.*



**LF SpA**  
via Voltri, 80 - 47522 Cesena (FC) ITALIA  
Tel. +39 0547 34 11 11 - Fax +39 0547 34 11 10  
[www.lfircambi724.it](http://www.lfircambi724.it) - [www.lfircambi724.mobi](http://www.lfircambi724.mobi)  
[info@lfircambi.it](mailto:info@lfircambi.it)  
Export Dept.: Tel. +39 0547 34 11 50 - Fax: +39 0547 34 11 55  
[www.lfspareparts724.com](http://www.lfspareparts724.com) - [www.lfspareparts724.mobi](http://www.lfspareparts724.mobi)  
[export@lfspareparts.com](mailto:export@lfspareparts.com)

**FRANCE**



**EPGC Sas**  
13, Rue des Forts - 59960 Neuville en Ferrain  
Tél. +33 (0)3 20 25 06 21  
Fax +33 (0)3 20 25 34 12  
[www.epgc.com](http://www.epgc.com)  
[www.epgc724.mobi](http://www.epgc724.mobi)  
[epgc@epgc.com](mailto:epgc@epgc.com)

**DEUTSCHLAND**



**LF GmbH**  
Junkersstrasse, 1 - D-82178 Puchheim - München  
Tel. +49 89 89 45 78 66  
Fax +49 89 89 45 78 88  
[www.lfersatzteile724.de](http://www.lfersatzteile724.de)  
[www.lfersatzteile724.mobi](http://www.lfersatzteile724.mobi)  
[info@lfersatzteile.de](mailto:info@lfersatzteile.de)

**SCHWEIZ**



**LF GmbH Verkaufsbüro**  
Sennweidstrasse, 45 - CH-6312 Steinhausen  
Tel. +41 (0)41 760 15 80-1  
Fax +41 (0)41 760 15 85  
[www.lfersatzteile724.ch](http://www.lfersatzteile724.ch)  
[www.lfersatzteile724.mobi](http://www.lfersatzteile724.mobi)  
[info@lfersatzteile.ch](mailto:info@lfersatzteile.ch)

**ESPAÑA**



**LF Repuestos Horeca S.L.U.**  
Calle Ciudad Real, 10 - 45517 Escalonilla - Toledo  
Tif. +34 91 477 91 00  
Fax +34 91 477 90 81  
[www.lfrepuestos724.es](http://www.lfrepuestos724.es)  
[www.lfrepuestos724.mobi](http://www.lfrepuestos724.mobi)  
[info@lfrepuestos.es](mailto:info@lfrepuestos.es)

**UNITED KINGDOM**



**LF Spare Parts Ltd.**  
A10a Lakeside Business Park, Broadway Lane  
South Cerney, Gloucestershire GL7 5XL  
Tel. +44 (0)1285 86 16 25  
Fax +44 (0)1285 86 39 49  
[www.lfspareparts724.co.uk](http://www.lfspareparts724.co.uk)  
[www.lfspareparts724.mobi](http://www.lfspareparts724.mobi)  
[info@lfspareparts.co.uk](mailto:info@lfspareparts.co.uk)

**RUSSIA**



**OOO LF**  
ul, Anatoliya Zhivova, 8 - office 1 - 123100 Moscow  
Tel. +7 499 259 85 75  
Fax +7 495 725 26 53  
[www.lfspareparts724.ru](http://www.lfspareparts724.ru)  
[www.lfspareparts724.mobi](http://www.lfspareparts724.mobi)  
[info@lfspareparts.ru](mailto:info@lfspareparts.ru)

**CHINA**



**LF China**  
Room 102, House 8, Lane 725, Mao Tai Rd.  
Changning Dist. - 200336 Shanghai  
Tel. +86 (0)21 33 53 66 31  
Fax +86 (0)21 33 53 66 32  
[www.lfspareparts724.com](http://www.lfspareparts724.com)  
[www.lfspareparts724.mobi](http://www.lfspareparts724.mobi)  
[china@lfspareparts.com](mailto:china@lfspareparts.com)