



Spare parts for:

Warewashing equipment



Suitable for:

NOSEM



This catalogue is automatically generated.
Therefore, the sequence of the items might
not be always shown at best.

Updates will be issued in case of additions
and/or amendments.

Suitable universal spare parts may not be included





Suitable for:

NOSEM




Suitable for:

Air Chambers

3060118 AIR CHAMBER

for Dishwasher MAGIC50
for Dishwasher hood type (SO.WE.BO.) 6.2PB




NOSEM K602

Bearings

3063102 S609RS BEARING F/ROTATING SUPPORT

for Dishwasher (AFI) A600 - A900
for Dishwasher (EUROSYSTEM) PRO400
for Dishwasher (HILTA) S41 - S42
for Dishwasher (NOSEM) C2050 - C5000 - C5010
NC501
for Dishwasher hood type (AFI) A1000L
for Dishwasher hood type (EUROSYSTEM) PRO600
for Dishwasher hood type (HILTA) W13 - W14 - W15
for Dishwasher hood type (NOSEM) K601 - K602
for Glasswasher/Cupwasher (AFI) A35 - A35Z2 - A36
for Glasswasher/Cupwasher (EUROSYSTEM) PRO100
PRO200
for Glasswasher/Cupwasher (HILTA) RB10 - RB22
SB10 - SB22
for Glasswasher/Cupwasher (NOSEM) C2010L - C4010L



NOSEM



Caps

3439007 HEXAGONAL TANK CAP 3/8" GAS
 for Glasswasher/Cupwasher (AFI) A35 - A35Z2 - A36
 for Glasswasher/Cupwasher (EUROSYSTEM) PRO100
 PRO200
 for Glasswasher/Cupwasher (HILTA) RB10 - RB22
 SB10 - SB22
 for Glasswasher/Cupwasher (IME OMNIWASH) DUE
 JA35 - JA36 - JA40 - JA41 - JOLLY - UNO
 for Glasswasher/Cupwasher (NOSEM) C2010L - C4010L
 NC201 - NR101 - R1010
 for Glasswasher/Cupwasher (NUOVA SIMONELLI) KIARA1
 KIARA2 - KIARA4
 for Glasswasher/Cupwasher (SAB ITALIA) C35 - C36
 for Glasswasher/Cupwasher (SO.WE.BO.) 600 - 601
 631 - 661 - 691 - 701 - 712 - 742 - 752
 for Glasswasher/Cupwasher (SOTAL) C230 - EC195



NOSEM

3186181 O-RING 03068 EPDM
 for Dishwasher (SO.WE.BO.) 601 - 701 - 752
 for Dishwasher (SOTAL) ER225
 for Glasswasher/Cupwasher (AFI) A35 - A35Z2 - A36
 for Glasswasher/Cupwasher (COMENDA) - Series B
 for Glasswasher/Cupwasher (EUROSYSTEM) PRO100
 PRO200
 for Glasswasher/Cupwasher (HILTA) RB10 - RB22
 SB10 - SB22
 for Glasswasher/Cupwasher (IME OMNIWASH) DUE
 JA35 - JA36 - JA40 - JA41 - JOLLY - UNO
 for Glasswasher/Cupwasher (NOSEM) C2010L - C4010L
 NC201 - NR101 - R1010
 for Glasswasher/Cupwasher (NUOVA SIMONELLI) KIARA1
 KIARA2 - KIARA4
 for Glasswasher/Cupwasher (SAB ITALIA) C35 - C36



NOSEM

Drain assembly

3316141 DRAIN ASSEMBLY 1"1/4
 for QUATTRO Q



NOSEM

Drain plugs

3448142 COMPLETE OVERFLOW PIPE \varnothing 25x100 mm
 in plastic
 for CL-CS-UNO-DUE
 for Glasswasher/Cupwasher (EMB) 35HL



NOSEM

3448177 COMPLETE OVERFLOW PIPE \varnothing 35x165 mm
 in plastic
 for QUATTRO Q-T-BA



NOSEM



Suitable for:

NOSEM


Suitable for:



Filters

3160321 FILTER 230x200 mm


for Dishwasher (AFI) A600
 for Dishwasher (EUROSYSTEM) PRO400
 for Dishwasher (HILTA) S41 - S42
 for Dishwasher (IME OMNIWASH) 4Q82
 for Dishwasher (NOSEM) C5000 - C5010 - C5020
 NC501
 for Dishwasher (NUOVA SIMONELLI) KIARA6
 for Dishwasher (SAB ITALIA) C50H
 for Dishwasher (SO.WE.BO.) 824
 for Dishwasher (SOTAL) F600ECO
 for Dishwasher (STORME) LT500M - LT500T
 for Dishwasher (UNIC) A410E



NOSEM

3160322 FILTER 330x310 mm

for Dishwasher (SO.WE.BO.) 701CQ - 752CQ - 752CT
 for Glasswasher/Cupwasher (AFI) A35Z2
 for Glasswasher/Cupwasher (EUROSYSTEM) PRO200
 for Glasswasher/Cupwasher (HILTA) RB22 - SB22
 for Glasswasher/Cupwasher (IME OMNIWASH) DUEAQ
 DUEAT - UNOQA - UNOAT - UNOQ - UNOT
 for Glasswasher/Cupwasher (NOSEM) C4010L - NC201
 NR101 - R1010
 for Glasswasher/Cupwasher (NUOVA SIMONELLI) KIARA4
 for Glasswasher/Cupwasher (SO.WE.BO.) ONECQ
 ONECT - 701VT - 712CQ - 712CT - 742CQ - 742CT
 for Glasswasher/Cupwasher (SOTAL) C230
 for Glasswasher/Cupwasher (STORME) ME400
 for Glasswasher/Cupwasher (UNIC) A20 - A21



NOSEM

3160038 INLET CONNECTOR \varnothing 1"1/4

for Dishwasher (AFI) A600
 for Dishwasher (EUROSYSTEM) PRO400
 for Dishwasher (HILTA) S41 - S42
 for Dishwasher (NOSEM) C5010 - C5020 - NC501
 for Dishwasher (NUOVA SIMONELLI) KIARA6
 for Dishwasher (SAB ITALIA) C50H
 for Dishwasher (SO.WE.BO.) 600CQ - 600CT - 619CQ
 619CT - 631CT - 661CQ - 701CQ - 701CT - 752CQ
 752CT - 824CQ - 824CT
 for Dishwasher (SOTAL) F600ECO
 for Dishwasher (STORME) LT500M - LT500T
 for Dishwasher (UNIC) A100 - A410E
 for Glasswasher/Cupwasher (AFI) A35 - A35Z2 - A36
 for Glasswasher/Cupwasher (EUROSYSTEM) PRO100
 PRO200



NOSEM

3160041 NUT \varnothing 1"1/4

for Dishwasher (AFI) A600
 for Dishwasher (EUROSYSTEM) PRO400
 for Dishwasher (HILTA) S41 - S42
 for Dishwasher (NOSEM) C5010 - C5020 - NC501
 for Dishwasher (NUOVA SIMONELLI) KIARA6
 for Dishwasher (SAB ITALIA) C50H
 for Dishwasher (SO.WE.BO.) 600CQ - 600CT - 619CQ
 619CT - 631CT - 661CQ - 701CQ - 701CT - 752CQ
 752CT - 824CQ - 824CT
 for Dishwasher (SOTAL) F600ECO
 for Dishwasher (STORME) LT500M - LT500T
 for Dishwasher (UNIC) A100 - A410E
 for Glasswasher/Cupwasher (AFI) A35 - A35Z2 - A36
 for Glasswasher/Cupwasher (EUROSYSTEM) PRO100
 PRO200



NOSEM



Suitable for:

3160040 O-RING 03168 EPDM

for Dishwasher (AFI) A600
 for Dishwasher (EUROSYSTEM) PRO400
 for Dishwasher (HILTA) S41 - S42
 for Dishwasher (NOSEM) C5010 - C5020 - NC501
 for Dishwasher (NUOVA SIMONELLI) KIARA6
 for Dishwasher (SAB ITALIA) C50H
 for Dishwasher (SO.WE.BO.) 600CQ - 600CT - 619CQ
 619CT - 631CT - 661CQ - 701CQ - 701CT - 752CQ
 752CT - 824CQ - 824CT
 for Dishwasher (SOTAL) F600ECO
 for Dishwasher (STORME) LT500M - LT500T
 for Dishwasher (UNIC) A100 - A410E
 for Glasswasher/Cupwasher (AFI) A35 - A35Z2 - A36
 for Glasswasher/Cupwasher (EUROSYSTEM) PRO100
 PRO200



NOSEM

3160039 TIE ROD FOR FILTER 52 mm

for Dishwasher (AFI) A600
 for Dishwasher (EUROSYSTEM) PRO400
 for Dishwasher (HILTA) S41 - S42
 for Dishwasher (NOSEM) C5010 - C5020 - NC501
 for Dishwasher (NUOVA SIMONELLI) KIARA6
 for Dishwasher (SAB ITALIA) C50H
 for Dishwasher (SO.WE.BO.) 600CQ - 600CT - 619CQ
 619CT - 631CT - 661CQ - 701CQ - 701CT - 752CQ
 752CT - 824CQ - 824CT
 for Dishwasher (SOTAL) F600ECO
 for Dishwasher (STORME) LT500M - LT500T
 for Dishwasher (UNIC) A100 - A410E
 for Glasswasher/Cupwasher (AFI) A35 - A35Z2 - A36
 for Glasswasher/Cupwasher (EUROSYSTEM) PRO100
 PRO200



NOSEM

NOSEM



Suitable for:

3160151 PUMP INLET FILTER

for Dishwasher (AFI) A600
 for Dishwasher (EUROSYSTEM) PRO400
 for Dishwasher (HILTA) S41 - S42
 for Dishwasher (IME OMNIWASH) 4Q82
 for Dishwasher (NOSEM) C5010 - C5020 - NC501
 for Dishwasher (NUOVA SIMONELLI) KIARA6
 for Dishwasher (SAB ITALIA) C50H
 for Dishwasher (SO.WE.BO.) 600CQ - 600CT - 601CQ
 601CT - 619CQ - 619CT - 701CQ - 701CT - 752CQ
 752CT - 824
 for Dishwasher (SOTAL) F600ECO
 for Dishwasher (STORME) LT500M - LT500T
 for Dishwasher (UNIC) A100 - A410E
 for Glasswasher/Cupwasher (AFI) A35 - A35Z2 - A36
 for Glasswasher/Cupwasher (EUROSYSTEM) PRO100



NOSEM



Suitable for:

NOSEM




3160037 PLASTIC INNER FILTER FOR TANK 230x200 mm
 for Dishwasher (IME OMNIWASH) 4Q82
 for Dishwasher (NOSEM) K602S
 for Dishwasher (SAB ITALIA) K5.2P
 for Dishwasher (SOTAL) C13001P
 for Dishwasher (STORME) L502BT
 for Dishwasher (UNIC) A61A - A61B
 for Dishwasher hood type (AFI) A1000L
 for Dishwasher hood type (EUROSYSTEM) PRO600
 for Dishwasher hood type (HILTA) W13 - W14 - W15
 for Dishwasher hood type (IME OMNIWASH) SEI1P
 SEI2P
 for Dishwasher hood type (NOSEM) K601
 for Dishwasher hood type (NUOVA SIMONELLI) LTM1500
 LTM1600
 for Dishwasher hood type (SAB ITALIA) K5.1P



NOSEM

Suitable for:

3160464 S/STEEL FILTER SURFACE 230x200 mm
 for Dishwasher (NOSEM) K602S
 for Dishwasher (SAB ITALIA) K5.2P
 for Dishwasher (SOTAL) C13001P - C130024V
 for Dishwasher (STORME) L502BT
 for Dishwasher (UNIC) A61A - A61B
 for Dishwasher hood type (AFI) A1000L
 for Dishwasher hood type (EUROSYSTEM) PRO600
 for Dishwasher hood type (HILTA) W13 - W14 - W15
 for Dishwasher hood type (IME OMNIWASH) SEI1P
 SEI2P
 for Dishwasher hood type (NOSEM) K601 - K602
 for Dishwasher hood type (NUOVA SIMONELLI) LTM1500
 LTM1600
 for Dishwasher hood type (SAB ITALIA) K5.1P
 for Dishwasher hood type (SO.WE.BO.) 6.1P - 6.2P



NOSEM

Guides

3189048 HOOD SLIDEWAY
 dimensions 595x35 mm
 for Dishwasher (IME OMNIWASH) SEI1PS
 for Dishwasher (SAB ITALIA) K5.1 - K5.2
 for Dishwasher (STORME) L502BT
 for Dishwasher (UNIC) A61A - A61B
 for Dishwasher hood type (AFI) A1000L
 for Dishwasher hood type (EUROSYSTEM) PRO600
 for Dishwasher hood type (HILTA) W13 - W14 - W15
 for Dishwasher hood type (IME OMNIWASH) SEI2PS
 for Dishwasher hood type (NOSEM) K601 - K602
 for Dishwasher hood type (NUOVA SIMONELLI) LTM1500
 LTM1600
 for Dishwasher hood type (SO.WE.BO.) 6.1P - 6.2P
 for Dishwasher hood type (SOTAL) C1300
 for Dishwasher hood type (STORME) L501 - L502



NOSEM



Heating elements

- 3355607 HEAT. ELEM. F/ TANK 2750/3250W 220/240V**
 immersed length 370 mm
 connection \varnothing 10 mm
 for Dishwasher (ELETTROBAR) 22 - 44 - 50
 for Dishwasher hood type (BONNET) INO60 - INO80
 for Dishwasher hood type (COLGED) L51
 for Dishwasher hood type (DEXION) LP101P
 for Dishwasher hood type (ELETTROBAR) CLEAN100



NOSEM CCREB230086

Hinges

- 3391046 BUSHING FOR DOOR HINGE**
 for Dishwasher (SO.WE.BO.) 601 - 701
 for Glasswasher/Cupwasher (AFI) A35
 for Glasswasher/Cupwasher (EUROSYSTEM) PRO100
 for Glasswasher/Cupwasher (HILTA) RB10 - SB10
 for Glasswasher/Cupwasher (IME OMNIWASH) JA35
 JA36 - JOLLY - UNO
 for Glasswasher/Cupwasher (NOSEM) C2010L - NC201
 R1010L
 for Glasswasher/Cupwasher (NUOVA SIMONELLI) KIARA1
 for Glasswasher/Cupwasher (SO.WE.BO.) 600 - 631
 661 - 691
 for Glasswasher/Cupwasher (SOTAL) EC195 - ER195
 for Glasswasher/Cupwasher (STORME) SM350
 for Glasswasher/Cupwasher (UNIC) A10J - A11J



NOSEM

- 3053319 DOOR SPRING LH**
 for Dishwasher (SO.WE.BO.) 601 - 701
 for Glasswasher/Cupwasher (AFI) A35
 for Glasswasher/Cupwasher (EUROSYSTEM) PRO100
 for Glasswasher/Cupwasher (HILTA) RB10 - SB10
 for Glasswasher/Cupwasher (IME OMNIWASH) JA35
 JA36 - JOLLY - UNO
 for Glasswasher/Cupwasher (NOSEM) C2010L - NC201
 R1010L
 for Glasswasher/Cupwasher (NUOVA SIMONELLI) KIARA1
 for Glasswasher/Cupwasher (SO.WE.BO.) 600 - 631
 661 - 691
 for Glasswasher/Cupwasher (SOTAL) EC195 - ER195
 for Glasswasher/Cupwasher (STORME) SM350
 for Glasswasher/Cupwasher (UNIC) A10J - A11J



NOSEM



Suitable for:

NOSEM



3053320 DOOR SPRING RH

for Dishwasher (SO.WE.BO.) 601 - 701
 for Glasswasher/Cupwasher (AFI) A35
 for Glasswasher/Cupwasher (EUROSYSTEM) PRO100
 for Glasswasher/Cupwasher (HILTA) RB10 - SB10
 for Glasswasher/Cupwasher (IME OMNIWASH) JA35
 JA36 - JOLLY - UNO
 for Glasswasher/Cupwasher (NOSEM) C2010L - NC201
 R1010L
 for Glasswasher/Cupwasher (NUOVA SIMONELLI) KIARA1
 for Glasswasher/Cupwasher (SO.WE.BO.) 600 - 631
 661 - 691
 for Glasswasher/Cupwasher (SOTAL) EC195 - ER195
 for Glasswasher/Cupwasher (STORME) SM350
 for Glasswasher/Cupwasher (UNIC) A10J - A11J



NOSEM

Suitable for:

3012001 SILICONE BUMPER FOR DOOR

for Dishwasher (SO.WE.BO.) 601 - 701
 for Glasswasher/Cupwasher (AFI) A35
 for Glasswasher/Cupwasher (EUROSYSTEM) PRO100
 for Glasswasher/Cupwasher (HILTA) RB10 - SB10
 for Glasswasher/Cupwasher (IME OMNIWASH) JA35
 JA36 - JOLLY - UNO
 for Glasswasher/Cupwasher (NOSEM) C2010L - NC201
 R1010L
 for Glasswasher/Cupwasher (NUOVA SIMONELLI) KIARA1
 for Glasswasher/Cupwasher (SO.WE.BO.) 600 - 631
 661 - 691
 for Glasswasher/Cupwasher (SOTAL) EC195 - ER195
 for Glasswasher/Cupwasher (STORME) SM350
 for Glasswasher/Cupwasher (UNIC) A10J - A11J



NOSEM

Hose-end fittings

3391042 HOSE-END FITTING FOR RINSE SHAFT \varnothing 16 mm

for Dishwasher (AFI) A600
 for Dishwasher (EUROSYSTEM) PRO400
 for Dishwasher (HILTA) S41 - S42
 for Dishwasher (IME OMNIWASH) 4Q82
 for Dishwasher (NOSEM) C5000 - C5010 - C5020
 NC501
 for Dishwasher (SAB ITALIA) C50
 for Dishwasher (SO.WE.BO.) 824
 for Glasswasher/Cupwasher (AFI) A35 - A35Z2 - A36
 for Glasswasher/Cupwasher (EUROSYSTEM) PRO100
 PRO200
 for Glasswasher/Cupwasher (HILTA) RB10 - RB22
 SB10 - SB22
 for Glasswasher/Cupwasher (IME OMNIWASH) DUEAQ
 DUEAT - JA35 - JA36 - JA40 - JA41 - JOLLYQ




NOSEM

3315027 T- HOSE END FITTING



NOSEM

3349601 3-WAY HOSE-END FITTING



NOSEM

3315107 3-WAYS HOSE END RUBBER FITTING \varnothing 12



NOSEM

**Lamps****3221595 BLUE INDICATOR CAP**

NOSEM

3221592 GREEN INDICATOR LAMP 230 V
ø 6 mm

NOSEM

3221127 ORANGE LAMP RECEPTACLE
head 14x14 mm - hole ø 11 mm
for 6.2P
for OEM PIZZA OVEN 4-5-8-10-11-15/DS

NOSEM

3221128 GREEN LAMP RECEPTACLE
hole ø 11 mm
head 14x14 mm
for 6.2P

NOSEM

3221126 INDICATOR LAMP 24V
head ø 8 mm

NOSEM

3221594 RED GEM FOR LAMPHOLDER ø 7mm

NOSEM



Suitable for:

NOSEM



Suitable for:

Microswitches

3803005 COMPLETE DOOR CONTACT

for Dishwasher (IME OMNIWASH) SEI1PCQ - SEI2CQB
SEI2PCQ
for Dishwasher (NOSEM) K602S
for Dishwasher (SAB ITALIA) K5.2P
for Dishwasher (SOTAL) C13001P - C130024V
for Dishwasher (STORME) L502BT
for Dishwasher (UNIC) A61A - A61B
for Dishwasher hood type (AFI) A1000L
for Dishwasher hood type (EUROSYSTEM) PRO600
for Dishwasher hood type (HILTA) W13 - W14 - W15
for Dishwasher hood type (NOSEM) K601 - K602
for Dishwasher hood type (NUOVA SIMONELLI) LTM1500
LTM1600
for Dishwasher hood type (SAB ITALIA) K5.1P
for Dishwasher hood type (SO.WE.BO.) 6.1P - 6.2P



NOSEM

3803018 ACTUATOR FOR REAR MICRO SWITCH 62P/SPPL



NOSEM

3240129 COMPLETE MICROSWITCH FOR DOOR



NOSEM

1186352 O-RING 02050 EPDM

for Dishwasher (AFI) A600
for Dishwasher (DIHR) C40CF - GASTRO450
GASTRO500 - GASTRO750 - GASTRO900 - GS45
GS50
for Dishwasher (EUROSYSTEM) PRO400
for Dishwasher (FAEMA) 1201
for Dishwasher (HILTA) S41 - S42
for Dishwasher (IME OMNIWASH) 4Q82
for Dishwasher (KROMO) K35 - K37
for Dishwasher (NOSEM) C5000 - C5010 - C5020
NC501
for Dishwasher (NUOVA SIMONELLI) KIARA6
for Dishwasher (OLIS) OLG550 - OLG585
for Dishwasher (SAB ITALIA) C50H - 1200
for Dishwasher (SILANOS) 200 - 300 - 400 - 600



NOSEM



Suitable for:

3186181 O-RING 03068 EPDM

for Dishwasher (SO.WE.BO.) 601 - 701 - 752
 for Dishwasher (SOTAL) ER225
 for Glasswasher/Cupwasher (AFI) A35 - A35Z2 - A36
 for Glasswasher/Cupwasher (COMENDA) - Series B
 for Glasswasher/Cupwasher (EUROSYSTEM) PRO100
 PRO200
 for Glasswasher/Cupwasher (HILTA) RB10 - RB22
 SB10 - SB22
 for Glasswasher/Cupwasher (IME OMNIWASH) DUE
 JA35 - JA36 - JA40 - JA41 - JOLLY - UNO
 for Glasswasher/Cupwasher (NOSEM) C2010L - C4010L
 NC201 - NR101 - R1010
 for Glasswasher/Cupwasher (NUOVA SIMONELLI) KIARA1
 KIARA2 - KIARA4
 for Glasswasher/Cupwasher (SAB ITALIA) C35 - C36



NOSEM

Suitable for:



NOSEM

Pegs

3389011 CONVEYOR FINGER

for Dishwasher conveyor type (ZANUSSI) RT100
 RT140 - RT190 - RT270



NOSEM MECEEV3

Pressure switches

3320076 DRAIN PUMP PRESSURE SWITCH 60/30 mm

1 - level 250V 16A
 max operating temperature 85°C
 for Dishwasher (AFI) A600 - A900
 for Dishwasher (EUROSYSTEM) PRO400
 for Dishwasher (HILTA) S41 - S42
 for Dishwasher (IME OMNIWASH) J50 - 4Q82
 for Dishwasher (NOSEM) C5000
 for Dishwasher (NUOVA SIMONELLI) KIARA6
 for Dishwasher (SAB ITALIA) C50H
 for Dishwasher (SOTAL) F600
 for Dishwasher (STORME) LT500M - LT500T
 for Dishwasher (UNIC) A410E



NOSEM

3320075 PRESSURE SWITCH 50/20 mm 250V 16A

1level
 max operating temperature 85°C
 for Dishwasher (AFI) A600 - A900
 for Dishwasher (EUROSYSTEM) PRO400
 for Dishwasher (HILTA) S41 - S42 - S49 - S55
 for Dishwasher (NOSEM) C5000 - C5010
 for Dishwasher (SAB ITALIA) C50H
 for Dishwasher hood type (IME OMNIWASH) SEI2P
 for Dishwasher hood type (NOSEM) K602
 for Dishwasher hood type (SAB ITALIA) K5.2P
 for Glasswasher/Cupwasher (AFI) A35 - A35Z2 - A36
 for Glasswasher/Cupwasher (EUROSYSTEM) PRO100
 PRO200
 for Glasswasher/Cupwasher (HILTA) RB10 - RB22
 SB10 - SB22



NOSEM



Suitable for:

NOSEM

Suitable for:



Protection plates

3519014 BLACK FRONT FRAME


for Dishwasher (AFI) A600
 for Dishwasher (EUROSYSTEM) PRO400
 for Dishwasher (HILTA) S41 - S42
 for Dishwasher (NOSEM) C1010 - C5000 - C5010
 C5020 - NC501
 for Dishwasher (SO.WE.BO.) ONE - 701 - 752 - 824
 for Dishwasher (SOTAL) F600
 for Dishwasher (STORME) LT500M
 for Dishwasher (UNIC) A410E
 for Glasswasher/Cupwasher (AFI) A35Z2
 for Glasswasher/Cupwasher (NOSEM) NC201 - NR101
 for Glasswasher/Cupwasher (SO.WE.BO.) 742
 for Glasswasher/Cupwasher (SOTAL) C230



NOSEM

3244008 LIGHT BLUE FRONT FRAME OMNI11

for Dishwasher (AFI) A600
 for Dishwasher (EUROSYSTEM) PRO400
 for Dishwasher (HILTA) S41 - S42
 for Dishwasher (NOSEM) C1010 - C5000 - C5010
 C5020 - NC501
 for Dishwasher (SO.WE.BO.) ONE - 701 - 752 - 824
 for Dishwasher (SOTAL) F600
 for Dishwasher (STORME) LT500M
 for Dishwasher (UNIC) A410E
 for Glasswasher/Cupwasher (AFI) A35Z2
 for Glasswasher/Cupwasher (NOSEM) NC201 - NR101
 for Glasswasher/Cupwasher (SO.WE.BO.) 742
 for Glasswasher/Cupwasher (SOTAL) C230



NOSEM

Pumps

3122740 DRAIN ELECTRO-PUMP 34W 220/240V


inlet external \varnothing 23 mm outlet external \varnothing 31 mm
 for Dishwasher (AFI) A600
 for Dishwasher (IME OMNIWASH) 4Q82
 for Dishwasher (NOSEM) C5000 - C501 - C5010
 for Dishwasher (NUOVA SIMONELLI) KIARA6
 for Dishwasher (SAB ITALIA) C50H
 for Dishwasher (SO.WE.BO.) 824
 for Dishwasher (SOTAL) F600
 for Dishwasher (STORME) LT500
 for Dishwasher (UNIC) A410E



NOSEM

3122432 ELECTRO-PUMP AP 1629030SX 0,30HP 230V

inlet external \varnothing 32 mm - outlet external \varnothing 31 mm
 motor revolutions 2800
 0.30HP 230V 50Hz - capacitor 10 μ f
 for Dishwasher (SO.WE.BO.) 601 - 701
 for Glasswasher/Cupwasher (AFI) A35 - A35Z2 - A36
 for Glasswasher/Cupwasher (EUROSYSTEM) PRO100
 PRO200
 for Glasswasher/Cupwasher (HILTA) RB10 - RB22
 SB10 - SB22
 for Glasswasher/Cupwasher (IME OMNIWASH) JOLLY
 UNOA - UNOQ - UNOT
 for Glasswasher/Cupwasher (NOSEM) C2010L - C4010L
 NR101 - R1010
 for Glasswasher/Cupwasher (NUOVA SIMONELLI) KIARA1
 for Glasswasher/Cupwasher (SAB ITALIA) C35 - C36



NOSEM

Suitable for:

3122434 ELECTRO-PUMP AP 2031SX 1HP 230V 50Hz
 inlet external \varnothing 46 mm - outlet external \varnothing 40 mm
 motor revolutions 2800
 1HP 230V 50Hz - capacitor 12.5 μ f
 for Dishwasher (AFI) A600
 for Dishwasher (IME OMNIWASH) 4Q82
 for Dishwasher hood type (AFI) A1000L
 for Dishwasher hood type (IME OMNIWASH) SEI1P
 SEI2P



NOSEM

Suitable for:

3122433 ELECTRO-PUMP AP 32591SX 0.60HP 230V 50Hz
 inlet external \varnothing 30 mm - outlet external \varnothing 30 mm
 motor revolutions 2850
 0.60HP 230V 50Hz - capacitor 12.5 μ f



NOSEM

3122728 ELECTRO-PUMP IME 1HP 230V 50Hz
 inlet external \varnothing 46 mm - outlet external \varnothing 41 mm
 for Dishwasher (SAB ITALIA) K5.2P
 for Dishwasher hood type (EUROSYSTEM) PRO600
 for Dishwasher hood type (HILTA) W14 - W15
 for Dishwasher hood type (IME OMNIWASH) SEI2P
 SEI2PA - SEI2PB
 for Dishwasher hood type (NOSEM) K602
 for Dishwasher hood type (NUOVA SIMONELLI) LTM1600
 for Dishwasher hood type (SO.WE.BO.) 6.2PA - 6.2PB
 for Dishwasher hood type (SOTAL) C1300
 for Dishwasher hood type (STORME) L502



NOSEM

Relays

3351012 RELAY 3TG 1001-1AL2
 16A 230V 50/60Hz
 contacts:3 NO + 1 NC
 for JOLLY Q/T - QUATTRO Q82



NOSEM



Suitable for:

NOSEM

Suitable for:



Rinse aid containers and accessories

3066040 COMPLETE RINSE AID CONTAINER

for Dishwasher (AFI) A600
 for Dishwasher (EUROSYSTEM) PRO400
 for Dishwasher (HILTA) S41 - S42
 for Dishwasher (NOSEM) C1010 - C5000 - C5010
 C5020 - NC501
 for Dishwasher (SO.WE.BO.) ONE - 701 - 752 - 824
 for Dishwasher (SOTAL) F600
 for Dishwasher (STORME) LT500M
 for Dishwasher (UNIC) A410E
 for Glasswasher/Cupwasher (AFI) A35Z2
 for Glasswasher/Cupwasher (NOSEM) NC201 - NR101
 for Glasswasher/Cupwasher (SO.WE.BO.) 742
 for Glasswasher/Cupwasher (SOTAL) C230



NOSEM

3324004 PLUG FOR RINSE AID CONTAINER ø 2x80 mm


for Dishwasher (AFI) A600
 for Dishwasher (EUROSYSTEM) PRO400
 for Dishwasher (HILTA) S41 - S42
 for Dishwasher (NOSEM) C1010 - C5000 - C5010
 C5020 - NC501
 for Dishwasher (SO.WE.BO.) ONE - 701 - 752 - 824
 for Dishwasher (SOTAL) F600
 for Dishwasher (STORME) LT500M
 for Dishwasher (UNIC) A410E
 for Glasswasher/Cupwasher (AFI) A35Z2
 for Glasswasher/Cupwasher (NOSEM) NC201 - NR101
 for Glasswasher/Cupwasher (SO.WE.BO.) 742
 for Glasswasher/Cupwasher (SOTAL) C230



NOSEM

3439001 RINSE AID CONTAINER

for Dishwasher (AFI) A600
 for Dishwasher (EUROSYSTEM) PRO400
 for Dishwasher (HILTA) S41 - S42
 for Dishwasher (NOSEM) C1010 - C5000 - C5010
 C5020 - NC501
 for Dishwasher (SO.WE.BO.) ONE - 701 - 752 - 824
 for Dishwasher (SOTAL) F600
 for Dishwasher (STORME) LT500M
 for Dishwasher (UNIC) A410E
 for Glasswasher/Cupwasher (AFI) A35Z2
 for Glasswasher/Cupwasher (NOSEM) NC201 - NR101
 for Glasswasher/Cupwasher (SO.WE.BO.) 742
 for Glasswasher/Cupwasher (SOTAL) C230



NOSEM

Rinse aid pumps and accessories

3090070 HYDRAULIC RINSE AID INJECTOR IB1


with smooth connecting tube ø 10 mm
 flow rate regulator



NOSEM

3090073 INJECTOR DIAPHRAGM

for Dishwasher (SO.WE.BO.) NK6.2P - 601CQ - 601CT
 661CQ - 661CT - 824
 for Glasswasher/Cupwasher (SO.WE.BO.) 712CQ
 712CT



NOSEM



Suitable for:

3090072 INJECTOR NON-RETURN VALVE
for Dishwasher (SO.WE.BO.) NK6.2P - QUATTRO
601CQ - 601CT - 661CQ - 661CT - 824
for Glasswasher/Cupwasher (SO.WE.BO.) 712CQ
712CT



NOSEM

Suitable for:



NOSEM

3090016 HYDRAULIC RINSE AID INJECTOR MODEL 3000
for rinse aid
with inspectionable filter
for Dishwasher (ADLER) DS400 - DS410 - DS600
for Dishwasher (WHIRLPOOL) F650
for Glasswasher/Cupwasher (ADLER) CF35 - CF40
DSF101 - DSF103 - DS101 - DS103 - DS201
DS203
for Glasswasher/Cupwasher (NOSEM) NA400
for Glasswasher/Cupwasher (WHIRLPOOL) D110 - D111
D210 - D211 - D310 - D311 - F300 - F312 - F35
F40 - F400 - F41 - F410



NOSEM

3090017 INLET FILTER MODEL 3000




NOSEM

3090018 T-FITTING BLACK



NOSEM

3090056 DIAPHRAGM MOD. DA 3010



NOSEM

3090003 INLET VALVE FOR RINSE AID INJECTOR
for Dishwasher (BONNET) IN08
for Dishwasher (COMENDA) F20 - F45
for Dishwasher (JEMI) GS-8/2 - GS-8/2D - GS-9/2
GS-9/2D
for Dishwasher hood type (JEMI) GS-100 - GS-83
for Glasswasher/Cupwasher (BONNET) IN07F - VR1000R
for Glasswasher/Cupwasher (COMENDA) B11T
for Glasswasher/Cupwasher (ELETTRORBAR) S621 - S636



NOSEM



Suitable for:

NOSEM

Suitable for:



Salt container and accessories

3067001 SALT CONTAINER



NOSEM 10370

Sleeves

3248177 DRAIN HOSE FOR TANK

internal \varnothing 38 mm
 overall length 455 mm
 for Dishwasher (AFI) A600
 for Dishwasher (EUROSYSTEM) PRO400
 for Dishwasher (HILTA) S41 - S42
 for Dishwasher (IME OMNIWASH) 4Q82
 for Dishwasher (NOSEM) C5000 - C5010 - C5020
 NC501
 for Dishwasher (NUOVA SIMONELLI) KIARA6
 for Dishwasher (SAB ITALIA) C50H
 for Dishwasher (SO.WE.BO.) 824
 for Dishwasher (SOTAL) F600ECO
 for Dishwasher (STORME) LT500
 for Dishwasher (UNIC) A410E



NOSEM

3248171 INLET HOSE

internal \varnothing 43 mm
 overall length 335 mm
 for Dishwasher (IME OMNIWASH) SEI1PCQ - SEI2PCQ
 for Dishwasher (NUOVA SIMONELLI) SEI1PCQ - SEI2PCQ
 for Dishwasher (SAB ITALIA) K5.2P
 for Dishwasher (UNIC) A61A - A61B
 for Dishwasher hood type (AFI) A1000L
 for Dishwasher hood type (EUROSYSTEM) PRO600
 for Dishwasher hood type (HILTA) W13 - W14 - W15
 for Dishwasher hood type (NOSEM) K601 - K602
 for Dishwasher hood type (NUOVA SIMONELLI) LTM1500
 LTM1600
 for Dishwasher hood type (SAB ITALIA) K5.1P
 for Dishwasher hood type (SO.WE.BO.) 6.1P - 6.2P
 6.2PB



NOSEM

3349479 DRAIN PUMP INLET HOSE

internal \varnothing 30 and 37 mm
 overall length 160 mm
 for Dishwasher (AFI) A600
 for Dishwasher (EUROSYSTEM) PRO400
 for Dishwasher (HILTA) S41 - S42
 for Dishwasher (IME OMNIWASH) 4Q82
 for Dishwasher (NOSEM) C5000 - C5010 - C5020
 NC501
 for Dishwasher (NUOVA SIMONELLI) KIARA6
 for Dishwasher (SAB ITALIA) C50H
 for Dishwasher (SO.WE.BO.) 824
 for Dishwasher (SOTAL) F600ECO
 for Dishwasher (STORME) LT500
 for Dishwasher (UNIC) A410E



NOSEM

3248173 INLET HOSE

internal \varnothing 43 mm
 overall length 485 mm
 for Dishwasher (IME OMNIWASH) SEI1PCQ - SEI2PCQ
 4SA
 for Dishwasher (SAB ITALIA) K5.2P
 for Dishwasher (UNIC) A61A - A61B
 for Dishwasher hood type (AFI) A1000L
 for Dishwasher hood type (EUROSYSTEM) PRO600
 for Dishwasher hood type (HILTA) W13 - W14 - W15
 for Dishwasher hood type (IME OMNIWASH) SEI2P
 for Dishwasher hood type (NOSEM) K601 - K602
 for Dishwasher hood type (NUOVA SIMONELLI) LTM1500
 LTM1600
 for Dishwasher hood type (SAB ITALIA) K5.1P
 for Dishwasher hood type (SO.WE.BO.) 6.1P - 6.2P



NOSEM

3248174 INLET HOSE

internal \varnothing 30 mm - 37 mm
 for Dishwasher (SO.WE.BO.) ONE - 601 - 701 - 752
 for Glasswasher/Cupwasher (AFI) A35 - A35Z2 - A36
 for Glasswasher/Cupwasher (EUROSYSTEM) PRO100
 PRO200
 for Glasswasher/Cupwasher (HILTA) RB10 - RB22
 SB10 - SB22
 for Glasswasher/Cupwasher (IME OMNIWASH)
 Series DUE - JA35 - JA36 - JA40 - JA41
 Series JOLLY - Series UNO
 for Glasswasher/Cupwasher (NOSEM) C2010L - C4010L
 NC201 - NR101 - R1010L
 for Glasswasher/Cupwasher (NUOVA SIMONELLI) KIARA1
 KIARA2 - KIARA4
 for Glasswasher/Cupwasher (SAB ITALIA) C35 - C36



NOSEM

3248023 OUTLET HOSE

internal \varnothing 30 mm
 overall length 200 mm
 for Dishwasher (IME OMNIWASH) CL - CS
 for Dishwasher (SO.WE.BO.) CL - CS - DUE - UNO
 601 - 701 - 752
 for Glasswasher/Cupwasher (AFI) A35 - A35Z2 - A36
 for Glasswasher/Cupwasher (EUROSYSTEM) PRO100
 PRO200
 for Glasswasher/Cupwasher (HILTA) RB10 - RB22
 SB10 - SB22
 for Glasswasher/Cupwasher (IME OMNIWASH) DUE
 JA35 - JA36 - JA40 - JA41 - JOLLY - UNO
 for Glasswasher/Cupwasher (NOSEM) C2010L - C4010L
 NC201 - NR101 - R1010L
 for Glasswasher/Cupwasher (NUOVA SIMONELLI) KIARA1



NOSEM

Suitable for:

3248175 INLET HOSE

internal \varnothing 44 mm
 overall length 280 mm
 for Dishwasher (AFI) A600
 for Dishwasher (EUROSYSTEM) PRO400
 for Dishwasher (HILTA) S41 - S42
 for Dishwasher (IME OMNIWASH) 4Q82
 for Dishwasher (NOSEM) C5000 - C5010 - C5020
 NC501
 for Dishwasher (NUOVA SIMONELLI) KIARA6
 for Dishwasher (SAB ITALIA) C50H
 for Dishwasher (SO.WE.BO.) 824
 for Dishwasher (SOTAL) F600ECO
 for Dishwasher (STORME) LT500
 for Dishwasher (UNIC) A410E



NOSEM

3248045 OUTLET HOSE

\varnothing internal 36 mm
 overall length 320 mm
 for Dishwasher (AFI) A600
 for Dishwasher (EUROSYSTEM) PRO400
 for Dishwasher (HILTA) S41 - S42
 for Dishwasher (IME OMNIWASH) QUATTROBA
 QUATTROQ82 - QUATTROSA - QUATTROT
 for Dishwasher (NOSEM) C5000 - C5010 - C5020
 NC501
 for Dishwasher (NUOVA SIMONELLI) KIARA6
 for Dishwasher (SAB ITALIA) C50H
 for Dishwasher (SO.WE.BO.) 824
 for Dishwasher (SOTAL) F600ECO
 for Dishwasher (STORME) LT500
 for Dishwasher (UNIC) A410E



NOSEM



Suitable for:

NOSEM



3248172 OUTLET HOSE

internal \varnothing 30 and 40 mm
 overall length 490 mm
 for Dishwasher (IME OMNIWASH) SEI1PCQ - SEI2PCQ
 for Dishwasher (SAB ITALIA) K5.2P
 for Dishwasher (UNIC) A61A - A61B
 for Dishwasher hood type (AFI) A1000L
 for Dishwasher hood type (EUROSYSTEM) PRO600
 for Dishwasher hood type (HILTA) W13 - W14 - W15
 for Dishwasher hood type (NOSEM) K601 - K602
 for Dishwasher hood type (NUOVA SIMONELLI) LTM1500
 LTM1600
 for Dishwasher hood type (SAB ITALIA) K5.1P
 for Dishwasher hood type (SO.WE.BO.) 6.1P - 6.2P
 6.2PB
 for Dishwasher hood type (SOTAL) C1300



NOSEM

3349477 PUMP OUTLET HOSE

internal \varnothing 29-40 mm
 overall length 1275 mm
 for Dishwasher (IME OMNIWASH) SEI1PCQ - SEI2PCQ
 for Dishwasher (SAB ITALIA) K5.2P
 for Dishwasher (UNIC) A61A - A61B
 for Dishwasher hood type (AFI) A1000L
 for Dishwasher hood type (EUROSYSTEM) PRO600
 for Dishwasher hood type (HILTA) W13 - W14 - W15
 for Dishwasher hood type (NOSEM) K601 - K602
 for Dishwasher hood type (NUOVA SIMONELLI) LTM1500
 LTM1600
 for Dishwasher hood type (SAB ITALIA) K5.1P
 for Dishwasher hood type (SO.WE.BO.) 6.1P - 6.2P
 6.2PB
 for Dishwasher hood type (SOTAL) C1300



NOSEM

3250211 HOOD LIFTING SPRING 925 mm

for OMNIWASH SEI 1PCQ-2PCQ-2PCQB
 for SIMONELLI LTM1500-LTM1600



NOSEM

Suitable for:

3248179 OUTLET HOSE

internal \varnothing 25 mm
 overall length 370 mm
 for Dishwasher (SO.WE.BO.) ONE - 601 - 701 - 752
 for Glasswasher/Cupwasher (AFI) A35 - A35Z2 - A36
 for Glasswasher/Cupwasher (EUROSYSTEM) PRO100
 PRO200
 for Glasswasher/Cupwasher (HILTA) RB10 - RB22
 SB10 - SB22
 for Glasswasher/Cupwasher (IME OMNIWASH)
 Series DUE - Series J - Series JOLLY - Series UNO
 for Glasswasher/Cupwasher (NOSEM) C2010L - C4010L
 NC201 - NR101 - R1010L
 for Glasswasher/Cupwasher (NUOVA SIMONELLI) KIARA1
 KIARA2 - KIARA4
 for Glasswasher/Cupwasher (SAB ITALIA) C35 - C36



NOSEM

3248176 TOP/BOTTOM OUTLET HOSE

internal \varnothing 35 - 37 - 40 mm
 overall length 1400 mm
 for Dishwasher (AFI) A600
 for Dishwasher (EUROSYSTEM) PRO400
 for Dishwasher (HILTA) S41 - S42
 for Dishwasher (IME OMNIWASH) 4Q82
 for Dishwasher (NOSEM) C5000 - C5010 - C5020
 NC501
 for Dishwasher (NUOVA SIMONELLI) KIARA6
 for Dishwasher (SAB ITALIA) C50H
 for Dishwasher (SO.WE.BO.) 824
 for Dishwasher (SOTAL) F600ECO
 for Dishwasher (STORME) LT500
 for Dishwasher (UNIC) A410E



NOSEM

Springs

3318013 SPRING HOOK PULLEY

for OMNIWASH SEI 1PCQ-2PCQ-2PCQB
 for SIMONELLI LTM1500-LTM1600



NOSEM



Suitable for:

3053526 STAINLESS STEEL TIE ROD
for OMNIWASH SEI 1PCQ-2PCQ-2PCQB
for SIMONELLI LTM1500-LTM1600



NOSEM

NOSEM



Suitable for:

Switches


3319222 BIPOLAR SWITCH 16A 250V



NOSEM

3319195 BLACK CHANGE-OVER BUTTON WITH SERIGRAPHY

for Dishwasher (AFI) A600
for Dishwasher (EUROSYSTEM) PRO400
for Dishwasher (IME OMNIWASH) 4Q82
for Dishwasher (NOSEM) C5000 - C5010 - C5020
NC501
for Dishwasher (NUOVA SIMONELLI) KIARA6
for Dishwasher (SAB ITALIA) C50H
for Dishwasher (SO.WE.BO.) 824
for Dishwasher (STORME) LT500T



NOSEM

3319553 BLUE PUSH-BUTTON

for Dishwasher (SO.WE.BO.) 631CQ - 631CT - 691CQ
691CT
for Glasswasher/Cupwasher (IME OMNIWASH) JA35
JA36 - JA40 - JA41 - J35 - J36 - UNOAT
for Glasswasher/Cupwasher (NOSEM) NC201 - NR101
R1010
for Glasswasher/Cupwasher (SO.WE.BO.) ONECQ
ONECT - 742CQ - 742CT



NOSEM

3319550 GREEN PUSH-BUTTON "RINSE"

for Dishwasher (SO.WE.BO.) 631CQ - 631CT - 691CQ
691CT
for Glasswasher/Cupwasher (IME OMNIWASH) JA35
JA36 - JA40 - JA41 - J35 - J36 - UNOAT
for Glasswasher/Cupwasher (NOSEM) NC201 - NR101
R1010
for Glasswasher/Cupwasher (SO.WE.BO.) ONECQ
ONECT - 742CQ - 742CT



NOSEM



Suitable for:

NOSEM



3319548 GREEN PUSH-BUTTON 0-1

for Dishwasher (SO.WE.BO.) 631CQ - 631CT - 691CQ
691CT
for Glasswasher/Cupwasher (IME OMNIWASH) JA35
JA36 - JA40 - JA41 - J35 - J36 - UNOAT
for Glasswasher/Cupwasher (NOSEM) NC201 - NR101
R1010
for Glasswasher/Cupwasher (SO.WE.BO.) ONECQ
ONECT - 742CQ - 742CT



NOSEM

Suitable for:

3319172 GREEN WARM/COLD BIPOLAR SWITCH

16(6)A/250V
for Dishwasher (AFI) A600 - A900
for Dishwasher (EUROSYSTEM) PRO400
for Dishwasher (HILTA) S41 - S42
for Dishwasher (IME OMNIWASH) 4Q82
for Dishwasher (NUOVA SIMONELLI) KIARA6
for Dishwasher (SAB ITALIA) C50H
for Dishwasher (SO.WE.BO.) 1342 - 824
for Dishwasher (SOTAL) F600
for Dishwasher (STORME) LT500M - LT500T
for Dishwasher (UNIC) A410E
for Glasswasher/Cupwasher (SO.WE.BO.) 742



NOSEM CEPUVSL

3319415 KEY SUPPORTING BODY


for all models



NOSEM

3319524 ON/OFF SWITCH

with support
for Dishwasher (NOSEM) K602S
for Dishwasher (SAB ITALIA) K5.2P
for Dishwasher hood type (HILTA) W14
for Dishwasher hood type (IME OMNIWASH) SEI2P
for Dishwasher hood type (SO.WE.BO.) 6.2P
for Dishwasher hood type (SOTAL) C1300
for Dishwasher hood type (STORME) L502



NOSEM

3057282 OPEN CONTACT 230V - 6A

for Dishwasher (NOSEM) K602S
for Dishwasher (SAB ITALIA) K5.2P
for Dishwasher (UNIC) A61A
for Dishwasher hood type (HILTA) W14
for Dishwasher hood type (IME OMNIWASH) SEI1P
for Dishwasher hood type (SO.WE.BO.) 6.1P - 6.2PA
for Dishwasher hood type (SOTAL) C1300
for Dishwasher hood type (STORME) L502



NOSEM

NOSEM LF-3454035

3319174 ORANGE BIPOLAR PUSH-BUTTON 16A 250V
 mounting hole 30x22 mm
 for Dishwasher (AFI) A600
 for Dishwasher (EUROSYSTEM) PRO400
 for Dishwasher (HILTA) S41 - S42
 for Dishwasher (IME OMNIWASH) 4Q82
 for Dishwasher (NOSEM) C5000 - C5010 - C5020
 NC501
 for Dishwasher (NUOVA SIMONELLI) KIARA6
 for Dishwasher (SAB ITALIA) C50H
 for Dishwasher (SO.WE.BO.) 701 - 752 - 824
 for Dishwasher (SOTAL) F600ECO
 for Dishwasher (STORME) LT500M - LT500T
 for Dishwasher (UNIC) A410E
 for Glasswasher/Cupwasher (AFI) A35Z2
 for Glasswasher/Cupwasher (NOSEM) NC201 - NR101



NOSEM

3319410 ORANGE PUSH-BUTTON
 for Dishwasher (SO.WE.BO.) 631CQ - 631CT - 691CQ
 691CT
 for Glasswasher/Cupwasher (IME OMNIWASH) DUE - J40
 J400 - J41 - J410 - N40 - N400 - N41 - N410
 UNO
 for Glasswasher/Cupwasher (NOSEM) NC201 - NR101
 R1010
 for Glasswasher/Cupwasher (SO.WE.BO.) ONECQ
 ONECT - 742CQ - 742CT



NOSEM

3319551 RECYCLE ORANGE PUSH-BUTTON
 for Dishwasher (SO.WE.BO.) 631CQ - 631CT - 691CQ
 691CT
 for Glasswasher/Cupwasher (IME OMNIWASH) JA35
 JA36 - JA40 - JA41 - J35 - J36 - UNOAT
 for Glasswasher/Cupwasher (NOSEM) NC201 - NR101
 R1010
 for Glasswasher/Cupwasher (SO.WE.BO.) ONECQ
 ONECT - 742CQ - 742CT



NOSEM

Suitable for:

3319173 ORANGE BIPOLAR SWITCH
 16(6)A/250V
 for drain pump
 for Dishwasher (AFI) A600 - A900
 for Dishwasher (EUROSYSTEM) PRO400
 for Dishwasher (HILTA) S41 - S42
 for Dishwasher (IME OMNIWASH) 4Q82
 for Dishwasher (NUOVA SIMONELLI) KIARA6
 for Dishwasher (SAB ITALIA) C50H
 for Dishwasher (SO.WE.BO.) 1342 - 824
 for Dishwasher (SOTAL) F600
 for Dishwasher (STORME) LT500M
 for Dishwasher (UNIC) A410E
 for Glasswasher/Cupwasher (SO.WE.BO.) 742



NOSEM CEPUPS

3319176 ORANGE REGENERATION BIPOLAR SWITCH
 contact capacity 10(4)A 250V
 for Dishwasher (AFI) A600 - A900
 for Dishwasher (EUROSYSTEM) PRO400
 for Dishwasher (HILTA) S41 - S42
 for Dishwasher (IME OMNIWASH) 4Q82
 for Dishwasher (NUOVA SIMONELLI) KIARA6
 for Dishwasher (SAB ITALIA) C50H
 for Dishwasher (SO.WE.BO.) 1342 - 824
 for Dishwasher (SOTAL) F600
 for Dishwasher (STORME) LT500M - LT500T
 for Dishwasher (UNIC) A41
 for Glasswasher/Cupwasher (SO.WE.BO.) 742



NOSEM CEPURIG




Suitable for:

NOSEM



3319523 SWITCH 3 POSITIONS

with support
 for Dishwasher (NOSEM) K6025
 for Dishwasher (SAB ITALIA) K5.2P
 for Dishwasher (SOTAL) CI300
 for Dishwasher (UNIC) A61A
 for Dishwasher hood type (HILTA) W14
 for Dishwasher hood type (IME OMNIWASH) SEI2P
 for Dishwasher hood type (NOSEM) K602
 for Dishwasher hood type (SO.WE.BO.) 6.1P - 6.2PA
 for Dishwasher hood type (STORME) L502




NOSEM

Suitable for:

3454040 NORMALLY CLOSED CONTACT 12A 400V

for Dishwasher hood type (AFI) A1000L
 for Dishwasher hood type (EUROSYSTEM) PRO600
 for Dishwasher hood type (HILTA) W13 - W14 - W15
 for Dishwasher hood type (IME OMNIWASH) SEI1P SEI2P
 for Dishwasher hood type (NOSEM) K601 - K602
 for Dishwasher hood type (NUOVA SIMONELLI) LTM1500 LTM1600
 for Dishwasher hood type (SAB ITALIA) K5.1P
 for Dishwasher hood type (SO.WE.BO.) 6.1P - 6.2P 6.2PB
 for Dishwasher hood type (SOTAL) C1300
 for Dishwasher hood type (STORME) L501 - L502
 for Dishwasher hood type (UNIC) A61




NOSEM

Thermostats

3444246 SAFETY THERMOSTAT FOR BOILER 100°C


4 contacts 16A 250V
 for Dishwasher (AFI) A600 - A900
 for Dishwasher (SAB ITALIA) C50H
 for Dishwasher (SO.WE.BO.)
 for Dishwasher (UNIVERBAR) BRAMA - CASTA - COSMO
 LOGOS - LOGOSD - MIDI50 - MIDI50D - OMEGA
 OMEGAD - SINCRO - SINCROD - TOP
 for Dishwasher hood type (IME OMNIWASH) SEI1P SEI2P
 for Dishwasher hood type (UNIVERBAR) COMPACT
 for Glasswasher/Cupwasher (AFI) A35 - A35Z2 - A36
 for Glasswasher/Cupwasher (NOSEM) R1010
 for Glasswasher/Cupwasher (SAB ITALIA) C35 - C36
 for Glasswasher/Cupwasher (UNIVERBAR) BET37
 BET37D - BET40 - BET40D - ERGON - ERGOND



NOSEM

3744070 SAFETY THERMOSTAT FOR TANK 85°C


4 contacts 16A 250V
 for Dishwasher hood type (AFI) A1000L
 for Dishwasher hood type (EUROSYSTEM) PRO600
 for Dishwasher hood type (HILTA) W13 - W15
 for Dishwasher hood type (IME OMNIWASH) SEI2P SEI2PS
 for Dishwasher hood type (NOSEM) K601 - K602
 for Dishwasher hood type (NUOVA SIMONELLI) LTM1500 LTM1600
 for Dishwasher hood type (SAB ITALIA) K5.1P
 for Dishwasher hood type (SO.WE.BO.) 6.1P - 6.2P
 for Dishwasher hood type (SOTAL) C1300
 for Dishwasher hood type (STORME) L501 - L502
 for Dishwasher hood type (UNIC) A61



NOSEM

Suitable for:


3444268 SINGLE-PHASE THERMOSTAT 0-90°C
 covered capillary 1000 mm
 bulb \varnothing 6.5x95 mm
 15A 250V
 D shaft \varnothing 6x4.6 mm
 for Dishwasher (IME OMNIWASH)
 for Dishwasher (RANCILIO) - Series LS
 for Glasswasher/Cupwasher (RANCILIO) - Series LT



NOSEM


Suitable for:

3444269 SINGLE-PHASE THERMOSTAT 52°C
 covered capillary 1000 mm
 bulb \varnothing 6.5x95 mm
 15A 250V
 for Dishwasher (AFI) A600 - A900
 for Dishwasher (IME OMNIWASH)
 for Dishwasher (SAB ITALIA) C50H
 for Dishwasher (SO.WE.BO.)
 for Glasswasher/Cupwasher (AFI) A35 - A35Z2 - A36
 for Glasswasher/Cupwasher (NOSEM) R1010
 for Glasswasher/Cupwasher (SAB ITALIA) C35 - C36



NOSEM

3444004 THERMOSTAT TR2 0-90°C
 D-shaped pin \varnothing 6x4.6 mm
 capillary 1500 mm - 15A 250V
 bulb \varnothing 6.5x95 mm
 for Dishwasher (BONNET) INO36
 for Dishwasher (COMENDA) F20 - F45 - LF320
 for Dishwasher (LINEA BLANCA) LC-1500 - LC-1700
 LC-2000 - LC-2300 - LC-2300TR - LC-2600
 LC-2800
 for Dishwasher (SAMMIC)
 for Dishwasher (THIRODE) VSL450
 for Dishwasher conveyor type (COMENDA) - Series AC
 Series ACR - Series ACS - Series S - Series SNL
 for Dishwasher hood type (LINEA BLANCA) LC-3500
 LC-4000
 for Glasswasher/Cupwasher (COMENDA) B11T



NOSEM



Suitable for:

NOSEM




Suitable for:

Timers

3446200 PROGRAMMER P26 2 CAMS


cycle 120 seconds, 230V 50Hz, without pin
for DRAIN PUMP
for Dishwasher (EUROSYSTEM) PRO400
for Dishwasher (HILTA) S41 - S42
for Dishwasher (IME OMNIWASH) 4Q82
for Dishwasher (NOSEM) C5000 - C5010 - C5020
NC501
for Dishwasher (NUOVA SIMONELLI) KIARA 6CF
for Dishwasher (SAB ITALIA) C50H
for Dishwasher (SO.WE.BO.) 824
for Dishwasher (SOTAL) F600ECO
for Dishwasher (STORME) LT5 - LT500M
for Glasswasher/Cupwasher (AFI) A35Z2



NOSEM

3322261 PROGRAMMER P265 3 CAMS


cycle 4 minutes
230V 50/60Hz
counter-clockwise rotation
D-shaped pin \varnothing 6x4.6 mm
for Dishwasher (NUOVA SIMONELLI) KIARA6CF
for Dishwasher (SAB ITALIA) C50H
for Dishwasher (SO.WE.BO.) 1342 - 701 - 752 - 824
for Dishwasher (STORME) LT500T
for Glasswasher/Cupwasher (AFI) A35Z2
for Glasswasher/Cupwasher (IME OMNIWASH) DUE - UNO
for Glasswasher/Cupwasher (SOTAL) C230



NOSEM

3322260 PROGRAMMER 7805DV 5 CAMS

50Hz - without pin
1° cycle 6" - 2° cycle 180"
for Dishwasher (IME OMNIWASH) GL1040 - GL1240
SEI1PCQ
for Dishwasher (SAB ITALIA) K1.5P
for Dishwasher (UNIC) A61A
for Dishwasher hood type (AFI) A1000L
for Dishwasher hood type (HILTA) W13
for Dishwasher hood type (NOSEM) K601
for Dishwasher hood type (NUOVA SIMONELLI) LTM1500
for Dishwasher hood type (SO.WE.BO.) 6.1P
for Dishwasher hood type (STORME) L501



NOSEM

3446199 PROGRAMMER 7805DV 5 CAMS

1° cycle 6 seconds - 2° cycle 135 seconds
230V 50Hz
for Dishwasher (IME OMNIWASH) 6.2PS
for Dishwasher (NOSEM) K602S
for Dishwasher (SAB ITALIA) K5.2P
for Dishwasher (UNIC) A61A
for Dishwasher hood type (HILTA) W14
for Dishwasher hood type (SO.WE.BO.) 6.2P
for Dishwasher hood type (SOTAL) C1300
for Dishwasher hood type (STORME) L502




NOSEM



Wash and rinse arms and accessories

3743265 BOTTOM RING NUT

for Dishwasher (NOSEM) K602S
 for Dishwasher (SAB ITALIA) K5.2P
 for Dishwasher (SOTAL) C13001P
 for Dishwasher (STORME) L502BT
 for Dishwasher (UNIC) A61A - A61B
 for Dishwasher hood type (AFI) A1000L
 for Dishwasher hood type (EUROSYSTEM) PRO600
 for Dishwasher hood type (HILTA) W13 - W14 - W15
 for Dishwasher hood type (IME OMNIWASH) SEI1P
 SEI2P
 for Dishwasher hood type (NOSEM) K601 - K602
 for Dishwasher hood type (NUOVA SIMONELLI) LTM1500
 LTM1600
 for Dishwasher hood type (SAB ITALIA) K5.1P
 for Dishwasher hood type (SO.WE.BO.) 6.1P - 6.2P



NOSEM

3743200 COMPLETE LOWER HUB SUPPORT

for Dishwasher (AFI) A600 - A900
 for Dishwasher (EUROSYSTEM) PRO400
 for Dishwasher (HILTA) S41 - S42
 for Dishwasher (IME OMNIWASH) QUATTROQ - TREQ
 4Q82
 for Dishwasher (NOSEM) C5000 - C5010 - C5020
 K602S - NC501
 for Dishwasher (SAB ITALIA) C50H - K5.2P
 for Dishwasher (SOTAL) C130001P
 for Dishwasher hood type (AFI) A1000L
 for Dishwasher hood type (HILTA) W13 - W14 - W15
 for Dishwasher hood type (IME OMNIWASH) SEI1P
 SEI2P
 for Dishwasher hood type (NOSEM) K601 - K602
 for Dishwasher hood type (SAB ITALIA) K5.1P



NOSEM

3743054 COMPLETE WATER INLET FITTING


for Dishwasher (AFI) A600
 for Dishwasher (EUROSYSTEM) PRO400
 for Dishwasher (HILTA) S41 - S42
 for Dishwasher (IME OMNIWASH) 4Q82
 for Dishwasher (NOSEM) C5000 - C5010 - C5020
 NC501
 for Dishwasher (NUOVA SIMONELLI) KIARA6
 for Dishwasher (SAB ITALIA) C50H
 for Dishwasher (SO.WE.BO.) 824
 for Dishwasher (SOTAL) F600
 for Dishwasher (STORME) LT500
 for Dishwasher (UNIC) A410E
 for Glasswasher/Cupwasher (SO.WE.BO.) ONECQ
 ONECT



NOSEM

3243526 LOWER RINSE SUPPORT

for Dishwasher (AFI) A600
 for Dishwasher (EUROSYSTEM) PRO400
 for Dishwasher (HILTA) S41 - S42
 for Dishwasher (IME OMNIWASH) 4Q82
 for Dishwasher (NOSEM) C5000 - C5010 - C5020
 NC501
 for Dishwasher (NUOVA SIMONELLI) KIARA6
 for Dishwasher (SAB ITALIA) C50H
 for Dishwasher (SO.WE.BO.) 824
 for Dishwasher (SOTAL) F600
 for Dishwasher (STORME) LT500
 for Dishwasher (UNIC) A410E
 for Glasswasher/Cupwasher (NOSEM) NR101
 for Glasswasher/Cupwasher (SO.WE.BO.) ONECQ
 ONECT



NOSEM



Suitable for:

NOSEM



3243527 LOWER SUPPORT SHORT MODEL

for Dishwasher (SO.WE.BO.) 601 - 701 - 752
 for Glasswasher/Cupwasher (AFI) A35 - A35Z2 - A36
 for Glasswasher/Cupwasher (EUROSYSTEM) PRO100
 PRO200
 for Glasswasher/Cupwasher (HILTA) RB10 - RB22
 SB10 - SB22
 for Glasswasher/Cupwasher (IME OMNIWASH) DUEAQ
 DUECL - DUECS - JA35 - JA36 - JA40 - JA41
 JOLLYQ - JOLLYT - UNO AQ - UNOCL - UNOCS - UNOQ
 for Glasswasher/Cupwasher (NOSEM) C2010L - C4010L
 NC201 - NR101 - R1010
 for Glasswasher/Cupwasher (NUOVA SIMONELLI) KIARA1
 KIARA2 - KIARA4
 for Glasswasher/Cupwasher (SAB ITALIA) C35 - C36
 for Glasswasher/Cupwasher (SO.WE.BO.) 600 - 631



NOSEM

3743602 LOWER/UPPER WASH ARM

length 200 mm with jets
 for Dishwasher (SO.WE.BO.) 601 - 701 - 752
 for Glasswasher/Cupwasher (AFI) A35 - A35Z2 - A36
 for Glasswasher/Cupwasher (EUROSYSTEM) PRO100
 PRO200
 for Glasswasher/Cupwasher (HILTA) RB10 - RB22
 SB10 - SB22
 for Glasswasher/Cupwasher (IME OMNIWASH) DUEAQ
 JA35 - JA36 - JA40 - JA41 - JOLLYAQ - JOLLYQ
 UNO AQ - UNOQ
 for Glasswasher/Cupwasher (NOSEM) C2010L - C4010L
 NC201 - NR101 - R1010
 for Glasswasher/Cupwasher (NUOVA SIMONELLI) KIARA1
 KIARA2 - KIARA4
 for Glasswasher/Cupwasher (SAB ITALIA) C35 - C36



NOSEM

Suitable for:

3743056 RINSE CONNECTION

for Dishwasher (SO.WE.BO.) 601
 for Glasswasher/Cupwasher (IME OMNIWASH) JOLLYA
 JOLLYQ
 for Glasswasher/Cupwasher (SO.WE.BO.) 600 - 631
 661 - 691



NOSEM

3743510 LOWER/UPPER WASH ARM

length 200 mm
 for Glasswasher/Cupwasher (AFI) A35 - A35Z2 - A36
 for Glasswasher/Cupwasher (EUROSYSTEM) PRO100
 PRO200
 for Glasswasher/Cupwasher (HILTA) RB10 - RB22
 SB10 - SB22
 for Glasswasher/Cupwasher (IME OMNIWASH) DUEAT
 JA35 - JA36 - JA40 - JA41 - JOLLYAT - JOLLYT
 UNOAT - UNOT
 for Glasswasher/Cupwasher (NOSEM) C2010L - C4010L
 NC201 - NR101 - R1010
 for Glasswasher/Cupwasher (NUOVA SIMONELLI) KIARA1
 KIARA2 - KIARA4
 for Glasswasher/Cupwasher (SAB ITALIA) C35 - C36



NOSEM

3743267 RINSE ARM CAP

for Dishwasher (AFI) A600
 for Dishwasher (EUROSYSTEM) PRO400
 for Dishwasher (HILTA) S41 - S42
 for Dishwasher (IME OMNIWASH) 4Q82
 for Dishwasher (NOSEM) C5000 - C5010 - C5020
 NC501
 for Dishwasher (SAB ITALIA) C50H
 for Glasswasher/Cupwasher (AFI) A35 - A35Z2 - A36
 for Glasswasher/Cupwasher (EUROSYSTEM) PRO100
 PRO200
 for Glasswasher/Cupwasher (HILTA) RB10 - RB22
 SB10 - SB22
 for Glasswasher/Cupwasher (IME OMNIWASH) DUEAQ
 JOLLYAQ - JOLLYQ - UNOQAQ - UNOQ
 for Glasswasher/Cupwasher (NOSEM) C2010L - C4010L



NOSEM

3743565 RINSE ROD SUPPORT EXTENSION OT

for Dishwasher (AFI) A600
 for Dishwasher (EUROSYSTEM) PRO400
 for Dishwasher (HILTA) S41 - S42
 for Dishwasher (IME OMNIWASH) 4Q82
 for Dishwasher (NOSEM) C5000 - C5010 - C5020
 NC501
 for Dishwasher (SAB ITALIA) C50H
 for Glasswasher/Cupwasher (AFI) A35 - A35Z2 - A36
 for Glasswasher/Cupwasher (EUROSYSTEM) PRO100
 PRO200
 for Glasswasher/Cupwasher (HILTA) RB10 - RB22
 SB10 - SB22
 for Glasswasher/Cupwasher (IME OMNIWASH) DUEAT
 JA35 - JA36 - JA40 - JA41 - JOLLYAT - JOLLYT
 UNOAT - UNOT



NOSEM

3743624

RINSE ARM WITH NOZZLES AND RING NUTS

for Dishwasher (SO.WE.BO.) 601 - 701 - 752
 for Glasswasher/Cupwasher (AFI) A35 - A35Z2 - A36
 for Glasswasher/Cupwasher (EUROSYSTEM) PRO100
 PRO200
 for Glasswasher/Cupwasher (HILTA) RB10 - RB22
 SB10 - SB22
 for Glasswasher/Cupwasher (IME OMNIWASH) DUEAQ
 JA35 - JA36 - JA40 - JA41 - JOLLYAQ - JOLLYQ
 UNOQAQ - UNOQ
 for Glasswasher/Cupwasher (NOSEM) C2010L - C4010L
 NC201 - NR101 - R1010
 for Glasswasher/Cupwasher (NUOVA SIMONELLI) KIARA1
 KIARA2 - KIARA4
 for Glasswasher/Cupwasher (SAB ITALIA) C35 - C36
 for Glasswasher/Cupwasher (SO.WE.BO.) 600 - 631



NOSEM

3743059

RINSE SHAFT SUPPORT

for Dishwasher (AFI) A600
 for Dishwasher (EUROSYSTEM) PRO400
 for Dishwasher (HILTA) S41 - S42
 for Dishwasher (IME OMNIWASH) 4Q82E
 for Dishwasher (NOSEM) C5000 - C5010 - C5020
 NC501
 for Dishwasher (NUOVA SIMONELLI) KIARA6
 for Dishwasher (SAB ITALIA) C50H
 for Dishwasher (SO.WE.BO.) 601 - 701 - 752 - 824
 for Dishwasher (SOTAL) F600ECO
 for Dishwasher (STORME) LT500
 for Dishwasher (UNIC) A410E
 for Glasswasher/Cupwasher (AFI) A35 - A35Z2 - A36
 for Glasswasher/Cupwasher (EUROSYSTEM) PRO100
 PRO200



NOSEM



Suitable for:

NOSEM



3243529 SPINDLE EXTENSION

for Dishwasher (SO.WE.BO.) 601 - 701 - 752
 for Glasswasher/Cupwasher (AFI) A35 - A35Z2 - A36
 for Glasswasher/Cupwasher (EUROSYSTEM) PRO100
 PRO200
 for Glasswasher/Cupwasher (HILTA) RB10 - RB22
 SB10 - SB22
 for Glasswasher/Cupwasher (IME OMNIWASH) DUEAQ
 JA35 - JA36 - JA40 - JA41 - JOLLYQ - JOLLYT
 UNOQA - UNOQ
 for Glasswasher/Cupwasher (NOSEM) C2010L - C4010L
 NC201 - NR101 - R1010
 for Glasswasher/Cupwasher (NUOVA SIMONELLI) KIARA1
 KIARA2 - KIARA4
 for Glasswasher/Cupwasher (SAB ITALIA) C35 - C36
 for Glasswasher/Cupwasher (SO.WE.BO.) 600 - 631




NOSEM

Suitable for:

3743269 TOP RINSE ARM FITTING

for Dishwasher hood type (IME OMNIWASH) SEI1P
 SEI2P



NOSEM

3743603 UPPER WASH ARM

height 145 mm - length 235 mm
 for Glasswasher/Cupwasher (IME OMNIWASH) DUEAT



NOSEM

3243533 UPPER WASH ARM ASSEMBLY SUPPORT

for Dishwasher (AFI) A600
 for Dishwasher (EUROSYSTEM) PRO400
 for Dishwasher (HILTA) S41 - S42
 for Dishwasher (IME OMNIWASH) 4Q82
 for Dishwasher (NOSEM) C5000 - C5010 - C5020
 NC501
 for Dishwasher (NUOVA SIMONELLI) KIARA6
 for Dishwasher (SAB ITALIA) C50H
 for Dishwasher (SO.WE.BO.) 824
 for Dishwasher (SOTAL) F600
 for Dishwasher (STORME) LT500
 for Dishwasher (UNIC) A410E
 for Glasswasher/Cupwasher (NOSEM) NR101
 for Glasswasher/Cupwasher (SO.WE.BO.) ONECQ
 ONECT



NOSEM

3243515 CORK GASKET ø 85 mm

for Dishwasher (AFI) A600
 for Dishwasher (EUROSYSTEM) PRO400
 for Dishwasher (HILTA) S41 - S42
 for Dishwasher (IME OMNIWASH) 4Q82
 for Dishwasher (NOSEM) C5000 - C5010 - C5020
 NC501
 for Dishwasher (NUOVA SIMONELLI) KIARA6
 for Dishwasher (SAB ITALIA) C50H
 for Dishwasher (SO.WE.BO.) 824
 for Dishwasher (SOTAL) F600
 for Dishwasher (STORME) LT500
 for Dishwasher (UNIC) A410E
 for Glasswasher/Cupwasher (NOSEM) NR101
 for Glasswasher/Cupwasher (SO.WE.BO.) ONECQ
 ONECT




NOSEM



Suitable for:

3243514 UPPER RING NUT \varnothing 110 mm

for Dishwasher (AFI) A600
 for Dishwasher (EUROSYSTEM) PRO400
 for Dishwasher (HILTA) C5000 - C5010 - C5020
 NC501 - S41 - S42
 for Dishwasher (IME OMNIWASH) 4Q82
 for Dishwasher (NUOVA SIMONELLI) KIARA6
 for Dishwasher (SAB ITALIA) C50H
 for Dishwasher (SO.WE.BO.) 824
 for Dishwasher (SOTAL) F600
 for Dishwasher (STORME) LT500
 for Dishwasher (UNIC) A410E
 for Glasswasher/Cupwasher (NOSEM) NR101
 for Glasswasher/Cupwasher (SO.WE.BO.) ONECQ
 ONECT



NOSEM

Suitable for:



NOSEM

3243486 WASH AND RINSE ARM ASSEMBLY

length 500 mm
 for Dishwasher (AFI) A600
 for Dishwasher (EUROSYSTEM) PRO400
 for Dishwasher (HILTA) S41 - S42
 for Dishwasher (IME OMNIWASH) 4Q82
 for Dishwasher (NOSEM) C5000 - C5010 - C5020
 NC501
 for Dishwasher (NUOVA SIMONELLI) KIARA6
 for Dishwasher (SAB ITALIA) C50H
 for Dishwasher (SO.WE.BO.) 824
 for Dishwasher (SOTAL) F600
 for Dishwasher (STORME) LT500
 for Dishwasher (UNIC) A410E
 for Glasswasher/Cupwasher (NOSEM) NR101
 for Glasswasher/Cupwasher (SO.WE.BO.) ONECQ



NOSEM

3743322 WASH ARM ASSEMBLY 310 mm

for Dishwasher (SO.WE.BO.) 601 - 701 - 752
 for Glasswasher/Cupwasher (AFI) A35 - A35Z2 - A36
 for Glasswasher/Cupwasher (EUROSYSTEM) PRO100
 PRO200
 for Glasswasher/Cupwasher (HILTA) RB10 - RB22
 SB10 - SB22
 for Glasswasher/Cupwasher (IME OMNIWASH) JA35
 JA350 - JA36 - JA360 - JOLLYAQ - JOLLYQ - J35
 J350 - J36 - J360
 for Glasswasher/Cupwasher (NOSEM) C2010L - C4010L
 NC201 - NR101 - R1010
 for Glasswasher/Cupwasher (NUOVA SIMONELLI) KIARA1
 KIARA2 - KIARA4
 for Glasswasher/Cupwasher (SAB ITALIA) C35 - C36
 for Glasswasher/Cupwasher (SO.WE.BO.) 600 - 631



NOSEM




Suitable for:

NOSEM



3743562 WASH ARM CT MOD.2/4 WHITE

for Dishwasher (AFI) A600
 for Dishwasher (EUROSYSTEM) PRO400
 for Dishwasher (HILTA) S41 - S42
 for Dishwasher (IME OMNIWASH) 4Q82
 for Dishwasher (NOSEM) C5000 - C5010 - C5020
 NC501
 for Dishwasher (NUOVA SIMONELLI) KIARA6
 for Dishwasher (SAB ITALIA) C50H
 for Dishwasher (SO.WE.BO.) 824
 for Dishwasher (SOTAL) F600ECO
 for Dishwasher (STORME) LT500
 for Dishwasher (UNIC) A410E



NOSEM

3743576 WASH ARM 4CT MOULD 24

for Dishwasher (AFI) A600
 for Dishwasher (EUROSYSTEM) PRO400
 for Dishwasher (HILTA) S41 - S42
 for Dishwasher (IME OMNIWASH) 4Q82
 for Dishwasher (NOSEM) C5000 - C5010 - C5020
 NC501
 for Dishwasher (NUOVA SIMONELLI) KIARA6
 for Dishwasher (SAB ITALIA) C50H
 for Dishwasher (SO.WE.BO.) 824
 for Dishwasher (SOTAL) 600ECO
 for Dishwasher (STORME) LT500
 for Dishwasher (UNIC) A410E



NOSEM

Suitable for:

3743264 WASH ARM 200 mm

for Dishwasher (SO.WE.BO.) 601 - 701 - 752
 for Glasswasher/Cupwasher (AFI) A35 - A35Z2 - A36
 for Glasswasher/Cupwasher (EUROSYSTEM) PRO100
 PRO200
 for Glasswasher/Cupwasher (HILTA) RB10 - RB22
 SB10 - SB22
 for Glasswasher/Cupwasher (IME OMNIWASH) JA35
 JA350 - JA36 - JA360 - JOLLYAQ - JOLLYQ - J35
 J350 - J36 - J360
 for Glasswasher/Cupwasher (NOSEM) C2010L - C4010L
 NC201 - NR101 - R1010
 for Glasswasher/Cupwasher (NUOVA SIMONELLI) KIARA1
 KIARA2 - KIARA4
 for Glasswasher/Cupwasher (SAB ITALIA) C35 - C36
 for Glasswasher/Cupwasher (SO.WE.BO.) 600 - 631



NOSEM

3743568 WASH COLUMN EXTENSION

for Dishwasher (SO.WE.BO.) 601 - 701 - 752
 for Glasswasher/Cupwasher (AFI) A35 - A35Z2 - A36
 for Glasswasher/Cupwasher (EUROSYSTEM) PRO100
 PRO200
 for Glasswasher/Cupwasher (HILTA) RB10 - RB22
 SB10 - SB22
 for Glasswasher/Cupwasher (IME OMNIWASH) DUEAT
 JA35 - JA36 - JA40 - JA41 - JOLLYAT - JOLLYT
 UNOAT - UNOT
 for Glasswasher/Cupwasher (NOSEM) C2010L - C4010L
 NC201 - NR101 - R1010
 for Glasswasher/Cupwasher (NUOVA SIMONELLI) KIARA1
 KIARA2 - KIARA4
 for Glasswasher/Cupwasher (SAB ITALIA) C35 - C36
 for Glasswasher/Cupwasher (SO.WE.BO.) 600 - 631



NOSEM

3743055 WASH COLUMN 380 mm

for Dishwasher (SO.WE.BO.) 601 - 701 - 752
 for Glasswasher/Cupwasher (AFI) A35 - A35Z2 - A36
 for Glasswasher/Cupwasher (EUROSYSTEM) PRO100
 PRO200
 for Glasswasher/Cupwasher (HILTA) RB10 - RB22
 SB10 - SB22
 for Glasswasher/Cupwasher (IME OMNIWASH) DUEAQ
 DUEAT - JA35 - JA36 - JA40 - JA41 - JOLLYQ
 JOLLYT - UNOQ - UNOT
 for Glasswasher/Cupwasher (NOSEM) C2010L - C4010L
 NC201 - NR101 - R1010
 for Glasswasher/Cupwasher (NUOVA SIMONELLI) KIARA1
 KIARA2 - KIARA4
 for Glasswasher/Cupwasher (SAB ITALIA) C35 - C36
 for Glasswasher/Cupwasher (SO.WE.BO.) 600 - 631



NOSEM

3743057 WATER INLET SUPPORT

for Dishwasher (SO.WE.BO.) 601 - 701 - 752
 for Glasswasher/Cupwasher (AFI) A35 - A35Z2 - A36
 for Glasswasher/Cupwasher (EUROSYSTEM) PRO100
 PRO200
 for Glasswasher/Cupwasher (HILTA) RB10 - RB22
 SB10 - SB22
 for Glasswasher/Cupwasher (IME OMNIWASH) DUEAQ
 DUEAT - JA35 - JA36 - JA40 - JA41 - JOLLYQ
 JOLLYT - UNOQ - UNOT
 for Glasswasher/Cupwasher (NOSEM) C2010L - C4010L
 NC201 - NR101 - R1010
 for Glasswasher/Cupwasher (NUOVA SIMONELLI) KIARA1
 KIARA2 - KIARA4
 for Glasswasher/Cupwasher (SAB ITALIA) C35 - C36
 for Glasswasher/Cupwasher (SO.WE.BO.) 600 - 631



NOSEM

Suitable for:

3743524 WASH ARM EXTENSION

for Dishwasher (SO.WE.BO.) 601 - 701 - 752
 for Glasswasher/Cupwasher (AFI) A35 - A35Z2 - A36
 for Glasswasher/Cupwasher (EUROSYSTEM) PRO100
 PRO200
 for Glasswasher/Cupwasher (HILTA) RB10 - RB22
 SB10 - SB22
 for Glasswasher/Cupwasher (IME OMNIWASH) DUEAQ
 JA40 - JA41 - JOLLYAT - JOLLYT - UNOAT - UNOT
 for Glasswasher/Cupwasher (NOSEM) C2010L - C4010L
 NC201 - NR101 - R1010
 for Glasswasher/Cupwasher (NUOVA SIMONELLI) KIARA1
 KIARA2 - KIARA4
 for Glasswasher/Cupwasher (SAB ITALIA) C35 - C36
 for Glasswasher/Cupwasher (SO.WE.BO.) 600 - 631
 661 - 691 - 712 - 742



NOSEM

3743058 GAS NUT Ø 1"

for Dishwasher (SO.WE.BO.) 601 - 701 - 752
 for Glasswasher/Cupwasher (AFI) A35 - A35Z2 - A36
 for Glasswasher/Cupwasher (EUROSYSTEM) PRO100
 PRO200
 for Glasswasher/Cupwasher (HILTA) RB10 - RB22
 SB10 - SB22
 for Glasswasher/Cupwasher (IME OMNIWASH) DUEAQ
 DUEAT - JA35 - JA36 - JA40 - JA41 - JOLLYQ
 JOLLYT - UNOQ - UNOT
 for Glasswasher/Cupwasher (NOSEM) C2010L - C4010L
 NC201 - NR101 - R1010
 for Glasswasher/Cupwasher (NUOVA SIMONELLI) KIARA1
 KIARA2 - KIARA4
 for Glasswasher/Cupwasher (SAB ITALIA) C35 - C36
 for Glasswasher/Cupwasher (SO.WE.BO.) 600 - 631



NOSEM



Suitable for:

3186847 OR GASKET 03131 EPDM

for Dishwasher (SO.WE.BO.) 601 - 701 - 752
 for Glasswasher/Cupwasher (AFI) A35 - A35Z2 - A36
 for Glasswasher/Cupwasher (EUROSYSTEM) PRO100
 PRO200
 for Glasswasher/Cupwasher (HILTA) RB10 - RB22
 SB10 - SB22
 for Glasswasher/Cupwasher (IME OMNIWASH) DUECL
 DUECS - JA35 - JA36 - JA40 - JA41 - JOLLY
 UNOCL - UNOCS
 for Glasswasher/Cupwasher (NOSEM) C2010L - C4010L
 NC201 - NR101 - R1010
 for Glasswasher/Cupwasher (NUOVA SIMONELLI) KIARA1
 KIARA2 - KIARA4
 for Glasswasher/Cupwasher (SAB ITALIA) C35 - C36
 for Glasswasher/Cupwasher (SO.WE.BO.) 600 - 631



NOSEM

Suitable for:




NOSEM

Washing baskets and accessories

3055691 ROUND RACK SUPPORT ø 280 mm


for Dishwasher (AFI) A600 - A900
 for Dishwasher (EUROSYSTEM) PRO400
 for Dishwasher (HILTA) S41 - S42
 for Dishwasher (NOSEM) C2050 - C5000 - C5010
 NC501
 for Dishwasher hood type (AFI) A1000L
 for Dishwasher hood type (EUROSYSTEM) PRO600
 for Dishwasher hood type (HILTA) W13 - W14 - W15
 for Dishwasher hood type (NOSEM) K601 - K602
 for Glasswasher/Cupwasher (AFI) A35 - A35Z2 - A36
 for Glasswasher/Cupwasher (EUROSYSTEM) PRO100
 PRO200
 for Glasswasher/Cupwasher (HILTA) RB10 - RB22
 SB10 - SB22
 for Glasswasher/Cupwasher (NOSEM) C2010L - C4010L



NOSEM

3528051 BASKET SUPPORT NUT

for Dishwasher (AFI) A600 - A900
 for Dishwasher (EUROSYSTEM) PRO400
 for Dishwasher (HILTA) S41 - S42
 for Dishwasher (NOSEM) C2050 - C5000 - C5010
 NC501
 for Dishwasher hood type (AFI) A1000L
 for Dishwasher hood type (EUROSYSTEM) PRO600
 for Dishwasher hood type (HILTA) W13 - W14 - W15
 for Dishwasher hood type (NOSEM) K601 - K602
 for Glasswasher/Cupwasher (AFI) A35 - A35Z2 - A36
 for Glasswasher/Cupwasher (EUROSYSTEM) PRO100
 PRO200
 for Glasswasher/Cupwasher (HILTA) RB10 - RB22
 SB10 - SB22
 for Glasswasher/Cupwasher (NOSEM) C2010L - C4010L



NOSEM



Suitable for:

3324007 ROTATING SUPPORT PIN CT WITH BALL 1-2

for Dishwasher (AFI) A600 - A900
 for Dishwasher (EUROSYSTEM) PRO400
 for Dishwasher (HILTA) S41 - S42
 for Dishwasher (NOSEM) C2050 - C5000 - C5010 NC501
 for Dishwasher hood type (AFI) A1000L
 for Dishwasher hood type (EUROSYSTEM) PRO600
 for Dishwasher hood type (HILTA) W13 - W14 - W15
 for Dishwasher hood type (NOSEM) K601 - K602
 for Glasswasher/Cupwasher (AFI) A35 - A35Z2 - A36
 for Glasswasher/Cupwasher (EUROSYSTEM) PRO100 PRO200
 for Glasswasher/Cupwasher (HILTA) RB10 - RB22 SB10 - SB22
 for Glasswasher/Cupwasher (NOSEM) C2010L - C4010L



NOSEM

3241838 S/STEEL TURNTABLE DISK 1-2

for Dishwasher (AFI) A600 - A900
 for Dishwasher (EUROSYSTEM) PRO400
 for Dishwasher (HILTA) S41 - S42
 for Dishwasher (NOSEM) C2050 - C5000 - C5010 NC501
 for Dishwasher hood type (AFI) A1000L
 for Dishwasher hood type (EUROSYSTEM) PRO600
 for Dishwasher hood type (HILTA) W13 - W14 - W15
 for Dishwasher hood type (NOSEM) K601 - K602
 for Glasswasher/Cupwasher (AFI) A35 - A35Z2 - A36
 for Glasswasher/Cupwasher (EUROSYSTEM) PRO100 PRO200
 for Glasswasher/Cupwasher (HILTA) RB10 - RB22 SB10 - SB22
 for Glasswasher/Cupwasher (NOSEM) C2010L - C4010L



NOSEM

NOSEM



Suitable for:

3055668 ROTATING SUPPORT SHAFT SPACER 1-2

for Dishwasher (AFI) A600 - A900
 for Dishwasher (EUROSYSTEM) PRO400
 for Dishwasher (HILTA) S41 - S42
 for Dishwasher (NOSEM) C2050 - C5000 - C5010 NC501
 for Dishwasher hood type (AFI) A1000L
 for Dishwasher hood type (EUROSYSTEM) PRO600
 for Dishwasher hood type (HILTA) W13 - W14 - W15
 for Dishwasher hood type (NOSEM) K601 - K602
 for Glasswasher/Cupwasher (AFI) A35 - A35Z2 - A36
 for Glasswasher/Cupwasher (EUROSYSTEM) PRO100 PRO200
 for Glasswasher/Cupwasher (HILTA) RB10 - RB22 SB10 - SB22
 for Glasswasher/Cupwasher (NOSEM) C2010L - C4010L



NOSEM

3250227 SEEGER FOR ROTATING SUPPORT SHAFT

for Dishwasher (AFI) A600 - A900
 for Dishwasher (EUROSYSTEM) PRO400
 for Dishwasher (HILTA) S41 - S42
 for Dishwasher (NOSEM) C2050 - C5000 - C5010 NC501
 for Dishwasher hood type (AFI) A1000L
 for Dishwasher hood type (EUROSYSTEM) PRO600
 for Dishwasher hood type (HILTA) W13 - W14 - W15
 for Dishwasher hood type (NOSEM) K601 - K602
 for Glasswasher/Cupwasher (AFI) A35 - A35Z2 - A36
 for Glasswasher/Cupwasher (EUROSYSTEM) PRO100 PRO200
 for Glasswasher/Cupwasher (HILTA) RB10 - RB22 SB10 - SB22
 for Glasswasher/Cupwasher (NOSEM) C2010L - C4010L



NOSEM

The data herewith contained may change without notice and LF SpA cannot be held responsible for possible errors stated or resulting by the use of this document. All rights reserved. No part of this publication may be reproduced without written permission by LF SpA.



LF SpA
via Voltri, 80 - 47522 Cesena (FC) ITALIA
Tel. +39 0547 34 11 11 - Fax +39 0547 34 11 10
www.lfricambi724.it - www.lfricambi724.mobi
info@lfricambi.it
Export Dept.: Tel. +39 0547 34 11 50 - Fax: +39 0547 34 11 55
www.lfspareparts724.com - www.lfspareparts724.mobi
export@lfspaceparts.com

FRANCE



EPGC Sas
13, Rue des Forts - 59960 Neuville en Ferrain
Tél. +33 (0)3 20 25 06 21
Fax +33 (0)3 20 25 34 12
www.epgc.com
www.epgc724.mobi
epgc@epgc.com

DEUTSCHLAND



LF GmbH
Junkersstrasse, 1 - D-82178 Puchheim - München
Tel. +49 89 89 45 78 66
Fax +49 89 89 45 78 88
www.lfersatzteile724.de
www.lfersatzteile724.mobi
info@lfersatzteile.de

SCHWEIZ



LF GmbH Verkaufsbüro
Sennweidstrasse, 45 - CH-6312 Steinhausen
Tel. +41 (0)41 760 15 80-1
Fax +41 (0)41 760 15 85
www.lfersatzteile724.ch
www.lfersatzteile724.mobi
info@lfersatzteile.ch

ESPAÑA



LF Repuestos Horeca S.L.U.
Calle Ciudad Real, 10 - 45517 Escalonilla - Toledo
Tif. +34 91 477 91 00
Fax +34 91 477 90 81
www.lfrepuestos724.es
www.lfrepuestos724.mobi
info@lfrepuestos.es

UNITED KINGDOM



LF Spare Parts Ltd.
A10a Lakeside Business Park, Broadway Lane
South Cerney, Gloucestershire GL7 5XL
Tel. +44 (0)1285 86 16 25
Fax +44 (0)1285 86 39 49
www.lfspareparts724.co.uk
www.lfspareparts724.mobi
info@lfspaceparts.co.uk

RUSSIA



OOO LF
ul, Anatoliya Zhivova, 8 - office 1 - 123100 Moscow
Tel. +7 499 259 85 75
Fax +7 495 725 26 53
www.lfspareparts724.ru
www.lfspareparts724.mobi
info@lfspaceparts.ru

CHINA



LF China
Room 102, House 8, Lane 725, Mao Tai Rd.
Changning Dist. - 200336 Shanghai
Tel. +86 (0)21 33 53 66 31
Fax +86 (0)21 33 53 66 32
www.lfspareparts724.com
www.lfspareparts724.mobi
china@lfspaceparts.com