



Spare parts for:

Warewashing equipment



Suitable for:

SOTAL



This catalogue is automatically generated.
Therefore, the sequence of the items might
not be always shown at best.

Updates will be issued in case of additions
and/or amendments.

Suitable universal spare parts may not be included





Suitable for:

SOTAL




Suitable for:

Air Chambers

3060118 AIR CHAMBER

for Dishwasher MAGIC50
for Dishwasher hood type (SO.WE.BO.) 6.2PB




SOTAL C1300

Bearings

3063102 S609RS BEARING F/ROTATING SUPPORT

for Dishwasher (AFI) A600 - A900
for Dishwasher (EUROSYSTEM) PRO400
for Dishwasher (HILTA) S41 - S42
for Dishwasher (NOSEM) C2050 - C5000 - C5010
NC501
for Dishwasher hood type (AFI) A1000L
for Dishwasher hood type (EUROSYSTEM) PRO600
for Dishwasher hood type (HILTA) W13 - W14 - W15
for Dishwasher hood type (NOSEM) K601 - K602
for Glasswasher/Cupwasher (AFI) A35 - A35Z2 - A36
for Glasswasher/Cupwasher (EUROSYSTEM) PRO100
PRO200
for Glasswasher/Cupwasher (HILTA) RB10 - RB22
SB10 - SB22
for Glasswasher/Cupwasher (NOSEM) C2010L - C4010L



SOTAL

Caps

3439007 HEXAGONAL TANK CAP 3/8" GAS
 for Glasswasher/Cupwasher (AFI) A35 - A35Z2 - A36
 for Glasswasher/Cupwasher (EUROSYSTEM) PRO100
 PRO200
 for Glasswasher/Cupwasher (HILTA) RB10 - RB22
 SB10 - SB22
 for Glasswasher/Cupwasher (IME OMNIWASH) DUE
 JA35 - JA36 - JA40 - JA41 - JOLLY - UNO
 for Glasswasher/Cupwasher (NOSEM) C2010L - C4010L
 NC201 - NR101 - R1010
 for Glasswasher/Cupwasher (NUOVA SIMONELLI) KIARA1
 KIARA2 - KIARA4
 for Glasswasher/Cupwasher (SAB ITALIA) C35 - C36
 for Glasswasher/Cupwasher (SO.WE.BO.) 600 - 601
 631 - 661 - 691 - 701 - 712 - 742 - 752
 for Glasswasher/Cupwasher (SOTAL) C230 - EC195



SOTAL

3186181 O-RING 03068 EPDM
 for Dishwasher (SO.WE.BO.) 601 - 701 - 752
 for Dishwasher (SOTAL) ER225
 for Glasswasher/Cupwasher (AFI) A35 - A35Z2 - A36
 for Glasswasher/Cupwasher (COMENDA) - Series B
 for Glasswasher/Cupwasher (EUROSYSTEM) PRO100
 PRO200
 for Glasswasher/Cupwasher (HILTA) RB10 - RB22
 SB10 - SB22
 for Glasswasher/Cupwasher (IME OMNIWASH) DUE
 JA35 - JA36 - JA40 - JA41 - JOLLY - UNO
 for Glasswasher/Cupwasher (NOSEM) C2010L - C4010L
 NC201 - NR101 - R1010
 for Glasswasher/Cupwasher (NUOVA SIMONELLI) KIARA1
 KIARA2 - KIARA4
 for Glasswasher/Cupwasher (SAB ITALIA) C35 - C36



SOTAL

Drain assembly

3316141 DRAIN ASSEMBLY 1"1/4
 for QUATTRO Q



SOTAL

Drain plugs

3448142 COMPLETE OVERFLOW PIPE \varnothing 25x100 mm
 in plastic
 for CL-CS-UNO-DUE
 for Glasswasher/Cupwasher (EMB) 35HL



SOTAL

3448177 COMPLETE OVERFLOW PIPE \varnothing 35x165 mm
 in plastic
 for QUATTRO Q-T-BA



SOTAL



Suitable for:

SOTAL


Suitable for:



Filters

3160321 FILTER 230x200 mm


for Dishwasher (AFI) A600
 for Dishwasher (EUROSYSTEM) PRO400
 for Dishwasher (HILTA) S41 - S42
 for Dishwasher (IME OMNIWASH) 4Q82
 for Dishwasher (NOSEM) C5000 - C5010 - C5020
 NC501
 for Dishwasher (NUOVA SIMONELLI) KIARA6
 for Dishwasher (SAB ITALIA) C50H
 for Dishwasher (SO.WE.BO.) 824
 for Dishwasher (SOTAL) F600ECO
 for Dishwasher (STORME) LT500M - LT500T
 for Dishwasher (UNIC) A410E



SOTAL

3160322 FILTER 330x310 mm

for Dishwasher (SO.WE.BO.) 701CQ - 752CQ - 752CT
 for Glasswasher/Cupwasher (AFI) A35Z2
 for Glasswasher/Cupwasher (EUROSYSTEM) PRO200
 for Glasswasher/Cupwasher (HILTA) RB22 - SB22
 for Glasswasher/Cupwasher (IME OMNIWASH) DUEAQ
 DUEAT - UNOQAQ - UNOAT - UNOQ - UNOT
 for Glasswasher/Cupwasher (NOSEM) C4010L - NC201
 NR101 - R1010
 for Glasswasher/Cupwasher (NUOVA SIMONELLI) KIARA4
 for Glasswasher/Cupwasher (SO.WE.BO.) ONECQ
 ONECT - 701VT - 712CQ - 712CT - 742CQ - 742CT
 for Glasswasher/Cupwasher (SOTAL) C230
 for Glasswasher/Cupwasher (STORME) ME400
 for Glasswasher/Cupwasher (UNIC) A20 - A21



SOTAL

3160038 INLET CONNECTOR \varnothing 1"1/4

for Dishwasher (AFI) A600
 for Dishwasher (EUROSYSTEM) PRO400
 for Dishwasher (HILTA) S41 - S42
 for Dishwasher (NOSEM) C5010 - C5020 - NC501
 for Dishwasher (NUOVA SIMONELLI) KIARA6
 for Dishwasher (SAB ITALIA) C50H
 for Dishwasher (SO.WE.BO.) 600CQ - 600CT - 619CQ
 619CT - 631CT - 661CQ - 701CQ - 701CT - 752CQ
 752CT - 824CQ - 824CT
 for Dishwasher (SOTAL) F600ECO
 for Dishwasher (STORME) LT500M - LT500T
 for Dishwasher (UNIC) A100 - A410E
 for Glasswasher/Cupwasher (AFI) A35 - A35Z2 - A36
 for Glasswasher/Cupwasher (EUROSYSTEM) PRO100
 PRO200



SOTAL


3160039 TIE ROD FOR FILTER 52 mm

for Dishwasher (AFI) A600
 for Dishwasher (EUROSYSTEM) PRO400
 for Dishwasher (HILTA) S41 - S42
 for Dishwasher (NOSEM) C5010 - C5020 - NC501
 for Dishwasher (NUOVA SIMONELLI) KIARA6
 for Dishwasher (SAB ITALIA) C50H
 for Dishwasher (SO.WE.BO.) 600CQ - 600CT - 619CQ
 619CT - 631CT - 661CQ - 701CQ - 701CT - 752CQ
 752CT - 824CQ - 824CT
 for Dishwasher (SOTAL) F600ECO
 for Dishwasher (STORME) LT500M - LT500T
 for Dishwasher (UNIC) A100 - A410E
 for Glasswasher/Cupwasher (AFI) A35 - A35Z2 - A36
 for Glasswasher/Cupwasher (EUROSYSTEM) PRO100
 PRO200



SOTAL

3160037 PLASTIC INNER FILTER FOR TANK 230x200 mm
 for Dishwasher (IME OMNIWASH) 4Q82
 for Dishwasher (NOSEM) K602S
 for Dishwasher (SAB ITALIA) K5.2P
 for Dishwasher (SOTAL) C13001P
 for Dishwasher (STORME) L502BT
 for Dishwasher (UNIC) A61A - A61B
 for Dishwasher hood type (AFI) A1000L
 for Dishwasher hood type (EUROSYSTEM) PRO600
 for Dishwasher hood type (HILTA) W13 - W14 - W15
 for Dishwasher hood type (IME OMNIWASH) SEI1P
 SEI2P
 for Dishwasher hood type (NOSEM) K601
 for Dishwasher hood type (NUOVA SIMONELLI) LTM1500
 LTM1600
 for Dishwasher hood type (SAB ITALIA) K5.1P



SOTAL

Suitable for:

3160464 S/STEEL FILTER SURFACE 230x200 mm
 for Dishwasher (NOSEM) K602S
 for Dishwasher (SAB ITALIA) K5.2P
 for Dishwasher (SOTAL) C13001P - C130024V
 for Dishwasher (STORME) L502BT
 for Dishwasher (UNIC) A61A - A61B
 for Dishwasher hood type (AFI) A1000L
 for Dishwasher hood type (EUROSYSTEM) PRO600
 for Dishwasher hood type (HILTA) W13 - W14 - W15
 for Dishwasher hood type (IME OMNIWASH) SEI1P
 SEI2P
 for Dishwasher hood type (NOSEM) K601 - K602
 for Dishwasher hood type (NUOVA SIMONELLI) LTM1500
 LTM1600
 for Dishwasher hood type (SAB ITALIA) K5.1P
 for Dishwasher hood type (SO.WE.BO.) 6.1P - 6.2P



SOTAL

Guides

3189048 HOOD SLIDEWAY
 dimensions 595x35 mm
 for Dishwasher (IME OMNIWASH) SEI1PS
 for Dishwasher (SAB ITALIA) K5.1 - K5.2
 for Dishwasher (STORME) L502BT
 for Dishwasher (UNIC) A61A - A61B
 for Dishwasher hood type (AFI) A1000L
 for Dishwasher hood type (EUROSYSTEM) PRO600
 for Dishwasher hood type (HILTA) W13 - W14 - W15
 for Dishwasher hood type (IME OMNIWASH) SEI2PS
 for Dishwasher hood type (NOSEM) K601 - K602
 for Dishwasher hood type (NUOVA SIMONELLI) LTM1500
 LTM1600
 for Dishwasher hood type (SO.WE.BO.) 6.1P - 6.2P
 for Dishwasher hood type (SOTAL) C1300
 for Dishwasher hood type (STORME) L501 - L502



SOTAL



Suitable for:

SOTAL



Suitable for:

Heating elements

3355407 HEATING ELEMENT FOR WASH TANK 1800W 230V

immersed length 295 mm
 connection ø 12 mm
 for Dishwasher (NOSEM) C4010 - NC202 - NR102
 N101 - R1020
 for Dishwasher (SO.WE.BO.) 701 - 752
 for Glasswasher/Cupwasher (AFI) A35Z2
 for Glasswasher/Cupwasher (EUROSYSTEM) PRO200
 for Glasswasher/Cupwasher (HILTA) RB22 - SB22
 for Glasswasher/Cupwasher (IME OMNIWASH) DUEAQ
 DUEAT - DUECL - DUECS - JA40 - JA41 - J40
 J41 - UNO AQ - UNO AT - UNO CL - UNO CS
 for Glasswasher/Cupwasher (NOSEM) NC201 - R1010
 for Glasswasher/Cupwasher (NUOVA SIMONELLI) KIARA4
 for Glasswasher/Cupwasher (SO.WE.BO.) 712 - 742
 for Glasswasher/Cupwasher (STORME) ME400



SOTAL

Hinges

3391046 BUSHING FOR DOOR HINGE

for Dishwasher (SO.WE.BO.) 601 - 701
 for Glasswasher/Cupwasher (AFI) A35
 for Glasswasher/Cupwasher (EUROSYSTEM) PRO100
 for Glasswasher/Cupwasher (HILTA) RB10 - SB10
 for Glasswasher/Cupwasher (IME OMNIWASH) JA35
 JA36 - JOLLY - UNO
 for Glasswasher/Cupwasher (NOSEM) C2010L - NC201
 R1010L
 for Glasswasher/Cupwasher (NUOVA SIMONELLI) KIARA1
 for Glasswasher/Cupwasher (SO.WE.BO.) 600 - 631
 661 - 691
 for Glasswasher/Cupwasher (SOTAL) EC195 - ER195
 for Glasswasher/Cupwasher (STORME) SM350
 for Glasswasher/Cupwasher (UNIC) A10J - A11J



SOTAL

3053317 DOOR SPRING LH

for Dishwasher (SO.WE.BO.) 601 - 701
 for Glasswasher/Cupwasher (AFI) A35
 for Glasswasher/Cupwasher (EUROSYSTEM) PRO100
 for Glasswasher/Cupwasher (HILTA) RB10 - SB10
 for Glasswasher/Cupwasher (IME OMNIWASH) JA35
 JA36 - JOLLYA - UNO
 for Glasswasher/Cupwasher (NOSEM) C2010L - NC201
 R1010L
 for Glasswasher/Cupwasher (NUOVA SIMONELLI) KIARA1
 for Glasswasher/Cupwasher (SO.WE.BO.) 600 - 631
 661 - 691
 for Glasswasher/Cupwasher (SOTAL) EC195 - ER195
 for Glasswasher/Cupwasher (STORME) SM350
 for Glasswasher/Cupwasher (UNIC) A10J - A11J



SOTAL

3053319 DOOR SPRING LH

for Dishwasher (SO.WE.BO.) 601 - 701
 for Glasswasher/Cupwasher (AFI) A35
 for Glasswasher/Cupwasher (EUROSYSTEM) PRO100
 for Glasswasher/Cupwasher (HILTA) RB10 - SB10
 for Glasswasher/Cupwasher (IME OMNIWASH) JA35
 JA36 - JOLLY - UNO
 for Glasswasher/Cupwasher (NOSEM) C2010L - NC201
 R1010L
 for Glasswasher/Cupwasher (NUOVA SIMONELLI) KIARA1
 for Glasswasher/Cupwasher (SO.WE.BO.) 600 - 631
 661 - 691
 for Glasswasher/Cupwasher (SOTAL) EC195 - ER195
 for Glasswasher/Cupwasher (STORME) SM350
 for Glasswasher/Cupwasher (UNIC) A10J - A11J



SOTAL

3053320 DOOR SPRING RH


for Dishwasher (SO.WE.BO.) 601 - 701
 for Glasswasher/Cupwasher (AFI) A35
 for Glasswasher/Cupwasher (EUROSYSTEM) PRO100
 for Glasswasher/Cupwasher (HILTA) RB10 - SB10
 for Glasswasher/Cupwasher (IME OMNIWASH) JA35
 JA36 - JOLLY - UNO
 for Glasswasher/Cupwasher (NOSEM) C2010L - NC201
 R1010L
 for Glasswasher/Cupwasher (NUOVA SIMONELLI) KIARA1
 for Glasswasher/Cupwasher (SO.WE.BO.) 600 - 631
 661 - 691
 for Glasswasher/Cupwasher (SOTAL) EC195 - ER195
 for Glasswasher/Cupwasher (STORME) SM350
 for Glasswasher/Cupwasher (UNIC) A10J - A11J



SOTAL

3053318 DOOR SPRING RH

for Dishwasher (SO.WE.BO.) 601 - 701
 for Glasswasher/Cupwasher (AFI) A35
 for Glasswasher/Cupwasher (EUROSYSTEM) PRO100
 for Glasswasher/Cupwasher (HILTA) RB10 - SB10
 for Glasswasher/Cupwasher (IME OMNIWASH) JA35
 JA36 - JOLLYA - UNO
 for Glasswasher/Cupwasher (NOSEM) C2010L - NC201
 R1010L
 for Glasswasher/Cupwasher (NUOVA SIMONELLI) KIARA1
 for Glasswasher/Cupwasher (SO.WE.BO.) 600 - 631
 661 - 691
 for Glasswasher/Cupwasher (SOTAL) EC195 - ER195
 for Glasswasher/Cupwasher (STORME) SM350
 for Glasswasher/Cupwasher (UNIC) A10J - A11J



SOTAL

3012001 SILICONE BUMPER FOR DOOR

for Dishwasher (SO.WE.BO.) 601 - 701
 for Glasswasher/Cupwasher (AFI) A35
 for Glasswasher/Cupwasher (EUROSYSTEM) PRO100
 for Glasswasher/Cupwasher (HILTA) RB10 - SB10
 for Glasswasher/Cupwasher (IME OMNIWASH) JA35
 JA36 - JOLLY - UNO
 for Glasswasher/Cupwasher (NOSEM) C2010L - NC201
 R1010L
 for Glasswasher/Cupwasher (NUOVA SIMONELLI) KIARA1
 for Glasswasher/Cupwasher (SO.WE.BO.) 600 - 631
 661 - 691
 for Glasswasher/Cupwasher (SOTAL) EC195 - ER195
 for Glasswasher/Cupwasher (STORME) SM350
 for Glasswasher/Cupwasher (UNIC) A10J - A11J



SOTAL



Suitable for:

SOTAL



Suitable for:

Hose-end fittings

3391042 HOSE-END FITTING FOR RINSE SHAFT \varnothing 16 mm
 for Dishwasher (AFI) A600
 for Dishwasher (EUROSYSTEM) PRO400
 for Dishwasher (HILTA) S41 - S42
 for Dishwasher (IME OMNIWASH) 4Q82
 for Dishwasher (NOSEM) C5000 - C5010 - C5020
 NC501
 for Dishwasher (SAB ITALIA) C50
 for Dishwasher (SO.WE.BO.) 824
 for Glasswasher/Cupwasher (AFI) A35 - A35Z2 - A36
 for Glasswasher/Cupwasher (EUROSYSTEM) PRO100
 PRO200
 for Glasswasher/Cupwasher (HILTA) RB10 - RB22
 SB10 - SB22
 for Glasswasher/Cupwasher (IME OMNIWASH) DUEAQ
 DUEAT - JA35 - JA36 - JA40 - JA41 - JOLLYQ



SOTAL

3315027 T- HOSE END FITTING



SOTAL

3349601 3-WAY HOSE-END FITTING



SOTAL

3315107 3-WAYS HOSE END RUBBER FITTING \varnothing 12



SOTAL

Lamps

3221127 ORANGE LAMP RECEPTACLE
 head 14x14 mm - hole \varnothing 11 mm
 for 6.2P
 for OEM PIZZA OVEN 4-5-8-10-11-15/DS



SOTAL

3221128 GREEN LAMP RECEPTACLE
 hole \varnothing 11 mm
 head 14x14 mm
 for 6.2P



SOTAL

3221126 INDICATOR LAMP 24V
 head \varnothing 8 mm



SOTAL



Microswitches

3803005 COMPLETE DOOR CONTACT

for Dishwasher (IME OMNIWASH) SEI1PCQ - SEI2CQB
SEI2PCQ
for Dishwasher (NOSEM) K602S
for Dishwasher (SAB ITALIA) K5.2P
for Dishwasher (SOTAL) C13001P - C130024V
for Dishwasher (STORME) L502BT
for Dishwasher (UNIC) A61A - A61B
for Dishwasher hood type (AFI) A1000L
for Dishwasher hood type (EUROSYSTEM) PRO600
for Dishwasher hood type (HILTA) W13 - W14 - W15
for Dishwasher hood type (NOSEM) K601 - K602
for Dishwasher hood type (NUOVA SIMONELLI) LTM1500
LTM1600
for Dishwasher hood type (SAB ITALIA) K5.1P
for Dishwasher hood type (SO.WE.BO.) 6.1P - 6.2P



SOTAL

3803018 ACTUATOR FOR REAR MICRO SWITCH 62P/SPPL



SOTAL

3240129 COMPLETE MICROSWITCH FOR DOOR



SOTAL

1186352 O-RING 02050 EPDM

for Dishwasher (AFI) A600
for Dishwasher (DIHR) C40CF - GASTRO450
GASTRO500 - GASTRO750 - GASTRO900 - GS45
GS50
for Dishwasher (EUROSYSTEM) PRO400
for Dishwasher (FAEMA) 1201
for Dishwasher (HILTA) S41 - S42
for Dishwasher (IME OMNIWASH) 4Q82
for Dishwasher (KROMO) K35 - K37
for Dishwasher (NOSEM) C5000 - C5010 - C5020
NC501
for Dishwasher (NUOVA SIMONELLI) KIARA6
for Dishwasher (OLIS) OLG550 - OLG585
for Dishwasher (SAB ITALIA) C50H - 1200
for Dishwasher (SILANOS) 200 - 300 - 400 - 600



SOTAL



Suitable for:

3186181 O-RING 03068 EPDM

for Dishwasher (SO.WE.BO.) 601 - 701 - 752
for Dishwasher (SOTAL) ER225
for Glasswasher/Cupwasher (AFI) A35 - A35Z2 - A36
for Glasswasher/Cupwasher (COMENDA) - Series B
for Glasswasher/Cupwasher (EUROSYSTEM) PRO100
PRO200
for Glasswasher/Cupwasher (HILTA) RB10 - RB22
SB10 - SB22
for Glasswasher/Cupwasher (IME OMNIWASH) DUE
JA35 - JA36 - JA40 - JA41 - JOLLY - UNO
for Glasswasher/Cupwasher (NOSEM) C2010L - C4010L
NC201 - NR101 - R1010
for Glasswasher/Cupwasher (NUOVA SIMONELLI) KIARA1
KIARA2 - KIARA4
for Glasswasher/Cupwasher (SAB ITALIA) C35 - C36



SOTAL



Suitable for:

SOTAL

Pressure switches

3320075 PRESSURE SWITCH 50/20 mm 250V 16A

1level
max operating temperature 85°C
for Dishwasher (AFI) A600 - A900
for Dishwasher (EUROSYSTEM) PRO400
for Dishwasher (HILTA) S41 - S42 - S49 - S55
for Dishwasher (NOSEM) C5000 - C5010
for Dishwasher (SAB ITALIA) C50H
for Dishwasher hood type (IME OMNIWASH) SEI2P
for Dishwasher hood type (NOSEM) K602
for Dishwasher hood type (SAB ITALIA) K5.2P
for Glasswasher/Cupwasher (AFI) A35 - A35Z2 - A36
for Glasswasher/Cupwasher (EUROSYSTEM) PRO100
PRO200
for Glasswasher/Cupwasher (HILTA) RB10 - RB22
SB10 - SB22



SOTAL



Protection plates

3519014 BLACK FRONT FRAME


for Dishwasher (AFI) A600
 for Dishwasher (EUROSYSTEM) PRO400
 for Dishwasher (HILTA) S41 - S42
 for Dishwasher (NOSEM) C1010 - C5000 - C5010
 C5020 - NC501
 for Dishwasher (SO.WE.BO.) ONE - 701 - 752 - 824
 for Dishwasher (SOTAL) F600
 for Dishwasher (STORME) LT500M
 for Dishwasher (UNIC) A410E
 for Glasswasher/Cupwasher (AFI) A35Z2
 for Glasswasher/Cupwasher (NOSEM) NC201 - NR101
 for Glasswasher/Cupwasher (SO.WE.BO.) 742
 for Glasswasher/Cupwasher (SOTAL) C230



SOTAL

3244008 LIGHT BLUE FRONT FRAME OMNI11

for Dishwasher (AFI) A600
 for Dishwasher (EUROSYSTEM) PRO400
 for Dishwasher (HILTA) S41 - S42
 for Dishwasher (NOSEM) C1010 - C5000 - C5010
 C5020 - NC501
 for Dishwasher (SO.WE.BO.) ONE - 701 - 752 - 824
 for Dishwasher (SOTAL) F600
 for Dishwasher (STORME) LT500M
 for Dishwasher (UNIC) A410E
 for Glasswasher/Cupwasher (AFI) A35Z2
 for Glasswasher/Cupwasher (NOSEM) NC201 - NR101
 for Glasswasher/Cupwasher (SO.WE.BO.) 742
 for Glasswasher/Cupwasher (SOTAL) C230



SOTAL

Pumps

3122740 DRAIN ELECTRO-PUMP 34W 220/240V


inlet external \varnothing 23 mm outlet external \varnothing 31 mm
 for Dishwasher (AFI) A600
 for Dishwasher (IME OMNIWASH) 4Q82
 for Dishwasher (NOSEM) C5000 - C501 - C5010
 for Dishwasher (NUOVA SIMONELLI) KIARA6
 for Dishwasher (SAB ITALIA) C50H
 for Dishwasher (SO.WE.BO.) 824
 for Dishwasher (SOTAL) F600
 for Dishwasher (STORME) LT500
 for Dishwasher (UNIC) A410E



SOTAL

3122432 ELECTRO-PUMP AP 1629030SX 0,30HP 230V

inlet external \varnothing 32 mm - outlet external \varnothing 31 mm
 motor revolutions 2800
 0.30HP 230V 50Hz - capacitor 10 μ f
 for Dishwasher (SO.WE.BO.) 601 - 701
 for Glasswasher/Cupwasher (AFI) A35 - A35Z2 - A36
 for Glasswasher/Cupwasher (EUROSYSTEM) PRO100
 PRO200
 for Glasswasher/Cupwasher (HILTA) RB10 - RB22
 SB10 - SB22
 for Glasswasher/Cupwasher (IME OMNIWASH) JOLLY
 UNOA - UNOQ - UNOT
 for Glasswasher/Cupwasher (NOSEM) C2010L - C4010L
 NR101 - R1010
 for Glasswasher/Cupwasher (NUOVA SIMONELLI) KIARA1
 for Glasswasher/Cupwasher (SAB ITALIA) C35 - C36



SOTAL



Suitable for:

SOTAL



3122434 ELECTRO-PUMP AP 2031SX 1HP 230V 50Hz
 inlet external \varnothing 46 mm - outlet external \varnothing 40 mm
 motor revolutions 2800
 1HP 230V 50Hz - capacitor 12.5 μ f
 for Dishwasher (AFI) A600
 for Dishwasher (IME OMNIWASH) 4Q82
 for Dishwasher hood type (AFI) A1000L
 for Dishwasher hood type (IME OMNIWASH) SEI1P
 SEI2P



SOTAL

3122433 ELECTRO-PUMP AP 32591SX 0.60HP 230V 50Hz
 inlet external \varnothing 30 mm - outlet external \varnothing 30 mm
 motor revolutions 2850
 0.60HP 230V 50Hz - capacitor 12.5 μ F



SOTAL


3122728 ELECTRO-PUMP IME 1HP 230V 50Hz
 inlet external \varnothing 46 mm - outlet external \varnothing 41 mm
 for Dishwasher (SAB ITALIA) K5.2P
 for Dishwasher hood type (EUROSYSTEM) PRO600
 for Dishwasher hood type (HILTA) W14 - W15
 for Dishwasher hood type (IME OMNIWASH) SEI2P
 SEI2PA - SEI2PB
 for Dishwasher hood type (NOSEM) K602
 for Dishwasher hood type (NUOVA SIMONELLI) LTM1600
 for Dishwasher hood type (SO.WE.BO.) 6.2PA - 6.2PB
 for Dishwasher hood type (SOTAL) C1300
 for Dishwasher hood type (STORME) L502



SOTAL

Rinse aid containers and accessories

3066040 COMPLETE RINSE AID CONTAINER
 for Dishwasher (AFI) A600
 for Dishwasher (EUROSYSTEM) PRO400
 for Dishwasher (HILTA) S41 - S42
 for Dishwasher (NOSEM) C1010 - C5000 - C5010
 C5020 - NC501
 for Dishwasher (SO.WE.BO.) ONE - 701 - 752 - 824
 for Dishwasher (SOTAL) F600
 for Dishwasher (STORME) LT500M
 for Dishwasher (UNIC) A410E
 for Glasswasher/Cupwasher (AFI) A35Z2
 for Glasswasher/Cupwasher (NOSEM) NC201 - NR101
 for Glasswasher/Cupwasher (SO.WE.BO.) 742
 for Glasswasher/Cupwasher (SOTAL) C230



SOTAL

3324004 PLUG FOR RINSE AID CONTAINER \varnothing 2x80 mm
 for Dishwasher (AFI) A600
 for Dishwasher (EUROSYSTEM) PRO400
 for Dishwasher (HILTA) S41 - S42
 for Dishwasher (NOSEM) C1010 - C5000 - C5010
 C5020 - NC501
 for Dishwasher (SO.WE.BO.) ONE - 701 - 752 - 824
 for Dishwasher (SOTAL) F600
 for Dishwasher (STORME) LT500M
 for Dishwasher (UNIC) A410E
 for Glasswasher/Cupwasher (AFI) A35Z2
 for Glasswasher/Cupwasher (NOSEM) NC201 - NR101
 for Glasswasher/Cupwasher (SO.WE.BO.) 742
 for Glasswasher/Cupwasher (SOTAL) C230




SOTAL



Suitable for:

3439001 RINSE AID CONTAINER

for Dishwasher (AFI) A600
for Dishwasher (EUROSYSTEM) PRO400
for Dishwasher (HILTA) S41 - S42
for Dishwasher (NOSEM) C1010 - C5000 - C5010
C5020 - NC501
for Dishwasher (SO.WE.BO.) ONE - 701 - 752 - 824
for Dishwasher (SOTAL) F600
for Dishwasher (STORME) LT500M
for Dishwasher (UNIC) A410E
for Glasswasher/Cupwasher (AFI) A35Z2
for Glasswasher/Cupwasher (NOSEM) NC201 - NR101
for Glasswasher/Cupwasher (SO.WE.BO.) 742
for Glasswasher/Cupwasher (SOTAL) C230



SOTAL

SOTAL

Suitable for:



Rinse aid pumps and accessories

3090070 HYDRAULIC RINSE AID INJECTOR IB1

with smooth connecting tube \varnothing 10 mm
flow rate regulator



SOTAL

3090072 INJECTOR NON-RETURN VALVE


for Dishwasher (SO.WE.BO.) NK6.2P - QUATTRO
601CQ - 601CT - 661CQ - 661CT - 824
for Glasswasher/Cupwasher (SO.WE.BO.) 712CQ
712CT



SOTAL

3090073 INJECTOR DIAPHRAGM

for Dishwasher (SO.WE.BO.) NK6.2P - 601CQ - 601CT
661CQ - 661CT - 824
for Glasswasher/Cupwasher (SO.WE.BO.) 712CQ
712CT



SOTAL



Suitable for:

SOTAL

Suitable for:



Sleeves

3248177 DRAIN HOSE FOR TANK

internal \varnothing 38 mm
 overall length 455 mm
 for Dishwasher (AFI) A600
 for Dishwasher (EUROSYSTEM) PRO400
 for Dishwasher (HILTA) S41 - S42
 for Dishwasher (IME OMNIWASH) 4Q82
 for Dishwasher (NOSEM) C5000 - C5010 - C5020
 NC501
 for Dishwasher (NUOVA SIMONELLI) KIARA6
 for Dishwasher (SAB ITALIA) C50H
 for Dishwasher (SO.WE.BO.) 824
 for Dishwasher (SOTAL) F600ECO
 for Dishwasher (STORME) LT500
 for Dishwasher (UNIC) A410E



SOTAL

3349479 DRAIN PUMP INLET HOSE

internal \varnothing 30 and 37 mm
 overall length 160 mm
 for Dishwasher (AFI) A600
 for Dishwasher (EUROSYSTEM) PRO400
 for Dishwasher (HILTA) S41 - S42
 for Dishwasher (IME OMNIWASH) 4Q82
 for Dishwasher (NOSEM) C5000 - C5010 - C5020
 NC501
 for Dishwasher (NUOVA SIMONELLI) KIARA6
 for Dishwasher (SAB ITALIA) C50H
 for Dishwasher (SO.WE.BO.) 824
 for Dishwasher (SOTAL) F600ECO
 for Dishwasher (STORME) LT500
 for Dishwasher (UNIC) A410E



SOTAL

3248171 INLET HOSE

internal \varnothing 43 mm
 overall length 335 mm
 for Dishwasher (IME OMNIWASH) SEI1PCQ - SEI2PCQ
 for Dishwasher (NUOVA SIMONELLI) SEI1PCQ - SEI2PCQ
 for Dishwasher (SAB ITALIA) K5.2P
 for Dishwasher (UNIC) A61A - A61B
 for Dishwasher hood type (AFI) A1000L
 for Dishwasher hood type (EUROSYSTEM) PRO600
 for Dishwasher hood type (HILTA) W13 - W14 - W15
 for Dishwasher hood type (NOSEM) K601 - K602
 for Dishwasher hood type (NUOVA SIMONELLI) LTM1500
 LTM1600
 for Dishwasher hood type (SAB ITALIA) K5.1P
 for Dishwasher hood type (SO.WE.BO.) 6.1P - 6.2P
 6.2PB



SOTAL

3248173 INLET HOSE

internal \varnothing 43 mm
 overall length 485 mm
 for Dishwasher (IME OMNIWASH) SEI1PCQ - SEI2PCQ
 4SA
 for Dishwasher (SAB ITALIA) K5.2P
 for Dishwasher (UNIC) A61A - A61B
 for Dishwasher hood type (AFI) A1000L
 for Dishwasher hood type (EUROSYSTEM) PRO600
 for Dishwasher hood type (HILTA) W13 - W14 - W15
 for Dishwasher hood type (IME OMNIWASH) SEI2P
 for Dishwasher hood type (NOSEM) K601 - K602
 for Dishwasher hood type (NUOVA SIMONELLI) LTM1500
 LTM1600
 for Dishwasher hood type (SAB ITALIA) K5.1P
 for Dishwasher hood type (SO.WE.BO.) 6.1P - 6.2P



SOTAL

3248174 INLET HOSE

internal \varnothing 30 mm - 37 mm
 for Dishwasher (SO.WE.BO.) ONE - 601 - 701 - 752
 for Glasswasher/Cupwasher (AFI) A35 - A35Z2 - A36
 for Glasswasher/Cupwasher (EUROSYSTEM) PRO100
 PRO200
 for Glasswasher/Cupwasher (HILTA) RB10 - RB22
 SB10 - SB22
 for Glasswasher/Cupwasher (IME OMNIWASH)
 Series DUE - JA35 - JA36 - JA40 - JA41
 Series JOLLY - Series UNO
 for Glasswasher/Cupwasher (NOSEM) C2010L - C4010L
 NC201 - NR101 - R1010L
 for Glasswasher/Cupwasher (NUOVA SIMONELLI) KIARA1
 KIARA2 - KIARA4
 for Glasswasher/Cupwasher (SAB ITALIA) C35 - C36



SOTAL

3248023 OUTLET HOSE

internal \varnothing 30 mm
 overall length 200 mm
 for Dishwasher (IME OMNIWASH) CL - CS
 for Dishwasher (SO.WE.BO.) CL - CS - DUE - UNO
 601 - 701 - 752
 for Glasswasher/Cupwasher (AFI) A35 - A35Z2 - A36
 for Glasswasher/Cupwasher (EUROSYSTEM) PRO100
 PRO200
 for Glasswasher/Cupwasher (HILTA) RB10 - RB22
 SB10 - SB22
 for Glasswasher/Cupwasher (IME OMNIWASH) DUE
 JA35 - JA36 - JA40 - JA41 - JOLLY - UNO
 for Glasswasher/Cupwasher (NOSEM) C2010L - C4010L
 NC201 - NR101 - R1010L
 for Glasswasher/Cupwasher (NUOVA SIMONELLI) KIARA1



SOTAL

Suitable for:

3248175 INLET HOSE

internal \varnothing 44 mm
 overall length 280 mm
 for Dishwasher (AFI) A600
 for Dishwasher (EUROSYSTEM) PRO400
 for Dishwasher (HILTA) S41 - S42
 for Dishwasher (IME OMNIWASH) 4Q82
 for Dishwasher (NOSEM) C5000 - C5010 - C5020
 NC501
 for Dishwasher (NUOVA SIMONELLI) KIARA6
 for Dishwasher (SAB ITALIA) C50H
 for Dishwasher (SO.WE.BO.) 824
 for Dishwasher (SOTAL) F600ECO
 for Dishwasher (STORME) LT500
 for Dishwasher (UNIC) A410E



SOTAL

3248045 OUTLET HOSE

\varnothing internal 36 mm
 overall length 320 mm
 for Dishwasher (AFI) A600
 for Dishwasher (EUROSYSTEM) PRO400
 for Dishwasher (HILTA) S41 - S42
 for Dishwasher (IME OMNIWASH) QUATTROBA
 QUATTROQ82 - QUATTROSA - QUATTROT
 for Dishwasher (NOSEM) C5000 - C5010 - C5020
 NC501
 for Dishwasher (NUOVA SIMONELLI) KIARA6
 for Dishwasher (SAB ITALIA) C50H
 for Dishwasher (SO.WE.BO.) 824
 for Dishwasher (SOTAL) F600ECO
 for Dishwasher (STORME) LT500
 for Dishwasher (UNIC) A410E



SOTAL



Suitable for:

SOTAL



3248172 OUTLET HOSE

internal \varnothing 30 and 40 mm
 overall length 490 mm
 for Dishwasher (IME OMNIWASH) SEI1PCQ - SEI2PCQ
 for Dishwasher (SAB ITALIA) K5.2P
 for Dishwasher (UNIC) A61A - A61B
 for Dishwasher hood type (AFI) A1000L
 for Dishwasher hood type (EUROSYSTEM) PRO600
 for Dishwasher hood type (HILTA) W13 - W14 - W15
 for Dishwasher hood type (NOSEM) K601 - K602
 for Dishwasher hood type (NUOVA SIMONELLI) LTM1500
 LTM1600
 for Dishwasher hood type (SAB ITALIA) K5.1P
 for Dishwasher hood type (SO.WE.BO.) 6.1P - 6.2P
 6.2PB
 for Dishwasher hood type (SOTAL) C1300



SOTAL

3349477 PUMP OUTLET HOSE

internal \varnothing 29-40 mm
 overall length 1275 mm
 for Dishwasher (IME OMNIWASH) SEI1PCQ - SEI2PCQ
 for Dishwasher (SAB ITALIA) K5.2P
 for Dishwasher (UNIC) A61A - A61B
 for Dishwasher hood type (AFI) A1000L
 for Dishwasher hood type (EUROSYSTEM) PRO600
 for Dishwasher hood type (HILTA) W13 - W14 - W15
 for Dishwasher hood type (NOSEM) K601 - K602
 for Dishwasher hood type (NUOVA SIMONELLI) LTM1500
 LTM1600
 for Dishwasher hood type (SAB ITALIA) K5.1P
 for Dishwasher hood type (SO.WE.BO.) 6.1P - 6.2P
 6.2PB
 for Dishwasher hood type (SOTAL) C1300



SOTAL

3250211 HOOD LIFTING SPRING 925 mm

for OMNIWASH SEI 1PCQ-2PCQ-2PCQB
 for SIMONELLI LTM1500-LTM1600



SOTAL

3248179 OUTLET HOSE

internal \varnothing 25 mm
 overall length 370 mm
 for Dishwasher (SO.WE.BO.) ONE - 601 - 701 - 752
 for Glasswasher/Cupwasher (AFI) A35 - A35Z2 - A36
 for Glasswasher/Cupwasher (EUROSYSTEM) PRO100
 PRO200
 for Glasswasher/Cupwasher (HILTA) RB10 - RB22
 SB10 - SB22
 for Glasswasher/Cupwasher (IME OMNIWASH)
 Series DUE - Series J - Series JOLLY - Series UNO
 for Glasswasher/Cupwasher (NOSEM) C2010L - C4010L
 NC201 - NR101 - R1010L
 for Glasswasher/Cupwasher (NUOVA SIMONELLI) KIARA1
 KIARA2 - KIARA4
 for Glasswasher/Cupwasher (SAB ITALIA) C35 - C36



SOTAL

3248176 TOP/BOTTOM OUTLET HOSE

internal \varnothing 35 - 37 - 40 mm
 overall length 1400 mm
 for Dishwasher (AFI) A600
 for Dishwasher (EUROSYSTEM) PRO400
 for Dishwasher (HILTA) S41 - S42
 for Dishwasher (IME OMNIWASH) 4Q82
 for Dishwasher (NOSEM) C5000 - C5010 - C5020
 NC501
 for Dishwasher (NUOVA SIMONELLI) KIARA6
 for Dishwasher (SAB ITALIA) C50H
 for Dishwasher (SO.WE.BO.) 824
 for Dishwasher (SOTAL) F600ECO
 for Dishwasher (STORME) LT500
 for Dishwasher (UNIC) A410E



SOTAL

Springs

3318013 SPRING HOOK PULLEY

for OMNIWASH SEI 1PCQ-2PCQ-2PCQB
 for SIMONELLI LTM1500-LTM1600




SOTAL

3053526 STAINLESS STEEL TIE ROD
for OMNIWASH SEI 1PCQ-2PCQ-2PCQB
for SIMONELLI LTM1500-LTM1600



Switches

3319524 ON/OFF SWITCH
with support
for Dishwasher (NOSEM) K602S
for Dishwasher (SAB ITALIA) K5.2P
for Dishwasher hood type (HILTA) W14
for Dishwasher hood type (IME OMNIWASH) SEI2P
for Dishwasher hood type (SO.WE.BO.) 6.2P
for Dishwasher hood type (SOTAL) C1300
for Dishwasher hood type (STORME) L502



3057282 OPEN CONTACT 230V - 6A
for Dishwasher (NOSEM) K602S
for Dishwasher (SAB ITALIA) K5.2P
for Dishwasher (UNIC) A61A
for Dishwasher hood type (HILTA) W14
for Dishwasher hood type (IME OMNIWASH) SEI1P
for Dishwasher hood type (SO.WE.BO.) 6.1P - 6.2PA
for Dishwasher hood type (SOTAL) C1300
for Dishwasher hood type (STORME) L502



3319174 ORANGE BIPOLAR PUSH-BUTTON 16A 250V
mounting hole 30x22 mm
for Dishwasher (AFI) A600
for Dishwasher (EUROSYSTEM) PRO400
for Dishwasher (HILTA) S41 - S42
for Dishwasher (IME OMNIWASH) 4Q82
for Dishwasher (NOSEM) C5000 - C5010 - C5020
NC501
for Dishwasher (NUOVA SIMONELLI) KIARA6
for Dishwasher (SAB ITALIA) C50H
for Dishwasher (SO.WE.BO.) 701 - 752 - 824
for Dishwasher (SOTAL) F600ECO
for Dishwasher (STORME) LT500M - LT500T
for Dishwasher (UNIC) A410E
for Glasswasher/Cupwasher (AFI) A35Z2
for Glasswasher/Cupwasher (NOSEM) NC201 - NR101






Suitable for:

SOTAL



3319523 SWITCH 3 POSITIONS

with support
 for Dishwasher (NOSEM) K6025
 for Dishwasher (SAB ITALIA) K5.2P
 for Dishwasher (SOTAL) CI300
 for Dishwasher (UNIC) A61A
 for Dishwasher hood type (HILTA) W14
 for Dishwasher hood type (IME OMNIWASH) SEI2P
 for Dishwasher hood type (NOSEM) K602
 for Dishwasher hood type (SO.WE.BO.) 6.1P - 6.2PA
 for Dishwasher hood type (STORME) L502




SOTAL LF-3057292

SOTAL

3454040 NORMALLY CLOSED CONTACT 12A 400V

for Dishwasher hood type (AFI) A1000L
 for Dishwasher hood type (EUROSYSTEM) PRO600
 for Dishwasher hood type (HILTA) W13 - W14 - W15
 for Dishwasher hood type (IME OMNIWASH) SEI1P SEI2P
 for Dishwasher hood type (NOSEM) K601 - K602
 for Dishwasher hood type (NUOVA SIMONELLI) LTM1500 LTM1600
 for Dishwasher hood type (SAB ITALIA) K5.1P
 for Dishwasher hood type (SO.WE.BO.) 6.1P - 6.2P 6.2PB
 for Dishwasher hood type (SOTAL) C1300
 for Dishwasher hood type (STORME) L501 - L502
 for Dishwasher hood type (UNIC) A61




SOTAL

Thermostats

3744070 SAFETY THERMOSTAT FOR TANK 85°C

4 contacts 16A 250V
 for Dishwasher hood type (AFI) A1000L
 for Dishwasher hood type (EUROSYSTEM) PRO600
 for Dishwasher hood type (HILTA) W13 - W15
 for Dishwasher hood type (IME OMNIWASH) SEI2P SEI2PS
 for Dishwasher hood type (NOSEM) K601 - K602
 for Dishwasher hood type (NUOVA SIMONELLI) LTM1500 LTM1600
 for Dishwasher hood type (SAB ITALIA) K5.1P
 for Dishwasher hood type (SO.WE.BO.) 6.1P - 6.2P
 for Dishwasher hood type (SOTAL) C1300
 for Dishwasher hood type (STORME) L501 - L502
 for Dishwasher hood type (UNIC) A61




SOTAL



Timers

3446200 PROGRAMMER P26 2 CAMS


cycle 120 seconds, 230V 50Hz, without pin
for DRAIN PUMP
for Dishwasher (EUROSYSTEM) PRO400
for Dishwasher (HILTA) S41 - S42
for Dishwasher (IME OMNIWASH) 4Q82
for Dishwasher (NOSEM) C5000 - C5010 - C5020
NC501
for Dishwasher (NUOVA SIMONELLI) KIARA 6CF
for Dishwasher (SAB ITALIA) C50H
for Dishwasher (SO.WE.BO.) 824
for Dishwasher (SOTAL) F600ECO
for Dishwasher (STORME) LT5 - LT500M
for Glasswasher/Cupwasher (AFI) A35Z2



SOTAL

3322261 PROGRAMMER P265 3 CAMS


cycle 4 minutes
230V 50/60Hz
counter-clockwise rotation
D-shaped pin \varnothing 6x4.6 mm
for Dishwasher (NUOVA SIMONELLI) KIARA6CF
for Dishwasher (SAB ITALIA) C50H
for Dishwasher (SO.WE.BO.) 1342 - 701 - 752 - 824
for Dishwasher (STORME) LT500T
for Glasswasher/Cupwasher (AFI) A35Z2
for Glasswasher/Cupwasher (IME OMNIWASH) DUE - UNO
for Glasswasher/Cupwasher (SOTAL) C230



SOTAL

3322260 PROGRAMMER 7805DV 5 CAMS

50Hz - without pin
1° cycle 6" - 2° cycle 180"
for Dishwasher (IME OMNIWASH) GL1040 - GL1240
SEI1PCQ
for Dishwasher (SAB ITALIA) K1.5P
for Dishwasher (UNIC) A61A
for Dishwasher hood type (AFI) A1000L
for Dishwasher hood type (HILTA) W13
for Dishwasher hood type (NOSEM) K601
for Dishwasher hood type (NUOVA SIMONELLI) LTM1500
for Dishwasher hood type (SO.WE.BO.) 6.1P
for Dishwasher hood type (STORME) L501



SOTAL

3446199 PROGRAMMER 7805DV 5 CAMS

1° cycle 6 seconds - 2° cycle 135 seconds
230V 50Hz
for Dishwasher (IME OMNIWASH) 6.2PS
for Dishwasher (NOSEM) K602S
for Dishwasher (SAB ITALIA) K5.2P
for Dishwasher (UNIC) A61A
for Dishwasher hood type (HILTA) W14
for Dishwasher hood type (SO.WE.BO.) 6.2P
for Dishwasher hood type (SOTAL) C1300
for Dishwasher hood type (STORME) L502



SOTAL



Suitable for:


SOTAL



Suitable for:

3322225 TIMER P25 230V 3 CAMS

cycle 120 seconds
 230V 50/60HZ
 without shaft
 for Dishwasher (NOSEM) R101L
 for Dishwasher (NUOVA SIMONELLI) KIARA4CF
 KIARA4CG
 for Glasswasher/Cupwasher (EUROSYSTEM) PRO200
 for Glasswasher/Cupwasher (HILTA) RB22 - SB22
 for Glasswasher/Cupwasher (IME OMNIWASH) DUE - UNO
 for Glasswasher/Cupwasher (NOSEM) C4010L
 for Glasswasher/Cupwasher (SO.WE.BO.) 712
 for Glasswasher/Cupwasher (STORME) ME400
 for Glasswasher/Cupwasher (UNIC) A20 - A21




SOTAL

Wash and rinse arms and accessories

3743265 BOTTOM RING NUT

for Dishwasher (NOSEM) K602S
 for Dishwasher (SAB ITALIA) K5.2P
 for Dishwasher (SOTAL) C13001P
 for Dishwasher (STORME) L502BT
 for Dishwasher (UNIC) A61A - A61B
 for Dishwasher hood type (AFI) A1000L
 for Dishwasher hood type (EUROSYSTEM) PRO600
 for Dishwasher hood type (HILTA) W13 - W14 - W15
 for Dishwasher hood type (IME OMNIWASH) SEI1P
 SEI2P
 for Dishwasher hood type (NOSEM) K601 - K602
 for Dishwasher hood type (NUOVA SIMONELLI) LTM1500
 LTM1600
 for Dishwasher hood type (SAB ITALIA) K5.1P
 for Dishwasher hood type (SO.WE.BO.) 6.1P - 6.2P



SOTAL

3743200 COMPLETE LOWER HUB SUPPORT

for Dishwasher (AFI) A600 - A900
 for Dishwasher (EUROSYSTEM) PRO400
 for Dishwasher (HILTA) S41 - S42
 for Dishwasher (IME OMNIWASH) QUATTROQ - TREQ
 4Q82
 for Dishwasher (NOSEM) C5000 - C5010 - C5020
 K602S - NC501
 for Dishwasher (SAB ITALIA) C50H - K5.2P
 for Dishwasher (SOTAL) C130001P
 for Dishwasher hood type (AFI) A1000L
 for Dishwasher hood type (HILTA) W13 - W14 - W15
 for Dishwasher hood type (IME OMNIWASH) SEI1P
 SEI2P
 for Dishwasher hood type (NOSEM) K601 - K602
 for Dishwasher hood type (SAB ITALIA) K5.1P



SOTAL

3743054 COMPLETE WATER INLET FITTING

for Dishwasher (AFI) A600
 for Dishwasher (EUROSYSTEM) PRO400
 for Dishwasher (HILTA) S41 - S42
 for Dishwasher (IME OMNIWASH) 4Q82
 for Dishwasher (NOSEM) C5000 - C5010 - C5020
 NC501
 for Dishwasher (NUOVA SIMONELLI) KIARA6
 for Dishwasher (SAB ITALIA) C50H
 for Dishwasher (SO.WE.BO.) 824
 for Dishwasher (SOTAL) F600
 for Dishwasher (STORME) LT500
 for Dishwasher (UNIC) A410E
 for Glasswasher/Cupwasher (SO.WE.BO.) ONECQ
 ONECT



SOTAL

3243527 LOWER SUPPORT SHORT MODEL


for Dishwasher (SO.WE.BO.) 601 - 701 - 752
 for Glasswasher/Cupwasher (AFI) A35 - A35Z2 - A36
 for Glasswasher/Cupwasher (EUROSYSTEM) PRO100
 PRO200
 for Glasswasher/Cupwasher (HILTA) RB10 - RB22
 SB10 - SB22
 for Glasswasher/Cupwasher (IME OMNIWASH) DUEAQ
 DUECL - DUECS - JA35 - JA36 - JA40 - JA41
 JOLLYQ - JOLLYT - UNO AQ - UNOCL - UNOCS - UNOQ
 for Glasswasher/Cupwasher (NOSEM) C2010L - C4010L
 NC201 - NR101 - R1010
 for Glasswasher/Cupwasher (NUOVA SIMONELLI) KIARA1
 KIARA2 - KIARA4
 for Glasswasher/Cupwasher (SAB ITALIA) C35 - C36
 for Glasswasher/Cupwasher (SO.WE.BO.) 600 - 631



SOTAL

3243526 LOWER RINSE SUPPORT


for Dishwasher (AFI) A600
 for Dishwasher (EUROSYSTEM) PRO400
 for Dishwasher (HILTA) S41 - S42
 for Dishwasher (IME OMNIWASH) 4Q82
 for Dishwasher (NOSEM) C5000 - C5010 - C5020
 NC501
 for Dishwasher (NUOVA SIMONELLI) KIARA6
 for Dishwasher (SAB ITALIA) C50H
 for Dishwasher (SO.WE.BO.) 824
 for Dishwasher (SOTAL) F600
 for Dishwasher (STORME) LT500
 for Dishwasher (UNIC) A410E
 for Glasswasher/Cupwasher (NOSEM) NR101
 for Glasswasher/Cupwasher (SO.WE.BO.) ONECQ
 ONECT



SOTAL

3743056 RINSE CONNECTION

for Dishwasher (SO.WE.BO.) 601
 for Glasswasher/Cupwasher (IME OMNIWASH) JOLLYA
 JOLLYQ
 for Glasswasher/Cupwasher (SO.WE.BO.) 600 - 631
 661 - 691



SOTAL




Suitable for:

SOTAL



3743602 LOWER/UPPER WASH ARM

length 200 mm with jets
 for Dishwasher (SO.WE.BO.) 601 - 701 - 752
 for Glasswasher/Cupwasher (AFI) A35 - A35Z2 - A36
 for Glasswasher/Cupwasher (EUROSYSTEM) PRO100
 PRO200
 for Glasswasher/Cupwasher (HILTA) RB10 - RB22
 SB10 - SB22
 for Glasswasher/Cupwasher (IME OMNIWASH) DUEAQ
 JA35 - JA36 - JA40 - JA41 - JOLLYAQ - JOLLYQ
 UNOAQ - UNOQ
 for Glasswasher/Cupwasher (NOSEM) C2010L - C4010L
 NC201 - NR101 - R1010
 for Glasswasher/Cupwasher (NUOVA SIMONELLI) KIARA1
 KIARA2 - KIARA4
 for Glasswasher/Cupwasher (SAB ITALIA) C35 - C36



SOTAL

3743267 RINSE ARM CAP

for Dishwasher (AFI) A600
 for Dishwasher (EUROSYSTEM) PRO400
 for Dishwasher (HILTA) S41 - S42
 for Dishwasher (IME OMNIWASH) 4Q82
 for Dishwasher (NOSEM) C5000 - C5010 - C5020
 NC501
 for Dishwasher (SAB ITALIA) C50H
 for Glasswasher/Cupwasher (AFI) A35 - A35Z2 - A36
 for Glasswasher/Cupwasher (EUROSYSTEM) PRO100
 PRO200
 for Glasswasher/Cupwasher (HILTA) RB10 - RB22
 SB10 - SB22
 for Glasswasher/Cupwasher (IME OMNIWASH) DUEAQ
 JOLLYAQ - JOLLYQ - UNOAQ - UNOQ
 for Glasswasher/Cupwasher (NOSEM) C2010L - C4010L



SOTAL

3743510 LOWER/UPPER WASH ARM

length 200 mm
 for Glasswasher/Cupwasher (AFI) A35 - A35Z2 - A36
 for Glasswasher/Cupwasher (EUROSYSTEM) PRO100
 PRO200
 for Glasswasher/Cupwasher (HILTA) RB10 - RB22
 SB10 - SB22
 for Glasswasher/Cupwasher (IME OMNIWASH) DUEAT
 JA35 - JA36 - JA40 - JA41 - JOLLYAT - JOLLYT
 UNOAT - UNOT
 for Glasswasher/Cupwasher (NOSEM) C2010L - C4010L
 NC201 - NR101 - R1010
 for Glasswasher/Cupwasher (NUOVA SIMONELLI) KIARA1
 KIARA2 - KIARA4
 for Glasswasher/Cupwasher (SAB ITALIA) C35 - C36



SOTAL

3743624 RINSE ARM WITH NOZZLES AND RING NUTS

for Dishwasher (SO.WE.BO.) 601 - 701 - 752
 for Glasswasher/Cupwasher (AFI) A35 - A35Z2 - A36
 for Glasswasher/Cupwasher (EUROSYSTEM) PRO100
 PRO200
 for Glasswasher/Cupwasher (HILTA) RB10 - RB22
 SB10 - SB22
 for Glasswasher/Cupwasher (IME OMNIWASH) DUEAQ
 JA35 - JA36 - JA40 - JA41 - JOLLYAQ - JOLLYQ
 UNOAQ - UNOQ
 for Glasswasher/Cupwasher (NOSEM) C2010L - C4010L
 NC201 - NR101 - R1010
 for Glasswasher/Cupwasher (NUOVA SIMONELLI) KIARA1
 KIARA2 - KIARA4
 for Glasswasher/Cupwasher (SAB ITALIA) C35 - C36
 for Glasswasher/Cupwasher (SO.WE.BO.) 600 - 631



SOTAL

3743565 RINSE ROD SUPPORT EXTENSION OT

for Dishwasher (AFI) A600
 for Dishwasher (EUROSYSTEM) PRO400
 for Dishwasher (HILTA) S41 - S42
 for Dishwasher (IME OMNIWASH) 4Q82
 for Dishwasher (NOSEM) C5000 - C5010 - C5020
 NC501
 for Dishwasher (SAB ITALIA) C50H
 for Glasswasher/Cupwasher (AFI) A35 - A35Z2 - A36
 for Glasswasher/Cupwasher (EUROSYSTEM) PRO100
 PRO200
 for Glasswasher/Cupwasher (HILTA) RB10 - RB22
 SB10 - SB22
 for Glasswasher/Cupwasher (IME OMNIWASH) DUEAT
 JA35 - JA36 - JA40 - JA41 - JOLLYAT - JOLLYT
 UNOAT - UNOT



SOTAL

3743059 RINSE SHAFT SUPPORT

for Dishwasher (AFI) A600
 for Dishwasher (EUROSYSTEM) PRO400
 for Dishwasher (HILTA) S41 - S42
 for Dishwasher (IME OMNIWASH) 4Q82E
 for Dishwasher (NOSEM) C5000 - C5010 - C5020
 NC501
 for Dishwasher (NUOVA SIMONELLI) KIARA6
 for Dishwasher (SAB ITALIA) C50H
 for Dishwasher (SO.WE.BO.) 601 - 701 - 752 - 824
 for Dishwasher (SOTAL) F600ECO
 for Dishwasher (STORME) LT500
 for Dishwasher (UNIC) A410E
 for Glasswasher/Cupwasher (AFI) A35 - A35Z2 - A36
 for Glasswasher/Cupwasher (EUROSYSTEM) PRO100
 PRO200



SOTAL

3243529 SPINDLE EXTENSION


for Dishwasher (SO.WE.BO.) 601 - 701 - 752
 for Glasswasher/Cupwasher (AFI) A35 - A35Z2 - A36
 for Glasswasher/Cupwasher (EUROSYSTEM) PRO100
 PRO200
 for Glasswasher/Cupwasher (HILTA) RB10 - RB22
 SB10 - SB22
 for Glasswasher/Cupwasher (IME OMNIWASH) DUEAQ
 JA35 - JA36 - JA40 - JA41 - JOLLYQ - JOLLYT
 UNOAQ - UNOQ
 for Glasswasher/Cupwasher (NOSEM) C2010L - C4010L
 NC201 - NR101 - R1010
 for Glasswasher/Cupwasher (NUOVA SIMONELLI) KIARA1
 KIARA2 - KIARA4
 for Glasswasher/Cupwasher (SAB ITALIA) C35 - C36
 for Glasswasher/Cupwasher (SO.WE.BO.) 600 - 631



SOTAL

3743269 TOP RINSE ARM FITTING

for Dishwasher hood type (IME OMNIWASH) SEI1P
 SEI2P



SOTAL

3743603 UPPER WASH ARM

height 145 mm - length 235 mm
 for Glasswasher/Cupwasher (IME OMNIWASH) DUEAT



SOTAL



Suitable for:

SOTAL



Suitable for:

3243533 UPPER WASH ARM ASSEMBLY SUPPORT


for Dishwasher (AFI) A600
 for Dishwasher (EUROSYSTEM) PRO400
 for Dishwasher (HILTA) S41 - S42
 for Dishwasher (IME OMNIWASH) 4Q82
 for Dishwasher (NOSEM) C5000 - C5010 - C5020
 NC501
 for Dishwasher (NUOVA SIMONELLI) KIARA6
 for Dishwasher (SAB ITALIA) C50H
 for Dishwasher (SO.WE.BO.) 824
 for Dishwasher (SOTAL) F600
 for Dishwasher (STORME) LT500
 for Dishwasher (UNIC) A410E
 for Glasswasher/Cupwasher (NOSEM) NR101
 for Glasswasher/Cupwasher (SO.WE.BO.) ONECQ
 ONECT



SOTAL

3243514 UPPER RING NUT \varnothing 110 mm

for Dishwasher (AFI) A600
 for Dishwasher (EUROSYSTEM) PRO400
 for Dishwasher (HILTA) C5000 - C5010 - C5020
 NC501 - S41 - S42
 for Dishwasher (IME OMNIWASH) 4Q82
 for Dishwasher (NUOVA SIMONELLI) KIARA6
 for Dishwasher (SAB ITALIA) C50H
 for Dishwasher (SO.WE.BO.) 824
 for Dishwasher (SOTAL) F600
 for Dishwasher (STORME) LT500
 for Dishwasher (UNIC) A410E
 for Glasswasher/Cupwasher (NOSEM) NR101
 for Glasswasher/Cupwasher (SO.WE.BO.) ONECQ
 ONECT



SOTAL

3243515 CORK GASKET \varnothing 85 mm

for Dishwasher (AFI) A600
 for Dishwasher (EUROSYSTEM) PRO400
 for Dishwasher (HILTA) S41 - S42
 for Dishwasher (IME OMNIWASH) 4Q82
 for Dishwasher (NOSEM) C5000 - C5010 - C5020
 NC501
 for Dishwasher (NUOVA SIMONELLI) KIARA6
 for Dishwasher (SAB ITALIA) C50H
 for Dishwasher (SO.WE.BO.) 824
 for Dishwasher (SOTAL) F600
 for Dishwasher (STORME) LT500
 for Dishwasher (UNIC) A410E
 for Glasswasher/Cupwasher (NOSEM) NR101
 for Glasswasher/Cupwasher (SO.WE.BO.) ONECQ
 ONECT



SOTAL

3243486 WASH AND RINSE ARM ASSEMBLY

length 500 mm
 for Dishwasher (AFI) A600
 for Dishwasher (EUROSYSTEM) PRO400
 for Dishwasher (HILTA) S41 - S42
 for Dishwasher (IME OMNIWASH) 4Q82
 for Dishwasher (NOSEM) C5000 - C5010 - C5020
 NC501
 for Dishwasher (NUOVA SIMONELLI) KIARA6
 for Dishwasher (SAB ITALIA) C50H
 for Dishwasher (SO.WE.BO.) 824
 for Dishwasher (SOTAL) F600
 for Dishwasher (STORME) LT500
 for Dishwasher (UNIC) A410E
 for Glasswasher/Cupwasher (NOSEM) NR101
 for Glasswasher/Cupwasher (SO.WE.BO.) ONECQ



SOTAL

3743562 WASH ARM CT MOD.2/4 WHITE

for Dishwasher (AFI) A600
 for Dishwasher (EUROSYSTEM) PRO400
 for Dishwasher (HILTA) S41 - S42
 for Dishwasher (IME OMNIWASH) 4Q82
 for Dishwasher (NOSEM) C5000 - C5010 - C5020
 NC501
 for Dishwasher (NUOVA SIMONELLI) KIARA6
 for Dishwasher (SAB ITALIA) C50H
 for Dishwasher (SO.WE.BO.) 824
 for Dishwasher (SOTAL) F600ECO
 for Dishwasher (STORME) LT500
 for Dishwasher (UNIC) A410E



SOTAL

3743322

WASH ARM ASSEMBLY 310 mm

for Dishwasher (SO.WE.BO.) 601 - 701 - 752
 for Glasswasher/Cupwasher (AFI) A35 - A35Z2 - A36
 for Glasswasher/Cupwasher (EUROSYSTEM) PRO100
 PRO200
 for Glasswasher/Cupwasher (HILTA) RB10 - RB22
 SB10 - SB22
 for Glasswasher/Cupwasher (IME OMNIWASH) JA35
 JA350 - JA36 - JA360 - JOLLYAQ - JOLLYQ - J35
 J350 - J36 - J360
 for Glasswasher/Cupwasher (NOSEM) C2010L - C4010L
 NC201 - NR101 - R1010
 for Glasswasher/Cupwasher (NUOVA SIMONELLI) KIARA1
 KIARA2 - KIARA4
 for Glasswasher/Cupwasher (SAB ITALIA) C35 - C36
 for Glasswasher/Cupwasher (SO.WE.BO.) 600 - 631



SOTAL

3743264

WASH ARM 200 mm

for Dishwasher (SO.WE.BO.) 601 - 701 - 752
 for Glasswasher/Cupwasher (AFI) A35 - A35Z2 - A36
 for Glasswasher/Cupwasher (EUROSYSTEM) PRO100
 PRO200
 for Glasswasher/Cupwasher (HILTA) RB10 - RB22
 SB10 - SB22
 for Glasswasher/Cupwasher (IME OMNIWASH) JA35
 JA350 - JA36 - JA360 - JOLLYAQ - JOLLYQ - J35
 J350 - J36 - J360
 for Glasswasher/Cupwasher (NOSEM) C2010L - C4010L
 NC201 - NR101 - R1010
 for Glasswasher/Cupwasher (NUOVA SIMONELLI) KIARA1
 KIARA2 - KIARA4
 for Glasswasher/Cupwasher (SAB ITALIA) C35 - C36
 for Glasswasher/Cupwasher (SO.WE.BO.) 600 - 631



SOTAL



Suitable for:

SOTAL



3743576 WASH ARM 4CT MOULD 24

for Dishwasher (AFI) A600
for Dishwasher (EUROSYSTEM) PRO400
for Dishwasher (HILTA) S41 - S42
for Dishwasher (IME OMNIWASH) 4Q82
for Dishwasher (NOSEM) C5000 - C5010 - C5020
NC501
for Dishwasher (NUOVA SIMONELLI) KIARA6
for Dishwasher (SAB ITALIA) C50H
for Dishwasher (SO.WE.BO.) 824
for Dishwasher (SOTAL) 600ECO
for Dishwasher (STORME) LT500
for Dishwasher (UNIC) A410E



SOTAL

3743055 WASH COLUMN 380 mm

for Dishwasher (SO.WE.BO.) 601 - 701 - 752
for Glasswasher/Cupwasher (AFI) A35 - A35Z2 - A36
for Glasswasher/Cupwasher (EUROSYSTEM) PRO100
PRO200
for Glasswasher/Cupwasher (HILTA) RB10 - RB22
SB10 - SB22
for Glasswasher/Cupwasher (IME OMNIWASH) DUEAQ
DUEAT - JA35 - JA36 - JA40 - JA41 - JOLLYQ
JOLLYT - UNOQ - UNOT
for Glasswasher/Cupwasher (NOSEM) C2010L - C4010L
NC201 - NR101 - R1010
for Glasswasher/Cupwasher (NUOVA SIMONELLI) KIARA1
KIARA2 - KIARA4
for Glasswasher/Cupwasher (SAB ITALIA) C35 - C36
for Glasswasher/Cupwasher (SO.WE.BO.) 600 - 631



SOTAL

Suitable for:

3743568 WASH COLUMN EXTENSION

for Dishwasher (SO.WE.BO.) 601 - 701 - 752
for Glasswasher/Cupwasher (AFI) A35 - A35Z2 - A36
for Glasswasher/Cupwasher (EUROSYSTEM) PRO100
PRO200
for Glasswasher/Cupwasher (HILTA) RB10 - RB22
SB10 - SB22
for Glasswasher/Cupwasher (IME OMNIWASH) DUEAT
JA35 - JA36 - JA40 - JA41 - JOLLYAT - JOLLYT
UNOAT - UNOT
for Glasswasher/Cupwasher (NOSEM) C2010L - C4010L
NC201 - NR101 - R1010
for Glasswasher/Cupwasher (NUOVA SIMONELLI) KIARA1
KIARA2 - KIARA4
for Glasswasher/Cupwasher (SAB ITALIA) C35 - C36
for Glasswasher/Cupwasher (SO.WE.BO.) 600 - 631



SOTAL

3743524 WASH ARM EXTENSION

for Dishwasher (SO.WE.BO.) 601 - 701 - 752
for Glasswasher/Cupwasher (AFI) A35 - A35Z2 - A36
for Glasswasher/Cupwasher (EUROSYSTEM) PRO100
PRO200
for Glasswasher/Cupwasher (HILTA) RB10 - RB22
SB10 - SB22
for Glasswasher/Cupwasher (IME OMNIWASH) DUEAT
JA40 - JA41 - JOLLYAT - JOLLYT - UNOAT - UNOT
for Glasswasher/Cupwasher (NOSEM) C2010L - C4010L
NC201 - NR101 - R1010
for Glasswasher/Cupwasher (NUOVA SIMONELLI) KIARA1
KIARA2 - KIARA4
for Glasswasher/Cupwasher (SAB ITALIA) C35 - C36
for Glasswasher/Cupwasher (SO.WE.BO.) 600 - 631
661 - 691 - 712 - 742



SOTAL

3743057 WATER INLET SUPPORT

for Dishwasher (SO.WE.BO.) 601 - 701 - 752
 for Glasswasher/Cupwasher (AFI) A35 - A35Z2 - A36
 for Glasswasher/Cupwasher (EUROSYSTEM) PRO100
 PRO200
 for Glasswasher/Cupwasher (HILTA) RB10 - RB22
 SB10 - SB22
 for Glasswasher/Cupwasher (IME OMNIWASH) DUEAQ
 DUEAT - JA35 - JA36 - JA40 - JA41 - JOLLYQ
 JOLLYT - UNOQ - UNOT
 for Glasswasher/Cupwasher (NOSEM) C2010L - C4010L
 NC201 - NR101 - R1010
 for Glasswasher/Cupwasher (NUOVA SIMONELLI) KIARA1
 KIARA2 - KIARA4
 for Glasswasher/Cupwasher (SAB ITALIA) C35 - C36
 for Glasswasher/Cupwasher (SO.WE.BO.) 600 - 631



SOTAL

3186847 OR GASKET 03131 EPDM

for Dishwasher (SO.WE.BO.) 601 - 701 - 752
 for Glasswasher/Cupwasher (AFI) A35 - A35Z2 - A36
 for Glasswasher/Cupwasher (EUROSYSTEM) PRO100
 PRO200
 for Glasswasher/Cupwasher (HILTA) RB10 - RB22
 SB10 - SB22
 for Glasswasher/Cupwasher (IME OMNIWASH) DUECL
 DUECS - JA35 - JA36 - JA40 - JA41 - JOLLY
 UNOCL - UNOCS
 for Glasswasher/Cupwasher (NOSEM) C2010L - C4010L
 NC201 - NR101 - R1010
 for Glasswasher/Cupwasher (NUOVA SIMONELLI) KIARA1
 KIARA2 - KIARA4
 for Glasswasher/Cupwasher (SAB ITALIA) C35 - C36
 for Glasswasher/Cupwasher (SO.WE.BO.) 600 - 631



SOTAL

3743058 GAS NUT \varnothing 1"

for Dishwasher (SO.WE.BO.) 601 - 701 - 752
 for Glasswasher/Cupwasher (AFI) A35 - A35Z2 - A36
 for Glasswasher/Cupwasher (EUROSYSTEM) PRO100
 PRO200
 for Glasswasher/Cupwasher (HILTA) RB10 - RB22
 SB10 - SB22
 for Glasswasher/Cupwasher (IME OMNIWASH) DUEAQ
 DUEAT - JA35 - JA36 - JA40 - JA41 - JOLLYQ
 JOLLYT - UNOQ - UNOT
 for Glasswasher/Cupwasher (NOSEM) C2010L - C4010L
 NC201 - NR101 - R1010
 for Glasswasher/Cupwasher (NUOVA SIMONELLI) KIARA1
 KIARA2 - KIARA4
 for Glasswasher/Cupwasher (SAB ITALIA) C35 - C36
 for Glasswasher/Cupwasher (SO.WE.BO.) 600 - 631



SOTAL



Suitable for:


SOTAL



Suitable for:

Washing baskets and accessories

3055691 ROUND RACK SUPPORT \varnothing 280 mm
 for Dishwasher (AFI) A600 - A900
 for Dishwasher (EUROSYSTEM) PRO400
 for Dishwasher (HILTA) S41 - S42
 for Dishwasher (NOSEM) C2050 - C5000 - C5010 NC501
 for Dishwasher hood type (AFI) A1000L
 for Dishwasher hood type (EUROSYSTEM) PRO600
 for Dishwasher hood type (HILTA) W13 - W14 - W15
 for Dishwasher hood type (NOSEM) K601 - K602
 for Glasswasher/Cupwasher (AFI) A35 - A35Z2 - A36
 for Glasswasher/Cupwasher (EUROSYSTEM) PRO100 PRO200
 for Glasswasher/Cupwasher (HILTA) RB10 - RB22 SB10 - SB22
 for Glasswasher/Cupwasher (NOSEM) C2010L - C4010L




SOTAL

3324007 ROTATING SUPPORT PIN CT WITH BALL 1-2
 for Dishwasher (AFI) A600 - A900
 for Dishwasher (EUROSYSTEM) PRO400
 for Dishwasher (HILTA) S41 - S42
 for Dishwasher (NOSEM) C2050 - C5000 - C5010 NC501
 for Dishwasher hood type (AFI) A1000L
 for Dishwasher hood type (EUROSYSTEM) PRO600
 for Dishwasher hood type (HILTA) W13 - W14 - W15
 for Dishwasher hood type (NOSEM) K601 - K602
 for Glasswasher/Cupwasher (AFI) A35 - A35Z2 - A36
 for Glasswasher/Cupwasher (EUROSYSTEM) PRO100 PRO200
 for Glasswasher/Cupwasher (HILTA) RB10 - RB22 SB10 - SB22
 for Glasswasher/Cupwasher (NOSEM) C2010L - C4010L



SOTAL

3528051 BASKET SUPPORT NUT
 for Dishwasher (AFI) A600 - A900
 for Dishwasher (EUROSYSTEM) PRO400
 for Dishwasher (HILTA) S41 - S42
 for Dishwasher (NOSEM) C2050 - C5000 - C5010 NC501
 for Dishwasher hood type (AFI) A1000L
 for Dishwasher hood type (EUROSYSTEM) PRO600
 for Dishwasher hood type (HILTA) W13 - W14 - W15
 for Dishwasher hood type (NOSEM) K601 - K602
 for Glasswasher/Cupwasher (AFI) A35 - A35Z2 - A36
 for Glasswasher/Cupwasher (EUROSYSTEM) PRO100 PRO200
 for Glasswasher/Cupwasher (HILTA) RB10 - RB22 SB10 - SB22
 for Glasswasher/Cupwasher (NOSEM) C2010L - C4010L



SOTAL

3055668 ROTATING SUPPORT SHAFT SPACER 1-2
 for Dishwasher (AFI) A600 - A900
 for Dishwasher (EUROSYSTEM) PRO400
 for Dishwasher (HILTA) S41 - S42
 for Dishwasher (NOSEM) C2050 - C5000 - C5010 NC501
 for Dishwasher hood type (AFI) A1000L
 for Dishwasher hood type (EUROSYSTEM) PRO600
 for Dishwasher hood type (HILTA) W13 - W14 - W15
 for Dishwasher hood type (NOSEM) K601 - K602
 for Glasswasher/Cupwasher (AFI) A35 - A35Z2 - A36
 for Glasswasher/Cupwasher (EUROSYSTEM) PRO100 PRO200
 for Glasswasher/Cupwasher (HILTA) RB10 - RB22 SB10 - SB22
 for Glasswasher/Cupwasher (NOSEM) C2010L - C4010L



SOTAL



Suitable for:

3241838 S/STEEL TURNTABLE DISK 1-2

for Dishwasher (AFI) A600 - A900
for Dishwasher (EUROSYSTEM) PRO400
for Dishwasher (HILTA) S41 - S42
for Dishwasher (NOSEM) C2050 - C5000 - C5010
NC501
for Dishwasher hood type (AFI) A1000L
for Dishwasher hood type (EUROSYSTEM) PRO600
for Dishwasher hood type (HILTA) W13 - W14 - W15
for Dishwasher hood type (NOSEM) K601 - K602
for Glasswasher/Cupwasher (AFI) A35 - A35Z2 - A36
for Glasswasher/Cupwasher (EUROSYSTEM) PRO100
PRO200
for Glasswasher/Cupwasher (HILTA) RB10 - RB22
SB10 - SB22
for Glasswasher/Cupwasher (NOSEM) C2010L - C4010L



SOTAL

SOTAL

Suitable for:

3250227

SEEGER FOR ROTATING SUPPORT SHAFT

for Dishwasher (AFI) A600 - A900
for Dishwasher (EUROSYSTEM) PRO400
for Dishwasher (HILTA) S41 - S42
for Dishwasher (NOSEM) C2050 - C5000 - C5010
NC501
for Dishwasher hood type (AFI) A1000L
for Dishwasher hood type (EUROSYSTEM) PRO600
for Dishwasher hood type (HILTA) W13 - W14 - W15
for Dishwasher hood type (NOSEM) K601 - K602
for Glasswasher/Cupwasher (AFI) A35 - A35Z2 - A36
for Glasswasher/Cupwasher (EUROSYSTEM) PRO100
PRO200
for Glasswasher/Cupwasher (HILTA) RB10 - RB22
SB10 - SB22
for Glasswasher/Cupwasher (NOSEM) C2010L - C4010L



SOTAL



The data herewith contained may change without notice and LF SpA cannot be held responsible for possible errors stated or resulting by the use of this document. All rights reserved. No part of this publication may be reproduced without written permission by LF SpA.



LF SpA
via Voltri, 80 - 47522 Cesena (FC) ITALIA
Tel. +39 0547 34 11 11 - Fax +39 0547 34 11 10
www.lfricambi724.it - www.lfricambi724.mobi
info@lfricambi.it
Export Dept.: Tel. +39 0547 34 11 50 - Fax: +39 0547 34 11 55
www.lfspareparts724.com - www.lfspareparts724.mobi
export@lfspaceparts.com

FRANCE



EPGC Sas
13, Rue des Forts - 59960 Neuville en Ferrain
Tél. +33 (0)3 20 25 06 21
Fax +33 (0)3 20 25 34 12
www.epgc.com
www.epgc724.mobi
epgc@epgc.com

DEUTSCHLAND



LF GmbH
Junkersstrasse, 1 - D-82178 Puchheim - München
Tel. +49 89 89 45 78 66
Fax +49 89 89 45 78 88
www.lfersatzteile724.de
www.lfersatzteile724.mobi
info@lfersatzteile.de

SCHWEIZ



LF GmbH Verkaufsbüro
Sennweidstrasse, 45 - CH-6312 Steinhausen
Tel. +41 (0)41 760 15 80-1
Fax +41 (0)41 760 15 85
www.lfersatzteile724.ch
www.lfersatzteile724.mobi
info@lfersatzteile.ch

ESPAÑA



LF Repuestos Horeca S.L.U.
Calle Ciudad Real, 10 - 45517 Escalonilla - Toledo
Tif. +34 91 477 91 00
Fax +34 91 477 90 81
www.lfrepuestos724.es
www.lfrepuestos724.mobi
info@lfrepuestos.es

UNITED KINGDOM



LF Spare Parts Ltd.
A10a Lakeside Business Park, Broadway Lane
South Cerney, Gloucestershire GL7 5XL
Tel. +44 (0)1285 86 16 25
Fax +44 (0)1285 86 39 49
www.lfspareparts724.co.uk
www.lfspareparts724.mobi
info@lfspaceparts.co.uk

RUSSIA



OOO LF
ul, Anatoliya Zhivova, 8 - office 1 - 123100 Moscow
Tel. +7 499 259 85 75
Fax +7 495 725 26 53
www.lfspareparts724.ru
www.lfspareparts724.mobi
info@lfspaceparts.ru

CHINA



LF China
Room 102, House 8, Lane 725, Mao Tai Rd.
Changning Dist. - 200336 Shanghai
Tel. +86 (0)21 33 53 66 31
Fax +86 (0)21 33 53 66 32
www.lfspareparts724.com
www.lfspareparts724.mobi
china@lfspaceparts.com