



Spare parts for:

Warewashing equipment



Suitable for:

SO.WE.BO.



This catalogue is automatically generated.
Therefore, the sequence of the items might
not be always shown at best.

Updates will be issued in case of additions
and/or amendments.

Suitable universal spare parts may not be included





Suitable for:

SO.WE.BO.



Suitable for:

Air Chambers

3060071 AIR CHAMBER

for Dishwasher (IME OMNIWASH) 4Q82
for Dishwasher hood type (IME OMNIWASH) SEI1P
SEI2P
for Glasswasher/Cupwasher (IME OMNIWASH) DUE
JOLLY - UNO




SO.WE.BO. GP025

SO.WE.BO. GP025B

3060118 AIR CHAMBER

for Dishwasher MAGIC50
for Dishwasher hood type (SO.WE.BO.) 6.2PB



SO.WE.BO. GP02562PB

SO.WE.BO. SE12PCQ

3060115 BRASS NUT 3/4" GAS

for air chamber
for Dishwasher (AFI) A600 - A900
for Dishwasher (EUROSYSTEM) PRO400
for Dishwasher (HILTA) S41 - S42
for Dishwasher (IME OMNIWASH)
for Dishwasher (NOSEM) C2010 - C4010 - C5000
R2020
for Dishwasher hood type (AFI) A1000L
for Dishwasher hood type (EUROSYSTEM) PRO600
for Dishwasher hood type (HILTA) W13 - W14 - W15
for Dishwasher hood type (NOSEM) K601 - K602
for Glasswasher/Cupwasher (AFI) A35 - A36
for Glasswasher/Cupwasher (EUROSYSTEM) PRO100
PRO200
for Glasswasher/Cupwasher (HILTA) RB10 - RB22



SO.WE.BO. D034


SO.WE.BO. D034



Bearings

3063102 S609RS BEARING F/ROTATING SUPPORT

for Dishwasher (AFI) A600 - A900
 for Dishwasher (EUROSYSTEM) PRO400
 for Dishwasher (HILTA) S41 - S42
 for Dishwasher (NOSEM) C2050 - C5000 - C5010
 NC501
 for Dishwasher hood type (AFI) A1000L
 for Dishwasher hood type (EUROSYSTEM) PRO600
 for Dishwasher hood type (HILTA) W13 - W14 - W15
 for Dishwasher hood type (NOSEM) K601 - K602
 for Glasswasher/Cupwasher (AFI) A35 - A35Z2 - A36
 for Glasswasher/Cupwasher (EUROSYSTEM) PRO100
 PRO200
 for Glasswasher/Cupwasher (HILTA) RB10 - RB22
 SB10 - SB22
 for Glasswasher/Cupwasher (NOSEM) C2010L - C4010L



SO.WE.BO. GG1TC

Boilers

3024023 BOILER ø 140x350 mm

for Dishwasher (IME OMNIWASH) UNOJAQ - UNOJQ
 UNOQCL - UNOQCS
 for Dishwasher (SO.WE.BO.) 601
 for Glasswasher/Cupwasher (AFI) A35
 for Glasswasher/Cupwasher (HILTA) RB10 - SB10
 for Glasswasher/Cupwasher (IME OMNIWASH) JOLLY
 UNOQ
 for Glasswasher/Cupwasher (NUOVA SIMONELLI) KIARA1
 KIARA2
 for Glasswasher/Cupwasher (SAB ITALIA) C35
 for Glasswasher/Cupwasher (SO.WE.BO.) 600 - 631
 661 - 691
 for Glasswasher/Cupwasher (SOTAL) EC195 - ER195



SO.WE.BO. GB11

SO.WE.BO. GB11NT

SO.WE.BO. GB11NTM

3024079

BOILER ø 140x350 mm

for Glasswasher/Cupwasher (IME OMNIWASH) DUE



SO.WE.BO. GB21

3024080 BOILER ø 140x425 mm

for Dishwasher (IME OMNIWASH) 4Q82



SO.WE.BO. GB4821F

3024077

BOILER ø 150x425 mm

for Dishwasher (IME OMNIWASH) 4Q82



SO.WE.BO. GB4823F



Suitable for:

SO.WE.BO.



Suitable for:

3024078 BOILER ø 160x440 mm

- for Dishwasher hood type (AFI) A1000L
- for Dishwasher hood type (EUROSYSTEM) PRO600
- for Dishwasher hood type (HILTA) W13 - W14 - W15
- for Dishwasher hood type (IME OMNIWASH) SEI1P SEI2P
- for Dishwasher hood type (NOSEM) K601 - K602
- for Dishwasher hood type (NUOVA SIMONELLI) LTM1500 LTM1600
- for Dishwasher hood type (SAB ITALIA) K5.1P
- for Dishwasher hood type (SO.WE.BO.) 6.1P - 6.2P
- for Dishwasher hood type (SOTAL) C1300
- for Dishwasher hood type (STORME) L501 - L502
- for Dishwasher hood type (UNIC) A61



SO.WE.BO. GB413FNT

SO.WE.BO. GB413FNT05

Caps

3439007 HEXAGONAL TANK CAP 3/8" GAS

- for Glasswasher/Cupwasher (AFI) A35 - A35Z2 - A36
- for Glasswasher/Cupwasher (EUROSYSTEM) PRO100 PRO200
- for Glasswasher/Cupwasher (HILTA) RB10 - RB22 SB10 - SB22
- for Glasswasher/Cupwasher (IME OMNIWASH) DUE JA35 - JA36 - JA40 - JA41 - JOLLY - UNO
- for Glasswasher/Cupwasher (NOSEM) C2010L - C4010L NC201 - NR101 - R1010
- for Glasswasher/Cupwasher (NUOVA SIMONELLI) KIARA1 KIARA2 - KIARA4
- for Glasswasher/Cupwasher (SAB ITALIA) C35 - C36
- for Glasswasher/Cupwasher (SO.WE.BO.) 600 - 601 631 - 661 - 691 - 701 - 712 - 742 - 752
- for Glasswasher/Cupwasher (SOTAL) C230 - EC195




SO.WE.BO. D0T38P

SO.WE.BO. D0T38PB

SO.WE.BO. D0T38PBGR

3240135 BRASS NUT ø 3/8"



SO.WE.BO. D038

SO.WE.BO. D038A



Suitable for:

3186181 O-RING 03068 EPDM

for Dishwasher (SO.WE.BO.) 601 - 701 - 752
for Dishwasher (SOTAL) ER225
for Glasswasher/Cupwasher (AFI) A35 - A35Z2 - A36
for Glasswasher/Cupwasher (COMENDA) - Series B
for Glasswasher/Cupwasher (EUROSYSTEM) PRO100
PRO200
for Glasswasher/Cupwasher (HILTA) RB10 - RB22
SB10 - SB22
for Glasswasher/Cupwasher (IME OMNIWASH) DUE
JA35 - JA36 - JA40 - JA41 - JOLLY - UNO
for Glasswasher/Cupwasher (NOSEM) C2010L - C4010L
NC201 - NR101 - R1010
for Glasswasher/Cupwasher (NUOVA SIMONELLI) KIARA1
KIARA2 - KIARA4
for Glasswasher/Cupwasher (SAB ITALIA) C35 - C36



SO.WE.BO. OR122

SO.WE.BO.



Suitable for:

Clamps

3449462 HOSE CLAMP 12-20

for hoses \varnothing 12÷20 mm
made of stainless steel AISI 304
height 9 mm and screw E7
for Glasswasher/Cupwasher (ADLER) DSF101



SO.WE.BO. FA1220

3449453

HOSE CLAMP 25-40

for pipes \varnothing 25÷40 mm
made of stainless steel AISI 304
height 9 mm and screw E7



SO.WE.BO. FA3040

Door catches

3398050 COMPLETE DOOR CATCH

for all models
for Glasswasher/Cupwasher (ADLER) DSF101 - DSF103
DS101 - DS103 - DS201 - DS203
for Glasswasher/Cupwasher (WHIRLPOOL) D110 - D111
D210 - D211 - D310 - D311 - F300 - F312



SO.WE.BO. AM011

SO.WE.BO. AM011A+AM011E+...



Suitable for:

SO.WE.BO.



Suitable for:

Drain assembly

3316062 COMPLETE DRAIN ASSEMBLY
connection \varnothing 1" outlet \varnothing 27 mm
complete with nut and gasket
for UNO-DUE-JOLLY



SO.WE.BO. GS117

SO.WE.BO. GS117+OR3131+DP1

SO.WE.BO. GS117B

SO.WE.BO. GS117B+OR3131+DP1

SO.WE.BO. GS117BGR

SO.WE.BO. GS117BGR+OR3131+

3316061 DRAIN ASSEMBLY - FITTING \varnothing 34 mm
fitting \varnothing 1"1/4 outlet \varnothing 38 mm
for DISHWASHER 6.2P-61P



SO.WE.BO. GS317

SO.WE.BO. GS317B

SO.WE.BO. GS317BGR

3160041 NUT \varnothing 1"1/4
for Dishwasher (AFI) A600
for Dishwasher (EUROSYSTEM) PRO400
for Dishwasher (HILTA) S41 - S42
for Dishwasher (NOSEM) C5010 - C5020 - NC501
for Dishwasher (NUOVA SIMONELLI) KIARA6
for Dishwasher (SAB ITALIA) C50H
for Dishwasher (SO.WE.BO.) 600CQ - 600CT - 619CQ
619CT - 631CT - 661CQ - 701CQ - 701CT - 752CQ
752CT - 824CQ - 824CT
for Dishwasher (SOTAL) F600ECO
for Dishwasher (STORME) LT500M - LT500T
for Dishwasher (UNIC) A100 - A410E
for Glasswasher/Cupwasher (AFI) A35 - A35Z2 - A36
for Glasswasher/Cupwasher (EUROSYSTEM) PRO100
PRO200



SO.WE.BO. DP114

SO.WE.BO. DP114GR

3160040 O-RING 03168 EPDM
for Dishwasher (AFI) A600
for Dishwasher (EUROSYSTEM) PRO400
for Dishwasher (HILTA) S41 - S42
for Dishwasher (NOSEM) C5010 - C5020 - NC501
for Dishwasher (NUOVA SIMONELLI) KIARA6
for Dishwasher (SAB ITALIA) C50H
for Dishwasher (SO.WE.BO.) 600CQ - 600CT - 619CQ
619CT - 631CT - 661CQ - 701CQ - 701CT - 752CQ
752CT - 824CQ - 824CT
for Dishwasher (SOTAL) F600ECO
for Dishwasher (STORME) LT500M - LT500T
for Dishwasher (UNIC) A100 - A410E
for Glasswasher/Cupwasher (AFI) A35 - A35Z2 - A36
for Glasswasher/Cupwasher (EUROSYSTEM) PRO100
PRO200



SO.WE.BO. OR3168

Suitable for:

Suitable for:

3316141 DRAIN ASSEMBLY 1"1/4
for QUATTRO Q




SO.WE.BO. GA111T

SO.WE.BO. GA111TB

Drain hoses

3450110 DRAIN PIPE ø 24x1500 mm



SO.WE.BO. GS130

3450189 DRAIN PIPE ø 31.5x1500 mm
for DISHWASHER 4Q82-J50-J500-N50-N500-4K50



SO.WE.BO. GS330

3450622 PRESSURE SWITCH PIPE ø 5x11 mm - 5 m
temperature -30°+110°C
operating pressure 10 bar
burst pressure 40 bar
non-toxic rubber hose
external ø 11 mm
internal ø 5 mm
5-m bundles
for 50-m bundles see 3450652



SO.WE.BO. TG510DS

SO.WE.BO. TG512FDA

3450652 PRESSURE SWITCH PIPE ø 5x11 mm - 50 m
temperature -30°+110°C
operating pressure 10 bar
burst pressure 40 bar
non-toxic rubber hose
external ø 11 mm
internal ø 5 mm
50-m bundles
for 5-m bundles see 3450622



SO.WE.BO. TG510DS

SO.WE.BO. TG512FDA

3450297 RUBBER HOSE ø 11x19 mm - 5 m
temperature -30°+110°C
operating pressure 10 bar
burst pressure 40 bar
non-toxic rubber hose
external ø 19 mm
internal ø 11 mm
5-m bundles
for 50-m bundles see 3450197



SO.WE.BO. TG1117

3450197 RUBBER HOSE ø 11x19 mm - 50 m
temperature -30°+110°C
operating pressure 10 bar
burst pressure 40 bar
non-toxic rubber hose
external ø 19 mm
internal ø 11 mm
50-m bundles
for 5-m bundles see 3450297



SO.WE.BO. TG1117



Suitable for:

SO.WE.BO.



Suitable for:

Drain plugs

3448142 COMPLETE OVERFLOW PIPE \varnothing 25x100 mm
in plastic
for CL-CS-UNO-DUE
for Glasswasher/Cupwasher (EMB) 35HL




SO.WE.BO. GS116CCA
SO.WE.BO. GS116CCAB

SO.WE.BO. GS116CC
SO.WE.BO. GS116CCABGR

SO.WE.BO. GS116CCA

3448177 COMPLETE OVERFLOW PIPE \varnothing 35x165 mm
in plastic
for QUATTRO Q-T-BA



SO.WE.BO. GS316CC
SO.WE.BO. GS416CCABGR

SO.WE.BO. GS416CC

SO.WE.BO. GS416CCAB

3448128 OVERFLOW PIPE \varnothing 33x192 mm
in plastic
for 6.2P-61P




SO.WE.BO. GS6013

SO.WE.BO. GS6013B

Filters

3160323 FILTER BOTTOM PLATE
for Dishwasher (IME OMNIWASH) J50 - J500 - N50
N500 - 4Q82
for Dishwasher hood type (IME OMNIWASH) SEI1P
SEI2P




SO.WE.BO. GA315RA
SO.WE.BO. GA315RAV0GR

SO.WE.BO. GA315RAB

SO.WE.BO. GA315RAV0

3160321 FILTER 230x200 mm
for Dishwasher (AFI) A600
for Dishwasher (EUROSYSTEM) PRO400
for Dishwasher (HILTA) S41 - S42
for Dishwasher (IME OMNIWASH) 4Q82
for Dishwasher (NOSEM) C5000 - C5010 - C5020
NC501
for Dishwasher (NUOVA SIMONELLI) KIARA6
for Dishwasher (SAB ITALIA) C50H
for Dishwasher (SO.WE.BO.) 824
for Dishwasher (SOTAL) F600ECO
for Dishwasher (STORME) LT500M - LT500T
for Dishwasher (UNIC) A410E




SO.WE.BO. LIF4V4TPP

SO.WE.BO. LIF4V4TPPGR

3160322 FILTER 330x310 mm

for Dishwasher (SO.WE.BO.) 701CQ - 752CQ - 752CT
 for Glasswasher/Cupwasher (AFI) A35Z2
 for Glasswasher/Cupwasher (EUROSYSTEM) PRO200
 for Glasswasher/Cupwasher (HILTA) RB22 - SB22
 for Glasswasher/Cupwasher (IME OMNIWASH) DUEAQ
 DUEAT - UNOAQ - UNOAT - UNOQ - UNOT
 for Glasswasher/Cupwasher (NOSEM) C4010L - NC201
 NR101 - R1010
 for Glasswasher/Cupwasher (NUOVA SIMONELLI) KIARA4
 for Glasswasher/Cupwasher (SO.WE.BO.) ONECQ
 ONECT - 701VT - 712CQ - 712CT - 742CQ - 742CT
 for Glasswasher/Cupwasher (SOTAL) C230
 for Glasswasher/Cupwasher (STORME) ME400
 for Glasswasher/Cupwasher (UNIC) A20 - A21



SO.WE.BO. LIF12V1P

SO.WE.BO. LIF12V1PV0

3160042 FITTING \varnothing 1"1/2

for Dishwasher (AFI) A600
 for Dishwasher (EUROSYSTEM) PRO400
 for Dishwasher (HILTA) S41 - S42
 for Dishwasher (IME OMNIWASH) QUATTROBA
 QUATTROSA - 4Q82
 for Dishwasher (NOSEM) C5000 - K602S
 for Dishwasher (NUOVA SIMONELLI) KIARA6
 for Dishwasher (SAB ITALIA) C50H - K5.2P
 for Dishwasher (SOTAL) C1300IP - F600
 for Dishwasher hood type (AFI) A1000L
 for Dishwasher hood type (EUROSYSTEM) PRO600
 for Dishwasher hood type (HILTA) W13 - W14 - W15
 for Dishwasher hood type (IME OMNIWASH) SEI1P
 SEI2P
 for Dishwasher hood type (NOSEM) K601



SO.WE.BO. GA311

SO.WE.BO. GA311B

SO.WE.BO. GA311BGR

3160152 FILTER RETAINING NUT

for Dishwasher (AFI) A600
 for Dishwasher (EUROSYSTEM) PRO400
 for Dishwasher (HILTA) S41 - S42
 for Dishwasher (IME OMNIWASH) 4Q82
 for Dishwasher (NOSEM) C5010 - C5020 - NC501
 for Dishwasher (NUOVA SIMONELLI) KIARA6
 for Dishwasher (SAB ITALIA) C50H
 for Dishwasher (SO.WE.BO.) 600CQ - 600CT - 601CQ
 601CT - 619CQ - 619CT - 701CQ - 701CT - 752CQ
 752CT - 824
 for Dishwasher (SOTAL) F600ECO
 for Dishwasher (STORME) LT500M - LT500T
 for Dishwasher (UNIC) A100 - A410E
 for Glasswasher/Cupwasher (AFI) A35 - A35Z2 - A36
 for Glasswasher/Cupwasher (EUROSYSTEM) PRO100



SO.WE.BO. GA013

SO.WE.BO. GA013B


SO.WE.BO. GA013BGR



Suitable for:

3160047 INLET FILTER

for Dishwasher (AFI) A600
 for Dishwasher (EUROSYSTEM) PRO400
 for Dishwasher (HILTA) S41 - S42
 for Dishwasher (IME OMNIWASH) 4Q82
 for Dishwasher (NOSEM) C5000 - K602S
 for Dishwasher (NUOVA SIMONELLI) KIARA6
 for Dishwasher (SAB ITALIA) C50H - K5.2P
 for Dishwasher (SO.WE.BO.) 824
 for Dishwasher (SOTAL) C1300IP - F600
 for Dishwasher (STORME) LT1500M - LT1500T - L502BT
 for Dishwasher (UNIC) A401E - A61A - A61B
 for Dishwasher hood type (AFI) A1000L
 for Dishwasher hood type (EUROSYSTEM) PRO600
 for Dishwasher hood type (HILTA) W13 - W14 - W15
 for Dishwasher hood type (IME OMNIWASH) SEI1P



SO.WE.BO. GA315R

SO.WE.BO. GA315RV0

SO.WE.BO. GA315RV0GR

3160044 O-RING 03187 EPDM

for Dishwasher (AFI) A600
 for Dishwasher (EUROSYSTEM) PRO400
 for Dishwasher (HILTA) S41 - S42
 for Dishwasher (IME OMNIWASH) 4Q82
 for Dishwasher (NOSEM) C5000 - K602S
 for Dishwasher (NUOVA SIMONELLI) KIARA6CF
 KIARA6ECF
 for Dishwasher (SAB ITALIA) C50H - K5.2P
 for Dishwasher (SO.WE.BO.)
 for Dishwasher (SOTAL) C1300IP - F600
 for Dishwasher hood type (AFI) A1000L
 for Dishwasher hood type (EUROSYSTEM) PRO600
 for Dishwasher hood type (HILTA) W13 - W14 - W15
 for Dishwasher hood type (IME OMNIWASH) SEI1P
 SEI2P



SO.WE.BO. OR3187

SO.WE.BO.



Suitable for:

3160045 NUT FOR DRAIN ELBOW ø 1"1/2

for Dishwasher (IME OMNIWASH) QUATTROBA
 QUATTROSA - 4Q82
 for Dishwasher (NUOVA SIMONELLI) KIARA6
 for Dishwasher hood type (IME OMNIWASH) SEI1P
 SEI2P
 for Dishwasher hood type (NUOVA SIMONELLI) LTM1500
 LTM1600



SO.WE.BO. DP112

SO.WE.BO. DP112GR

3160043 TIE ROD FOR FILTER 97 mm

for Dishwasher (AFI) A600
 for Dishwasher (EUROSYSTEM) PRO400
 for Dishwasher (HILTA) S41 - S42
 for Dishwasher (NOSEM) C5000 - K602S
 for Dishwasher (NUOVA SIMONELLI) KIARA6
 for Dishwasher (SAB ITALIA) C50H - K5.2P
 for Dishwasher hood type (AFI) A1000L
 for Dishwasher hood type (EUROSYSTEM) PRO600
 for Dishwasher hood type (HILTA) W13 - W14 - W15
 for Dishwasher hood type (IME OMNIWASH) SEI1P
 SEI2P
 for Dishwasher hood type (NOSEM) K601
 for Dishwasher hood type (SAB ITALIA) K5.1P



SO.WE.BO. GA012A

SO.WE.BO. GA6122

SO.WE.BO. GA512

SO.WE.BO. GA61220T

SO.WE.BO. GA5120T

Suitable for:

Suitable for:

3160038 INLET CONNECTOR \varnothing 1"1/4

for Dishwasher (AFI) A600
 for Dishwasher (EUROSYSTEM) PRO400
 for Dishwasher (HILTA) S41 - S42
 for Dishwasher (NOSEM) C5010 - C5020 - NC501
 for Dishwasher (NUOVA SIMONELLI) KIARA6
 for Dishwasher (SAB ITALIA) C50H
 for Dishwasher (SO.WE.BO.) 600CQ - 600CT - 619CQ
 619CT - 631CT - 661CQ - 701CQ - 701CT - 752CQ
 752CT - 824CQ - 824CT
 for Dishwasher (SOTAL) F600ECO
 for Dishwasher (STORME) LT500M - LT500T
 for Dishwasher (UNIC) A100 - A410E
 for Glasswasher/Cupwasher (AFI) A35 - A35Z2 - A36
 for Glasswasher/Cupwasher (EUROSYSTEM) PRO100
 PRO200



SO.WE.BO. GA111

SO.WE.BO. GA111B

3160152 FILTER RETAINING NUT

for Dishwasher (AFI) A600
 for Dishwasher (EUROSYSTEM) PRO400
 for Dishwasher (HILTA) S41 - S42
 for Dishwasher (IME OMNIWASH) 4Q82
 for Dishwasher (NOSEM) C5010 - C5020 - NC501
 for Dishwasher (NUOVA SIMONELLI) KIARA6
 for Dishwasher (SAB ITALIA) C50H
 for Dishwasher (SO.WE.BO.) 600CQ - 600CT - 601CQ
 601CT - 619CQ - 619CT - 701CQ - 701CT - 752CQ
 752CT - 824
 for Dishwasher (SOTAL) F600ECO
 for Dishwasher (STORME) LT500M - LT500T
 for Dishwasher (UNIC) A100 - A410E
 for Glasswasher/Cupwasher (AFI) A35 - A35Z2 - A36
 for Glasswasher/Cupwasher (EUROSYSTEM) PRO100




SO.WE.BO. GA013

SO.WE.BO. GA013B

SO.WE.BO. GA013BGR

3160468 BOTTOM PLATE FOR PUMP FILTER

for Dishwasher (IME OMNIWASH) J50 - 4Q82



SO.WE.BO. GA115RAB

SO.WE.BO. GA115RABV0

SO.WE.BO. GA115RABV0GR

3160041 NUT \varnothing 1"1/4

for Dishwasher (AFI) A600
 for Dishwasher (EUROSYSTEM) PRO400
 for Dishwasher (HILTA) S41 - S42
 for Dishwasher (NOSEM) C5010 - C5020 - NC501
 for Dishwasher (NUOVA SIMONELLI) KIARA6
 for Dishwasher (SAB ITALIA) C50H
 for Dishwasher (SO.WE.BO.) 600CQ - 600CT - 619CQ
 619CT - 631CT - 661CQ - 701CQ - 701CT - 752CQ
 752CT - 824CQ - 824CT
 for Dishwasher (SOTAL) F600ECO
 for Dishwasher (STORME) LT500M - LT500T
 for Dishwasher (UNIC) A100 - A410E
 for Glasswasher/Cupwasher (AFI) A35 - A35Z2 - A36
 for Glasswasher/Cupwasher (EUROSYSTEM) PRO100
 PRO200



SO.WE.BO. DP114


SO.WE.BO. DP114GR



Suitable for:

3160040 O-RING 03168 EPDM

for Dishwasher (AFI) A600
 for Dishwasher (EUROSYSTEM) PRO400
 for Dishwasher (HILTA) S41 - S42
 for Dishwasher (NOSEM) C5010 - C5020 - NC501
 for Dishwasher (NUOVA SIMONELLI) KIARA6
 for Dishwasher (SAB ITALIA) C50H
 for Dishwasher (SO.WE.BO.) 600CQ - 600CT - 619CQ
 619CT - 631CT - 661CQ - 701CQ - 701CT - 752CQ
 752CT - 824CQ - 824CT
 for Dishwasher (SOTAL) F600ECO
 for Dishwasher (STORME) LT500M - LT500T
 for Dishwasher (UNIC) A100 - A410E
 for Glasswasher/Cupwasher (AFI) A35 - A35Z2 - A36
 for Glasswasher/Cupwasher (EUROSYSTEM) PRO100
 PRO200



SO.WE.BO. OR3168

3160472 PUMP INLET FILTER

for Dishwasher (AFI) A600
 for Dishwasher (EUROSYSTEM) PRO400
 for Dishwasher (HILTA) S41 - S42
 for Dishwasher (IME OMNIWASH) J50 - 4Q82
 for Dishwasher (NOSEM) C4010 - C5000 - C5010
 C5020 - NC501
 for Dishwasher (NUOVA SIMONELLI) KIARA6
 for Dishwasher (SAB ITALIA) C50H
 for Dishwasher (SO.WE.BO.) 600CQ - 600CT - 601CQ
 601CT - 619CQ - 619CT - 701CQ - 701CT - 752CQ
 752CT - 824
 for Dishwasher (SOTAL) F600ECO
 for Dishwasher (STORME) LT500M - LT500T
 for Dishwasher (UNIC) A100 - A410E
 for Glasswasher/Cupwasher (AFI) A35 - A35Z2 - A36



SO.WE.BO. GA115SCOMP

SO.WE.BO. GA214AT

SO.WE.BO.



Suitable for:

3160151 PUMP INLET FILTER

for Dishwasher (AFI) A600
 for Dishwasher (EUROSYSTEM) PRO400
 for Dishwasher (HILTA) S41 - S42
 for Dishwasher (IME OMNIWASH) 4Q82
 for Dishwasher (NOSEM) C5010 - C5020 - NC501
 for Dishwasher (NUOVA SIMONELLI) KIARA6
 for Dishwasher (SAB ITALIA) C50H
 for Dishwasher (SO.WE.BO.) 600CQ - 600CT - 601CQ
 601CT - 619CQ - 619CT - 701CQ - 701CT - 752CQ
 752CT - 824
 for Dishwasher (SOTAL) F600ECO
 for Dishwasher (STORME) LT500M - LT500T
 for Dishwasher (UNIC) A100 - A410E
 for Glasswasher/Cupwasher (AFI) A35 - A35Z2 - A36
 for Glasswasher/Cupwasher (EUROSYSTEM) PRO100



SO.WE.BO. GA115R

SO.WE.BO. GA115RCBV0

SO.WE.BO. GA115RV0

SO.WE.BO. GA115RV0GR+...

3160039 TIE ROD FOR FILTER 52 mm

for Dishwasher (AFI) A600
 for Dishwasher (EUROSYSTEM) PRO400
 for Dishwasher (HILTA) S41 - S42
 for Dishwasher (NOSEM) C5010 - C5020 - NC501
 for Dishwasher (NUOVA SIMONELLI) KIARA6
 for Dishwasher (SAB ITALIA) C50H
 for Dishwasher (SO.WE.BO.) 600CQ - 600CT - 619CQ
 619CT - 631CT - 661CQ - 701CQ - 701CT - 752CQ
 752CT - 824CQ - 824CT
 for Dishwasher (SOTAL) F600ECO
 for Dishwasher (STORME) LT500M - LT500T
 for Dishwasher (UNIC) A100 - A410E
 for Glasswasher/Cupwasher (AFI) A35 - A35Z2 - A36
 for Glasswasher/Cupwasher (EUROSYSTEM) PRO100
 PRO200




SO.WE.BO. GAGS1299

SO.WE.BO. GA012B

Suitable for:

3160049 INLET FILTER

for Dishwasher (IME OMNIWASH) 4Q82
for Dishwasher (SO.WE.BO.) 824



SO.WE.BO. GA315RCB

SO.WE.BO. GA315RCBV0

Suitable for:

3160037 PLASTIC INNER FILTER FOR TANK 230x200 mm

for Dishwasher (IME OMNIWASH) 4Q82
for Dishwasher (NOSEM) K602S
for Dishwasher (SAB ITALIA) K5.2P
for Dishwasher (SOTAL) C13001P
for Dishwasher (STORME) L502BT
for Dishwasher (UNIC) A61A - A61B
for Dishwasher hood type (AFI) A1000L
for Dishwasher hood type (EUROSYSTEM) PRO600
for Dishwasher hood type (HILTA) W13 - W14 - W15
for Dishwasher hood type (IME OMNIWASH) SEI1P SEI2P
for Dishwasher hood type (NOSEM) K601
for Dishwasher hood type (NUOVA SIMONELLI) LTM1500 LTM1600
for Dishwasher hood type (SAB ITALIA) K5.1P



SO.WE.BO. LIF4V4P


SO.WE.BO. LIF4V4PL

SO.WE.BO. LIF4V4PV0

SO.WE.BO. LIF4V4PV0GR

3160464 S/STEEL FILTER SURFACE 230x200 mm

for Dishwasher (NOSEM) K602S
for Dishwasher (SAB ITALIA) K5.2P
for Dishwasher (SOTAL) C13001P - C130024V
for Dishwasher (STORME) L502BT
for Dishwasher (UNIC) A61A - A61B
for Dishwasher hood type (AFI) A1000L
for Dishwasher hood type (EUROSYSTEM) PRO600
for Dishwasher hood type (HILTA) W13 - W14 - W15
for Dishwasher hood type (IME OMNIWASH) SEI1P SEI2P
for Dishwasher hood type (NOSEM) K601 - K602
for Dishwasher hood type (NUOVA SIMONELLI) LTM1500 LTM1600
for Dishwasher hood type (SAB ITALIA) K5.1P
for Dishwasher hood type (SO.WE.BO.) 6.1P - 6.2P



SO.WE.BO. LIF4V4

SO.WE.BO. LIF4V4C



Suitable for:

SO.WE.BO.

Suitable for:



Gaskets and seals

1186014 O-RING 02015 EPDM



SO.WE.BO. OR102

1186421 O-RING 02018 EPDM

for Dishwasher (DIHR) C40CF - GASTRO450
GASTRO500 - GASTRO750 - GASTRO900 - GS45
GS50
for Dishwasher (OLIS) OLG50 - OLG85
for Dishwasher hood type (DIHR) GASTRO115
for Dishwasher hood type (KROMO) K100



SO.WE.BO. OR103

Guides

3189048 HOOD SLIDEWAY

dimensions 595x35 mm
for Dishwasher (IME OMNIWASH) SEI1PS
for Dishwasher (SAB ITALIA) K5.1 - K5.2
for Dishwasher (STORME) L502BT
for Dishwasher (UNIC) A61A - A61B
for Dishwasher hood type (AFI) A1000L
for Dishwasher hood type (EUROSYSTEM) PRO600
for Dishwasher hood type (HILTA) W13 - W14 - W15
for Dishwasher hood type (IME OMNIWASH) SEI2PS
for Dishwasher hood type (NOSEM) K601 - K602
for Dishwasher hood type (NUOVA SIMONELLI) LTM1500
LTM1600
for Dishwasher hood type (SO.WE.BO.) 6.1P - 6.2P
for Dishwasher hood type (SOTAL) C1300
for Dishwasher hood type (STORME) L501 - L502



SO.WE.BO. GMGCP6

Handles

3242372 BLACK HANDLE

distance between mounting holes 120 mm
for JOLLY-J35÷360



SO.WE.BO. AM010PA

SO.WE.BO. AM010PAGR

3242081 BLACK PLASTIC HANDLE


distance between holes 120 mm - length 252 mm
for Dishwasher (IME OMNIWASH) - Series QUATTRO
TREQ
for Glasswasher/Cupwasher (IME OMNIWASH) DUE - UNO



SO.WE.BO. AM010MPC

SO.WE.BO. AM010PC

3242379 DOOR HANDLE 250 mm
for UNO-DUE-J-N



SO.WE.BO. AM010SIM

Heating elements

3455302 BOILER HEATING ELEMENT 9000W 230/400V

immersed length 395 mm
flange external \varnothing 72 mm
with bulb sheath
with O-ring \varnothing 67 mm (3186014)
for Dishwasher (SOTAL) CI300
for Dishwasher hood type (EUROSYSTEM) PRO600
for Dishwasher hood type (HILTA) W13 - W14 - W15
for Dishwasher hood type (IME OMNIWASH) SEI1P
SEI2P
for Dishwasher hood type (NOSEM) K601 - K602
for Dishwasher hood type (NUOVA SIMONELLI) LTM1500
LTM1600
for Dishwasher hood type (SO.WE.BO.) 6.1P - 6.2P
for Dishwasher hood type (UNIC) A61



SO.WE.BO. CERB903F


3355409 HEATING ELEM. F/WASH TANK 4500W 230/415V

immersed length 280 mm
connection \varnothing 1"1/4 (43 mm)
complete with gasket (3186010)
for Dishwasher (AFI) A900
for Dishwasher (IME OMNIWASH) 4SA
for Dishwasher (NOSEM) K602S
for Dishwasher (SO.WE.BO.) 1315 - 1342
for Dishwasher (SOTAL) C1300/24V - C13001P - F600
for Dishwasher (STORME) LT501 - LT502 - LT502BT
for Dishwasher (UNIC) A61B - A861A
for Dishwasher hood type (AFI) A1000L
for Dishwasher hood type (EUROSYSTEM) PRO600
for Dishwasher hood type (HILTA) W13 - W14 - W15
for Dishwasher hood type (IME OMNIWASH) SEI1P
SEI2P



SO.WE.BO. CERV453F

3186010 ASBESTOS FREE FLAT GASKET \varnothing 54x42x2 mm



SO.WE.BO. G50403GT



Suitable for:

SO.WE.BO.



3355412 HEATING ELEMENT F/BOILER 4500W 230/415V
 immersed length 370 mm
 flange external \varnothing 72 mm
 with thermostat probe receptacle \varnothing 8 mm
 complete with gasket (3186014)
 upon request nut (3528003) and washer (3528004)
 for Dishwasher (AFI) A600 - A900
 for Dishwasher (EUROSYSTEM) PRO400
 for Dishwasher (HILTA) S41 - S42
 for Dishwasher (IME OMNIWASH) 4Q82
 for Dishwasher (NOSEM) C5000 - C5010 - C5020
 K602S - NC501
 for Dishwasher (NUOVA SIMONELLI) KIARA6
 for Dishwasher (SAB ITALIA) C50H - K5.2P
 for Dishwasher (SO.WE.BO.) 1315 - 1342 - 824
 for Dishwasher (SOTAL) C13001P - F600ECO



SO.WE.BO. CERB453F

3186014 O-RING GASKET 06225 EPDM \varnothing 67 mm
 for Dishwasher (ZANUSSI) LS62/F



SO.WE.BO. ORRB3F

3355413 HEATING ELEMENT F/BOILER 6000W 230/415V
 immersed length 410 mm
 flange external \varnothing 72 mm
 with thermostat probe receptacle \varnothing 8 mm
 complete with gasket (3186014)
 upon request nut (3528003) and washer (3528004)
 for Dishwasher (AFI) A600
 for Dishwasher (EUROSYSTEM) PRO400
 for Dishwasher (HILTA) S41 - S42
 for Dishwasher (IME OMNIWASH) 4Q82
 for Dishwasher (NOSEM) C5000 - C5010 - C5020
 K602S - NC501
 for Dishwasher (NUOVA SIMONELLI) KIARA6
 for Dishwasher (SAB ITALIA) C50H - K5.2P
 for Dishwasher (SO.WE.BO.) 824
 for Dishwasher (SOTAL) C13001P - C300 - F600



SO.WE.BO. CERB603F

Suitable for:

3716003 HEATING ELEMENT CAP



SO.WE.BO. GB083FV0

3716003 HEATING ELEMENT CAP



SO.WE.BO. GB083FV0



Suitable for:

3186014 O-RING GASKET 06225 EPDM ø 67 mm
for Dishwasher (ZANUSSI) LS62/F



SO.WE.BO. ORRB3F

335594 HEATING ELEMENT FOR BOILER 2200W 230V

immersed length 247 mm
flange hole 30 mm
distance between fixing holes 45 mm
complete with gasket (3186195)
for Dishwasher (SO.WE.BO.) 601
for Glasswasher/Cupwasher (AFI) A35 - A36
for Glasswasher/Cupwasher (EUROSYSTEM) PRO100
for Glasswasher/Cupwasher (IME OMNIWASH) JA35
JA36 - JOLLYAQ - JOLLYAT - JOLLYQ - JOLLYT
J35 - J36
for Glasswasher/Cupwasher (NUOVA SIMONELLI) KIARA1
KIARA2
for Glasswasher/Cupwasher (SAB ITALIA) C35 - C36
for Glasswasher/Cupwasher (SO.WE.BO.) 600 - 631
661 - 691



SO.WE.BO. CERB22

3355410 HEATING ELEMENT FOR BOILER 2700W 230V

immersed length 290 mm
flange hole 30 mm
distance between fixing holes 45 mm
complete with gasket (3186195)
for Dishwasher (NOSEM) NC202 - NR102 - R1020
for Dishwasher (SO.WE.BO.) ONEQ - 701 - 752
for Glasswasher/Cupwasher (AFI) A35Z2
for Glasswasher/Cupwasher (EUROSYSTEM) PRO200
for Glasswasher/Cupwasher (HILTA) RB22 - SB22
for Glasswasher/Cupwasher (IME OMNIWASH) DUEAQ
DUEAT - DUECL - DUECS - JA40 - JA41 - J40
J41 - UNO AQ - UNOAT - UNOCL - UNOCS
for Glasswasher/Cupwasher (NOSEM) C2010L - C4010L
NC201 - NR101 - R1010
for Glasswasher/Cupwasher (NUOVA SIMONELLI) KIARA4



SO.WE.BO. CERB2712

SO.WE.BO.

Suitable for:



3716002 HEATING ELEMENT CAP




SO.WE.BO. GB08V0



Suitable for:

3186195 SILICONE GASKET FOR HEATING ELEMENT
ø 41x30x3 mm



SO.WE.BO. G42303S

SO.WE.BO.



Suitable for:

3355595 HEATING ELEMENT FOR BOILER 3000W 230V

immersed length 325 mm
flange hole 30 mm
distance between fixing holes 45 mm
complete with gasket (3186195)
for Dishwasher (AFI) A600
for Dishwasher (EUROSYSTEM) PRO400
for Dishwasher (HILTA) S41 - S42
for Dishwasher (IME OMNIWASH) QUATTROI - QUATTROQ
QUATTROQ82 - TREQ
for Dishwasher (NOSEM) C5000 - C5010 - C5020
NC501
for Dishwasher (NUOVA SIMONELLI) KIARA6
for Dishwasher (SAB ITALIA) C50H
for Dishwasher (SO.WE.BO.) 824
for Dishwasher (SOTAL) F600ECO



SO.WE.BO. CERB30

3716002 HEATING ELEMENT CAP



SO.WE.BO. GB08V0

3355407 HEATING ELEMENT FOR WASH TANK 1800W 230V

immersed length 295 mm
connection ø 12 mm
for Dishwasher (NOSEM) C4010 - NC202 - NR102
N101 - R1020
for Dishwasher (SO.WE.BO.) 701 - 752
for Glasswasher/Cupwasher (AFI) A35Z2
for Glasswasher/Cupwasher (EUROSYSTEM) PRO200
for Glasswasher/Cupwasher (HILTA) RB22 - SB22
for Glasswasher/Cupwasher (IME OMNIWASH) DUEAQ
DUEAT - DUECL - DUECS - JA40 - JA41 - J40
J41 - UNO AQ - UNOAT - UNOCL - UNOCS
for Glasswasher/Cupwasher (NOSEM) NC201 - R1010
for Glasswasher/Cupwasher (NUOVA SIMONELLI) KIARA4
for Glasswasher/Cupwasher (SO.WE.BO.) 712 - 742
for Glasswasher/Cupwasher (STORME) ME400



SO.WE.BO. CERV18


Suitable for:

Suitable for:

3355408 HEATING ELEMENT FOR WASH TANK 2500W 230V

3455414 HEAT.ELEMENT PROTECTION - MOULD 41 UNI

immersed length 400 mm
 connection \varnothing 12 mm
 for Dishwasher (AFI) A600
 for Dishwasher (EUROSYSTEM) PRO400
 for Dishwasher (HILTA) S41 - S42
 for Dishwasher (IME OMNIWASH) 4Q82
 for Dishwasher (NOSEM) C5000 - C5010 - C5020
 NC501
 for Dishwasher (NUOVA SIMONELLI) KIARA6
 for Dishwasher (SAB ITALIA) C50H
 for Dishwasher (SO.WE.BO.) 824
 for Dishwasher (SOTAL) F600ECO
 for Dishwasher (STORME) LT500M - LT500T
 for Dishwasher (UNIC) A410E



SO.WE.BO. CERV22

SO.WE.BO. CERV25

SO.WE.BO. CEPRV


SO.WE.BO. CEPRVV0

SO.WE.BO. CEPRV0GR

3355596 HEATING ELEMENT FOR WASH TANK 800W 230V

3786562 ASBESTOS FREE FLAT GASKET \varnothing 18x12x2 mm

immersed length 330 mm
 width 50 mm height 30 mm
 connection \varnothing 12 mm
 for Dishwasher (SO.WE.BO.) 601
 for Glasswasher/Cupwasher (AFI) A35 - A36
 for Glasswasher/Cupwasher (EUROSYSTEM) PRO100
 for Glasswasher/Cupwasher (HILTA) RB10 - SB10
 for Glasswasher/Cupwasher (IME OMNIWASH) JA35
 JA36 - JOLLYAQ - JOLLYAT - JOLLYQ - JOLLYT
 J35 - J36
 for Glasswasher/Cupwasher (NOSEM) C2010L - R1010L
 for Glasswasher/Cupwasher (NUOVA SIMONELLI) KIARA1
 KIARA2
 for Glasswasher/Cupwasher (SAB ITALIA) C35 - C36
 for Glasswasher/Cupwasher (SO.WE.BO.) 600 - 631



SO.WE.BO. CERV8

SO.WE.BO. G18122GT



Suitable for:

SO.WE.BO.



Suitable for:

Hinges

3391046 BUSHING FOR DOOR HINGE

for Dishwasher (SO.WE.BO.) 601 - 701
 for Glasswasher/Cupwasher (AFI) A35
 for Glasswasher/Cupwasher (EUROSYSTEM) PRO100
 for Glasswasher/Cupwasher (HILTA) RB10 - SB10
 for Glasswasher/Cupwasher (IME OMNIWASH) JA35
 JA36 - JOLLY - UNO
 for Glasswasher/Cupwasher (NOSEM) C2010L - NC201
 R1010L
 for Glasswasher/Cupwasher (NUOVA SIMONELLI) KIARA1
 for Glasswasher/Cupwasher (SO.WE.BO.) 600 - 631
 661 - 691
 for Glasswasher/Cupwasher (SOTAL) EC195 - ER195
 for Glasswasher/Cupwasher (STORME) SM350
 for Glasswasher/Cupwasher (UNIC) A10J - A11J



SO.WE.BO. AM012M

3053317 DOOR SPRING LH

for Dishwasher (SO.WE.BO.) 601 - 701
 for Glasswasher/Cupwasher (AFI) A35
 for Glasswasher/Cupwasher (EUROSYSTEM) PRO100
 for Glasswasher/Cupwasher (HILTA) RB10 - SB10
 for Glasswasher/Cupwasher (IME OMNIWASH) JA35
 JA36 - JOLLYA - UNO
 for Glasswasher/Cupwasher (NOSEM) C2010L - NC201
 R1010L
 for Glasswasher/Cupwasher (NUOVA SIMONELLI) KIARA1
 for Glasswasher/Cupwasher (SO.WE.BO.) 600 - 631
 661 - 691
 for Glasswasher/Cupwasher (SOTAL) EC195 - ER195
 for Glasswasher/Cupwasher (STORME) SM350
 for Glasswasher/Cupwasher (UNIC) A10J - A11J



SO.WE.BO. AMMP1A2SX

3053319 DOOR SPRING LH


for Dishwasher (SO.WE.BO.) 601 - 701
 for Glasswasher/Cupwasher (AFI) A35
 for Glasswasher/Cupwasher (EUROSYSTEM) PRO100
 for Glasswasher/Cupwasher (HILTA) RB10 - SB10
 for Glasswasher/Cupwasher (IME OMNIWASH) JA35
 JA36 - JOLLY - UNO
 for Glasswasher/Cupwasher (NOSEM) C2010L - NC201
 R1010L
 for Glasswasher/Cupwasher (NUOVA SIMONELLI) KIARA1
 for Glasswasher/Cupwasher (SO.WE.BO.) 600 - 631
 661 - 691
 for Glasswasher/Cupwasher (SOTAL) EC195 - ER195
 for Glasswasher/Cupwasher (STORME) SM350
 for Glasswasher/Cupwasher (UNIC) A10J - A11J



SO.WE.BO. AMMP1SX

3053318 DOOR SPRING RH

for Dishwasher (SO.WE.BO.) 601 - 701
 for Glasswasher/Cupwasher (AFI) A35
 for Glasswasher/Cupwasher (EUROSYSTEM) PRO100
 for Glasswasher/Cupwasher (HILTA) RB10 - SB10
 for Glasswasher/Cupwasher (IME OMNIWASH) JA35
 JA36 - JOLLYA - UNO
 for Glasswasher/Cupwasher (NOSEM) C2010L - NC201
 R1010L
 for Glasswasher/Cupwasher (NUOVA SIMONELLI) KIARA1
 for Glasswasher/Cupwasher (SO.WE.BO.) 600 - 631
 661 - 691
 for Glasswasher/Cupwasher (SOTAL) EC195 - ER195
 for Glasswasher/Cupwasher (STORME) SM350
 for Glasswasher/Cupwasher (UNIC) A10J - A11J



SO.WE.BO. AMMP1A2DX

Suitable for:

3053320 DOOR SPRING RH

for Dishwasher (SO.WE.BO.) 601 - 701
 for Glasswasher/Cupwasher (AFI) A35
 for Glasswasher/Cupwasher (EUROSYSTEM) PRO100
 for Glasswasher/Cupwasher (HILTA) RB10 - SB10
 for Glasswasher/Cupwasher (IME OMNIWASH) JA35
 JA36 - JOLLY - UNO
 for Glasswasher/Cupwasher (NOSEM) C2010L - NC201
 R1010L
 for Glasswasher/Cupwasher (NUOVA SIMONELLI) KIARA1
 for Glasswasher/Cupwasher (SO.WE.BO.) 600 - 631
 661 - 691
 for Glasswasher/Cupwasher (SOTAL) EC195 - ER195
 for Glasswasher/Cupwasher (STORME) SM350
 for Glasswasher/Cupwasher (UNIC) A10J - A11J



SO.WE.BO. AMMP1DX

Suitable for:

3012001 SILICONE BUMPER FOR DOOR

for Dishwasher (SO.WE.BO.) 601 - 701
 for Glasswasher/Cupwasher (AFI) A35
 for Glasswasher/Cupwasher (EUROSYSTEM) PRO100
 for Glasswasher/Cupwasher (HILTA) RB10 - SB10
 for Glasswasher/Cupwasher (IME OMNIWASH) JA35
 JA36 - JOLLY - UNO
 for Glasswasher/Cupwasher (NOSEM) C2010L - NC201
 R1010L
 for Glasswasher/Cupwasher (NUOVA SIMONELLI) KIARA1
 for Glasswasher/Cupwasher (SO.WE.BO.) 600 - 631
 661 - 691
 for Glasswasher/Cupwasher (SOTAL) EC195 - ER195
 for Glasswasher/Cupwasher (STORME) SM350
 for Glasswasher/Cupwasher (UNIC) A10J - A11J



SO.WE.BO. AMPCP

Hose-end fittings


3391042 HOSE-END FITTING FOR RINSE SHAFT \varnothing 16 mm

for Dishwasher (AFI) A600
 for Dishwasher (EUROSYSTEM) PRO400
 for Dishwasher (HILTA) S41 - S42
 for Dishwasher (IME OMNIWASH) 4Q82
 for Dishwasher (NOSEM) C5000 - C5010 - C5020
 NC501
 for Dishwasher (SAB ITALIA) C50
 for Dishwasher (SO.WE.BO.) 824
 for Glasswasher/Cupwasher (AFI) A35 - A35Z2 - A36
 for Glasswasher/Cupwasher (EUROSYSTEM) PRO100
 PRO200
 for Glasswasher/Cupwasher (HILTA) RB10 - RB22
 SB10 - SB22
 for Glasswasher/Cupwasher (IME OMNIWASH) DUEAQ
 DUEAT - JA35 - JA36 - JA40 - JA41 - JOLLYQ



SO.WE.BO. GR016PNT

3349601 3-WAY HOSE-END FITTING



SO.WE.BO. GB017NT

3315027 T- HOSE END FITTING



SO.WE.BO. GB055

3315107 3-WAYS HOSE END RUBBER FITTING \varnothing 12



SO.WE.BO. GR6183



Suitable for:

SO.WE.BO.



Suitable for:

Inlet hoses

3090759 PVC PIPE \varnothing 4/6 mm - 10 m
alimentary



SO.WE.BO. TC46

3090259 PVC PIPE \varnothing 4/6 mm - 100 m
alimentary



SO.WE.BO. TC46

Interference suppression filters

3160404 TRAP FILTER 0.47 μ F 250V
for Dishwasher (AFI)
for Dishwasher (EUROSYSTEM)
for Dishwasher (HILTA)
for Dishwasher (IME OMNIWASH)
for Dishwasher (NOSEM)
for Dishwasher (NUOVA SIMONELLI)
for Dishwasher (SAB ITALIA)
for Dishwasher (SO.WE.BO.)
for Dishwasher (SOTAL)
for Dishwasher (UNIC)



SO.WE.BO. CEFA

Ironmongery (screws,nuts,washers)

1348813 HEXAGONAL NORM.NUT M4 ST.STEEL UNI 5588



SO.WE.BO. VD4I

3528213 HEXAGONAL NORMAL NUT M5 UNI 5588



SO.WE.BO. VD5I

Lamps

3221595 BLUE INDICATOR CAP



SO.WE.BO. CETP6B

3221113 DOUBLE INDICATOR LAMP 230V
mounting hole 30x22 mm
16A 250V
green-yellow colours
for CS - CL



SO.WE.BO. CESDAV

SO.WE.BO. CESPDAV

Suitable for:

3221592 GREEN INDICATOR LAMP 230 V
ø 6 mm

SO.WE.BO. CESPV6

Suitable for:

3221591 GREEN TORPEDO LAMP 220V

SO.WE.BO. CESP27V

3221127 ORANGE LAMP RECEPTACLE
head 14x14 mm - hole ø 11 mm
for 6.2P
for OEM PIZZA OVEN 4-5-8-10-11-15/DS

SO.WE.BO. CESP6274

3221128 GREEN LAMP RECEPTACLE
hole ø 11 mm
head 14x14 mm
for 6.2P

SO.WE.BO. CESP6224

3221126 INDICATOR LAMP 24V
head ø 8 mm

SO.WE.BO. CESP6394

3221594 RED GEM FOR LAMPHOLDER ø 7mm

SO.WE.BO. CEGA6



Suitable for:

SO.WE.BO.



Suitable for:

Microswitches

3803005 COMPLETE DOOR CONTACT

for Dishwasher (IME OMNIWASH) SEI1PCQ - SEI2CQB
SEI2PCQ
for Dishwasher (NOSEM) K602S
for Dishwasher (SAB ITALIA) K5.2P
for Dishwasher (SOTAL) C13001P - C130024V
for Dishwasher (STORME) L502BT
for Dishwasher (UNIC) A61A - A61B
for Dishwasher hood type (AFI) A1000L
for Dishwasher hood type (EUROSYSTEM) PRO600
for Dishwasher hood type (HILTA) W13 - W14 - W15
for Dishwasher hood type (NOSEM) K601 - K602
for Dishwasher hood type (NUOVA SIMONELLI) LTM1500
LTM1600
for Dishwasher hood type (SAB ITALIA) K5.1P
for Dishwasher hood type (SO.WE.BO.) 6.1P - 6.2P



SO.WE.BO. CESMP61SC

3803018 ACTUATOR FOR REAR MICRO SWITCH 62P/SPPL



SO.WE.BO. CEAZM62PS

3240129 COMPLETE MICROSWITCH FOR DOOR




SO.WE.BO. CEMP12

SO.WE.BO. CEMP12CS

SO.WE.BO. CEMP12CSC

3240135 BRASS NUT \varnothing 3/8"



SO.WE.BO. D038

SO.WE.BO. D038A

3803034 COMPLETE MICRO SUPPORT



SO.WE.BO. CEMP1823

SO.WE.BO. CEMP1823B

SO.WE.BO. CEMP1823BGR

3240130 MICROSWITCH FRONT BODY



SO.WE.BO. CEMP23

SO.WE.BO. CEMP23B



Suitable for:

3240134 MICROSWITCH REAR BODY



SO.WE.BO. CEMP18

SO.WE.BO. CEMP18B

SO.WE.BO. CEMP18BGR

3186181 O-RING 03068 EPDM

for Dishwasher (SO.WE.BO.) 601 - 701 - 752
 for Dishwasher (SOTAL) ER225
 for Glasswasher/Cupwasher (AFI) A35 - A35Z2 - A36
 for Glasswasher/Cupwasher (COMENDA) - Series B
 for Glasswasher/Cupwasher (EUROSYSTEM) PRO100
 PRO200
 for Glasswasher/Cupwasher (HILTA) RB10 - RB22
 SB10 - SB22
 for Glasswasher/Cupwasher (IME OMNIWASH) DUE
 JA35 - JA36 - JA40 - JA41 - JOLLY - UNO
 for Glasswasher/Cupwasher (NOSEM) C2010L - C4010L
 NC201 - NR101 - R1010
 for Glasswasher/Cupwasher (NUOVA SIMONELLI) KIARA1
 KIARA2 - KIARA4
 for Glasswasher/Cupwasher (SAB ITALIA) C35 - C36



SO.WE.BO. OR122

3240133 STAINLESS STEEL ROD FOR MICRO SWITCH 77m



SO.WE.BO. CEMP21

SO.WE.BO.

Suitable for:

1186352

O-RING 02050 EPDM

for Dishwasher (AFI) A600
 for Dishwasher (DIHR) C40CF - GASTRO450
 GASTRO500 - GASTRO750 - GASTRO900 - GS45
 GS50
 for Dishwasher (EUROSYSTEM) PRO400
 for Dishwasher (FAEMA) 1201
 for Dishwasher (HILTA) S41 - S42
 for Dishwasher (IME OMNIWASH) 4Q82
 for Dishwasher (KROMO) K35 - K37
 for Dishwasher (NOSEM) C5000 - C5010 - C5020
 NC501
 for Dishwasher (NUOVA SIMONELLI) KIARA6
 for Dishwasher (OLIS) OLG550 - OLG85
 for Dishwasher (SAB ITALIA) C50H - 1200
 for Dishwasher (SILANOS) 200 - 300 - 400 - 600



SO.WE.BO. OR2050

3240132 SPRING FOR ROD



SO.WE.BO. CEMP20





Suitable for:

9014014 MAGNETIC MICROSWITCH \varnothing 6x29 mm
0.5A 250V - contact NO
with cable length 750 mm
for Dishwasher (SO.WE.BO.) - Series CL



SO.WE.BO. CEMPMR

SO.WE.BO.



Suitable for:

3240138 MAGNETIC MICROSWITCH E5301C
250V 0.4A
capillary length 3000 mm
for Dishwasher (AFI) A900
for Dishwasher (NOSEM) K602S
for Dishwasher (STORME) L502BT
for Dishwasher (UNIC) A61A
for Dishwasher hood type (EUROSYSTEM) PRO600
for Dishwasher hood type (HILTA) W14 - W15
for Dishwasher hood type (IME OMNIWASH)
till 1/01/96
SEI2P
for Dishwasher hood type (JEMI) GS-82
for Dishwasher hood type (NOSEM) K602
for Dishwasher hood type (NUOVA SIMONELLI) LTM1600
for Dishwasher hood type (SO.WE.BO.) 6.2PA - 6.2PB



SO.WE.BO. CERD6434

Motors

3240501 AXIAL VENTILATOR SUNON 120x120x38 mm
ball bearings
22W 230V 50/60Hz 2850 Rpm
DP200A 2123XBT.GN



SO.WE.BO. TKS0122


Pressure switches

3320076 DRAIN PUMP PRESSURE SWITCH 60/30 mm
1 - level 250V 16A
max operating temperature 85°C
for Dishwasher (AFI) A600 - A900
for Dishwasher (EUROSYSTEM) PRO400
for Dishwasher (HILTA) S41 - S42
for Dishwasher (IME OMNIWASH) J50 - 4Q82
for Dishwasher (NOSEM) C5000
for Dishwasher (NUOVA SIMONELLI) KIARA6
for Dishwasher (SAB ITALIA) C50H
for Dishwasher (SOTAL) F600
for Dishwasher (STORME) LT500M - LT500T
for Dishwasher (UNIC) A410E



SO.WE.BO. CEPRE

3320214 PRESSURE SWITCH 45/18-65/47 mm 2 LEVELS



SO.WE.BO. CEPRE2LUL

Suitable for:

3320075 PRESSURE SWITCH 50/20 mm 250V 16A

1level
 max operating temperature 85°C
 for Dishwasher (AFI) A600 - A900
 for Dishwasher (EUROSYSTEM) PRO400
 for Dishwasher (HILTA) S41 - S42 - S49 - S55
 for Dishwasher (NOSEM) C5000 - C5010
 for Dishwasher (SAB ITALIA) C50H
 for Dishwasher hood type (IME OMNIWASH) SEI2P
 for Dishwasher hood type (NOSEM) K602
 for Dishwasher hood type (SAB ITALIA) K5.2P
 for Glasswasher/Cupwasher (AFI) A35 - A35Z2 - A36
 for Glasswasher/Cupwasher (EUROSYSTEM) PRO100
 PRO200
 for Glasswasher/Cupwasher (HILTA) RB10 - RB22
 SB10 - SB22



SO.WE.BO. CECBCMPR

SO.WE.BO. CEPR

Suitable for:

3320208 PRESSURE SWITCH 90/30 mm 1 LEVEL

for Dishwasher hood type (SO.WE.BO.) 6.2AB



SO.WE.BO. CEPR62P

Protection plates

3519014 BLACK FRONT FRAME


for Dishwasher (AFI) A600
 for Dishwasher (EUROSYSTEM) PRO400
 for Dishwasher (HILTA) S41 - S42
 for Dishwasher (NOSEM) C1010 - C5000 - C5010
 C5020 - NC501
 for Dishwasher (SO.WE.BO.) ONE - 701 - 752 - 824
 for Dishwasher (SOTAL) F600
 for Dishwasher (STORME) LT500M
 for Dishwasher (UNIC) A410E
 for Glasswasher/Cupwasher (AFI) A35Z2
 for Glasswasher/Cupwasher (NOSEM) NC201 - NR101
 for Glasswasher/Cupwasher (SO.WE.BO.) 742
 for Glasswasher/Cupwasher (SOTAL) C230



SO.WE.BO. AM028N

3244008 LIGHT BLUE FRONT FRAME OMNI11

for Dishwasher (AFI) A600
 for Dishwasher (EUROSYSTEM) PRO400
 for Dishwasher (HILTA) S41 - S42
 for Dishwasher (NOSEM) C1010 - C5000 - C5010
 C5020 - NC501
 for Dishwasher (SO.WE.BO.) ONE - 701 - 752 - 824
 for Dishwasher (SOTAL) F600
 for Dishwasher (STORME) LT500M
 for Dishwasher (UNIC) A410E
 for Glasswasher/Cupwasher (AFI) A35Z2
 for Glasswasher/Cupwasher (NOSEM) NC201 - NR101
 for Glasswasher/Cupwasher (SO.WE.BO.) 742
 for Glasswasher/Cupwasher (SOTAL) C230



SO.WE.BO. AM028A

SO.WE.BO. AM028AO



Suitable for:

SO.WE.BO.



Suitable for:

Pumps

3122203 DRAIN ELECTRIC PUMP 40W 230V 50Hz
inlet external \varnothing 23 mm - outlet external \varnothing 23 mm



SO.WE.BO. CEP5031

3122740 DRAIN ELECTRO-PUMP 34W 220/240V
inlet external \varnothing 23 mm outlet external \varnothing 31 mm
for Dishwasher (AFI) A600
for Dishwasher (IME OMNIWASH) 4Q82
for Dishwasher (NOSEM) C5000 - C501 - C5010
for Dishwasher (NUOVA SIMONELLI) KIARA6
for Dishwasher (SAB ITALIA) C50H
for Dishwasher (SO.WE.BO.) 824
for Dishwasher (SOTAL) F600
for Dishwasher (STORME) LT500
for Dishwasher (UNIC) A410E



SO.WE.BO. CEP55

3122172 ELECTRIC PUMP IME 0.30HP 230V 50Hz
inlet external \varnothing 32 mm - outlet external \varnothing 31 mm
motor revolutions 2800
0.30HP 230V 50Hz - capacitor 10 μ f
for Dishwasher (NUOVA SIMONELLI) - Series KIARA
for Dishwasher (SO.WE.BO.) 601 - 701
for Glasswasher/Cupwasher (AFI) A35 - A35Z2 - A36
for Glasswasher/Cupwasher (EUROSYSTEM) PRO100
PRO200
for Glasswasher/Cupwasher (HILTA) RB10 - RB22
SB10 - SB22
for Glasswasher/Cupwasher (IME OMNIWASH)
Series JOLLY - UNOA - UNOQ - UNOT
for Glasswasher/Cupwasher (NOSEM) C2010L - C4010L
R1010
for Glasswasher/Cupwasher (SAB ITALIA) C35 - C36



SO.WE.BO. EP25CPG

SO.WE.BO. EP30

3122058 MECHANICAL SEAL \varnothing 11mm INNER SURFACE 8mm



SO.WE.BO. EP04

3122673 PUMP HOUSING
inlet external \varnothing 32 mm - outlet external \varnothing 31 mm



SO.WE.BO. EP251TP

3122730 PUMP IMPELLER \varnothing 88 mm



SO.WE.BO. EP253

3786492 SMALL PUMP GASKET



SO.WE.BO. EP252NT

Suitable for:

Suitable for:

3122432 ELECTRO-PUMP AP 1629030SX 0,30HP 230V
 inlet external \varnothing 32 mm - outlet external \varnothing 31 mm
 motor revolutions 2800
 0.30HP 230V 50Hz - capacitor 10 μ f
 for Dishwasher (SO.WE.BO.) 601 - 701
 for Glasswasher/Cupwasher (AFI) A35 - A35Z2 - A36
 for Glasswasher/Cupwasher (EUROSYSTEM) PRO100
 PRO200
 for Glasswasher/Cupwasher (HILTA) RB10 - RB22
 SB10 - SB22
 for Glasswasher/Cupwasher (IME OMNIWASH) JOLLY
 UNOA - UNOQ - UNOT
 for Glasswasher/Cupwasher (NOSEM) C2010L - C4010L
 NR101 - R1010
 for Glasswasher/Cupwasher (NUOVA SIMONELLI) KIARA1
 for Glasswasher/Cupwasher (SAB ITALIA) C35 - C36



SO.WE.BO. EP25CPG

SO.WE.BO. EP30

SO.WE.BO.

3122434 ELECTRO-PUMP AP 2031SX 1HP 230V 50Hz
 inlet external \varnothing 46 mm - outlet external \varnothing 40 mm
 motor revolutions 2800
 1HP 230V 50Hz - capacitor 12.5 μ f
 for Dishwasher (AFI) A600
 for Dishwasher (IME OMNIWASH) 4Q82
 for Dishwasher hood type (AFI) A1000L
 for Dishwasher hood type (IME OMNIWASH) SEI1P
 SEI2P



SO.WE.BO. EP100

3122058 MECHANICAL SEAL \varnothing 11mm INNER SURFACE 8mm



SO.WE.BO. EP04

3122433 ELECTRO-PUMP AP 325915X 0.60HP 230V 50Hz
 inlet external \varnothing 30 mm - outlet external \varnothing 30 mm
 motor revolutions 2850
 0.60HP 230V 50Hz - capacitor 12.5 μ F



SO.WE.BO.



Suitable for:

SO.WE.BO.



3122728 ELECTRO-PUMP IME 1HP 230V 50Hz
 inlet external \varnothing 46 mm - outlet external \varnothing 41 mm
 for Dishwasher (SAB ITALIA) K5.2P
 for Dishwasher hood type (EUROSYSTEM) PRO600
 for Dishwasher hood type (HILTA) W14 - W15
 for Dishwasher hood type (IME OMNIWASH) SEI2P
 SEI2PA - SEI2PB
 for Dishwasher hood type (NOSEM) K602
 for Dishwasher hood type (NUOVA SIMONELLI) LTM1600
 for Dishwasher hood type (SO.WE.BO.) 6.2PA - 6.2PB
 for Dishwasher hood type (SOTAL) C1300
 for Dishwasher hood type (STORME) L502



SO.WE.BO. EP100C

3122444 IMPELLER \varnothing 100 mm
 for Dishwasher (IME OMNIWASH) 4Q82
 for Dishwasher hood type (IME OMNIWASH) SEI1P
 SEI2P



SO.WE.BO. EP753

3122058 MECHANICAL SEAL \varnothing 11mm INNER SURFACE 8mm



SO.WE.BO. EP04

3122729 PUMP IME 0.60HP 230V 50Hz
 inlet external \varnothing 32 mm - outlet external \varnothing 30 mm
 motor revolutions 2800
 0.60HP 230V 50Hz - capacitor 12.5 μ F
 for Glasswasher/Cupwasher (IME OMNIWASH) DUEAQ
 DUEAT



SO.WE.BO. EP50CPG


SO.WE.BO. EP60

3122058 MECHANICAL SEAL \varnothing 11mm INNER SURFACE 8mm



SO.WE.BO. EP04

3122673 PUMP HOUSING
 inlet external \varnothing 32 mm - outlet external \varnothing 31 mm



SO.WE.BO. EP251TP

3122730 PUMP IMPELLER \varnothing 88 mm



SO.WE.BO. EP253

3786492 SMALL PUMP GASKET



SO.WE.BO. EP252NT



Relays

3360002 PUMP DELAYING DEVICE 24V



SO.WE.BO. CETF60

3351012 RELAY 3TG 1001-1AL2
16A 230V 50/60Hz
contacts:3 NO + 1 NC
for JOLLY Q/T - QUATTRO Q82



SO.WE.BO. CECTF

SO.WE.BO. CER16A2NO

3360003 2ND PUMP DELAYING DEVICE 220V 50Hz



SO.WE.BO. CETF604SA

SO.WE.BO. CETF604SA

Remote control switches

3454033 CONTACTOR SIEMENS 3RT1016-1AB01
24V 50/60Hz 4Kw 400V
for Dishwasher hood type (IME OMNIWASH) SEI1P
SEI2P
for Dishwasher hood type (SO.WE.BO.) 6.1P - 6.2P



SO.WE.BO. CECT24G


3454034 CONTACTOR 3TG1001-20A 24V
for Dishwasher hood type (IME OMNIWASH) SEI1P
SEI2P
for Dishwasher hood type (SO.WE.BO.) 6.1P - 6.2P



SO.WE.BO. CECT24P

Rinse aid containers and accessories

3066040 COMPLETE RINSE AID CONTAINER
for Dishwasher (AFI) A600
for Dishwasher (EUROSYSTEM) PRO400
for Dishwasher (HILTA) S41 - S42
for Dishwasher (NOSEM) C1010 - C5000 - C5010
C5020 - NC501
for Dishwasher (SO.WE.BO.) ONE - 701 - 752 - 824
for Dishwasher (SOTAL) F600
for Dishwasher (STORME) LT500M
for Dishwasher (UNIC) A410E
for Glasswasher/Cupwasher (AFI) A35Z2
for Glasswasher/Cupwasher (NOSEM) NC201 - NR101
for Glasswasher/Cupwasher (SO.WE.BO.) 742
for Glasswasher/Cupwasher (SOTAL) C230



SO.WE.BO. AM027

3324004 PLUG FOR RINSE AID CONTAINER ø 2x80 mm
for Dishwasher (AFI) A600
for Dishwasher (EUROSYSTEM) PRO400
for Dishwasher (HILTA) S41 - S42
for Dishwasher (NOSEM) C1010 - C5000 - C5010
C5020 - NC501
for Dishwasher (SO.WE.BO.) ONE - 701 - 752 - 824
for Dishwasher (SOTAL) F600
for Dishwasher (STORME) LT500M
for Dishwasher (UNIC) A410E
for Glasswasher/Cupwasher (AFI) A35Z2
for Glasswasher/Cupwasher (NOSEM) NC201 - NR101
for Glasswasher/Cupwasher (SO.WE.BO.) 742
for Glasswasher/Cupwasher (SOTAL) C230



SO.WE.BO. AM029



Suitable for:

3439001 RINSE AID CONTAINER

for Dishwasher (AFI) A600
 for Dishwasher (EUROSYSTEM) PRO400
 for Dishwasher (HILTA) S41 - S42
 for Dishwasher (NOSEM) C1010 - C5000 - C5010
 C5020 - NC501
 for Dishwasher (SO.WE.BO.) ONE - 701 - 752 - 824
 for Dishwasher (SOTAL) F600
 for Dishwasher (STORME) LT500M
 for Dishwasher (UNIC) A410E
 for Glasswasher/Cupwasher (AFI) A35Z2
 for Glasswasher/Cupwasher (NOSEM) NC201 - NR101
 for Glasswasher/Cupwasher (SO.WE.BO.) 742
 for Glasswasher/Cupwasher (SOTAL) C230



SO.WE.BO. AM030

SO.WE.BO.

Suitable for:



Rinse aid pumps and accessories

3090354 ELBOW FITTING FOR HOSE 4x6

for tank inlet
 in stainless steel
 for Dishwasher (HILTA) W13T



SO.WE.BO. DSDTET62PC

3090070 HYDRAULIC RINSE AID INJECTOR IB1

with smooth connecting tube \varnothing 10 mm
 flow rate regulator



SO.WE.BO. DSAM3

SO.WE.BO. DSAM3NTSPL

SO.WE.BO. DSAM3NT


SO.WE.BO. DSBM3

SO.WE.BO. DSAM3NTGR

SO.WE.BO. DSBM3NT

3090073 INJECTOR DIAPHRAGM

for Dishwasher (SO.WE.BO.) NK6.2P - 601CQ - 601CT
 661CQ - 661CT - 824
 for Glasswasher/Cupwasher (SO.WE.BO.) 712CQ
 712CT



SO.WE.BO. DS06M3



Suitable for:

3090072 INJECTOR NON-RETURN VALVE
 for Dishwasher (SO.WE.BO.) NK6.2P - QUATTRO
 601CQ - 601CT - 661CQ - 661CT - 824
 for Glasswasher/Cupwasher (SO.WE.BO.) 712CQ
 712CT



SO.WE.BO. DS085

SO.WE.BO. DS88

SO.WE.BO.



Suitable for:

Salt container and accessories

3067001 SALT CONTAINER



SO.WE.BO. CER143

3067007 SALT CONTAINER CAP



SO.WE.BO. CER146

3067002 GASKET FOR CONTAINER

external \varnothing 82 mm
 internal \varnothing 64 mm
 thickness 3 mm



SO.WE.BO. CER144

SO.WE.BO. CER144GS

3067005 SALT CONTAINER RING NUT



SO.WE.BO. CER145

Sleeves

3248177 DRAIN HOSE FOR TANK

internal \varnothing 38 mm
 overall length 455 mm
 for Dishwasher (AFI) A600
 for Dishwasher (EUROSYSTEM) PRO400
 for Dishwasher (HILTA) S41 - S42
 for Dishwasher (IME OMNIWASH) 4Q82
 for Dishwasher (NOSEM) C5000 - C5010 - C5020
 NC501
 for Dishwasher (NUOVA SIMONELLI) KIARA6
 for Dishwasher (SAB ITALIA) C50H
 for Dishwasher (SO.WE.BO.) 824
 for Dishwasher (SOTAL) F600ECO
 for Dishwasher (STORME) LT500
 for Dishwasher (UNIC) A410E



SO.WE.BO. GS520

3349479 DRAIN PUMP INLET HOSE

internal \varnothing 30 and 37 mm
 overall length 160 mm
 for Dishwasher (AFI) A600
 for Dishwasher (EUROSYSTEM) PRO400
 for Dishwasher (HILTA) S41 - S42
 for Dishwasher (IME OMNIWASH) 4Q82
 for Dishwasher (NOSEM) C5000 - C5010 - C5020
 NC501
 for Dishwasher (NUOVA SIMONELLI) KIARA6
 for Dishwasher (SAB ITALIA) C50H
 for Dishwasher (SO.WE.BO.) 824
 for Dishwasher (SOTAL) F600ECO
 for Dishwasher (STORME) LT500
 for Dishwasher (UNIC) A410E



SO.WE.BO. GSMPS5



Suitable for:

SO.WE.BO.



Suitable for:

3248171 INLET HOSE

internal \varnothing 43 mm
overall length 335 mm
for Dishwasher (IME OMNIWASH) SEI1PCQ - SEI2PCQ
for Dishwasher (NUOVA SIMONELLI) SEI1PCQ - SEI2PCQ
for Dishwasher (SAB ITALIA) K5.2P
for Dishwasher (UNIC) A61A - A61B
for Dishwasher hood type (AFI) A1000L
for Dishwasher hood type (EUROSYSTEM) PRO600
for Dishwasher hood type (HILTA) W13 - W14 - W15
for Dishwasher hood type (NOSEM) K601 - K602
for Dishwasher hood type (NUOVA SIMONELLI) LTM1500
LTM1600
for Dishwasher hood type (SAB ITALIA) K5.1P
for Dishwasher hood type (SO.WE.BO.) 6.1P - 6.2P
6.2PB



SO.WE.BO. GA38

3248174 INLET HOSE

internal \varnothing 30 mm - 37 mm
for Dishwasher (SO.WE.BO.) ONE - 601 - 701 - 752
for Glasswasher/Cupwasher (AFI) A35 - A35Z2 - A36
for Glasswasher/Cupwasher (EUROSYSTEM) PRO100
PRO200
for Glasswasher/Cupwasher (HILTA) RB10 - RB22
SB10 - SB22
for Glasswasher/Cupwasher (IME OMNIWASH)
Series DUE - JA35 - JA36 - JA40 - JA41
Series JOLLY - Series UNO
for Glasswasher/Cupwasher (NOSEM) C2010L - C4010L
NC201 - NR101 - R1010L
for Glasswasher/Cupwasher (NUOVA SIMONELLI) KIARA1
KIARA2 - KIARA4
for Glasswasher/Cupwasher (SAB ITALIA) C35 - C36



SO.WE.BO. GA18

3349494 LOWER/UPPER PUMP OUTLET HOSE

internal \varnothing 29/35mm
for Dishwasher (SO.WE.BO.) 701
for Glasswasher/Cupwasher (IME OMNIWASH)
Series UNO



SO.WE.BO. GLMSIC1

SO.WE.BO. GLMSIC104

3248173 INLET HOSE

internal \varnothing 43 mm
overall length 485 mm
for Dishwasher (IME OMNIWASH) SEI1PCQ - SEI2PCQ
4SA
for Dishwasher (SAB ITALIA) K5.2P
for Dishwasher (UNIC) A61A - A61B
for Dishwasher hood type (AFI) A1000L
for Dishwasher hood type (EUROSYSTEM) PRO600
for Dishwasher hood type (HILTA) W13 - W14 - W15
for Dishwasher hood type (IME OMNIWASH) SEI2P
for Dishwasher hood type (NOSEM) K601 - K602
for Dishwasher hood type (NUOVA SIMONELLI) LTM1500
LTM1600
for Dishwasher hood type (SAB ITALIA) K5.1P
for Dishwasher hood type (SO.WE.BO.) 6.1P - 6.2P



SO.WE.BO. GASA8

3248175 INLET HOSE

internal \varnothing 44 mm
overall length 280 mm
for Dishwasher (AFI) A600
for Dishwasher (EUROSYSTEM) PRO400
for Dishwasher (HILTA) S41 - S42
for Dishwasher (IME OMNIWASH) 4Q82
for Dishwasher (NOSEM) C5000 - C5010 - C5020
NC501
for Dishwasher (NUOVA SIMONELLI) KIARA6
for Dishwasher (SAB ITALIA) C50H
for Dishwasher (SO.WE.BO.) 824
for Dishwasher (SOTAL) F600ECO
for Dishwasher (STORME) LT500
for Dishwasher (UNIC) A410E



SO.WE.BO. GA538

3349495 LOWER/UPPER PUMP OUTLET HOSE

internal \varnothing 29/35mm
for Dishwasher (SO.WE.BO.) 752
for Glasswasher/Cupwasher (IME OMNIWASH)
Series DUE



SO.WE.BO. GLMSIC2A04

Suitable for:

3248023 OUTLET HOSE

internal \varnothing 30 mm
 overall length 200 mm
 for Dishwasher (IME OMNIWASH) CL - CS
 for Dishwasher (SO.WE.BO.) CL - CS - DUE - UNO
 601 - 701 - 752
 for Glasswasher/Cupwasher (AFI) A35 - A35Z2 - A36
 for Glasswasher/Cupwasher (EUROSYSTEM) PRO100
 PRO200
 for Glasswasher/Cupwasher (HILTA) RB10 - RB22
 SB10 - SB22
 for Glasswasher/Cupwasher (IME OMNIWASH) DUE
 JA35 - JA36 - JA40 - JA41 - JOLLY - UNO
 for Glasswasher/Cupwasher (NOSEM) C2010L - C4010L
 NC201 - NR101 - R1010L
 for Glasswasher/Cupwasher (NUOVA SIMONELLI) KIARA1



SO.WE.BO. GL1T22

3248172 OUTLET HOSE

internal \varnothing 30 and 40 mm
 overall length 490 mm
 for Dishwasher (IME OMNIWASH) SEI1PCQ - SEI2PCQ
 for Dishwasher (SAB ITALIA) K5.2P
 for Dishwasher (UNIC) A61A - A61B
 for Dishwasher hood type (AFI) A1000L
 for Dishwasher hood type (EUROSYSTEM) PRO600
 for Dishwasher hood type (HILTA) W13 - W14 - W15
 for Dishwasher hood type (NOSEM) K601 - K602
 for Dishwasher hood type (NUOVA SIMONELLI) LTM1500
 LTM1600
 for Dishwasher hood type (SAB ITALIA) K5.1P
 for Dishwasher hood type (SO.WE.BO.) 6.1P - 6.2P
 6.2PB
 for Dishwasher hood type (SOTAL) C1300



SO.WE.BO. LI6312

Suitable for:

3248045 OUTLET HOSE

\varnothing internal 36 mm
 overall length 320 mm
 for Dishwasher (AFI) A600
 for Dishwasher (EUROSYSTEM) PRO400
 for Dishwasher (HILTA) S41 - S42
 for Dishwasher (IME OMNIWASH) QUATTROBA
 QUATTROQ82 - QUATTROSA - QUATTROT
 for Dishwasher (NOSEM) C5000 - C5010 - C5020
 NC501
 for Dishwasher (NUOVA SIMONELLI) KIARA6
 for Dishwasher (SAB ITALIA) C50H
 for Dishwasher (SO.WE.BO.) 824
 for Dishwasher (SOTAL) F600ECO
 for Dishwasher (STORME) LT500
 for Dishwasher (UNIC) A410E



SO.WE.BO. GL4T22

3248179 OUTLET HOSE

internal \varnothing 25 mm
 overall length 370 mm
 for Dishwasher (SO.WE.BO.) ONE - 601 - 701 - 752
 for Glasswasher/Cupwasher (AFI) A35 - A35Z2 - A36
 for Glasswasher/Cupwasher (EUROSYSTEM) PRO100
 PRO200
 for Glasswasher/Cupwasher (HILTA) RB10 - RB22
 SB10 - SB22
 for Glasswasher/Cupwasher (IME OMNIWASH)
 Series DUE - Series J - Series JOLLY - Series UNO
 for Glasswasher/Cupwasher (NOSEM) C2010L - C4010L
 NC201 - NR101 - R1010L
 for Glasswasher/Cupwasher (NUOVA SIMONELLI) KIARA1
 KIARA2 - KIARA4
 for Glasswasher/Cupwasher (SAB ITALIA) C35 - C36



SO.WE.BO. GS120



Suitable for:

SO.WE.BO.



3349477 PUMP OUTLET HOSE
 internal \varnothing 29-40 mm
 overall length 1275 mm
 for Dishwasher (IME OMNIWASH) SEI1PCQ - SEI2PCQ
 for Dishwasher (SAB ITALIA) K5.2P
 for Dishwasher (UNIC) A61A - A61B
 for Dishwasher hood type (AFI) A1000L
 for Dishwasher hood type (EUROSYSTEM) PRO600
 for Dishwasher hood type (HILTA) W13 - W14 - W15
 for Dishwasher hood type (NOSEM) K601 - K602
 for Dishwasher hood type (NUOVA SIMONELLI) LTM1500
 LTM1600
 for Dishwasher hood type (SAB ITALIA) K5.1P
 for Dishwasher hood type (SO.WE.BO.) 6.1P - 6.2P
 6.2PB
 for Dishwasher hood type (SOTAL) C1300



SO.WE.BO. GLMSI61P

Suitable for:

3248176 TOP/BOTTOM OUTLET HOSE
 internal \varnothing 35 - 37 - 40 mm
 overall length 1400 mm
 for Dishwasher (AFI) A600
 for Dishwasher (EUROSYSTEM) PRO400
 for Dishwasher (HILTA) S41 - S42
 for Dishwasher (IME OMNIWASH) 4Q82
 for Dishwasher (NOSEM) C5000 - C5010 - C5020
 NC501
 for Dishwasher (NUOVA SIMONELLI) KIARA6
 for Dishwasher (SAB ITALIA) C50H
 for Dishwasher (SO.WE.BO.) 824
 for Dishwasher (SOTAL) F600ECO
 for Dishwasher (STORME) LT500
 for Dishwasher (UNIC) A410E



SO.WE.BO. GLMSIC4

SO.WE.BO. GLMSIC404

Solenoid valves

3120404 SOLENOID VALVE 230V \varnothing 10.5 mm
 solenoid valve 90° - 230V 50/60Hz - max 90°C
 3/4" inlet - 1 outlet \varnothing 10.5 mm



SO.WE.BO.

3120014 SOLENOID VALVE 264 220/240V \varnothing 10 mm
 solenoid valve 180° - 220/240V 50/60Hz - max 90°C
 inlet 3/4" - triple outlet \varnothing 10 mm



SO.WE.BO. CEEV3

3120005 SOLENOID VALVE 329 220/240V \varnothing 10 mm
 solenoid valve 180° - 220/240V 50/60Hz - max 90°C
 inlet 3/4" - outlet \varnothing 10 mm



SO.WE.BO. CEEV1

3120505 SOLENOID VALVE 329 24V \varnothing 10 mm
 solenoid valve 180° - 24V 50Hz - max 90°C
 inlet 3/4" - outlet \varnothing 10 mm



SO.WE.BO. CEEV124

3120007 SOLENOID VALVE 349 220/240V \varnothing 10 mm
 solenoid valve 180° - 220/240V 50/60Hz - max 90°C
 inlet 3/4" - dual outlet \varnothing 10 mm



SO.WE.BO. CEEV2

Springs

3250211 HOOD LIFTING SPRING 925 mm
for OMNIWASH SEI 1PCQ-2PCQ-2PCQB
for SIMONELLI LTM1500-LTM1600



SO.WE.BO. GMLL6261

3318013 SPRING HOOK PULLEY
for OMNIWASH SEI 1PCQ-2PCQ-2PCQB
for SIMONELLI LTM1500-LTM1600



SO.WE.BO. GMLL6251

3053526 STAINLESS STEEL TIE ROD
for OMNIWASH SEI 1PCQ-2PCQ-2PCQB
for SIMONELLI LTM1500-LTM1600



SO.WE.BO. GMLL6271I

Switches

3319240 BIPOLAR PUSH-BUTTON
16(4)A 250V
for Dishwasher (ADLER) CF50 - CF50A
for Dishwasher hood type (ADLER) CF1201




SO.WE.BO. CEPUD08

3319222 BIPOLAR SWITCH 16A 250V



SO.WE.BO. CEPBPF0

3319195 BLACK CHANGE-OVER BUTTON WITH SERIGRAPHY
for Dishwasher (AFI) A600
for Dishwasher (EUROSYSTEM) PRO400
for Dishwasher (IME OMNIWASH) 4Q82
for Dishwasher (NOSEM) C5000 - C5010 - C5020
NC501
for Dishwasher (NUOVA SIMONELLI) KIARA6
for Dishwasher (SAB ITALIA) C50H
for Dishwasher (SO.WE.BO.) 824
for Dishwasher (STORME) LT500T



SO.WE.BO. CEDVC2

3319399 BLACK SILK-SCREEN PR.PUSH-BUTTON
for Dishwasher (NOSEM) K602S
for Dishwasher (SAB ITALIA) K5.2P
for Dishwasher (UNIC) A61A - A61B
for Dishwasher hood type (AFI) A1000L
for Dishwasher hood type (HILTA) W13 - W14 - W15
for Dishwasher hood type (IME OMNIWASH) SEI1P
SEI2P
for Dishwasher hood type (NOSEM) K601
for Dishwasher hood type (NUOVA SIMONELLI) LTM1500
for Dishwasher hood type (SAB ITALIA) K5.1P
for Dishwasher hood type (SO.WE.BO.) 6.1P - 6.2P
for Dishwasher hood type (SOTAL) C1300
for Dishwasher hood type (STORME) L501 - L502
for Dishwasher hood type (UNIC) A61



SO.WE.BO. CEGA2328



Suitable for:

SO.WE.BO.



3319400 BLACK SILK-SCREEN PR.PUSH-BUTTON

for Dishwasher (NOSEM) K602S
for Dishwasher (SAB ITALIA) K5.2P
for Dishwasher (STORME) A61A - A61B
for Dishwasher hood type (AFI) A1000L
for Dishwasher hood type (HILTA) W13 - W14 - W15
for Dishwasher hood type (IME OMNIWASH) SEI1P SEI2P
for Dishwasher hood type (NOSEM) K601
for Dishwasher hood type (NUOVA SIMONELLI) LTM1500
for Dishwasher hood type (SAB ITALIA) K5.1P
for Dishwasher hood type (SO.WE.BO.) 6.1P - 6.2P
for Dishwasher hood type (STORME) L501 - L502
for Dishwasher hood type (UNIC) A61



SO.WE.BO. CEGV2320

3319405 BLACK SILK-SCREEN PR.PUSH-BUTTON

for Dishwasher (NOSEM) K602S
for Dishwasher (SAB ITALIA) K5.2P
for Dishwasher (UNIC) A61A - A61B
for Dishwasher hood type (AFI) A1000L
for Dishwasher hood type (HILTA) W13 - W15
for Dishwasher hood type (IME OMNIWASH) SEI1P SEI2P
for Dishwasher hood type (NOSEM) K601
for Dishwasher hood type (SAB ITALIA) K5.1P
for Dishwasher hood type (SO.WE.BO.) 6.1P - 6.2P
for Dishwasher hood type (STORME) L501 - L502
for Dishwasher hood type (UNIC) A61



SO.WE.BO. CEGV2307


3319404 BLACK SILK-SCREEN PR.PUSH-BUTTON

for Dishwasher (NOSEM) K602S
for Dishwasher (SAB ITALIA) K5.2P
for Dishwasher (UNIC) A61A - A61B
for Dishwasher hood type (AFI) A1000L
for Dishwasher hood type (HILTA) W13 - W15
for Dishwasher hood type (IME OMNIWASH) SEI1P SEI2P
for Dishwasher hood type (NOSEM) K601
for Dishwasher hood type (SAB ITALIA) K5.1P
for Dishwasher hood type (SO.WE.BO.) 6.1P - 6.2P
for Dishwasher hood type (STORME) L501 - L502
for Dishwasher hood type (UNIC) A61



SO.WE.BO. CEGV2329

3319407 BLUE PUSH-BUTTON



SO.WE.BO. CETPCBSIM

Suitable for:

3319553 BLUE PUSH-BUTTON

for Dishwasher (SO.WE.BO.) 631CQ - 631CT - 691CQ
691CT
for Glasswasher/Cupwasher (IME OMNIWASH) JA35
JA36 - JA40 - JA41 - J35 - J36 - UNOAT
for Glasswasher/Cupwasher (NOSEM) NC201 - NR101
R1010
for Glasswasher/Cupwasher (SO.WE.BO.) ONECQ
ONECT - 742CQ - 742CT




SO.WE.BO. CETP25B

Suitable for:

3319627 DOUBLE CHANGE OVER SWITCH 16A 250V

for Dishwasher (CONTI) CM5000
for Dishwasher (ELETTROBAR) E50 - E51 - E52
for Dishwasher (EUROSYSTEM) A600
for Dishwasher (SAB ITALIA) K5.2P - K6.1P
for Dishwasher (SOTAL) C13001P
for Dishwasher (UNIC) A61A
for Dishwasher hood type (AFI) A1000L
for Dishwasher hood type (HILTA) W13 - W15
for Dishwasher hood type (IME OMNIWASH) SEI1P
SEI2P
for Dishwasher hood type (NOSEM) K601 - K602
for Dishwasher hood type (NUOVA SIMONELLI) LTM1500
for Dishwasher hood type (SO.WE.BO.) 6.1P - 6.2PB
for Dishwasher hood type (SOTAL) C1300
for Dishwasher hood type (UNIC) A61



SO.WE.BO. CEDP62PS

3319130 GREEN BIPOLAR CHANGE OVER SWITCH 250V 16

with indicator lamp
mounting hole 12x34 mm
for Dishwasher (SO.WE.BO.) 601
for Glasswasher/Cupwasher (AFI) A35 - A36
for Glasswasher/Cupwasher (EUROSYSTEM) PRO100
PRO200
for Glasswasher/Cupwasher (HILTA) RB10 - RB22
SB10 - SB22
for Glasswasher/Cupwasher (IME OMNIWASH) DUECL
DUECS - UNOCL - UNOCS
for Glasswasher/Cupwasher (NOSEM) C2010L - C4010L
R1010L
for Glasswasher/Cupwasher (NUOVA SIMONELLI) KIARA1
KIARA2 - KIARA4
for Glasswasher/Cupwasher (SAB ITALIA) C35 - C36



SO.WE.BO. CEINVSL

SO.WE.BO. CEIN3012

3319175 GREEN CHANGE OVER SWITCH 16A 24V

with indicator lamp
max temperature 120°C
mounting hole 22x30 mm
for Dishwasher hood type (IME OMNIWASH) SEI2P
for Dishwasher hood type (STORME) L502



SO.WE.BO. CEDVRT

SO.WE.BO. CEDV6364

3319030 GREEN CHANGE OVER SWITCH 16A 250V

with indicator lamp
max temperature 120°C
mounting hole 22x30 mm



SO.WE.BO. CEDV01VSL

3319550 GREEN PUSH-BUTTON "RINSE"

for Dishwasher (SO.WE.BO.) 631CQ - 631CT - 691CQ
691CT
for Glasswasher/Cupwasher (IME OMNIWASH) JA35
JA36 - JA40 - JA41 - J35 - J36 - UNOAT
for Glasswasher/Cupwasher (NOSEM) NC201 - NR101
R1010
for Glasswasher/Cupwasher (SO.WE.BO.) ONECQ
ONECT - 742CQ - 742CT



SO.WE.BO. CETP25VRF



Suitable for:

SO.WE.BO.



3319548 GREEN PUSH-BUTTON 0-1


for Dishwasher (SO.WE.BO.) 631CQ - 631CT - 691CQ
691CT
for Glasswasher/Cupwasher (IME OMNIWASH) JA35
JA36 - JA40 - JA41 - J35 - J36 - UNOAT
for Glasswasher/Cupwasher (NOSEM) NC201 - NR101
R1010
for Glasswasher/Cupwasher (SO.WE.BO.) ONECQ
ONECT - 742CQ - 742CT



SO.WE.BO. CETP25V01

3319408 GREY PUSH-BUTTON

for Glasswasher/Cupwasher (IME OMNIWASH) DUE
JOLLY - UNO



SO.WE.BO. CETPCSM

3319409 GREY SILK-SCREEN PR.PUSH-BUTTON


cycle start
for Dishwasher (IME OMNIWASH) J50 - J500 - N50
N500 - 4Q82 - 4Q82ECO



SO.WE.BO. CETP25GPC

3319524 ON/OFF SWITCH

with support
for Dishwasher (NOSEM) K602S
for Dishwasher (SAB ITALIA) K5.2P
for Dishwasher hood type (HILTA) W14
for Dishwasher hood type (IME OMNIWASH) SEI2P
for Dishwasher hood type (SO.WE.BO.) 6.2P
for Dishwasher hood type (SOTAL) C1300
for Dishwasher hood type (STORME) L502



SO.WE.BO. CEIN623A4NT

SO.WE.BO. CEIN623B4

Suitable for:

3319172 GREEN WARM/COLD BIPOLAR SWITCH

16(6)A/250V
for Dishwasher (AFI) A600 - A900
for Dishwasher (EUROSYSTEM) PRO400
for Dishwasher (HILTA) S41 - S42
for Dishwasher (IME OMNIWASH) 4Q82
for Dishwasher (NUOVA SIMONELLI) KIARA6
for Dishwasher (SAB ITALIA) C50H
for Dishwasher (SO.WE.BO.) 1342 - 824
for Dishwasher (SOTAL) F600
for Dishwasher (STORME) LT500M - LT500T
for Dishwasher (UNIC) A410E
for Glasswasher/Cupwasher (SO.WE.BO.) 742



SO.WE.BO. CEPUVSL

3319406 GREY SILK-SCREEN PR.PUSH-BUTTON

cold rinse
for Dishwasher (IME OMNIWASH) J50 - J500 - N50
N500 - 4Q82 - 4Q82ECO



SO.WE.BO. CETP25GRF

3319415 KEY SUPPORTING BODY

for all models



SO.WE.BO. CETP25SF

3057282 OPEN CONTACT 230V - 6A

for Dishwasher (NOSEM) K602S
for Dishwasher (SAB ITALIA) K5.2P
for Dishwasher (UNIC) A61A
for Dishwasher hood type (HILTA) W14
for Dishwasher hood type (IME OMNIWASH) SEI1P
for Dishwasher hood type (SO.WE.BO.) 6.1P - 6.2PA
for Dishwasher hood type (SOTAL) C1300
for Dishwasher hood type (STORME) L502



SO.WE.BO. CECN06244

SO.WE.BO. CECN06244NT

Suitable for:

3319174 ORANGE BIPOLAR PUSH-BUTTON 16A 250V
 mounting hole 30x22 mm
 for Dishwasher (AFI) A600
 for Dishwasher (EUROSYSTEM) PR0400
 for Dishwasher (HILTA) S41 - S42
 for Dishwasher (IME OMNIWASH) 4Q82
 for Dishwasher (NOSEM) C5000 - C5010 - C5020
 NC501
 for Dishwasher (NUOVA SIMONELLI) KIARA6
 for Dishwasher (SAB ITALIA) C50H
 for Dishwasher (SO.WE.BO.) 701 - 752 - 824
 for Dishwasher (SOTAL) F600ECO
 for Dishwasher (STORME) LT500M - LT500T
 for Dishwasher (UNIC) A410E
 for Glasswasher/Cupwasher (AFI) A35Z2
 for Glasswasher/Cupwasher (NOSEM) NC201 - NR101



SO.WE.BO. CEPUASL

Suitable for:

3319171 ORANGE BIPOLAR PUSH-BUTTON 24V
 mounting hole 30x22 mm
 for Dishwasher hood type (IME OMNIWASH) SEI2P
 for Dishwasher hood type (STORME) L502



SO.WE.BO. CEPU6374

3319173 ORANGE BIPOLAR SWITCH
 16(6)A/250V
 for drain pump
 for Dishwasher (AFI) A600 - A900
 for Dishwasher (EUROSYSTEM) PR0400
 for Dishwasher (HILTA) S41 - S42
 for Dishwasher (IME OMNIWASH) 4Q82
 for Dishwasher (NUOVA SIMONELLI) KIARA6
 for Dishwasher (SAB ITALIA) C50H
 for Dishwasher (SO.WE.BO.) 1342 - 824
 for Dishwasher (SOTAL) F600
 for Dishwasher (STORME) LT500M
 for Dishwasher (UNIC) A410E
 for Glasswasher/Cupwasher (SO.WE.BO.) 742



SO.WE.BO. CEPUPS

3319623 ORANGE BUTTON 16(4)A 250V
 for Glasswasher/Cupwasher (ELETTROBAR) 10F



SO.WE.BO. CEPU25A



Suitable for:

SO.WE.BO.



3319410 ORANGE PUSH-BUTTON

for Dishwasher (SO.WE.BO.) 631CQ - 631CT - 691CQ
691CT
for Glasswasher/Cupwasher (IME OMNIWASH) DUE - J40
J400 - J41 - J410 - N40 - N400 - N41 - N410
UNO
for Glasswasher/Cupwasher (NOSEM) NC201 - NR101
R1010
for Glasswasher/Cupwasher (SO.WE.BO.) ONECQ
ONECT - 742CQ - 742CT



SO.WE.BO. CETRP2230A

3319551 RECYCLE ORANGE PUSH-BUTTON


for Dishwasher (SO.WE.BO.) 631CQ - 631CT - 691CQ
691CT
for Glasswasher/Cupwasher (IME OMNIWASH) JA35
JA36 - JA40 - JA41 - J35 - J36 - UNOAT
for Glasswasher/Cupwasher (NOSEM) NC201 - NR101
R1010
for Glasswasher/Cupwasher (SO.WE.BO.) ONECQ
ONECT - 742CQ - 742CT



SO.WE.BO. CETP25AR

3319523 SWITCH 3 POSITIONS

with support
for Dishwasher (NOSEM) K6025
for Dishwasher (SAB ITALIA) K5.2P
for Dishwasher (SOTAL) C1300
for Dishwasher (UNIC) A61A
for Dishwasher hood type (HILTA) W14
for Dishwasher hood type (IME OMNIWASH) SEI2P
for Dishwasher hood type (NOSEM) K602
for Dishwasher hood type (SO.WE.BO.) 6.1P - 6.2PA
for Dishwasher hood type (STORME) L502



SO.WE.BO. CEIN623A4

SO.WE.BO. CESC6284

SO.WE.BO. CESC6284NT

Suitable for:

3319176 ORANGE REGENERATION BIPOLAR SWITCH


contact capacity 10(4)A 250V
for Dishwasher (AFI) A600 - A900
for Dishwasher (EUROSYSTEM) PRO400
for Dishwasher (HILTA) S41 - S42
for Dishwasher (IME OMNIWASH) 4Q82
for Dishwasher (NUOVA SIMONELLI) KIARA6
for Dishwasher (SAB ITALIA) C50H
for Dishwasher (SO.WE.BO.) 1342 - 824
for Dishwasher (SOTAL) F600
for Dishwasher (STORME) LT500M - LT500T
for Dishwasher (UNIC) A41
for Glasswasher/Cupwasher (SO.WE.BO.) 742



SO.WE.BO. CEPURIG

3319922 SINGLE POLE CHANGEOVER SWITCH

lead connector 6.35x0.8 mm



SO.WE.BO. CEDPU08

3454040 NORMALLY CLOSED CONTACT 12A 400V

for Dishwasher hood type (AFI) A1000L
for Dishwasher hood type (EUROSYSTEM) PRO600
for Dishwasher hood type (HILTA) W13 - W14 - W15
for Dishwasher hood type (IME OMNIWASH) SEI1P
SEI2P
for Dishwasher hood type (NOSEM) K601 - K602
for Dishwasher hood type (NUOVA SIMONELLI) LTM1500
LTM1600
for Dishwasher hood type (SAB ITALIA) K5.1P
for Dishwasher hood type (SO.WE.BO.) 6.1P - 6.2P
6.2PB
for Dishwasher hood type (SOTAL) C1300
for Dishwasher hood type (STORME) L501 - L502
for Dishwasher hood type (UNIC) A61



SO.WE.BO. CECNC6294

SO.WE.BO. CECNC6294NT

Suitable for:

3319132 YELLOW RINSE BIPOLAR SWITCH

bipolar switch
with indicator lamp 16A 250V
mounting hole 12x34 mm
for Dishwasher (SO.WE.BO.) 601
for Glasswasher/Cupwasher (AFI) A35 - A36
for Glasswasher/Cupwasher (EUROSYSTEM) PRO100
PRO200
for Glasswasher/Cupwasher (HILTA) RB10 - RB22
SB10 - SB22
for Glasswasher/Cupwasher (IME OMNIWASH) DUECL
DUECS - UNOCL - UNOCS
for Glasswasher/Cupwasher (NOSEM) C2010L - C4010L
R1010L
for Glasswasher/Cupwasher (NUOVA SIMONELLI) KIARA1
KIARA2 - KIARA4



SO.WE.BO. CEPUR3012

Suitable for:

3319131 YELLOW START BIPOLAR SWITCH 250V 16A

bipolar switch
with indicator lamp
mounting hole 12x34 mm
for Dishwasher (SO.WE.BO.) 601
for Glasswasher/Cupwasher (AFI) A35 - A36
for Glasswasher/Cupwasher (EUROSYSTEM) PRO100
PRO200
for Glasswasher/Cupwasher (HILTA) RB10 - RB22
SB10 - SB22
for Glasswasher/Cupwasher (IME OMNIWASH) DUECL
DUECS - UNOCL - UNOCS
for Glasswasher/Cupwasher (NOSEM) C2010L - C4010L
R1010L
for Glasswasher/Cupwasher (NUOVA SIMONELLI) KIARA1
KIARA2 - KIARA4



SO.WE.BO. CEPUC3012

Telethermometers

3441011 BLACK TELETHERMOMETER 56x25 mm 0-120°C

plastic case
capillary 1500 mm
bulb \varnothing 6x26 mm
for Dishwasher



SO.WE.BO. CETEM

Terminal blocks

3247011 6-POLE TERMINAL BLOCK FV122 40A 600V

for cable max 6 mm²
operating temperature 150°C
nominal voltage 450 V



SO.WE.BO. CEM0S3F



Suitable for:

SO.WE.BO.



Suitable for:

Thermostats

3444008 BLACK KNOB \varnothing 41 mm 0-90°C


D-shaped pin \varnothing 6x4.6 mm
 for thermostat TR/2
 for Dishwasher (LINEA BLANCA) LC-1500 - LC-1700
 LC-2000 - LC-2300 - LC-2300TR - LC-2600
 LC-2800
 for Dishwasher hood type (LINEA BLANCA) LC-3500
 LC-4000
 for Glasswasher/Cupwasher (LINEA BLANCA) LC-1000
 LC-80



SO.WE.BO. CEMTB

3744070 SAFETY THERMOSTAT FOR TANK 85°C


4 contacts 16A 250V
 for Dishwasher hood type (AFI) A1000L
 for Dishwasher hood type (EUROSYSTEM) PRO600
 for Dishwasher hood type (HILTA) W13 - W15
 for Dishwasher hood type (IME OMNIWASH) SEI2P
 SEI2PS
 for Dishwasher hood type (NOSEM) K601 - K602
 for Dishwasher hood type (NUOVA SIMONELLI) LTM1500
 LTM1600
 for Dishwasher hood type (SAB ITALIA) K5.1P
 for Dishwasher hood type (SO.WE.BO.) 6.1P - 6.2P
 for Dishwasher hood type (SOTAL) C1300
 for Dishwasher hood type (STORME) L501 - L502
 for Dishwasher hood type (UNIC) A61



SO.WE.BO. CESV001

3444246 SAFETY THERMOSTAT FOR BOILER 100°C


4 contacts 16A 250V
 for Dishwasher (AFI) A600 - A900
 for Dishwasher (SAB ITALIA) C50H
 for Dishwasher (SO.WE.BO.)
 for Dishwasher (UNIVERBAR) BRAMA - CASTA - COSMO
 LOGOS - LOGOSD - MIDI50 - MIDI50D - OMEGA
 OMEGAD - SINCRO - SINCROD - TOP
 for Dishwasher hood type (IME OMNIWASH) SEI1P
 SEI2P
 for Dishwasher hood type (UNIVERBAR) COMPACT
 for Glasswasher/Cupwasher (AFI) A35 - A35Z2 - A36
 for Glasswasher/Cupwasher (NOSEM) R1010
 for Glasswasher/Cupwasher (SAB ITALIA) C35 - C36
 for Glasswasher/Cupwasher (UNIVERBAR) BET37
 BET37D - BET40 - BET40D - ERGON - ERGOND



SO.WE.BO. CESB454

3444268 SINGLE-PHASE THERMOSTAT 0-90°C


covered capillary 1000 mm
 bulb \varnothing 6.5x95 mm
 15A 250V
 D shaft \varnothing 6x4.6 mm
 for Dishwasher (IME OMNIWASH)
 for Dishwasher (RANCILIO) - Series LS
 for Glasswasher/Cupwasher (RANCILIO) - Series LT



SO.WE.BO. CETB85

3444269 SINGLE-PHASE THERMOSTAT 52°C

covered capillary 1000 mm
bulb \varnothing 6.5x95 mm
15A 250V
for Dishwasher (AFI) A600 - A900
for Dishwasher (IME OMNIWASH)
for Dishwasher (SAB ITALIA) C50H
for Dishwasher (SO.WE.BO.)
for Glasswasher/Cupwasher (AFI) A35 - A35Z2 - A36
for Glasswasher/Cupwasher (NOSEM) R1010
for Glasswasher/Cupwasher (SAB ITALIA) C35 - C36




SO.WE.BO. CETV55

Timers

3446200 PROGRAMMER P26 2 CAMS

cycle 120 seconds, 230V 50Hz, without pin
for DRAIN PUMP
for Dishwasher (EUROSYSTEM) PRO400
for Dishwasher (HILTA) S41 - S42
for Dishwasher (IME OMNIWASH) 4Q82
for Dishwasher (NOSEM) C5000 - C5010 - C5020
NC501
for Dishwasher (NUOVA SIMONELLI) KIARA 6CF
for Dishwasher (SAB ITALIA) C50H
for Dishwasher (SO.WE.BO.) 824
for Dishwasher (SOTAL) F600ECO
for Dishwasher (STORME) LT5 - LT500M
for Glasswasher/Cupwasher (AFI) A35Z2




SO.WE.BO. CEPSTF

SO.WE.BO. CEPSTFB

3322261 PROGRAMMER P265 3 CAMS


cycle 4 minutes
230V 50/60Hz
counter-clockwise rotation
D-shaped pin \varnothing 6x4.6 mm
for Dishwasher (NUOVA SIMONELLI) KIARA6CF
for Dishwasher (SAB ITALIA) C50H
for Dishwasher (SO.WE.BO.) 1342 - 701 - 752 - 824
for Dishwasher (STORME) LT500T
for Glasswasher/Cupwasher (AFI) A35Z2
for Glasswasher/Cupwasher (IME OMNIWASH) DUE - UNO
for Glasswasher/Cupwasher (SOTAL) C230



SO.WE.BO. CEP24B

3322260 PROGRAMMER 7805DV 5 CAMS


50Hz - without pin
1° cycle 6" - 2° cycle 180"
for Dishwasher (IME OMNIWASH) GL1040 - GL1240
SEI1PCQ
for Dishwasher (SAB ITALIA) K1.5P
for Dishwasher (UNIC) A61A
for Dishwasher hood type (AFI) A1000L
for Dishwasher hood type (HILTA) W13
for Dishwasher hood type (NOSEM) K601
for Dishwasher hood type (NUOVA SIMONELLI) LTM1500
for Dishwasher hood type (SO.WE.BO.) 6.1P
for Dishwasher hood type (STORME) L501



SO.WE.BO. CET2C61P

3446199 PROGRAMMER 7805DV 5 CAMS

1° cycle 6 seconds - 2° cycle 135 seconds
230V 50Hz
for Dishwasher (IME OMNIWASH) 6.2PS
for Dishwasher (NOSEM) K602S
for Dishwasher (SAB ITALIA) K5.2P
for Dishwasher (UNIC) A61A
for Dishwasher hood type (HILTA) W14
for Dishwasher hood type (SO.WE.BO.) 6.2P
for Dishwasher hood type (SOTAL) C1300
for Dishwasher hood type (STORME) L502



SO.WE.BO. CET2C6S



Suitable for:


SO.WE.BO.



Suitable for:

3322225 TIMER P25 230V 3 CAMS


cycle 120 seconds
230V 50/60HZ
without shaft
for Dishwasher (NOSEM) R101L
for Dishwasher (NUOVA SIMONELLI) KIARA4CF
KIARA4CG
for Glasswasher/Cupwasher (EUROSYSTEM) PRO200
for Glasswasher/Cupwasher (HILTA) RB22 - SB22
for Glasswasher/Cupwasher (IME OMNIWASH) DUE - UNO
for Glasswasher/Cupwasher (NOSEM) C4010L
for Glasswasher/Cupwasher (SO.WE.BO.) 712
for Glasswasher/Cupwasher (STORME) ME400
for Glasswasher/Cupwasher (UNIC) A20 - A21



SO.WE.BO. CETF12

3322203 TIMER P255 3 CAMS

230V 50/60Hz
cycle 150 seconds
without pin
for Dishwasher (NUOVA SIMONELLI) KIARA1CF
KIARA1CG - KIARA2CF
for Dishwasher (SO.WE.BO.) 601
for Dishwasher (UNIC) A10 - A11
for Glasswasher/Cupwasher (AFI) A35 - A36
for Glasswasher/Cupwasher (EUROSYSTEM) PRO100
for Glasswasher/Cupwasher (HILTA) RB10 - SB10
for Glasswasher/Cupwasher (IME OMNIWASH) JOLLYA
JOLLYAQ - JOLLYAT - JOLLYQ - JOLLYT
for Glasswasher/Cupwasher (NOSEM) C2010L - R1010L
for Glasswasher/Cupwasher (SAB ITALIA) C35 - C36
for Glasswasher/Cupwasher (SO.WE.BO.) 600 - 631




SO.WE.BO. CETF150J

SO.WE.BO. CETF150J05

3322147 TIMER P26 5 CAMS


230V 50/60Hz
1st cycle: 4 minutes
2nd cycle: 40 seconds
for Dishwasher (AFI) A900
for Dishwasher (EUROSYSTEM) PRO400
for Dishwasher (HILTA) S42
for Dishwasher (IME OMNIWASH) DUE Q/82
QUATTROQ82 - UNOQ82
for Dishwasher (NOSEM) C5010 - NC501
for Dishwasher (NUOVA SIMONELLI) KIARA
for Dishwasher (SAB ITALIA) C50H
for Dishwasher (SO.WE.BO.) 1342 - 824
for Dishwasher (STORME) LT500T



SO.WE.BO. CETD1224B

3322146 TIMER 7807DV 7 CAMS

24V 50Hz
cycle: 6-180 seconds
for Dishwasher (IME OMNIWASH) SEI2PCQB
for Dishwasher (SAB ITALIA) K5.2P
for Dishwasher (STORME) L502BT
for Dishwasher hood type (EUROSYSTEM) PRO600
for Dishwasher hood type (HILTA) W15
for Dishwasher hood type (NOSEM) K602
for Dishwasher hood type (NUOVA SIMONELLI) LTM1600
for Dishwasher hood type (SO.WE.BO.) 6.2PB
for Dishwasher hood type (SOTAL) C1300



SO.WE.BO. CET3C6

SO.WE.BO. CET3C6NT



Wash and rinse arms and accessories

3243532 ARM ASSEMBLY SPINDLE 72 mm


for Dishwasher (SO.WE.BO.) 601 - 701 - 752
 for Glasswasher/Cupwasher (AFI) A35 - A35Z2 - A36
 for Glasswasher/Cupwasher (EUROSYSTEM) PRO100
 PRO200
 for Glasswasher/Cupwasher (HILTA) RB10 - RB22
 SB10 - SB22
 for Glasswasher/Cupwasher (IME OMNIWASH) DUEAQ
 JA35 - JA36 - JA40 - JA41 - JOLLYQ - JOLLYT
 UNOAQ - UNOQ
 for Glasswasher/Cupwasher (NOSEM) C2010L - C4010L
 NC201 - NR101 - R1010
 for Glasswasher/Cupwasher (NUOVA SIMONELLI) KIARA1
 KIARA2 - KIARA4
 for Glasswasher/Cupwasher (SAB ITALIA) C35 - C36
 for Glasswasher/Cupwasher (SO.WE.BO.) 600 - 631



SO.WE.BO. LI18F

3743265 BOTTOM RING NUT

for Dishwasher (NOSEM) K602S
 for Dishwasher (SAB ITALIA) K5.2P
 for Dishwasher (SOTAL) C13001P
 for Dishwasher (STORME) L502BT
 for Dishwasher (UNIC) A61A - A61B
 for Dishwasher hood type (AFI) A1000L
 for Dishwasher hood type (EUROSYSTEM) PRO600
 for Dishwasher hood type (HILTA) W13 - W14 - W15
 for Dishwasher hood type (IME OMNIWASH) SEI1P
 SEI2P
 for Dishwasher hood type (NOSEM) K601 - K602
 for Dishwasher hood type (NUOVA SIMONELLI) LTM1500
 LTM1600
 for Dishwasher hood type (SAB ITALIA) K5.1P
 for Dishwasher hood type (SO.WE.BO.) 6.1P - 6.2P



SO.WE.BO. LI034P

SO.WE.BO. LI034PV0

SO.WE.BO. LI034PV0GR

3743646 BOTTOM WASH ARM ASSEMBLY SUPPORT CT

for Dishwasher (AFI) A600
 for Dishwasher (HILTA) S42
 for Dishwasher (IME OMNIWASH) 4Q82
 for Dishwasher (NOSEM) C2010
 for Dishwasher (SAB ITALIA) C50H
 for Dishwasher (STORME) LT500T
 for Glasswasher/Cupwasher (AFI) A35 - A35Z2 - A36
 for Glasswasher/Cupwasher (EUROSYSTEM) PRO100
 PRO200
 for Glasswasher/Cupwasher (HILTA) RB10 - RB22
 SB10 - SB22
 for Glasswasher/Cupwasher (IME OMNIWASH) DUEAT
 JOLLYAT - JOLLYT - UNOAT - UNOT
 for Glasswasher/Cupwasher (NOSEM) C4010L - R1010
 for Glasswasher/Cupwasher (NUOVA SIMONELLI) KIARA1



SO.WE.BO. GL033

SO.WE.BO. GL033B

SO.WE.BO. GL033BGR

3243528 BRASS CAP FOR TANK HOLE 3/8"

for DISHWASHER all models
 for Dishwasher (HILTA)
 for Dishwasher (IME OMNIWASH)
 for Dishwasher (SO.WE.BO.)



SO.WE.BO. D0T38

3240135 BRASS NUT \varnothing 3/8"



SO.WE.BO. D038

SO.WE.BO. D038A



Suitable for:

3186181 O-RING 03068 EPDM

for Dishwasher (SO.WE.BO.) 601 - 701 - 752
 for Dishwasher (SOTAL) ER225
 for Glasswasher/Cupwasher (AFI) A35 - A35Z2 - A36
 for Glasswasher/Cupwasher (COMENDA) - Series B
 for Glasswasher/Cupwasher (EUROSYSTEM) PRO100
 PRO200
 for Glasswasher/Cupwasher (HILTA) RB10 - RB22
 SB10 - SB22
 for Glasswasher/Cupwasher (IME OMNIWASH) DUE
 JA35 - JA36 - JA40 - JA41 - JOLLY - UNO
 for Glasswasher/Cupwasher (NOSEM) C2010L - C4010L
 NC201 - NR101 - R1010
 for Glasswasher/Cupwasher (NUOVA SIMONELLI) KIARA1
 KIARA2 - KIARA4
 for Glasswasher/Cupwasher (SAB ITALIA) C35 - C36



SO.WE.BO.

Suitable for:



SO.WE.BO. OR122

3743200 COMPLETE LOWER HUB SUPPORT

for Dishwasher (AFI) A600 - A900
 for Dishwasher (EUROSYSTEM) PRO400
 for Dishwasher (HILTA) S41 - S42
 for Dishwasher (IME OMNIWASH) QUATTROQ - TREQ
 4Q82
 for Dishwasher (NOSEM) C5000 - C5010 - C5020
 K602S - NC501
 for Dishwasher (SAB ITALIA) C50H - K5.2P
 for Dishwasher (SOTAL) C130001P
 for Dishwasher hood type (AFI) A1000L
 for Dishwasher hood type (HILTA) W13 - W14 - W15
 for Dishwasher hood type (IME OMNIWASH) SEI1P
 SEI2P
 for Dishwasher hood type (NOSEM) K601 - K602
 for Dishwasher hood type (SAB ITALIA) K5.1P



SO.WE.BO. LI029CA

SO.WE.BO. LI029CAB

SO.WE.BO. LI029CABGR

3743054 COMPLETE WATER INLET FITTING

for Dishwasher (AFI) A600
 for Dishwasher (EUROSYSTEM) PRO400
 for Dishwasher (HILTA) S41 - S42
 for Dishwasher (IME OMNIWASH) 4Q82
 for Dishwasher (NOSEM) C5000 - C5010 - C5020
 NC501
 for Dishwasher (NUOVA SIMONELLI) KIARA6
 for Dishwasher (SAB ITALIA) C50H
 for Dishwasher (SO.WE.BO.) 824
 for Dishwasher (SOTAL) F600
 for Dishwasher (STORME) LT500
 for Dishwasher (UNIC) A410E
 for Glasswasher/Cupwasher (SO.WE.BO.) ONECQ
 ONECT



SO.WE.BO. LI430FC

SO.WE.BO. LI430FCB

SO.WE.BO. LI430FCBGR

3743807 COUPLING FOR SPINDLE FASTENING

for Glasswasher/Cupwasher (IME OMNIWASH) DUECL
 DUECS - UNOCL - UNOCS



SO.WE.BO. GRS06B

SO.WE.BO. GRS06BGR

3743215 HOOD UPPER SUPPORT



SO.WE.BO. LS6012

SO.WE.BO. LS6012B

SO.WE.BO. LS6012BGR

Suitable for:


3743808 INTERNAL FASTENING SUPPORT FOR SPINDLE
for Glasswasher/Cupwasher (IME OMNIWASH) DUECL
DUECS - UNOCL - UNOCS



SO.WE.BO. GRS03B

Suitable for:

3243526 LOWER RINSE SUPPORT
for Dishwasher (AFI) A600
for Dishwasher (EUROSYSTEM) PRO400
for Dishwasher (HILTA) S41 - S42
for Dishwasher (IME OMNIWASH) 4Q82
for Dishwasher (NOSEM) C5000 - C5010 - C5020
NC501
for Dishwasher (NUOVA SIMONELLI) KIARA6
for Dishwasher (SAB ITALIA) C50H
for Dishwasher (SO.WE.BO.) 824
for Dishwasher (SOTAL) F600
for Dishwasher (STORME) LT500
for Dishwasher (UNIC) A410E
for Glasswasher/Cupwasher (NOSEM) NR101
for Glasswasher/Cupwasher (SO.WE.BO.) ONECQ
ONECT



SO.WE.BO. LI533FOT

3243527 LOWER SUPPORT SHORT MODEL
for Dishwasher (SO.WE.BO.) 601 - 701 - 752
for Glasswasher/Cupwasher (AFI) A35 - A35Z2 - A36
for Glasswasher/Cupwasher (EUROSYSTEM) PRO100
PRO200
for Glasswasher/Cupwasher (HILTA) RB10 - RB22
SB10 - SB22
for Glasswasher/Cupwasher (IME OMNIWASH) DUEAQ
DUECL - DUECS - JA35 - JA36 - JA40 - JA41
JOLLYQ - JOLLYT - UNO AQ - UNOCL - UNOCS - UNOQ
for Glasswasher/Cupwasher (NOSEM) C2010L - C4010L
NC201 - NR101 - R1010
for Glasswasher/Cupwasher (NUOVA SIMONELLI) KIARA1
KIARA2 - KIARA4
for Glasswasher/Cupwasher (SAB ITALIA) C35 - C36
for Glasswasher/Cupwasher (SO.WE.BO.) 600 - 631



SO.WE.BO. LI029CB

SO.WE.BO. LI029CBB

SO.WE.BO. LI029CJB

SO.WE.BO. LI029CJBGR

3743056 RINSE CONNECTION
for Dishwasher (SO.WE.BO.) 601
for Glasswasher/Cupwasher (IME OMNIWASH) JOLLYA
JOLLYQ
for Glasswasher/Cupwasher (SO.WE.BO.) 600 - 631
661 - 691



SO.WE.BO. LI133FOT



Suitable for:


SO.WE.BO.



Suitable for:

3743602 LOWER/UPPER WASH ARM

length 200 mm with jets
for Dishwasher (SO.WE.BO.) 601 - 701 - 752
for Glasswasher/Cupwasher (AFI) A35 - A35Z2 - A36
for Glasswasher/Cupwasher (EUROSYSTEM) PRO100
PRO200
for Glasswasher/Cupwasher (HILTA) RB10 - RB22
SB10 - SB22
for Glasswasher/Cupwasher (IME OMNIWASH) DUEAQ
JA35 - JA36 - JA40 - JA41 - JOLLYAQ - JOLLYQ
UNOAQ - UNOQ
for Glasswasher/Cupwasher (NOSEM) C2010L - C4010L
NC201 - NR101 - R1010
for Glasswasher/Cupwasher (NUOVA SIMONELLI) KIARA1
KIARA2 - KIARA4
for Glasswasher/Cupwasher (SAB ITALIA) C35 - C36



SO.WE.BO. GL2T28BCM

3743510 LOWER/UPPER WASH ARM

length 200 mm
for Glasswasher/Cupwasher (AFI) A35 - A35Z2 - A36
for Glasswasher/Cupwasher (EUROSYSTEM) PRO100
PRO200
for Glasswasher/Cupwasher (HILTA) RB10 - RB22
SB10 - SB22
for Glasswasher/Cupwasher (IME OMNIWASH) DUEAT
JA35 - JA36 - JA40 - JA41 - JOLLYAT - JOLLYT
UNOAT - UNOT
for Glasswasher/Cupwasher (NOSEM) C2010L - C4010L
NC201 - NR101 - R1010
for Glasswasher/Cupwasher (NUOVA SIMONELLI) KIARA1
KIARA2 - KIARA4
for Glasswasher/Cupwasher (SAB ITALIA) C35 - C36



SO.WE.BO. GL1T28P

SO.WE.BO. GL1T28PBG

3743661 RINSE ARM ASSY

for Dishwasher (AFI) A600
for Dishwasher (EUROSYSTEM) PRO400
for Dishwasher (HILTA) S41 - S42
for Dishwasher (IME OMNIWASH) 4Q82
for Dishwasher (NOSEM) C5000 - C5010 - C5020
NC501
for Dishwasher (NUOVA SIMONELLI) KIARA6
for Dishwasher (SAB ITALIA) C50H
for Dishwasher (SO.WE.BO.) 601 - 701 - 752 - 824
for Dishwasher (SOTAL) F600ECO
for Dishwasher (STORME) LT500
for Dishwasher (UNIC) A410E
for Glasswasher/Cupwasher (AFI) A35 - A35Z2 - A36
for Glasswasher/Cupwasher (EUROSYSTEM) PRO100
PRO200



SO.WE.BO. GR119INB

SO.WE.BO. GR119NBGR

3743267 RINSE ARM CAP

for Dishwasher (AFI) A600
for Dishwasher (EUROSYSTEM) PRO400
for Dishwasher (HILTA) S41 - S42
for Dishwasher (IME OMNIWASH) 4Q82
for Dishwasher (NOSEM) C5000 - C5010 - C5020
NC501
for Dishwasher (SAB ITALIA) C50H
for Glasswasher/Cupwasher (AFI) A35 - A35Z2 - A36
for Glasswasher/Cupwasher (EUROSYSTEM) PRO100
PRO200
for Glasswasher/Cupwasher (HILTA) RB10 - RB22
SB10 - SB22
for Glasswasher/Cupwasher (IME OMNIWASH) DUEAQ
JOLLYAQ - JOLLYQ - UNOAQ - UNOQ
for Glasswasher/Cupwasher (NOSEM) C2010L - C4010L



SO.WE.BO. GR019G

SO.WE.BO. GR019GB

Suitable for:

3743624 RINSE ARM WITH NOZZLES AND RING NUTS

for Dishwasher (SO.WE.BO.) 601 - 701 - 752
 for Glasswasher/Cupwasher (AFI) A35 - A35Z2 - A36
 for Glasswasher/Cupwasher (EUROSYSTEM) PRO100
 PRO200
 for Glasswasher/Cupwasher (HILTA) RB10 - RB22
 SB10 - SB22
 for Glasswasher/Cupwasher (IME OMNIWASH) DUEAQ
 JA35 - JA36 - JA40 - JA41 - JOLLYAQ - JOLLYQ
 UNOAQ - UNOQ
 for Glasswasher/Cupwasher (NOSEM) C2010L - C4010L
 NC201 - NR101 - R1010
 for Glasswasher/Cupwasher (NUOVA SIMONELLI) KIARA1
 KIARA2 - KIARA4
 for Glasswasher/Cupwasher (SAB ITALIA) C35 - C36
 for Glasswasher/Cupwasher (SO.WE.BO.) 600 - 631



SO.WE.BO. LSI16C

SO.WE.BO. LSI16CB

SO.WE.BO. LSI16CDSBGR

Suitable for:

3743565 RINSE ROD SUPPORT EXTENSION OT

for Dishwasher (AFI) A600
 for Dishwasher (EUROSYSTEM) PRO400
 for Dishwasher (HILTA) S41 - S42
 for Dishwasher (IME OMNIWASH) 4Q82
 for Dishwasher (NOSEM) C5000 - C5010 - C5020
 NC501
 for Dishwasher (SAB ITALIA) C50H
 for Glasswasher/Cupwasher (AFI) A35 - A35Z2 - A36
 for Glasswasher/Cupwasher (EUROSYSTEM) PRO100
 PRO200
 for Glasswasher/Cupwasher (HILTA) RB10 - RB22
 SB10 - SB22
 for Glasswasher/Cupwasher (IME OMNIWASH) DUEAT
 JA35 - JA36 - JA40 - JA41 - JOLLYAT - JOLLYT
 UNOAT - UNOT



SO.WE.BO. GR016A

3743059 RINSE SHAFT SUPPORT

for Dishwasher (AFI) A600
 for Dishwasher (EUROSYSTEM) PRO400
 for Dishwasher (HILTA) S41 - S42
 for Dishwasher (IME OMNIWASH) 4Q82E
 for Dishwasher (NOSEM) C5000 - C5010 - C5020
 NC501
 for Dishwasher (NUOVA SIMONELLI) KIARA6
 for Dishwasher (SAB ITALIA) C50H
 for Dishwasher (SO.WE.BO.) 601 - 701 - 752 - 824
 for Dishwasher (SOTAL) F600ECO
 for Dishwasher (STORME) LT500
 for Dishwasher (UNIC) A410E
 for Glasswasher/Cupwasher (AFI) A35 - A35Z2 - A36
 for Glasswasher/Cupwasher (EUROSYSTEM) PRO100
 PRO200



SO.WE.BO. GR019A

SO.WE.BO. GR019ANT

SO.WE.BO. GR019ANTB

SO.WE.BO. GR019ANTBGR

3243529 SPINDLE EXTENSION

for Dishwasher (SO.WE.BO.) 601 - 701 - 752
 for Glasswasher/Cupwasher (AFI) A35 - A35Z2 - A36
 for Glasswasher/Cupwasher (EUROSYSTEM) PRO100
 PRO200
 for Glasswasher/Cupwasher (HILTA) RB10 - RB22
 SB10 - SB22
 for Glasswasher/Cupwasher (IME OMNIWASH) DUEAQ
 JA35 - JA36 - JA40 - JA41 - JOLLYQ - JOLLYT
 UNOAQ - UNOQ
 for Glasswasher/Cupwasher (NOSEM) C2010L - C4010L
 NC201 - NR101 - R1010
 for Glasswasher/Cupwasher (NUOVA SIMONELLI) KIARA1
 KIARA2 - KIARA4
 for Glasswasher/Cupwasher (SAB ITALIA) C35 - C36
 for Glasswasher/Cupwasher (SO.WE.BO.) 600 - 631



SO.WE.BO. LI130



Suitable for:

SO.WE.BO.



3743269 TOP RINSE ARM FITTING

for Dishwasher hood type (IME OMNIWASH) SEI1P SEI2P



SO.WE.BO. GR6193

SO.WE.BO. GR6193GR

3743645

TOP WASH ARM ASSEMBLY JET SUPPORT CT

for Dishwasher (AFI) A600
for Dishwasher (HILTA) S42
for Dishwasher (IME OMNIWASH) 4Q82
for Dishwasher (NOSEM) C2010
for Dishwasher (SAB ITALIA) C50H
for Dishwasher (STORME) LT500T
for Glasswasher/Cupwasher (AFI) A35 - A35Z2 - A36
for Glasswasher/Cupwasher (EUROSYSTEM) PRO100 PRO200
for Glasswasher/Cupwasher (HILTA) RB10 - RB22 SB10 - SB22
for Glasswasher/Cupwasher (IME OMNIWASH) DUEAT JOLLYAT - JOLLYT - UNOAT - UNOT
for Glasswasher/Cupwasher (NOSEM) C4010L - R1010
for Glasswasher/Cupwasher (NUOVA SIMONELLI) KIARA1



SO.WE.BO. GL032

SO.WE.BO. GL032B

SO.WE.BO. GL032BGR

3743603 UPPER WASH ARM

height 145 mm - length 235 mm
for Glasswasher/Cupwasher (IME OMNIWASH) DUEAT




SO.WE.BO. GL2AT28BCMI

SO.WE.BO. GL2AT28CMI

3243533 UPPER WASH ARM ASSEMBLY SUPPORT

for Dishwasher (AFI) A600
for Dishwasher (EUROSYSTEM) PRO400
for Dishwasher (HILTA) S41 - S42
for Dishwasher (IME OMNIWASH) 4Q82
for Dishwasher (NOSEM) C5000 - C5010 - C5020 NC501
for Dishwasher (NUOVA SIMONELLI) KIARA6
for Dishwasher (SAB ITALIA) C50H
for Dishwasher (SO.WE.BO.) 824
for Dishwasher (SOTAL) F600
for Dishwasher (STORME) LT500
for Dishwasher (UNIC) A410E
for Glasswasher/Cupwasher (NOSEM) NR101
for Glasswasher/Cupwasher (SO.WE.BO.) ONECQ ONECT



SO.WE.BO. LS01

SO.WE.BO. LS5

SO.WE.BO. LS5B

SO.WE.BO. LS5BGR

3243515

CORK GASKET ø 85 mm

for Dishwasher (AFI) A600
for Dishwasher (EUROSYSTEM) PRO400
for Dishwasher (HILTA) S41 - S42
for Dishwasher (IME OMNIWASH) 4Q82
for Dishwasher (NOSEM) C5000 - C5010 - C5020 NC501
for Dishwasher (NUOVA SIMONELLI) KIARA6
for Dishwasher (SAB ITALIA) C50H
for Dishwasher (SO.WE.BO.) 824
for Dishwasher (SOTAL) F600
for Dishwasher (STORME) LT500
for Dishwasher (UNIC) A410E
for Glasswasher/Cupwasher (NOSEM) NR101
for Glasswasher/Cupwasher (SO.WE.BO.) ONECQ ONECT




SO.WE.BO. LS02



Suitable for:

3243514 UPPER RING NUT \varnothing 110 mm

for Dishwasher (AFI) A600
 for Dishwasher (EUROSYSTEM) PRO400
 for Dishwasher (HILTA) C5000 - C5010 - C5020
 NC501 - S41 - S42
 for Dishwasher (IME OMNIWASH) 4Q82
 for Dishwasher (NUOVA SIMONELLI) KIARA6
 for Dishwasher (SAB ITALIA) C50H
 for Dishwasher (SO.WE.BO.) 824
 for Dishwasher (SOTAL) F600
 for Dishwasher (STORME) LT500
 for Dishwasher (UNIC) A410E
 for Glasswasher/Cupwasher (NOSEM) NR101
 for Glasswasher/Cupwasher (SO.WE.BO.) ONECQ
 ONECT



SO.WE.BO. LS03P

SO.WE.BO. LS03PGR

3243486 WASH AND RINSE ARM ASSEMBLY

length 500 mm
 for Dishwasher (AFI) A600
 for Dishwasher (EUROSYSTEM) PRO400
 for Dishwasher (HILTA) S41 - S42
 for Dishwasher (IME OMNIWASH) 4Q82
 for Dishwasher (NOSEM) C5000 - C5010 - C5020
 NC501
 for Dishwasher (NUOVA SIMONELLI) KIARA6
 for Dishwasher (SAB ITALIA) C50H
 for Dishwasher (SO.WE.BO.) 824
 for Dishwasher (SOTAL) F600
 for Dishwasher (STORME) LT500
 for Dishwasher (UNIC) A410E
 for Glasswasher/Cupwasher (NOSEM) NR101
 for Glasswasher/Cupwasher (SO.WE.BO.) ONECQ



SO.WE.BO. LSI46

SO.WE.BO. LSI46BBB

SO.WE.BO. LSI46BBBGR

SO.WE.BO. LSI66BBB

SO.WE.BO. LSI66BBBGR

SO.WE.BO.

Suitable for:



3501166 LEFT-HAND WASH JET

for Glasswasher/Cupwasher (AFI) A35 - A35Z2 - A36
 for Glasswasher/Cupwasher (EUROSYSTEM) PRO100
 PRO200
 for Glasswasher/Cupwasher (HILTA) RB10 - RB22
 SB10 - SB22
 for Glasswasher/Cupwasher (IME OMNIWASH) DUEAQ
 DUEAT - JA35 - JA36 - JA40 - JA41 - JOLLYAQ
 JOLLYAT - UNO AQ - UNOAT - UNOQ - UNOT
 for Glasswasher/Cupwasher (NOSEM) C2010L - C4010L
 NC201 - NR101 - R1010
 for Glasswasher/Cupwasher (NUOVA SIMONELLI) KIARA1
 KIARA2 - KIARA4
 for Glasswasher/Cupwasher (SAB ITALIA) C35 - C36
 for Glasswasher/Cupwasher (SOTAL) C230 - EC195
 EC255 - ER195 - ER255



SO.WE.BO. LSI016

SO.WE.BO. LSI016B

SO.WE.BO. LSI016BGR



Suitable for:

3243497 LEFTHAND RINSE ARM

complete with jets
 for Dishwasher (AFI) A600 - A900
 for Dishwasher (EUROSYSTEM) PRO400
 for Dishwasher (HILTA) S41 - S42
 for Dishwasher (IME OMNIWASH) QUATTROBA
 QUATTROSA - 4Q82
 for Dishwasher (NOSEM) C5000 - C5010 - C5020
 K602S - NC401 - NC501
 for Dishwasher (SAB ITALIA) C50H - K5.2P
 for Dishwasher hood type (AFI) A1000L
 for Dishwasher hood type (EUROSYSTEM) PRO600
 for Dishwasher hood type (HILTA) W13 - W14 - W15
 for Dishwasher hood type (IME OMNIWASH) SEI1P
 SEI2P
 for Dishwasher hood type (NOSEM) K601 - K602



SO.WE.BO. LSI46CS

SO.WE.BO. LSI46CSB

SO.WE.BO. LSI46CSBGR

3186181 O-RING 03068 EPDM

for Dishwasher (SO.WE.BO.) 601 - 701 - 752
 for Dishwasher (SOTAL) ER225
 for Glasswasher/Cupwasher (AFI) A35 - A35Z2 - A36
 for Glasswasher/Cupwasher (COMENDA) - Series B
 for Glasswasher/Cupwasher (EUROSYSTEM) PRO100
 PRO200
 for Glasswasher/Cupwasher (HILTA) RB10 - RB22
 SB10 - SB22
 for Glasswasher/Cupwasher (IME OMNIWASH) DUE
 JA35 - JA36 - JA40 - JA41 - JOLLY - UNO
 for Glasswasher/Cupwasher (NOSEM) C2010L - C4010L
 NC201 - NR101 - R1010
 for Glasswasher/Cupwasher (NUOVA SIMONELLI) KIARA1
 KIARA2 - KIARA4
 for Glasswasher/Cupwasher (SAB ITALIA) C35 - C36



SO.WE.BO. OR122

SO.WE.BO.



Suitable for:

3243501 LEFTHAND WASH ARM

complete with jets
 for Dishwasher (AFI) A600
 for Dishwasher (EUROSYSTEM) PRO400
 for Dishwasher (HILTA) S41 - S42
 for Dishwasher (IME OMNIWASH) QUATTROBA
 QUATTROSA - 4Q82
 for Dishwasher (NOSEM) C5000 - C5010 - C5020
 NC401 - NC501
 for Dishwasher (NUOVA SIMONELLI) KIARA6
 for Dishwasher (SAB ITALIA) C50H
 for Dishwasher (SO.WE.BO.) 824
 for Dishwasher (SOTAL) C13001P - F600
 for Dishwasher hood type (AFI) A1000L
 for Dishwasher hood type (EUROSYSTEM) PRO600
 for Dishwasher hood type (HILTA) W13



SO.WE.BO. LSI46BS

SO.WE.BO. LSI46BSB

1186356 O-RING 03075 EPDM

for Dishwasher (AFI) A600 - A900
 for Dishwasher (ANGELO PO) L40 - L40S - L60
 for Dishwasher (EUROSYSTEM) PRO400
 for Dishwasher (HILTA) S41 - S42
 for Dishwasher (NOSEM) C5000 - C5010 - C5020
 K602S - NC401
 for Dishwasher hood type (AFI) A1000L
 for Dishwasher hood type (ANGELO PO) L100 - L80
 for Dishwasher hood type (EUROSYSTEM) PRO600
 for Dishwasher hood type (HILTA) W13 - W14 - W15
 for Dishwasher hood type (NOSEM) K601 - K602
 for Glasswasher/Cupwasher (AFI) A35 - A35Z2 - A36
 for Glasswasher/Cupwasher (EUROSYSTEM) PRO100
 PRO200
 for Glasswasher/Cupwasher (HILTA) RB10 - RB22



SO.WE.BO. OR124



Suitable for:

3501165 RIGHT-HAND WASH JET

for Glasswasher/Cupwasher (AFI) A35 - A35Z2 - A36
 for Glasswasher/Cupwasher (EUROSYSTEM) PRO100
 PRO200
 for Glasswasher/Cupwasher (HILTA) RB10 - RB22
 SB10 - SB22
 for Glasswasher/Cupwasher (IME OMNIWASH) DUEAQ
 DUEAT - JA35 - JA36 - JA40 - JA41 - JOLLYAQ
 JOLLYAT - UNOAQ - UNOAT - UNOQ - UNOT
 for Glasswasher/Cupwasher (NOSEM) C2010L - C4010L
 NC201 - NR101 - R1010
 for Glasswasher/Cupwasher (NUOVA SIMONELLI) KIARA1
 KIARA2 - KIARA4
 for Glasswasher/Cupwasher (SAB ITALIA) C35 - C36
 for Glasswasher/Cupwasher (SOTAL) C230 - EC195
 EC255 - ER195 - ER255



SO.WE.BO. LSI015

SO.WE.BO. LSI015B

SO.WE.BO. LSI015BGR

SO.WE.BO. LSI015

3243502 RIGHTHAND WASH ARM

complete with jets
 for Dishwasher (AFI) A600
 for Dishwasher (EUROSYSTEM) PRO400
 for Dishwasher (HILTA) S41 - S42
 for Dishwasher (IME OMNIWASH) QUATTROBA
 QUATTROSA - 4Q82
 for Dishwasher (NOSEM) C5000 - C5010 - C5020
 NC401 - NC501
 for Dishwasher (NUOVA SIMONELLI) KIARA6
 for Dishwasher (SAB ITALIA) C50H
 for Dishwasher (SOTAL) C13001P - F600
 for Dishwasher hood type (AFI) A1000L
 for Dishwasher hood type (EUROSYSTEM) PRO600
 for Dishwasher hood type (HILTA) W13
 for Dishwasher hood type (IME OMNIWASH) SEI1P



SO.WE.BO. LSI46BD


SO.WE.BO. LSI46BDB

SO.WE.BO.

Suitable for:

3243496 RIGHTHAND RINSE ARM

complete with jets
 for Dishwasher (AFI) A600 - A900
 for Dishwasher (EUROSYSTEM) PRO400
 for Dishwasher (HILTA) S41 - S42
 for Dishwasher (IME OMNIWASH) QUATTROBA
 QUATTROSA - 4Q82
 for Dishwasher (NOSEM) C5000 - C5010 - C5020
 NC401 - NC501
 for Dishwasher (SAB ITALIA) K5.2P
 for Dishwasher hood type (AFI) A1000L
 for Dishwasher hood type (EUROSYSTEM) PRO600
 for Dishwasher hood type (HILTA) W13 - W14 - W15
 for Dishwasher hood type (IME OMNIWASH) SEI1P
 SEI2P
 for Dishwasher hood type (NOSEM) K601 - K602



SO.WE.BO. LSI46CD

SO.WE.BO. LSI46CDB

SO.WE.BO. LSI46CDBGR

3501168 RINSE JET

for Glasswasher/Cupwasher (AFI) A35 - A35Z2 - A36
 for Glasswasher/Cupwasher (EUROSYSTEM) PRO100
 PRO200
 for Glasswasher/Cupwasher (HILTA) RB10 - RB22
 SB10 - SB22
 for Glasswasher/Cupwasher (IME OMNIWASH) DUEAQ
 DUEAT - JA35 - JA36 - JA40 - JA41 - JOLLYAQ
 JOLLYAT - UNOAQ - UNOAT - UNOQ - UNOT
 for Glasswasher/Cupwasher (NOSEM) C2010L - C4010L
 NC201 - NR101 - R1010L
 for Glasswasher/Cupwasher (NUOVA SIMONELLI) KIARA1
 KIARA2 - KIARA4
 for Glasswasher/Cupwasher (SAB ITALIA) C35 - C36
 for Glasswasher/Cupwasher (SOTAL) C230 - EC195
 EC255 - ER195 - ER255



SO.WE.BO. LSI020

SO.WE.BO. LSI020B

SO.WE.BO. LSI020BGR





Suitable for:

3243488

RINSE JET CAP

for Dishwasher (AFI) A600 - A900
 for Dishwasher (EUROSYSTEM) PRO400
 for Dishwasher (HILTA) S41 - S42
 for Dishwasher (IME OMNIWASH) 4Q82
 for Dishwasher (NOSEM) C5000 - C5010 - C5020
 K602S - NC401 - NC501
 for Dishwasher (SAB ITALIA) C50H - K5.2P
 for Dishwasher hood type (AFI) A1000L
 for Dishwasher hood type (EUROSYSTEM) PRO600
 for Dishwasher hood type (HILTA) W13 - W14 - W15
 for Dishwasher hood type (IME OMNIWASH) SEI1P
 SEI2P
 for Dishwasher hood type (NOSEM) K601 - K602
 for Glasswasher/Cupwasher (NOSEM) NR101



SO.WE.BO. LSI022

SO.WE.BO. LSI022B

SO.WE.BO. LSI022BGR

3243493

WASH AND RINSE ARM ASSEMBLY BOSS

complete with bushings
 for Dishwasher (IME OMNIWASH) QUATTROBA
 QUATTROSA - 4Q82
 for Dishwasher (NOSEM) NC101
 for Dishwasher (SO.WE.BO.) 601 - 701 - 752
 for Dishwasher (SOTAL) EC225 - ER225
 for Dishwasher hood type (IME OMNIWASH) SEI1P
 SEI2P
 for Glasswasher/Cupwasher (AFI) A35 - A35Z2 - A36
 for Glasswasher/Cupwasher (EUROSYSTEM) PRO100
 PRO200
 for Glasswasher/Cupwasher (HILTA) RB10 - RB22
 SB10 - SB22
 for Glasswasher/Cupwasher (IME OMNIWASH) DUEAQ
 DUEAT - JA35 - JA36 - JA40 - JA41 - JOLLYQ



SO.WE.BO. LSI0607A

SO.WE.BO. LSI0607AB

SO.WE.BO. LSI0607AN

SO.WE.BO. LSI0607ANT

SO.WE.BO.



Suitable for:

3501169

RINSE JET RING

for Glasswasher/Cupwasher (AFI) A35 - A35Z2 - A36
 for Glasswasher/Cupwasher (EUROSYSTEM) PRO100
 PRO200
 for Glasswasher/Cupwasher (HILTA) RB10 - RB22
 SB10 - SB22
 for Glasswasher/Cupwasher (IME OMNIWASH) DUEAQ
 DUEAT - JA35 - JA36 - JA40 - JA41 - JOLLYAQ
 JOLLYAT - UNO AQ - UNOAT - UNOQ - UNOT
 for Glasswasher/Cupwasher (NOSEM) C2010L - C4010L
 NC201 - NR101 - R1010L
 for Glasswasher/Cupwasher (NUOVA SIMONELLI) KIARA1
 KIARA2 - KIARA4
 for Glasswasher/Cupwasher (SAB ITALIA) C35 - C36
 for Glasswasher/Cupwasher (SOTAL) C230 - EC195
 EC255 - ER195 - ER255



SO.WE.BO. LSI021

SO.WE.BO. LSI021B

SO.WE.BO. LSI021BGR

3501167

WASH JETS RING

for Dishwasher (AFI) A600 - A900
 for Dishwasher (EUROSYSTEM) PRO400
 for Dishwasher (HILTA) S41 - S42
 for Dishwasher (NOSEM) C5000 - C5010 - C5020
 NC401
 for Dishwasher hood type (AFI) A1000L
 for Dishwasher hood type (EUROSYSTEM) PRO600
 for Dishwasher hood type (HILTA) W13 - W14 - W15
 for Dishwasher hood type (NOSEM) K601 - K602
 K602S
 for Dishwasher hood type (STORME) L501 - L502
 for Glasswasher/Cupwasher (AFI) A35 - A35Z2 - A36
 for Glasswasher/Cupwasher (EUROSYSTEM) PRO100
 PRO200
 for Glasswasher/Cupwasher (HILTA) RB10 - RB22



SO.WE.BO. LSI017

SO.WE.BO. LSI017B

SO.WE.BO. LSI017BGR

Suitable for:

Suitable for:

3243491 WASH AND RINSE ARM ASSEMBLY

length 500 mm
 for Dishwasher (AFI) A900
 for Dishwasher (EUROSYSTEM) PRO400
 for Dishwasher (IME OMNIWASH) QUATTROBA QUATTROSA
 for Dishwasher (NOSEM) K602S
 for Dishwasher (SAB ITALIA) K5.2P
 for Dishwasher (SO.WE.BO.) 1342
 for Dishwasher (UNIC) A61A
 for Dishwasher hood type (HILTA) W14 - W15
 for Dishwasher hood type (IME OMNIWASH) SEI2P
 for Dishwasher hood type (NOSEM) K602
 for Dishwasher hood type (NUOVA SIMONELLI) LTM1600
 for Dishwasher hood type (SO.WE.BO.) 6.2PA - 6.2PB
 for Dishwasher hood type (UNIC) A61



SO.WE.BO. LSISA6

SO.WE.BO. LSISA6B

SO.WE.BO. LSISA6BGR

3243499 LEFTHAND WASH ARM

complete with jets
 for Dishwasher (AFI) A900
 for Dishwasher (EUROSYSTEM) PRO400
 for Dishwasher (NOSEM) K602S
 for Dishwasher (SAB ITALIA) K5.2P
 for Dishwasher (SO.WE.BO.) 1342
 for Dishwasher (STORME) L502BT
 for Dishwasher (UNIC) A61A
 for Dishwasher hood type (HILTA) W14 - W15
 for Dishwasher hood type (IME OMNIWASH) SEI2P
 for Dishwasher hood type (NOSEM) K602
 for Dishwasher hood type (NUOVA SIMONELLI) LTM1600
 for Dishwasher hood type (SO.WE.BO.) 6.2PA - 6.2PB
 for Dishwasher hood type (SOTAL) C1300
 for Dishwasher hood type (STORME) L502



SO.WE.BO. LSISA6BS

SO.WE.BO. LSISA6BSB

SO.WE.BO. LSISA6BSBGR

3243497 LEFTHAND RINSE ARM

complete with jets
 for Dishwasher (AFI) A600 - A900
 for Dishwasher (EUROSYSTEM) PRO400
 for Dishwasher (HILTA) S41 - S42
 for Dishwasher (IME OMNIWASH) QUATTROBA QUATTROSA - 4Q82
 for Dishwasher (NOSEM) C5000 - C5010 - C5020 K602S - NC401 - NC501
 for Dishwasher (SAB ITALIA) C50H - K5.2P
 for Dishwasher hood type (AFI) A1000L
 for Dishwasher hood type (EUROSYSTEM) PRO600
 for Dishwasher hood type (HILTA) W13 - W14 - W15
 for Dishwasher hood type (IME OMNIWASH) SEI1P SEI2P
 for Dishwasher hood type (NOSEM) K601 - K602



SO.WE.BO. LSIA46CS

SO.WE.BO. LSIA46CSB

SO.WE.BO. LSIA46CSBGR

3243492 LEFTHAND WASH JET LARGE MODEL

for Dishwasher (AFI) A900
 for Dishwasher (EUROSYSTEM) PRO400
 for Dishwasher (NOSEM) K602S
 for Dishwasher (SAB ITALIA) K5.2P
 for Dishwasher (SO.WE.BO.) 1342
 for Dishwasher (STORME) L502BT
 for Dishwasher (UNIC) A61A
 for Dishwasher hood type (EUROSYSTEM) PRO600
 for Dishwasher hood type (HILTA) W14 - W15
 for Dishwasher hood type (NOSEM) K602
 for Dishwasher hood type (NUOVA SIMONELLI) LTM1600
 for Dishwasher hood type (SO.WE.BO.) 6.2PA - 6.2PB
 for Dishwasher hood type (SOTAL) C1300
 for Dishwasher hood type (STORME) L502
 for Dishwasher hood type (UNIC) A61



SO.WE.BO. LSISA16

SO.WE.BO. LSISA16B


SO.WE.BO. LSISA16BGR



Suitable for:

3243496 RIGHTHAND RINSE ARM

complete with jets
 for Dishwasher (AFI) A600 - A900
 for Dishwasher (EUROSYSTEM) PRO400
 for Dishwasher (HILTA) S41 - S42
 for Dishwasher (IME OMNIWASH) QUATTROBA
 QUATTROSA - 4Q82
 for Dishwasher (NOSEM) C5000 - C5010 - C5020
 NC401 - NC501
 for Dishwasher (SAB ITALIA) K5.2P
 for Dishwasher hood type (AFI) A1000L
 for Dishwasher hood type (EUROSYSTEM) PRO600
 for Dishwasher hood type (HILTA) W13 - W14 - W15
 for Dishwasher hood type (IME OMNIWASH) SEI1P
 SEI2P
 for Dishwasher hood type (NOSEM) K601 - K602



SO.WE.BO. LSI46CD

SO.WE.BO. LSI46CDB

SO.WE.BO. LSI46CDBGR

3243487 RIGHTHAND WASH JET LARGE MODEL

for Dishwasher (AFI) A900
 for Dishwasher (NOSEM) K602S
 for Dishwasher (SAB ITALIA) K5.2P
 for Dishwasher (SO.WE.BO.) 1342
 for Dishwasher (STORME) L502BT
 for Dishwasher hood type (EUROSYSTEM) PRO600
 for Dishwasher hood type (HILTA) W14 - W15
 for Dishwasher hood type (IME OMNIWASH) SEI2P
 for Dishwasher hood type (NOSEM) K602
 for Dishwasher hood type (NUOVA SIMONELLI) LTM1600
 for Dishwasher hood type (SO.WE.BO.) 6.2PA - 6.2PB
 for Dishwasher hood type (SOTAL) C1300
 for Dishwasher hood type (STORME) L502



SO.WE.BO. LSISA15

SO.WE.BO. LSISA15B

SO.WE.BO. LSISA15BGR

SO.WE.BO.



Suitable for:

3243498 RIGHTHAND WASH ARM

complete with jets
 for Dishwasher (AFI) A900
 for Dishwasher (EUROSYSTEM) PRO400
 for Dishwasher (NOSEM) K602S
 for Dishwasher (SAB ITALIA) K5.2P
 for Dishwasher (SO.WE.BO.) 1342
 for Dishwasher (STORME) L502BT
 for Dishwasher (UNIC) A61A
 for Dishwasher hood type (HILTA) W14 - W15
 for Dishwasher hood type (IME OMNIWASH) SEI2P
 for Dishwasher hood type (NOSEM) K602
 for Dishwasher hood type (NUOVA SIMONELLI) LTM1600
 for Dishwasher hood type (SO.WE.BO.) 6.2PA - 6.2PB
 for Dishwasher hood type (SOTAL) C1300
 for Dishwasher hood type (STORME) L502



SO.WE.BO. LSISA6BD

SO.WE.BO. LSISA6BDB

SO.WE.BO. LSISA6BDBGR

3501168 RINSE JET

for Glasswasher/Cupwasher (AFI) A35 - A35Z2 - A36
 for Glasswasher/Cupwasher (EUROSYSTEM) PRO100
 PRO200
 for Glasswasher/Cupwasher (HILTA) RB10 - RB22
 SB10 - SB22
 for Glasswasher/Cupwasher (IME OMNIWASH) DUEAQ
 DUEAT - JA35 - JA36 - JA40 - JA41 - JOLLYAQ
 JOLLYAT - UNOQA - UNOAT - UNOQ - UNOT
 for Glasswasher/Cupwasher (NOSEM) C2010L - C4010L
 NC201 - NR101 - R1010L
 for Glasswasher/Cupwasher (NUOVA SIMONELLI) KIARA1
 KIARA2 - KIARA4
 for Glasswasher/Cupwasher (SAB ITALIA) C35 - C36
 for Glasswasher/Cupwasher (SOTAL) C230 - EC195
 EC255 - ER195 - ER255



SO.WE.BO. LSI020

SO.WE.BO. LSI020B

SO.WE.BO. LSI020BGR



Suitable for:

3243488 RINSE JET CAP

for Dishwasher (AFI) A600 - A900
 for Dishwasher (EUROSYSTEM) PRO400
 for Dishwasher (HILTA) S41 - S42
 for Dishwasher (IME OMNIWASH) 4Q82
 for Dishwasher (NOSEM) C5000 - C5010 - C5020
 K602S - NC401 - NC501
 for Dishwasher (SAB ITALIA) C50H - K5.2P
 for Dishwasher hood type (AFI) A1000L
 for Dishwasher hood type (EUROSYSTEM) PRO600
 for Dishwasher hood type (HILTA) W13 - W14 - W15
 for Dishwasher hood type (IME OMNIWASH) SEI1P
 SEI2P
 for Dishwasher hood type (NOSEM) K601 - K602
 for Glasswasher/Cupwasher (NOSEM) NR101



SO.WE.BO. LSI022

SO.WE.BO. LSI022B

SO.WE.BO. LSI022BGR

3243530 SPINDLE EXTENSION

for Dishwasher (AFI) A600 - A900
 for Dishwasher (EUROSYSTEM) PRO400
 for Dishwasher (HILTA) S41 - S42
 for Dishwasher (IME OMNIWASH) QUATTROQ - TREQ
 4Q82
 for Dishwasher (NOSEM) K602S
 for Dishwasher (SAB ITALIA) C50H - K5.2P
 for Dishwasher (SOTAL) C130001P
 for Dishwasher hood type (AFI) A1000L
 for Dishwasher hood type (HILTA) W13 - W14 - W15
 for Dishwasher hood type (IME OMNIWASH) SEI1P
 SEI2P
 for Dishwasher hood type (NOSEM) K601 - K602
 for Dishwasher hood type (SAB ITALIA) K5.1P
 for Dishwasher hood type (SOTAL) C1300



SO.WE.BO. LI330

SO.WE.BO.



Suitable for:

3501169 RINSE JET RING

for Glasswasher/Cupwasher (AFI) A35 - A35Z2 - A36
 for Glasswasher/Cupwasher (EUROSYSTEM) PRO100
 PRO200
 for Glasswasher/Cupwasher (HILTA) RB10 - RB22
 SB10 - SB22
 for Glasswasher/Cupwasher (IME OMNIWASH) DUEAQ
 DUEAT - JA35 - JA36 - JA40 - JA41 - JOLLYAQ
 JOLLYAT - UNOQAQ - UNOAT - UNOQ - UNOT
 for Glasswasher/Cupwasher (NOSEM) C2010L - C4010L
 NC201 - NR101 - R1010L
 for Glasswasher/Cupwasher (NUOVA SIMONELLI) KIARA1
 KIARA2 - KIARA4
 for Glasswasher/Cupwasher (SAB ITALIA) C35 - C36
 for Glasswasher/Cupwasher (SOTAL) C230 - EC195
 EC255 - ER195 - ER255



SO.WE.BO. LSI021

SO.WE.BO. LSI021B

SO.WE.BO. LSI021BGR

3243516 UPPER WASH ARM ASSEMBLY SUPPORT

for Dishwasher (AFI) A600 - A900
 for Dishwasher (EUROSYSTEM) PRO400
 for Dishwasher (HILTA) S41 - S42
 for Dishwasher (IME OMNIWASH) 4Q82
 for Dishwasher (NOSEM) C5000 - K602S - NC401
 for Dishwasher (NUOVA SIMONELLI) KIARA6
 for Dishwasher (SAB ITALIA) C50H - K5.2P
 for Dishwasher hood type (AFI) A1000L
 for Dishwasher hood type (EUROSYSTEM) PRO600
 for Dishwasher hood type (HILTA) W13 - W14 - W15
 for Dishwasher hood type (IME OMNIWASH) SEI1P
 SEI2P
 for Dishwasher hood type (NOSEM) K601 - K602
 for Dishwasher hood type (NUOVA SIMONELLI) LTM1500
 LTM1600



SO.WE.BO. LS08+LS6012

SO.WE.BO. LS6012+LS08

SO.WE.BO. LS6012B+LS08

SO.WE.BO. LS6012BGR+LS08



Suitable for:

3243493 WASH AND RINSE ARM ASSEMBLY BOSS

complete with bushings
 for Dishwasher (IME OMNIWASH) QUATTROBA
 QUATTROSA - 4Q82
 for Dishwasher (NOSEM) NC101
 for Dishwasher (SO.WE.BO.) 601 - 701 - 752
 for Dishwasher (SOTAL) EC225 - ER225
 for Dishwasher hood type (IME OMNIWASH) SEI1P
 SEI2P
 for Glasswasher/Cupwasher (AFI) A35 - A35Z2 - A36
 for Glasswasher/Cupwasher (EUROSYSTEM) PRO100
 PRO200
 for Glasswasher/Cupwasher (HILTA) RB10 - RB22
 SB10 - SB22
 for Glasswasher/Cupwasher (IME OMNIWASH) DUEAQ
 DUEAT - JA35 - JA36 - JA40 - JA41 - JOLLYQ



SO.WE.BO. LSI0607A

SO.WE.BO. LSI0607AB

SO.WE.BO. LSI0607AN

SO.WE.BO. LSI0607ANT

3501167 WASH JETS RING

for Dishwasher (AFI) A600 - A900
 for Dishwasher (EUROSYSTEM) PRO400
 for Dishwasher (HILTA) S41 - S42
 for Dishwasher (NOSEM) C5000 - C5010 - C5020
 NC401
 for Dishwasher hood type (AFI) A1000L
 for Dishwasher hood type (EUROSYSTEM) PRO600
 for Dishwasher hood type (HILTA) W13 - W14 - W15
 for Dishwasher hood type (NOSEM) K601 - K602
 K602S
 for Dishwasher hood type (STORME) L501 - L502
 for Glasswasher/Cupwasher (AFI) A35 - A35Z2 - A36
 for Glasswasher/Cupwasher (EUROSYSTEM) PRO100
 PRO200
 for Glasswasher/Cupwasher (HILTA) RB10 - RB22



SO.WE.BO. LSI017

SO.WE.BO. LSI017B

SO.WE.BO. LSI017BGR

SO.WE.BO.



Suitable for:

3243531 WASH ARM ASSEMBLY SPINDLE 85 mm

for Dishwasher (AFI) A900
 for Dishwasher (EUROSYSTEM) PRO400
 for Dishwasher (IME OMNIWASH) QUATTROQ - TREQ
 4Q82
 for Dishwasher (NOSEM) K602S
 for Dishwasher (SAB ITALIA) K5.2P
 for Dishwasher (SO.WE.BO.) 1342
 for Dishwasher (SOTAL) C130001P
 for Dishwasher hood type (AFI) A1000L
 for Dishwasher hood type (HILTA) W13 - W14 - W15
 for Dishwasher hood type (IME OMNIWASH) SEI1P
 SEI2P
 for Dishwasher hood type (NOSEM) K601 - K602
 for Dishwasher hood type (NUOVA SIMONELLI) LTM1500
 LTM1600



SO.WE.BO. LS08

Suitable for:

Suitable for:

3243524 WASH ARM ASSEMBLY LOCKING NUT

for Dishwasher (SO.WE.BO.) 601 - 701 - 752
 for Glasswasher/Cupwasher (AFI) A35 - A35Z2 - A36
 for Glasswasher/Cupwasher (EUROSYSTEM) PRO100
 PRO200
 for Glasswasher/Cupwasher (HILTA) RB10 - RB22
 SB10 - SB22
 for Glasswasher/Cupwasher (IME OMNIWASH) DUEAQ
 DUEAT - JA35 - JA36 - JA40 - JA41 - JOLLYQ
 JOLLYT - UNOQ - UNOT
 for Glasswasher/Cupwasher (NOSEM) C2010L - C4010L
 NC201 - NR101 - R1010
 for Glasswasher/Cupwasher (NUOVA SIMONELLI) KIARA1
 KIARA2 - KIARA4
 for Glasswasher/Cupwasher (SAB ITALIA) C35 - C36
 for Glasswasher/Cupwasher (SO.WE.BO.) 600 - 631



SO.WE.BO. LS09P

SO.WE.BO. LS09PB

SO.WE.BO. LS09PBGR

3743322 WASH ARM ASSEMBLY 310 mm

for Dishwasher (SO.WE.BO.) 601 - 701 - 752
 for Glasswasher/Cupwasher (AFI) A35 - A35Z2 - A36
 for Glasswasher/Cupwasher (EUROSYSTEM) PRO100
 PRO200
 for Glasswasher/Cupwasher (HILTA) RB10 - RB22
 SB10 - SB22
 for Glasswasher/Cupwasher (IME OMNIWASH) JA35
 JA350 - JA36 - JA360 - JOLLYAQ - JOLLYQ - J35
 J350 - J36 - J360
 for Glasswasher/Cupwasher (NOSEM) C2010L - C4010L
 NC201 - NR101 - R1010
 for Glasswasher/Cupwasher (NUOVA SIMONELLI) KIARA1
 KIARA2 - KIARA4
 for Glasswasher/Cupwasher (SAB ITALIA) C35 - C36
 for Glasswasher/Cupwasher (SO.WE.BO.) 600 - 631



SO.WE.BO. LSI16


SO.WE.BO. LSI16BBB

SO.WE.BO. LSI16BBBGR

SO.WE.BO. LSI16CSL

3743263 WASH ARM ASSEMBLY 370 mm

for Glasswasher/Cupwasher (IME OMNIWASH) DUEAQ
 J40 - J400 - J41 - J410 - N40 - N400 - N41
 N410 - UNOAQ - UNOQ



SO.WE.BO. LSI26

SO.WE.BO. LSI26B


SO.WE.BO. LSI26BBB

SO.WE.BO. LSI26BBBGR

SO.WE.BO. LSI26CSL

3743268 WASH ARM CAP

for Dishwasher (IME OMNIWASH) QUATTROBA
 QUATTROSA
 for Dishwasher (SOTAL) C13001P
 for Dishwasher (STORME) LT501
 for Dishwasher (UNIC) A61B
 for Dishwasher hood type (AFI) A1000L
 for Dishwasher hood type (HILTA) W13
 for Dishwasher hood type (IME OMNIWASH) SEI1P
 for Dishwasher hood type (NOSEM) K601
 for Dishwasher hood type (NUOVA SIMONELLI) LTM1500
 for Dishwasher hood type (SAB ITALIA) K5.1P
 for Glasswasher/Cupwasher (IME OMNIWASH) DUEAQ
 JOLLYAQ - JOLLYQ - UNOAQ - UNOQ



SO.WE.BO. LSI018

SO.WE.BO. LSI018B

SO.WE.BO. LSI018BGR




Suitable for:

SO.WE.BO.



3743562 WASH ARM CT MOD.2/4 WHITE

for Dishwasher (AFI) A600
 for Dishwasher (EUROSYSTEM) PRO400
 for Dishwasher (HILTA) S41 - S42
 for Dishwasher (IME OMNIWASH) 4Q82
 for Dishwasher (NOSEM) C5000 - C5010 - C5020
 NC501
 for Dishwasher (NUOVA SIMONELLI) KIARA6
 for Dishwasher (SAB ITALIA) C50H
 for Dishwasher (SO.WE.BO.) 824
 for Dishwasher (SOTAL) F600ECO
 for Dishwasher (STORME) LT500
 for Dishwasher (UNIC) A410E



SO.WE.BO. GL034A

SO.WE.BO. GL034AB

3743264 WASH ARM 200 mm

for Dishwasher (SO.WE.BO.) 601 - 701 - 752
 for Glasswasher/Cupwasher (AFI) A35 - A35Z2 - A36
 for Glasswasher/Cupwasher (EUROSYSTEM) PRO100
 PRO200
 for Glasswasher/Cupwasher (HILTA) RB10 - RB22
 SB10 - SB22
 for Glasswasher/Cupwasher (IME OMNIWASH) JA35
 JA350 - JA36 - JA360 - JOLLYAQ - JOLLYQ - J35
 J350 - J36 - J360
 for Glasswasher/Cupwasher (NOSEM) C2010L - C4010L
 NC201 - NR101 - R1010
 for Glasswasher/Cupwasher (NUOVA SIMONELLI) KIARA1
 KIARA2 - KIARA4
 for Glasswasher/Cupwasher (SAB ITALIA) C35 - C36
 for Glasswasher/Cupwasher (SO.WE.BO.) 600 - 631



SO.WE.BO. GL030BGR

SO.WE.BO. GL031BGR

SO.WE.BO. GL1T28BCM

SO.WE.BO. GL1T28CM

SO.WE.BO. GL1T28PBGR

SO.WE.BO. LS116CDSB

3743576 WASH ARM 4CT MOULD 24

for Dishwasher (AFI) A600
 for Dishwasher (EUROSYSTEM) PRO400
 for Dishwasher (HILTA) S41 - S42
 for Dishwasher (IME OMNIWASH) 4Q82
 for Dishwasher (NOSEM) C5000 - C5010 - C5020
 NC501
 for Dishwasher (NUOVA SIMONELLI) KIARA6
 for Dishwasher (SAB ITALIA) C50H
 for Dishwasher (SO.WE.BO.) 824
 for Dishwasher (SOTAL) 600ECO
 for Dishwasher (STORME) LT500
 for Dishwasher (UNIC) A410E



SO.WE.BO. GL4T27

3743568 WASH COLUMN EXTENSION

for Dishwasher (SO.WE.BO.) 601 - 701 - 752
 for Glasswasher/Cupwasher (AFI) A35 - A35Z2 - A36
 for Glasswasher/Cupwasher (EUROSYSTEM) PRO100
 PRO200
 for Glasswasher/Cupwasher (HILTA) RB10 - RB22
 SB10 - SB22
 for Glasswasher/Cupwasher (IME OMNIWASH) DUEAT
 JA35 - JA36 - JA40 - JA41 - JOLLYAT - JOLLYT
 UNOAT - UNOT
 for Glasswasher/Cupwasher (NOSEM) C2010L - C4010L
 NC201 - NR101 - R1010
 for Glasswasher/Cupwasher (NUOVA SIMONELLI) KIARA1
 KIARA2 - KIARA4
 for Glasswasher/Cupwasher (SAB ITALIA) C35 - C36
 for Glasswasher/Cupwasher (SO.WE.BO.) 600 - 631



SO.WE.BO. GL2T32

SO.WE.BO. GL2T32BGR

Suitable for:

Suitable for:

3743055 WASH COLUMN 380 mm

for Dishwasher (SO.WE.BO.) 601 - 701 - 752
 for Glasswasher/Cupwasher (AFI) A35 - A35Z2 - A36
 for Glasswasher/Cupwasher (EUROSYSTEM) PRO100
 PRO200
 for Glasswasher/Cupwasher (HILTA) RB10 - RB22
 SB10 - SB22
 for Glasswasher/Cupwasher (IME OMNIWASH) DUEAQ
 DUEAT - JA35 - JA36 - JA40 - JA41 - JOLLYQ
 JOLLYT - UNOQ - UNOT
 for Glasswasher/Cupwasher (NOSEM) C2010L - C4010L
 NC201 - NR101 - R1010
 for Glasswasher/Cupwasher (NUOVA SIMONELLI) KIARA1
 KIARA2 - KIARA4
 for Glasswasher/Cupwasher (SAB ITALIA) C35 - C36
 for Glasswasher/Cupwasher (SO.WE.BO.) 600 - 631



SO.WE.BO. GL1T27

SO.WE.BO. GL1T27B

SO.WE.BO. GL1T27BGR

3743524 WASH ARM EXTENSION

for Dishwasher (SO.WE.BO.) 601 - 701 - 752
 for Glasswasher/Cupwasher (AFI) A35 - A35Z2 - A36
 for Glasswasher/Cupwasher (EUROSYSTEM) PRO100
 PRO200
 for Glasswasher/Cupwasher (HILTA) RB10 - RB22
 SB10 - SB22
 for Glasswasher/Cupwasher (IME OMNIWASH) DUEAQ
 JA40 - JA41 - JOLLYAT - JOLLYT - UNOAT - UNOT
 for Glasswasher/Cupwasher (NOSEM) C2010L - C4010L
 NC201 - NR101 - R1010
 for Glasswasher/Cupwasher (NUOVA SIMONELLI) KIARA1
 KIARA2 - KIARA4
 for Glasswasher/Cupwasher (SAB ITALIA) C35 - C36
 for Glasswasher/Cupwasher (SO.WE.BO.) 600 - 631
 661 - 691 - 712 - 742



SO.WE.BO. GL1T32

SO.WE.BO. GL1T32B

SO.WE.BO. GL1T32BGR

3743057 WATER INLET SUPPORT

for Dishwasher (SO.WE.BO.) 601 - 701 - 752
 for Glasswasher/Cupwasher (AFI) A35 - A35Z2 - A36
 for Glasswasher/Cupwasher (EUROSYSTEM) PRO100
 PRO200
 for Glasswasher/Cupwasher (HILTA) RB10 - RB22
 SB10 - SB22
 for Glasswasher/Cupwasher (IME OMNIWASH) DUEAQ
 DUEAT - JA35 - JA36 - JA40 - JA41 - JOLLYQ
 JOLLYT - UNOQ - UNOT
 for Glasswasher/Cupwasher (NOSEM) C2010L - C4010L
 NC201 - NR101 - R1010
 for Glasswasher/Cupwasher (NUOVA SIMONELLI) KIARA1
 KIARA2 - KIARA4
 for Glasswasher/Cupwasher (SAB ITALIA) C35 - C36
 for Glasswasher/Cupwasher (SO.WE.BO.) 600 - 631



SO.WE.BO. LI126FC

SO.WE.BO. LI126FCB

SO.WE.BO. LI126FCBGR

3743058 GAS NUT \varnothing 1"

for Dishwasher (SO.WE.BO.) 601 - 701 - 752
 for Glasswasher/Cupwasher (AFI) A35 - A35Z2 - A36
 for Glasswasher/Cupwasher (EUROSYSTEM) PRO100
 PRO200
 for Glasswasher/Cupwasher (HILTA) RB10 - RB22
 SB10 - SB22
 for Glasswasher/Cupwasher (IME OMNIWASH) DUEAQ
 DUEAT - JA35 - JA36 - JA40 - JA41 - JOLLYQ
 JOLLYT - UNOQ - UNOT
 for Glasswasher/Cupwasher (NOSEM) C2010L - C4010L
 NC201 - NR101 - R1010
 for Glasswasher/Cupwasher (NUOVA SIMONELLI) KIARA1
 KIARA2 - KIARA4
 for Glasswasher/Cupwasher (SAB ITALIA) C35 - C36
 for Glasswasher/Cupwasher (SO.WE.BO.) 600 - 631



SO.WE.BO. DP1

SO.WE.BO. DP1GR



Suitable for:

3186847 OR GASKET 03131 EPDM

for Dishwasher (SO.WE.BO.) 601 - 701 - 752
 for Glasswasher/Cupwasher (AFI) A35 - A35Z2 - A36
 for Glasswasher/Cupwasher (EUROSYSTEM) PRO100
 PRO200
 for Glasswasher/Cupwasher (HILTA) RB10 - RB22
 SB10 - SB22
 for Glasswasher/Cupwasher (IME OMNIWASH) DUECL
 DUECS - JA35 - JA36 - JA40 - JA41 - JOLLY
 UNOCL - UNOCS
 for Glasswasher/Cupwasher (NOSEM) C2010L - C4010L
 NC201 - NR101 - R1010
 for Glasswasher/Cupwasher (NUOVA SIMONELLI) KIARA1
 KIARA2 - KIARA4
 for Glasswasher/Cupwasher (SAB ITALIA) C35 - C36
 for Glasswasher/Cupwasher (SO.WE.BO.) 600 - 631



SO.WE.BO. OR3131

SO.WE.BO.

Suitable for:



3743806 WHITE LH WASH SHAFT WITH JETS

for Glasswasher/Cupwasher (IME OMNIWASH) JA40
 JA400 - JA401 - JA41



SO.WE.BO. LSI16BSB

3743805 WHITE RH WASH SHAFT WITH JETS

for Glasswasher/Cupwasher (IME OMNIWASH) JA40
 JA400 - JA401 - JA41



SO.WE.BO. LSI16BDB

SO.WE.BO. LSI16BDBGR

Wash jets and accessories

3501255 RINSE JET COMPLETE



SO.WE.BO. GR019B

SO.WE.BO. GR019BB

SO.WE.BO. GR019D

SO.WE.BO. GR019DB

SO.WE.BO. GR020

SO.WE.BO. GR020B

SO.WE.BO. GR020BGR

SO.WE.BO. GR021

SO.WE.BO. GR021B



Wash jets and accessories

3501161 WASH JET

for Dishwasher (AFI) A600
 for Dishwasher (EUROSYSTEM) PRO400
 for Dishwasher (HILTA) C5000 - C5010 - C5020
 NC501 - S41 - S42
 for Dishwasher (IME OMNIWASH) 4Q82
 for Dishwasher (SAB ITALIA) C50H
 for Dishwasher (STORME) LT500T
 for Glasswasher/Cupwasher (AFI) A35Z2 - A36
 for Glasswasher/Cupwasher (EUROSYSTEM) PRO100
 PRO200
 for Glasswasher/Cupwasher (HILTA) C2010L - RB10
 RB22 - R1010 - SB10 - SB22
 for Glasswasher/Cupwasher (IME OMNIWASH) DUEAQ
 DUEAT - JOLLYAQ - JOLLYAT - UNOAQ - UNOAT
 UNOQ - UNOT



SO.WE.BO. GL030

SO.WE.BO. GL030B

SO.WE.BO. GL030BGR

3501162 WASH JET

for Dishwasher (AFI) A600
 for Dishwasher (EUROSYSTEM) PRO400
 for Dishwasher (HILTA) S41 - S42
 for Dishwasher (IME OMNIWASH) 4Q82
 for Dishwasher (NOSEM) C5000 - C5010 - C5020
 NC501
 for Dishwasher (SAB ITALIA) C50H
 for Dishwasher (STORME) LT500T
 for Glasswasher/Cupwasher (AFI) A35 - A35Z2 - A36
 for Glasswasher/Cupwasher (EUROSYSTEM) PRO100
 PRO200
 for Glasswasher/Cupwasher (HILTA) RB10 - RB22
 SB10 - SB22
 for Glasswasher/Cupwasher (IME OMNIWASH) DUEAQ
 DUEAT - JOLLYAQ - JOLLYAT - UNOAQ - UNOAT



SO.WE.BO. GL031

SO.WE.BO. GL031B

SO.WE.BO. GL031BGR

Washing baskets and accessories

3055351 COMPLETE ROTATING RACK SUPPORT \varnothing 292 mm

height 120 mm
 complete with spindle \varnothing 15 mm
 for Dishwasher (IME OMNIWASH) DUET
 for Glasswasher/Cupwasher (IME OMNIWASH) DUEAT
 JOLLYAQ - JOLLYAT - JOLLYQ - JOLLYT - UNOAT
 UNOT



SO.WE.BO. GG1T1

SO.WE.BO. GG1T1B

SO.WE.BO. GG1T1BGR

3055354 BASE TIE ROD 172 mm

for Dishwasher (AFI) A600 - A900
 for Dishwasher (EUROSYSTEM) PRO400
 for Dishwasher (HILTA) S41 - S42
 for Dishwasher (NOSEM) C2050 - C5000 - C5010
 NC501
 for Dishwasher hood type (AFI) A1000L
 for Dishwasher hood type (EUROSYSTEM) PRO600
 for Dishwasher hood type (HILTA) W13 - W14 - W15
 for Dishwasher hood type (NOSEM) K601 - K602
 for Glasswasher/Cupwasher (AFI) A35 - A35Z2 - A36
 for Glasswasher/Cupwasher (EUROSYSTEM) PRO100
 PRO200
 for Glasswasher/Cupwasher (HILTA) RB10 - RB22
 SB10 - SB22
 for Glasswasher/Cupwasher (NOSEM) C2010L - C4010L



SO.WE.BO. GG1T5



Suitable for:

3186181 O-RING 03068 EPDM

for Dishwasher (SO.WE.BO.) 601 - 701 - 752
for Dishwasher (SOTAL) ER225
for Glasswasher/Cupwasher (AFI) A35 - A35Z2 - A36
for Glasswasher/Cupwasher (COMENDA) - Series B
for Glasswasher/Cupwasher (EUROSYSTEM) PRO100
PRO200
for Glasswasher/Cupwasher (HILTA) RB10 - RB22
SB10 - SB22
for Glasswasher/Cupwasher (IME OMNIWASH) DUE
JA35 - JA36 - JA40 - JA41 - JOLLY - UNO
for Glasswasher/Cupwasher (NOSEM) C2010L - C4010L
NC201 - NR101 - R1010
for Glasswasher/Cupwasher (NUOVA SIMONELLI) KIARA1
KIARA2 - KIARA4
for Glasswasher/Cupwasher (SAB ITALIA) C35 - C36



SO.WE.BO. OR122

SO.WE.BO.



Suitable for:

3055352 ROTATING SUPPORT GUIDE - HOLE ø 15 mm

complete with closing cap
tank hole for OLD MODEL
for Dishwasher (AFI) A600 - A900
for Dishwasher (EUROSYSTEM) PRO400
for Dishwasher (HILTA) S41 - S42
for Dishwasher (NOSEM) C2050 - C5000 - C5010
NC501
for Dishwasher hood type (AFI) A1000L
for Dishwasher hood type (EUROSYSTEM) PRO600
for Dishwasher hood type (HILTA) W13 - W14 - W15
for Dishwasher hood type (NOSEM) K601 - K602
for Glasswasher/Cupwasher (AFI) A35 - A35Z2 - A36
for Glasswasher/Cupwasher (EUROSYSTEM) PRO100
PRO200
for Glasswasher/Cupwasher (HILTA) RB10 - RB22



SO.WE.BO. GG1T2

SO.WE.BO. GG1T2+D0T14P

SO.WE.BO. GG1T2+D0T14PB

SO.WE.BO. GG1T2+D0T14PBGR

3055353 WASHER UNI 6592 HOLE ø 18 mm



SO.WE.BO. GG0T4

3055078 CUTLERY INSERT RACK 130x55x100 mm
with 2 compartments in moplen



SO.WE.BO. IP2PP


3055525 GLASS BASKET ø 368x282x175 mm
top ø 368 mm - bottom ø 282 mm
plastic made
for Glasswasher/Cupwasher (IME OMNIWASH) JA35
JA350 - JA36 - JA360 - J35 - J350 - J36 - J360



SO.WE.BO. CT3617L

SO.WE.BO. CT3617PL2

3055484 GLASS RACK ø 400x180 mm
made of plastic
with ring ø 28 mm
for Dishwasher (IME OMNIWASH) OMBG400 - OMPG400



SO.WE.BO. CT4114L

SO.WE.BO. CT4117L

3055676 GLASS RACK 350x350x160 mm
for Glasswasher/Cupwasher (EMB) 35HL



SO.WE.BO. CQ3516LPL


3055380 RACK 400x400x160 mm



SO.WE.BO. CQ4016LPL

3055691 ROUND RACK SUPPORT \varnothing 280 mm

for Dishwasher (AFI) A600 - A900
 for Dishwasher (EUROSYSTEM) PRO400
 for Dishwasher (HILTA) S41 - S42
 for Dishwasher (NOSEM) C2050 - C5000 - C5010
 NC501
 for Dishwasher hood type (AFI) A1000L
 for Dishwasher hood type (EUROSYSTEM) PRO600
 for Dishwasher hood type (HILTA) W13 - W14 - W15
 for Dishwasher hood type (NOSEM) K601 - K602
 for Glasswasher/Cupwasher (AFI) A35 - A35Z2 - A36
 for Glasswasher/Cupwasher (EUROSYSTEM) PRO100
 PRO200
 for Glasswasher/Cupwasher (HILTA) RB10 - RB22
 SB10 - SB22
 for Glasswasher/Cupwasher (NOSEM) C2010L - C4010L



SO.WE.BO. GG1TA

SO.WE.BO. GG1TAB

3324007 ROTATING SUPPORT PIN CT WITH BALL 1-2


for Dishwasher (AFI) A600 - A900
 for Dishwasher (EUROSYSTEM) PRO400
 for Dishwasher (HILTA) S41 - S42
 for Dishwasher (NOSEM) C2050 - C5000 - C5010
 NC501
 for Dishwasher hood type (AFI) A1000L
 for Dishwasher hood type (EUROSYSTEM) PRO600
 for Dishwasher hood type (HILTA) W13 - W14 - W15
 for Dishwasher hood type (NOSEM) K601 - K602
 for Glasswasher/Cupwasher (AFI) A35 - A35Z2 - A36
 for Glasswasher/Cupwasher (EUROSYSTEM) PRO100
 PRO200
 for Glasswasher/Cupwasher (HILTA) RB10 - RB22
 SB10 - SB22
 for Glasswasher/Cupwasher (NOSEM) C2010L - C4010L



SO.WE.BO. GG1TFEG

3528051 BASKET SUPPORT NUT

for Dishwasher (AFI) A600 - A900
 for Dishwasher (EUROSYSTEM) PRO400
 for Dishwasher (HILTA) S41 - S42
 for Dishwasher (NOSEM) C2050 - C5000 - C5010
 NC501
 for Dishwasher hood type (AFI) A1000L
 for Dishwasher hood type (EUROSYSTEM) PRO600
 for Dishwasher hood type (HILTA) W13 - W14 - W15
 for Dishwasher hood type (NOSEM) K601 - K602
 for Glasswasher/Cupwasher (AFI) A35 - A35Z2 - A36
 for Glasswasher/Cupwasher (EUROSYSTEM) PRO100
 PRO200
 for Glasswasher/Cupwasher (HILTA) RB10 - RB22
 SB10 - SB22
 for Glasswasher/Cupwasher (NOSEM) C2010L - C4010L



SO.WE.BO. GG1THB

3055668 ROTATING SUPPORT SHAFT SPACER 1-2

for Dishwasher (AFI) A600 - A900
 for Dishwasher (EUROSYSTEM) PRO400
 for Dishwasher (HILTA) S41 - S42
 for Dishwasher (NOSEM) C2050 - C5000 - C5010
 NC501
 for Dishwasher hood type (AFI) A1000L
 for Dishwasher hood type (EUROSYSTEM) PRO600
 for Dishwasher hood type (HILTA) W13 - W14 - W15
 for Dishwasher hood type (NOSEM) K601 - K602
 for Glasswasher/Cupwasher (AFI) A35 - A35Z2 - A36
 for Glasswasher/Cupwasher (EUROSYSTEM) PRO100
 PRO200
 for Glasswasher/Cupwasher (HILTA) RB10 - RB22
 SB10 - SB22
 for Glasswasher/Cupwasher (NOSEM) C2010L - C4010L



SO.WE.BO. GG1TD



Suitable for:

3241838 S/STEEL TURNTABLE DISK 1-2

for Dishwasher (AFI) A600 - A900
for Dishwasher (EUROSYSTEM) PRO400
for Dishwasher (HILTA) S41 - S42
for Dishwasher (NOSEM) C2050 - C5000 - C5010
NC501
for Dishwasher hood type (AFI) A1000L
for Dishwasher hood type (EUROSYSTEM) PRO600
for Dishwasher hood type (HILTA) W13 - W14 - W15
for Dishwasher hood type (NOSEM) K601 - K602
for Glasswasher/Cupwasher (AFI) A35 - A35Z2 - A36
for Glasswasher/Cupwasher (EUROSYSTEM) PRO100
PRO200
for Glasswasher/Cupwasher (HILTA) RB10 - RB22
SB10 - SB22
for Glasswasher/Cupwasher (NOSEM) C2010L - C4010L



SO.WE.BO. GG1TB

SO.WE.BO.



Suitable for:

3250227 SEEGER FOR ROTATING SUPPORT SHAFT

for Dishwasher (AFI) A600 - A900
for Dishwasher (EUROSYSTEM) PRO400
for Dishwasher (HILTA) S41 - S42
for Dishwasher (NOSEM) C2050 - C5000 - C5010
NC501
for Dishwasher hood type (AFI) A1000L
for Dishwasher hood type (EUROSYSTEM) PRO600
for Dishwasher hood type (HILTA) W13 - W14 - W15
for Dishwasher hood type (NOSEM) K601 - K602
for Glasswasher/Cupwasher (AFI) A35 - A35Z2 - A36
for Glasswasher/Cupwasher (EUROSYSTEM) PRO100
PRO200
for Glasswasher/Cupwasher (HILTA) RB10 - RB22
SB10 - SB22
for Glasswasher/Cupwasher (NOSEM) C2010L - C4010L



SO.WE.BO. GG1TE

The data herewith contained may change without notice and LF SpA cannot be held responsible for possible errors stated or resulting by the use of this document. All rights reserved. No part of this publication may be reproduced without written permission by LF SpA.



LF SpA
via Voltri, 80 - 47522 Cesena (FC) ITALIA
Tel. +39 0547 34 11 11 - Fax +39 0547 34 11 10
www.lfricambi724.it - www.lfricambi724.mobi
info@lfricambi.it
Export Dept.: Tel. +39 0547 34 11 50 - Fax: +39 0547 34 11 55
www.lfspareparts724.com - www.lfspareparts724.mobi
export@lfspaceparts.com

FRANCE



EPGC Sas
13, Rue des Forts - 59960 Neuville en Ferrain
Tél. +33 (0)3 20 25 06 21
Fax +33 (0)3 20 25 34 12
www.epgc.com
www.epgc724.mobi
epgc@epgc.com

DEUTSCHLAND



LF GmbH
Junkersstrasse, 1 - D-82178 Puchheim - München
Tel. +49 89 89 45 78 66
Fax +49 89 89 45 78 88
www.lfersatzteile724.de
www.lfersatzteile724.mobi
info@lfersatzteile.de

SCHWEIZ



LF GmbH Verkaufsbüro
Sennweidstrasse, 45 - CH-6312 Steinhausen
Tel. +41 (0)41 760 15 80-1
Fax +41 (0)41 760 15 85
www.lfersatzteile724.ch
www.lfersatzteile724.mobi
info@lfersatzteile.ch

ESPAÑA



LF Repuestos Horeca S.L.U.
Calle Ciudad Real, 10 - 45517 Escalonilla - Toledo
Tif. +34 91 477 91 00
Fax +34 91 477 90 81
www.lfrepuestos724.es
www.lfrepuestos724.mobi
info@lfrepuestos.es

UNITED KINGDOM



LF Spare Parts Ltd.
A10a Lakeside Business Park, Broadway Lane
South Cerney, Gloucestershire GL7 5XL
Tel. +44 (0)1285 86 16 25
Fax +44 (0)1285 86 39 49
www.lfspareparts724.co.uk
www.lfspareparts724.mobi
info@lfspaceparts.co.uk

RUSSIA



OOO LF
ul, Anatoliya Zhivova, 8 - office 1 - 123100 Moscow
Tel. +7 499 259 85 75
Fax +7 495 725 26 53
www.lfspareparts724.ru
www.lfspareparts724.mobi
info@lfspaceparts.ru

CHINA



LF China
Room 102, House 8, Lane 725, Mao Tai Rd.
Changning Dist. - 200336 Shanghai
Tel. +86 (0)21 33 53 66 31
Fax +86 (0)21 33 53 66 32
www.lfspareparts724.com
www.lfspareparts724.mobi
china@lfspaceparts.com