



Spare parts for:

Warewashing equipment



Suitable for:

STORME



This catalogue is automatically generated.
Therefore, the sequence of the items might
not be always shown at best.

Updates will be issued in case of additions
and/or amendments.

Suitable universal spare parts may not be included





Suitable for:

STORME




Suitable for:

Air Chambers

3060118 AIR CHAMBER

for Dishwasher MAGIC50
for Dishwasher hood type (SO.WE.BO.) 6.2PB




STORME L502

Bearings

3063102 S609RS BEARING F/ROTATING SUPPORT

for Dishwasher (AFI) A600 - A900
for Dishwasher (EUROSYSTEM) PRO400
for Dishwasher (HILTA) S41 - S42
for Dishwasher (NOSEM) C2050 - C5000 - C5010
NC501
for Dishwasher hood type (AFI) A1000L
for Dishwasher hood type (EUROSYSTEM) PRO600
for Dishwasher hood type (HILTA) W13 - W14 - W15
for Dishwasher hood type (NOSEM) K601 - K602
for Glasswasher/Cupwasher (AFI) A35 - A35Z2 - A36
for Glasswasher/Cupwasher (EUROSYSTEM) PRO100
PRO200
for Glasswasher/Cupwasher (HILTA) RB10 - RB22
SB10 - SB22
for Glasswasher/Cupwasher (NOSEM) C2010L - C4010L



STORME



Caps

3439007 HEXAGONAL TANK CAP 3/8" GAS

for Glasswasher/Cupwasher (AFI) A35 - A35Z2 - A36
 for Glasswasher/Cupwasher (EUROSYSTEM) PRO100
 PRO200
 for Glasswasher/Cupwasher (HILTA) RB10 - RB22
 SB10 - SB22
 for Glasswasher/Cupwasher (IME OMNIWASH) DUE
 JA35 - JA36 - JA40 - JA41 - JOLLY - UNO
 for Glasswasher/Cupwasher (NOSEM) C2010L - C4010L
 NC201 - NR101 - R1010
 for Glasswasher/Cupwasher (NUOVA SIMONELLI) KIARA1
 KIARA2 - KIARA4
 for Glasswasher/Cupwasher (SAB ITALIA) C35 - C36
 for Glasswasher/Cupwasher (SO.WE.BO.) 600 - 601
 631 - 661 - 691 - 701 - 712 - 742 - 752
 for Glasswasher/Cupwasher (SOTAL) C230 - EC195



STORME

3240135 BRASS NUT \varnothing 3/8"



STORME

3186181 O-RING 03068 EPDM

for Dishwasher (SO.WE.BO.) 601 - 701 - 752
 for Dishwasher (SOTAL) ER225
 for Glasswasher/Cupwasher (AFI) A35 - A35Z2 - A36
 for Glasswasher/Cupwasher (COMENDA) - Series B
 for Glasswasher/Cupwasher (EUROSYSTEM) PRO100
 PRO200
 for Glasswasher/Cupwasher (HILTA) RB10 - RB22
 SB10 - SB22
 for Glasswasher/Cupwasher (IME OMNIWASH) DUE
 JA35 - JA36 - JA40 - JA41 - JOLLY - UNO
 for Glasswasher/Cupwasher (NOSEM) C2010L - C4010L
 NC201 - NR101 - R1010
 for Glasswasher/Cupwasher (NUOVA SIMONELLI) KIARA1
 KIARA2 - KIARA4
 for Glasswasher/Cupwasher (SAB ITALIA) C35 - C36



STORME



Suitable for:

STORME



Suitable for:

Door catches

3398050 COMPLETE DOOR CATCH

for all models
for Glasswasher/Cupwasher (ADLER) DSF101 - DSF103
DS101 - DS103 - DS201 - DS203
for Glasswasher/Cupwasher (WHIRLPOOL) D110 - D111
D210 - D211 - D310 - D311 - F300 - F312



STORME

Drain assembly

3316062 COMPLETE DRAIN ASSEMBLY

connection \varnothing 1" outlet \varnothing 27 mm
complete with nut and gasket
for UNO-DUE-JOLLY



STORME

3316061 DRAIN ASSEMBLY - FITTING \varnothing 34 mm

fitting \varnothing 1"1/4 outlet \varnothing 38 mm
for DISHWASHER 6.2P-61P



STORME

3160041 NUT \varnothing 1"1/4

for Dishwasher (AFI) A600
for Dishwasher (EUROSYSTEM) PRO400
for Dishwasher (HILTA) S41 - S42
for Dishwasher (NOSEM) C5010 - C5020 - NC501
for Dishwasher (NUOVA SIMONELLI) KIARA6
for Dishwasher (SAB ITALIA) C50H
for Dishwasher (SO.WE.BO.) 600CQ - 600CT - 619CQ
619CT - 631CT - 661CQ - 701CQ - 701CT - 752CQ
752CT - 824CQ - 824CT
for Dishwasher (SOTAL) F600ECO
for Dishwasher (STORME) LT500M - LT500T
for Dishwasher (UNIC) A100 - A410E
for Glasswasher/Cupwasher (AFI) A35 - A35Z2 - A36
for Glasswasher/Cupwasher (EUROSYSTEM) PRO100
PRO200




STORME



Suitable for:

3160040 O-RING 03168 EPDM

for Dishwasher (AFI) A600
 for Dishwasher (EUROSYSTEM) PRO400
 for Dishwasher (HILTA) S41 - S42
 for Dishwasher (NOSEM) C5010 - C5020 - NC501
 for Dishwasher (NUOVA SIMONELLI) KIARA6
 for Dishwasher (SAB ITALIA) C50H
 for Dishwasher (SO.WE.BO.) 600CQ - 600CT - 619CQ
 619CT - 631CT - 661CQ - 701CQ - 701CT - 752CQ
 752CT - 824CQ - 824CT
 for Dishwasher (SOTAL) F600ECO
 for Dishwasher (STORME) LT500M - LT500T
 for Dishwasher (UNIC) A100 - A410E
 for Glasswasher/Cupwasher (AFI) A35 - A35Z2 - A36
 for Glasswasher/Cupwasher (EUROSYSTEM) PRO100
 PRO200



STORME

3316141 DRAIN ASSEMBLY 1"1/4

for QUATTRO Q



STORME

Drain plugs

3448142 COMPLETE OVERFLOW PIPE \varnothing 25x100 mm

in plastic
 for CL-CS-UNO-DUE
 for Glasswasher/Cupwasher (EMB) 35HL



STORME

3448128 OVERFLOW PIPE \varnothing 33x192 mm

in plastic
 for 6.2P-61P



STORME

3448177 COMPLETE OVERFLOW PIPE \varnothing 35x165 mm

in plastic
 for QUATTRO Q-T-BA



STORME

3448054 OVERFLOW PIPE \varnothing 34x220 mm

of plastic
 for COLGED CS900-CS1500-S800



STORME

STORME

Suitable for:





Suitable for:

STORME



Suitable for:

Filters

3160323 FILTER BOTTOM PLATE


for Dishwasher (IME OMNIWASH) J50 - J500 - N50
N500 - 4Q82
for Dishwasher hood type (IME OMNIWASH) SEI1P
SEI2P



STORME

3160321 FILTER 230x200 mm


for Dishwasher (AFI) A600
for Dishwasher (EUROSYSTEM) PRO400
for Dishwasher (HILTA) S41 - S42
for Dishwasher (IME OMNIWASH) 4Q82
for Dishwasher (NOSEM) C5000 - C5010 - C5020
NC501
for Dishwasher (NUOVA SIMONELLI) KIARA6
for Dishwasher (SAB ITALIA) C50H
for Dishwasher (SO.WE.BO.) 824
for Dishwasher (SOTAL) F600ECO
for Dishwasher (STORME) LT500M - LT500T
for Dishwasher (UNIC) A410E



STORME

3160322 FILTER 330x310 mm

for Dishwasher (SO.WE.BO.) 701CQ - 752CQ - 752CT
for Glasswasher/Cupwasher (AFI) A35Z2
for Glasswasher/Cupwasher (EUROSYSTEM) PRO200
for Glasswasher/Cupwasher (HILTA) RB22 - SB22
for Glasswasher/Cupwasher (IME OMNIWASH) DUEAQ
DUEAT - UNO AQ - UNOAT - UNOQ - UNOT
for Glasswasher/Cupwasher (NOSEM) C4010L - NC201
NR101 - R1010
for Glasswasher/Cupwasher (NUOVA SIMONELLI) KIARA4
for Glasswasher/Cupwasher (SO.WE.BO.) ONECQ
ONECT - 701VT - 712CQ - 712CT - 742CQ - 742CT
for Glasswasher/Cupwasher (SOTAL) C230
for Glasswasher/Cupwasher (STORME) ME400
for Glasswasher/Cupwasher (UNIC) A20 - A21



STORME

3160042 FITTING \varnothing 1"1/2


for Dishwasher (AFI) A600
 for Dishwasher (EUROSYSTEM) PRO400
 for Dishwasher (HILTA) S41 - S42
 for Dishwasher (IME OMNIWASH) QUATTROBA QUATTROSA - 4Q82
 for Dishwasher (NOSEM) C5000 - K602S
 for Dishwasher (NUOVA SIMONELLI) KIARA6
 for Dishwasher (SAB ITALIA) C50H - K5.2P
 for Dishwasher (SOTAL) C1300IP - F600
 for Dishwasher hood type (AFI) A1000L
 for Dishwasher hood type (EUROSYSTEM) PRO600
 for Dishwasher hood type (HILTA) W13 - W14 - W15
 for Dishwasher hood type (IME OMNIWASH) SEI1P SEI2P
 for Dishwasher hood type (NOSEM) K601



STORME

3160047 INLET FILTER

for Dishwasher (AFI) A600
 for Dishwasher (EUROSYSTEM) PRO400
 for Dishwasher (HILTA) S41 - S42
 for Dishwasher (IME OMNIWASH) 4Q82
 for Dishwasher (NOSEM) C5000 - K602S
 for Dishwasher (NUOVA SIMONELLI) KIARA6
 for Dishwasher (SAB ITALIA) C50H - K5.2P
 for Dishwasher (SO.WE.BO.) 824
 for Dishwasher (SOTAL) C1300IP - F600
 for Dishwasher (STORME) LT1500M - LT1500T - L502BT
 for Dishwasher (UNIC) A401E - A61A - A61B
 for Dishwasher hood type (AFI) A1000L
 for Dishwasher hood type (EUROSYSTEM) PRO600
 for Dishwasher hood type (HILTA) W13 - W14 - W15
 for Dishwasher hood type (IME OMNIWASH) SEI1P



STORME

3160152

FILTER RETAINING NUT

for Dishwasher (AFI) A600
 for Dishwasher (EUROSYSTEM) PRO400
 for Dishwasher (HILTA) S41 - S42
 for Dishwasher (IME OMNIWASH) 4Q82
 for Dishwasher (NOSEM) C5010 - C5020 - NC501
 for Dishwasher (NUOVA SIMONELLI) KIARA6
 for Dishwasher (SAB ITALIA) C50H
 for Dishwasher (SO.WE.BO.) 600CQ - 600CT - 601CQ 601CT - 619CQ - 619CT - 701CQ - 701CT - 752CQ 752CT - 824
 for Dishwasher (SOTAL) F600ECO
 for Dishwasher (STORME) LT500M - LT500T
 for Dishwasher (UNIC) A100 - A410E
 for Glasswasher/Cupwasher (AFI) A35 - A35Z2 - A36
 for Glasswasher/Cupwasher (EUROSYSTEM) PRO100



STORME

3160045

NUT FOR DRAIN ELBOW \varnothing 1"1/2

for Dishwasher (IME OMNIWASH) QUATTROBA QUATTROSA - 4Q82
 for Dishwasher (NUOVA SIMONELLI) KIARA6
 for Dishwasher hood type (IME OMNIWASH) SEI1P SEI2P
 for Dishwasher hood type (NUOVA SIMONELLI) LTM1500 LTM1600



STORME



Suitable for:

3160044 O-RING 03187 EPDM

for Dishwasher (AFI) A600
 for Dishwasher (EUROSYSTEM) PRO400
 for Dishwasher (HILTA) S41 - S42
 for Dishwasher (IME OMNIWASH) 4Q82
 for Dishwasher (NOSEM) C5000 - K602S
 for Dishwasher (NUOVA SIMONELLI) KIARA6CF
 KIARA6ECF
 for Dishwasher (SAB ITALIA) C50H - K5.2P
 for Dishwasher (SO.WE.BO.)
 for Dishwasher (SOTAL) C1300IP - F600
 for Dishwasher hood type (AFI) A1000L
 for Dishwasher hood type (EUROSYSTEM) PRO600
 for Dishwasher hood type (HILTA) W13 - W14 - W15
 for Dishwasher hood type (IME OMNIWASH) SEI1P
 SEI2P



STORME

3160038 INLET CONNECTOR \varnothing 1"1/4

for Dishwasher (AFI) A600
 for Dishwasher (EUROSYSTEM) PRO400
 for Dishwasher (HILTA) S41 - S42
 for Dishwasher (NOSEM) C5010 - C5020 - NC501
 for Dishwasher (NUOVA SIMONELLI) KIARA6
 for Dishwasher (SAB ITALIA) C50H
 for Dishwasher (SO.WE.BO.) 600CQ - 600CT - 619CQ
 619CT - 631CT - 661CQ - 701CQ - 701CT - 752CQ
 752CT - 824CQ - 824CT
 for Dishwasher (SOTAL) F600ECO
 for Dishwasher (STORME) LT500M - LT500T
 for Dishwasher (UNIC) A100 - A410E
 for Glasswasher/Cupwasher (AFI) A35 - A35Z2 - A36
 for Glasswasher/Cupwasher (EUROSYSTEM) PRO100
 PRO200



STORME

STORME



Suitable for:

3160043 TIE ROD FOR FILTER 97 mm


for Dishwasher (AFI) A600
 for Dishwasher (EUROSYSTEM) PRO400
 for Dishwasher (HILTA) S41 - S42
 for Dishwasher (NOSEM) C5000 - K602S
 for Dishwasher (NUOVA SIMONELLI) KIARA6
 for Dishwasher (SAB ITALIA) C50H - K5.2P
 for Dishwasher hood type (AFI) A1000L
 for Dishwasher hood type (EUROSYSTEM) PRO600
 for Dishwasher hood type (HILTA) W13 - W14 - W15
 for Dishwasher hood type (IME OMNIWASH) SEI1P
 SEI2P
 for Dishwasher hood type (NOSEM) K601
 for Dishwasher hood type (SAB ITALIA) K5.1P



STORME

3160468 BOTTOM PLATE FOR PUMP FILTER

for Dishwasher (IME OMNIWASH) J50 - 4Q82



STORME



Suitable for:

3160152 FILTER RETAINING NUT

for Dishwasher (AFI) A600
 for Dishwasher (EUROSYSTEM) PRO400
 for Dishwasher (HILTA) S41 - S42
 for Dishwasher (IME OMNIWASH) 4Q82
 for Dishwasher (NOSEM) C5010 - C5020 - NC501
 for Dishwasher (NUOVA SIMONELLI) KIARA6
 for Dishwasher (SAB ITALIA) C50H
 for Dishwasher (SO.WE.BO.) 600CQ - 600CT - 601CQ
 601CT - 619CQ - 619CT - 701CQ - 701CT - 752CQ
 752CT - 824
 for Dishwasher (SOTAL) F600ECO
 for Dishwasher (STORME) LT500M - LT500T
 for Dishwasher (UNIC) A100 - A410E
 for Glasswasher/Cupwasher (AFI) A35 - A35Z2 - A36
 for Glasswasher/Cupwasher (EUROSYSTEM) PRO100



STORME

3160040 O-RING 03168 EPDM

for Dishwasher (AFI) A600
 for Dishwasher (EUROSYSTEM) PRO400
 for Dishwasher (HILTA) S41 - S42
 for Dishwasher (NOSEM) C5010 - C5020 - NC501
 for Dishwasher (NUOVA SIMONELLI) KIARA6
 for Dishwasher (SAB ITALIA) C50H
 for Dishwasher (SO.WE.BO.) 600CQ - 600CT - 619CQ
 619CT - 631CT - 661CQ - 701CQ - 701CT - 752CQ
 752CT - 824CQ - 824CT
 for Dishwasher (SOTAL) F600ECO
 for Dishwasher (STORME) LT500M - LT500T
 for Dishwasher (UNIC) A100 - A410E
 for Glasswasher/Cupwasher (AFI) A35 - A35Z2 - A36
 for Glasswasher/Cupwasher (EUROSYSTEM) PRO100
 PRO200



STORME

STORME



Suitable for:

3160041 NUT ø 1"1/4

for Dishwasher (AFI) A600
 for Dishwasher (EUROSYSTEM) PRO400
 for Dishwasher (HILTA) S41 - S42
 for Dishwasher (NOSEM) C5010 - C5020 - NC501
 for Dishwasher (NUOVA SIMONELLI) KIARA6
 for Dishwasher (SAB ITALIA) C50H
 for Dishwasher (SO.WE.BO.) 600CQ - 600CT - 619CQ
 619CT - 631CT - 661CQ - 701CQ - 701CT - 752CQ
 752CT - 824CQ - 824CT
 for Dishwasher (SOTAL) F600ECO
 for Dishwasher (STORME) LT500M - LT500T
 for Dishwasher (UNIC) A100 - A410E
 for Glasswasher/Cupwasher (AFI) A35 - A35Z2 - A36
 for Glasswasher/Cupwasher (EUROSYSTEM) PRO100
 PRO200



STORME

3160151 PUMP INLET FILTER

for Dishwasher (AFI) A600
 for Dishwasher (EUROSYSTEM) PRO400
 for Dishwasher (HILTA) S41 - S42
 for Dishwasher (IME OMNIWASH) 4Q82
 for Dishwasher (NOSEM) C5010 - C5020 - NC501
 for Dishwasher (NUOVA SIMONELLI) KIARA6
 for Dishwasher (SAB ITALIA) C50H
 for Dishwasher (SO.WE.BO.) 600CQ - 600CT - 601CQ
 601CT - 619CQ - 619CT - 701CQ - 701CT - 752CQ
 752CT - 824
 for Dishwasher (SOTAL) F600ECO
 for Dishwasher (STORME) LT500M - LT500T
 for Dishwasher (UNIC) A100 - A410E
 for Glasswasher/Cupwasher (AFI) A35 - A35Z2 - A36
 for Glasswasher/Cupwasher (EUROSYSTEM) PRO100



STORME



Suitable for:

3160472 PUMP INLET FILTER

for Dishwasher (AFI) A600
 for Dishwasher (EUROSYSTEM) PRO400
 for Dishwasher (HILTA) S41 - S42
 for Dishwasher (IME OMNIWASH) J50 - 4Q82
 for Dishwasher (NOSEM) C4010 - C5000 - C5010
 C5020 - NC501
 for Dishwasher (NUOVA SIMONELLI) KIARA6
 for Dishwasher (SAB ITALIA) C50H
 for Dishwasher (SO.WE.BO.) 600CQ - 600CT - 601CQ
 601CT - 619CQ - 619CT - 701CQ - 701CT - 752CQ
 752CT - 824
 for Dishwasher (SOTAL) F600ECO
 for Dishwasher (STORME) LT500M - LT500T
 for Dishwasher (UNIC) A100 - A410E
 for Glasswasher/Cupwasher (AFI) A35 - A35Z2 - A36



STORME

3160037 PLASTIC INNER FILTER FOR TANK 230x200 mm

for Dishwasher (IME OMNIWASH) 4Q82
 for Dishwasher (NOSEM) K602S
 for Dishwasher (SAB ITALIA) K5.2P
 for Dishwasher (SOTAL) C13001P
 for Dishwasher (STORME) L502BT
 for Dishwasher (UNIC) A61A - A61B
 for Dishwasher hood type (AFI) A1000L
 for Dishwasher hood type (EUROSYSTEM) PRO600
 for Dishwasher hood type (HILTA) W13 - W14 - W15
 for Dishwasher hood type (IME OMNIWASH) SEI1P
 SEI2P
 for Dishwasher hood type (NOSEM) K601
 for Dishwasher hood type (NUOVA SIMONELLI) LTM1500
 LTM1600
 for Dishwasher hood type (SAB ITALIA) K5.1P



STORME

STORME



Suitable for:

3160039 TIE ROD FOR FILTER 52 mm


for Dishwasher (AFI) A600
 for Dishwasher (EUROSYSTEM) PRO400
 for Dishwasher (HILTA) S41 - S42
 for Dishwasher (NOSEM) C5010 - C55020 - NC501
 for Dishwasher (NUOVA SIMONELLI) KIARA6
 for Dishwasher (SAB ITALIA) C50H
 for Dishwasher (SO.WE.BO.) 600CQ - 600CT - 619CQ
 619CT - 631CT - 661CQ - 701CQ - 701CT - 752CQ
 752CT - 824CQ - 824CT
 for Dishwasher (SOTAL) F600ECO
 for Dishwasher (STORME) LT500M - LT500T
 for Dishwasher (UNIC) A100 - A410E
 for Glasswasher/Cupwasher (AFI) A35 - A35Z2 - A36
 for Glasswasher/Cupwasher (EUROSYSTEM) PRO100
 PRO200



STORME

3160464 S/STEEL FILTER SURFACE 230x200 mm

for Dishwasher (NOSEM) K602S
 for Dishwasher (SAB ITALIA) K5.2P
 for Dishwasher (SOTAL) C13001P - C130024V
 for Dishwasher (STORME) L502BT
 for Dishwasher (UNIC) A61A - A61B
 for Dishwasher hood type (AFI) A1000L
 for Dishwasher hood type (EUROSYSTEM) PRO600
 for Dishwasher hood type (HILTA) W13 - W14 - W15
 for Dishwasher hood type (IME OMNIWASH) SEI1P
 SEI2P
 for Dishwasher hood type (NOSEM) K601 - K602
 for Dishwasher hood type (NUOVA SIMONELLI) LTM1500
 LTM1600
 for Dishwasher hood type (SAB ITALIA) K5.1P
 for Dishwasher hood type (SO.WE.BO.) 6.1P - 6.2P



STORME



Guides

3189048 HOOD SLIDEWAY

dimensions 595x35 mm
 for Dishwasher (IME OMNIWASH) SEI1PS
 for Dishwasher (SAB ITALIA) K5.1 - K5.2
 for Dishwasher (STORME) L502BT
 for Dishwasher (UNIC) A61A - A61B
 for Dishwasher hood type (AFI) A1000L
 for Dishwasher hood type (EUROSYSTEM) PRO600
 for Dishwasher hood type (HILTA) W13 - W14 - W15
 for Dishwasher hood type (IME OMNIWASH) SEI2PS
 for Dishwasher hood type (NOSEM) K601 - K602
 for Dishwasher hood type (NUOVA SIMONELLI) LTM1500
 LTM1600
 for Dishwasher hood type (SO.WE.BO.) 6.1P - 6.2P
 for Dishwasher hood type (SOTAL) C1300
 for Dishwasher hood type (STORME) L501 - L502



STORME

Heating elements

3355409 HEATING ELEM. F/WASH TANK 4500W 230/415V

immersed length 280 mm
 connection \varnothing 1"1/4 (43 mm)
 complete with gasket (3186010)
 for Dishwasher (AFI) A900
 for Dishwasher (IME OMNIWASH) 4SA
 for Dishwasher (NOSEM) K602S
 for Dishwasher (SO.WE.BO.) 1315 - 1342
 for Dishwasher (SOTAL) C1300/24V - C13001P - F600
 for Dishwasher (STORME) LT501 - LT502 - LT502BT
 for Dishwasher (UNIC) A61B - A861A
 for Dishwasher hood type (AFI) A1000L
 for Dishwasher hood type (EUROSYSTEM) PRO600
 for Dishwasher hood type (HILTA) W13 - W14 - W15
 for Dishwasher hood type (IME OMNIWASH) SEI1P
 SEI2P



STORME



Suitable for:

STORME



Suitable for:

Heating elements

3355412 HEATING ELEMENT F/BOILER 4500W 230/415V
 immersed length 370 mm
 flange external \varnothing 72 mm
 with thermostat probe receptacle \varnothing 8 mm
 complete with gasket (3186014)
 upon request nut (3528003) and washer (3528004)
 for Dishwasher (AFI) A600 - A900
 for Dishwasher (EUROSYSTEM) PRO400
 for Dishwasher (HILTA) S41 - S42
 for Dishwasher (IME OMNIWASH) 4Q82
 for Dishwasher (NOSEM) C5000 - C5010 - C5020
 K602S - NC501
 for Dishwasher (NUOVA SIMONELLI) KIARA6
 for Dishwasher (SAB ITALIA) C50H - K5.2P
 for Dishwasher (SO.WE.BO.) 1315 - 1342 - 824
 for Dishwasher (SOTAL) C13001P - F600ECO



STORME

3186014 O-RING GASKET 06225 EPDM \varnothing 67 mm
 for Dishwasher (ZANUSSI) LS62/F



STORME

3716003 HEATING ELEMENT CAP



STORME

3355413 HEATING ELEMENT F/BOILER 6000W 230/415V
 immersed length 410 mm
 flange external \varnothing 72 mm
 with thermostat probe receptacle \varnothing 8 mm
 complete with gasket (3186014)
 upon request nut (3528003) and washer (3528004)
 for Dishwasher (AFI) A600
 for Dishwasher (EUROSYSTEM) PRO400
 for Dishwasher (HILTA) S41 - S42
 for Dishwasher (IME OMNIWASH) 4Q82
 for Dishwasher (NOSEM) C5000 - C5010 - C5020
 K602S - NC501
 for Dishwasher (NUOVA SIMONELLI) KIARA6
 for Dishwasher (SAB ITALIA) C50H - K5.2P
 for Dishwasher (SO.WE.BO.) 824
 for Dishwasher (SOTAL) C13001P - C300 - F600



STORME

3716003 HEATING ELEMENT CAP



STORME



Suitable for:

3186014 O-RING GASKET 06225 EPDM ø 67 mm
for Dishwasher (ZANUSSI) LS62/F



STORME



Suitable for:

STORME

3355594 HEATING ELEMENT FOR BOILER 2200W 230V

immersed length 247 mm
flange hole 30 mm
distance between fixing holes 45 mm
complete with gasket (3186195)
for Dishwasher (SO.WE.BO.) 601
for Glasswasher/Cupwasher (AFI) A35 - A36
for Glasswasher/Cupwasher (EUROSYSTEM) PRO100
for Glasswasher/Cupwasher (IME OMNIWASH) JA35
JA36 - JOLLYAQ - JOLLYAT - JOLLYQ - JOLLYT
J35 - J36
for Glasswasher/Cupwasher (NUOVA SIMONELLI) KIARA1
KIARA2
for Glasswasher/Cupwasher (SAB ITALIA) C35 - C36
for Glasswasher/Cupwasher (SO.WE.BO.) 600 - 631
661 - 691



STORME

3355410 HEATING ELEMENT FOR BOILER 2700W 230V

immersed length 290 mm
flange hole 30 mm
distance between fixing holes 45 mm
complete with gasket (3186195)
for Dishwasher (NOSEM) NC202 - NR102 - R1020
for Dishwasher (SO.WE.BO.) ONEQ - 701 - 752
for Glasswasher/Cupwasher (AFI) A35Z2
for Glasswasher/Cupwasher (EUROSYSTEM) PRO200
for Glasswasher/Cupwasher (HILTA) RB22 - SB22
for Glasswasher/Cupwasher (IME OMNIWASH) DUEAQ
DUEAT - DUECL - DUECS - JA40 - JA41 - J40
J41 - UNO AQ - UNOAT - UNOCL - UNOCS
for Glasswasher/Cupwasher (NOSEM) C2010L - C4010L
NC201 - NR101 - R1010
for Glasswasher/Cupwasher (NUOVA SIMONELLI) KIARA4



3716002 HEATING ELEMENT CAP




STORME

STORME



Suitable for:

3186195 SILICONE GASKET FOR HEATING ELEMENT
ø 41x30x3 mm



STORME



Suitable for:

STORME

3355595 HEATING ELEMENT FOR BOILER 3000W 230V

immersed length 325 mm
flange hole 30 mm
distance between fixing holes 45 mm
complete with gasket (3186195)
for Dishwasher (AFI) A600
for Dishwasher (EUROSYSTEM) PRO400
for Dishwasher (HILTA) S41 - S42
for Dishwasher (IME OMNIWASH) QUATTROI - QUATTROQ
QUATTROQ82 - TREQ
for Dishwasher (NOSEM) C5000 - C5010 - C5020
NC501
for Dishwasher (NUOVA SIMONELLI) KIARA6
for Dishwasher (SAB ITALIA) C50H
for Dishwasher (SO.WE.BO.) 824
for Dishwasher (SOTAL) F600ECO



3716002 HEATING ELEMENT CAP



STORME

STORME

3355407 HEATING ELEMENT FOR WASH TANK 1800W 230V

immersed length 295 mm
connection ø 12 mm
for Dishwasher (NOSEM) C4010 - NC202 - NR102
N101 - R1020
for Dishwasher (SO.WE.BO.) 701 - 752
for Glasswasher/Cupwasher (AFI) A35Z2
for Glasswasher/Cupwasher (EUROSYSTEM) PRO200
for Glasswasher/Cupwasher (HILTA) RB22 - SB22
for Glasswasher/Cupwasher (IME OMNIWASH) DUEAQ
DUEAT - DUECL - DUECS - JA40 - JA41 - J40
J41 - UNOAQ - UNOAT - UNOCL - UNOCS
for Glasswasher/Cupwasher (NOSEM) NC201 - R1010
for Glasswasher/Cupwasher (NUOVA SIMONELLI) KIARA4
for Glasswasher/Cupwasher (SO.WE.BO.) 712 - 742
for Glasswasher/Cupwasher (STORME) ME400



3355408 HEATING ELEMENT FOR WASH TANK 2500W 230V

immersed length 400 mm
connection ø 12 mm
for Dishwasher (AFI) A600
for Dishwasher (EUROSYSTEM) PRO400
for Dishwasher (HILTA) S41 - S42
for Dishwasher (IME OMNIWASH) 4Q82
for Dishwasher (NOSEM) C5000 - C5010 - C5020
NC501
for Dishwasher (NUOVA SIMONELLI) KIARA6
for Dishwasher (SAB ITALIA) C50H
for Dishwasher (SO.WE.BO.) 824
for Dishwasher (SOTAL) F600ECO
for Dishwasher (STORME) LT500M - LT500T
for Dishwasher (UNIC) A410E




STORME

STORME

3355596 HEATING ELEMENT FOR WASH TANK 800W 230V

immersed length 330 mm
width 50 mm height 30 mm
connection ø 12 mm
for Dishwasher (SO.WE.BO.) 601
for Glasswasher/Cupwasher (AFI) A35 - A36
for Glasswasher/Cupwasher (EUROSYSTEM) PRO100
for Glasswasher/Cupwasher (HILTA) RB10 - SB10
for Glasswasher/Cupwasher (IME OMNIWASH) JA35
JA36 - JOLLYAQ - JOLLYAT - JOLLYQ - JOLLYT
J35 - J36
for Glasswasher/Cupwasher (NOSEM) C2010L - R1010L
for Glasswasher/Cupwasher (NUOVA SIMONELLI) KIARA1
KIARA2
for Glasswasher/Cupwasher (SAB ITALIA) C35 - C36
for Glasswasher/Cupwasher (SO.WE.BO.) 600 - 631



STORME

Hinges

3391046 BUSHING FOR DOOR HINGE

for Dishwasher (SO.WE.BO.) 601 - 701
for Glasswasher/Cupwasher (AFI) A35
for Glasswasher/Cupwasher (EUROSYSTEM) PRO100
for Glasswasher/Cupwasher (HILTA) RB10 - SB10
for Glasswasher/Cupwasher (IME OMNIWASH) JA35
JA36 - JOLLY - UNO
for Glasswasher/Cupwasher (NOSEM) C2010L - NC201
R1010L
for Glasswasher/Cupwasher (NUOVA SIMONELLI) KIARA1
for Glasswasher/Cupwasher (SO.WE.BO.) 600 - 631
661 - 691
for Glasswasher/Cupwasher (SOTAL) EC195 - ER195
for Glasswasher/Cupwasher (STORME) SM350
for Glasswasher/Cupwasher (UNIC) A10J - A11J



STORME

3053319 DOOR SPRING LH

for Dishwasher (SO.WE.BO.) 601 - 701
for Glasswasher/Cupwasher (AFI) A35
for Glasswasher/Cupwasher (EUROSYSTEM) PRO100
for Glasswasher/Cupwasher (HILTA) RB10 - SB10
for Glasswasher/Cupwasher (IME OMNIWASH) JA35
JA36 - JOLLY - UNO
for Glasswasher/Cupwasher (NOSEM) C2010L - NC201
R1010L
for Glasswasher/Cupwasher (NUOVA SIMONELLI) KIARA1
for Glasswasher/Cupwasher (SO.WE.BO.) 600 - 631
661 - 691
for Glasswasher/Cupwasher (SOTAL) EC195 - ER195
for Glasswasher/Cupwasher (STORME) SM350
for Glasswasher/Cupwasher (UNIC) A10J - A11J



STORME



Suitable for:

STORME



3053320 DOOR SPRING RH

for Dishwasher (SO.WE.BO.) 601 - 701
 for Glasswasher/Cupwasher (AFI) A35
 for Glasswasher/Cupwasher (EUROSYSTEM) PRO100
 for Glasswasher/Cupwasher (HILTA) RB10 - SB10
 for Glasswasher/Cupwasher (IME OMNIWASH) JA35
 JA36 - JOLLY - UNO
 for Glasswasher/Cupwasher (NOSEM) C2010L - NC201
 R1010L
 for Glasswasher/Cupwasher (NUOVA SIMONELLI) KIARA1
 for Glasswasher/Cupwasher (SO.WE.BO.) 600 - 631
 661 - 691
 for Glasswasher/Cupwasher (SOTAL) EC195 - ER195
 for Glasswasher/Cupwasher (STORME) SM350
 for Glasswasher/Cupwasher (UNIC) A10J - A11J



STORME

Suitable for:

3012001 SILICONE BUMPER FOR DOOR

for Dishwasher (SO.WE.BO.) 601 - 701
 for Glasswasher/Cupwasher (AFI) A35
 for Glasswasher/Cupwasher (EUROSYSTEM) PRO100
 for Glasswasher/Cupwasher (HILTA) RB10 - SB10
 for Glasswasher/Cupwasher (IME OMNIWASH) JA35
 JA36 - JOLLY - UNO
 for Glasswasher/Cupwasher (NOSEM) C2010L - NC201
 R1010L
 for Glasswasher/Cupwasher (NUOVA SIMONELLI) KIARA1
 for Glasswasher/Cupwasher (SO.WE.BO.) 600 - 631
 661 - 691
 for Glasswasher/Cupwasher (SOTAL) EC195 - ER195
 for Glasswasher/Cupwasher (STORME) SM350
 for Glasswasher/Cupwasher (UNIC) A10J - A11J



STORME

Hose-end fittings

3391042 HOSE-END FITTING FOR RINSE SHAFT \varnothing 16 mm

for Dishwasher (AFI) A600
 for Dishwasher (EUROSYSTEM) PRO400
 for Dishwasher (HILTA) S41 - S42
 for Dishwasher (IME OMNIWASH) 4Q82
 for Dishwasher (NOSEM) C5000 - C5010 - C5020
 NC501
 for Dishwasher (SAB ITALIA) C50
 for Dishwasher (SO.WE.BO.) 824
 for Glasswasher/Cupwasher (AFI) A35 - A35Z2 - A36
 for Glasswasher/Cupwasher (EUROSYSTEM) PRO100
 PRO200
 for Glasswasher/Cupwasher (HILTA) RB10 - RB22
 SB10 - SB22
 for Glasswasher/Cupwasher (IME OMNIWASH) DUEAQ
 DUEAT - JA35 - JA36 - JA40 - JA41 - JOLLYQ




STORME

3315027 T- HOSE END FITTING



STORME

3349601 3-WAY HOSE-END FITTING



STORME

3315107 3-WAYS HOSE END RUBBER FITTING \varnothing 12



STORME



Lamps

3221113 DOUBLE INDICATOR LAMP 230V

mounting hole 30x22 mm
16A 250V
green-yellow colours
for CS - CL



STORME

3221591 GREEN TORPEDO LAMP 220V



STORME

3221127 ORANGE LAMP RECEPTACLE

head 14x14 mm - hole \varnothing 11 mm
for 6.2P
for OEM PIZZA OVEN 4-5-8-10-11-15/DS



STORME

3221128 GREEN LAMP RECEPTACLE

hole \varnothing 11 mm
head 14x14 mm
for 6.2P



STORME

3221126 INDICATOR LAMP 24V

head \varnothing 8 mm




STORME

Microswitches

3803005 COMPLETE DOOR CONTACT

for Dishwasher (IME OMNIWASH) SEI1PCQ - SEI2CQB
SEI2PCQ
for Dishwasher (NOSEM) K602S
for Dishwasher (SAB ITALIA) K5.2P
for Dishwasher (SOTAL) C13001P - C130024V
for Dishwasher (STORME) L502BT
for Dishwasher (UNIC) A61A - A61B
for Dishwasher hood type (AFI) A1000L
for Dishwasher hood type (EUROSYSTEM) PRO600
for Dishwasher hood type (HILTA) W13 - W14 - W15
for Dishwasher hood type (NOSEM) K601 - K602
for Dishwasher hood type (NUOVA SIMONELLI) LTM1500
LTM1600
for Dishwasher hood type (SAB ITALIA) K5.1P
for Dishwasher hood type (SO.WE.BO.) 6.1P - 6.2P



STORME

3803018 ACTUATOR FOR REAR MICRO SWITCH 62P/SPPL



STORME



Suitable for:

3240129 COMPLETE MICROSWITCH FOR DOOR



STORME

3240130 MICROSWITCH FRONT BODY



STORME

1186352 O-RING 02050 EPDM

for Dishwasher (AFI) A600
 for Dishwasher (DIHR) C40CF - GASTRO450
 GASTRO500 - GASTRO750 - GASTRO900 - GS45
 GS50
 for Dishwasher (EUROSYSTEM) PRO400
 for Dishwasher (FAEMA) 1201
 for Dishwasher (HILTA) S41 - S42
 for Dishwasher (IME OMNIWASH) 4Q82
 for Dishwasher (KROMO) K35 - K37
 for Dishwasher (NOSEM) C5000 - C5010 - C5020
 NC501
 for Dishwasher (NUOVA SIMONELLI) KIARA6
 for Dishwasher (OLIS) OLG50 - OLG585
 for Dishwasher (SAB ITALIA) C50H - 1200
 for Dishwasher (SILANOS) 200 - 300 - 400 - 600



STORME

3240132 SPRING FOR ROD




STORME

STORME



Suitable for:

3240135 BRASS NUT \varnothing 3/8"



STORME

3240134 MICROSWITCH REAR BODY



STORME

3186181 O-RING 03068 EPDM

for Dishwasher (SO.WE.BO.) 601 - 701 - 752
 for Dishwasher (SOTAL) ER225
 for Glasswasher/Cupwasher (AFI) A35 - A35Z2 - A36
 for Glasswasher/Cupwasher (COMENDA) - Series B
 for Glasswasher/Cupwasher (EUROSYSTEM) PRO100
 PRO200
 for Glasswasher/Cupwasher (HILTA) RB10 - RB22
 SB10 - SB22
 for Glasswasher/Cupwasher (IME OMNIWASH) DUE
 JA35 - JA36 - JA40 - JA41 - JOLLY - UNO
 for Glasswasher/Cupwasher (NOSEM) C2010L - C4010L
 NC201 - NR101 - R1010
 for Glasswasher/Cupwasher (NUOVA SIMONELLI) KIARA1
 KIARA2 - KIARA4
 for Glasswasher/Cupwasher (SAB ITALIA) C35 - C36



STORME

3240133 STAINLESS STEEL ROD FOR MICRO SWITCH 77m



STORME

- 3240138 MAGNETIC MICROSWITCH E5301C**
 250V 0.4A
 capillary length 3000 mm
 for Dishwasher (AFI) A900
 for Dishwasher (NOSEM) K602S
 for Dishwasher (STORME) L502BT
 for Dishwasher (UNIC) A61A
 for Dishwasher hood type (EUROSYSTEM) PRO600
 for Dishwasher hood type (HILTA) W14 - W15
 for Dishwasher hood type (IME OMNIWASH)
 till 1/01/96
 SEI2P
 for Dishwasher hood type (JEMI) GS-82
 for Dishwasher hood type (NOSEM) K602
 for Dishwasher hood type (NUOVA SIMONELLI) LTM1600
 for Dishwasher hood type (SO.WE.BO.) 6.2PA - 6.2PB



STORME

Pressure switches

- 3320076 DRAIN PUMP PRESSURE SWITCH 60/30 mm**
 1 - level 250V 16A
 max operating temperature 85°C
 for Dishwasher (AFI) A600 - A900
 for Dishwasher (EUROSYSTEM) PRO400
 for Dishwasher (HILTA) S41 - S42
 for Dishwasher (IME OMNIWASH) J50 - 4Q82
 for Dishwasher (NOSEM) C5000
 for Dishwasher (NUOVA SIMONELLI) KIARA6
 for Dishwasher (SAB ITALIA) C50H
 for Dishwasher (SOTAL) F600
 for Dishwasher (STORME) LT500M - LT500T
 for Dishwasher (UNIC) A410E



STORME

- 3320075 PRESSURE SWITCH 50/20 mm 250V 16A**
 1level
 max operating temperature 85°C
 for Dishwasher (AFI) A600 - A900
 for Dishwasher (EUROSYSTEM) PRO400
 for Dishwasher (HILTA) S41 - S42 - S49 - S55
 for Dishwasher (NOSEM) C5000 - C5010
 for Dishwasher (SAB ITALIA) C50H
 for Dishwasher hood type (IME OMNIWASH) SEI2P
 for Dishwasher hood type (NOSEM) K602
 for Dishwasher hood type (SAB ITALIA) K5.2P
 for Glasswasher/Cupwasher (AFI) A35 - A35Z2 - A36
 for Glasswasher/Cupwasher (EUROSYSTEM) PRO100
 PRO200
 for Glasswasher/Cupwasher (HILTA) RB10 - RB22
 SB10 - SB22



STORME



Suitable for:

STORME



Suitable for:

Protection plates

3519014 BLACK FRONT FRAME


for Dishwasher (AFI) A600
 for Dishwasher (EUROSYSTEM) PRO400
 for Dishwasher (HILTA) S41 - S42
 for Dishwasher (NOSEM) C1010 - C5000 - C5010
 C5020 - NC501
 for Dishwasher (SO.WE.BO.) ONE - 701 - 752 - 824
 for Dishwasher (SOTAL) F600
 for Dishwasher (STORME) LT500M
 for Dishwasher (UNIC) A410E
 for Glasswasher/Cupwasher (AFI) A35Z2
 for Glasswasher/Cupwasher (NOSEM) NC201 - NR101
 for Glasswasher/Cupwasher (SO.WE.BO.) 742
 for Glasswasher/Cupwasher (SOTAL) C230



STORME

3244008 LIGHT BLUE FRONT FRAME OMNI11

for Dishwasher (AFI) A600
 for Dishwasher (EUROSYSTEM) PRO400
 for Dishwasher (HILTA) S41 - S42
 for Dishwasher (NOSEM) C1010 - C5000 - C5010
 C5020 - NC501
 for Dishwasher (SO.WE.BO.) ONE - 701 - 752 - 824
 for Dishwasher (SOTAL) F600
 for Dishwasher (STORME) LT500M
 for Dishwasher (UNIC) A410E
 for Glasswasher/Cupwasher (AFI) A35Z2
 for Glasswasher/Cupwasher (NOSEM) NC201 - NR101
 for Glasswasher/Cupwasher (SO.WE.BO.) 742
 for Glasswasher/Cupwasher (SOTAL) C230



STORME

Pumps

3122740 DRAIN ELECTRO-PUMP 34W 220/240V


inlet external \varnothing 23 mm outlet external \varnothing 31 mm
 for Dishwasher (AFI) A600
 for Dishwasher (IME OMNIWASH) 4Q82
 for Dishwasher (NOSEM) C5000 - C501 - C5010
 for Dishwasher (NUOVA SIMONELLI) KIARA6
 for Dishwasher (SAB ITALIA) C50H
 for Dishwasher (SO.WE.BO.) 824
 for Dishwasher (SOTAL) F600
 for Dishwasher (STORME) LT500
 for Dishwasher (UNIC) A410E



STORME

3122172 ELECTRIC PUMP IME 0.30HP 230V 50Hz


inlet external \varnothing 32 mm - outlet external \varnothing 31 mm
 motor revolutions 2800
 0.30HP 230V 50Hz - capacitor 10 μ f
 for Dishwasher (NUOVA SIMONELLI) - Series KIARA
 for Dishwasher (SO.WE.BO.) 601 - 701
 for Glasswasher/Cupwasher (AFI) A35 - A35Z2 - A36
 for Glasswasher/Cupwasher (EUROSYSTEM) PRO100
 PRO200
 for Glasswasher/Cupwasher (HILTA) RB10 - RB22
 SB10 - SB22
 for Glasswasher/Cupwasher (IME OMNIWASH)
 Series JOLLY - UNOA - UNOQ - UNOT
 for Glasswasher/Cupwasher (NOSEM) C2010L - C4010L
 R1010
 for Glasswasher/Cupwasher (SAB ITALIA) C35 - C36



STORME

Suitable for:

3122432 ELECTRO-PUMP AP 1629030SX 0,30HP 230V
 inlet external \varnothing 32 mm - outlet external \varnothing 31 mm
 motor revolutions 2800
 0.30HP 230V 50Hz - capacitor 10 μ f
 for Dishwasher (SO.WE.BO.) 601 - 701
 for Glasswasher/Cupwasher (AFI) A35 - A35Z2 - A36
 for Glasswasher/Cupwasher (EUROSYSTEM) PRO100
 PRO200
 for Glasswasher/Cupwasher (HILTA) RB10 - RB22
 SB10 - SB22
 for Glasswasher/Cupwasher (IME OMNIWASH) JOLLY
 UNOA - UNOQ - UNOT
 for Glasswasher/Cupwasher (NOSEM) C2010L - C4010L
 NR101 - R1010
 for Glasswasher/Cupwasher (NUOVA SIMONELLI) KIARA1
 for Glasswasher/Cupwasher (SAB ITALIA) C35 - C36



STORME LF-3122172

STORME

Suitable for:

3122434 ELECTRO-PUMP AP 2031SX 1HP 230V 50Hz
 inlet external \varnothing 46 mm - outlet external \varnothing 40 mm
 motor revolutions 2800
 1HP 230V 50Hz - capacitor 12.5 μ f
 for Dishwasher (AFI) A600
 for Dishwasher (IME OMNIWASH) 4Q82
 for Dishwasher hood type (AFI) A1000L
 for Dishwasher hood type (IME OMNIWASH) SEI1P
 SEI2P



STORME

3122728 ELECTRO-PUMP IME 1HP 230V 50Hz
 inlet external \varnothing 46 mm - outlet external \varnothing 41 mm
 for Dishwasher (SAB ITALIA) K5.2P
 for Dishwasher hood type (EUROSYSTEM) PRO600
 for Dishwasher hood type (HILTA) W14 - W15
 for Dishwasher hood type (IME OMNIWASH) SEI2P
 SEI2PA - SEI2PB
 for Dishwasher hood type (NOSEM) K602
 for Dishwasher hood type (NUOVA SIMONELLI) LTM1600
 for Dishwasher hood type (SO.WE.BO.) 6.2PA - 6.2PB
 for Dishwasher hood type (SOTAL) C1300
 for Dishwasher hood type (STORME) L502



STORME

Relays

3351012 RELAY 3TG 1001-1AL2
 16A 230V 50/60Hz
 contacts:3 NO + 1 NC
 for JOLLY Q/T - QUATTRO Q82



STORME



Suitable for:

STORME


Suitable for:



Rinse aid containers and accessories

3066040 COMPLETE RINSE AID CONTAINER

for Dishwasher (AFI) A600
 for Dishwasher (EUROSYSTEM) PRO400
 for Dishwasher (HILTA) S41 - S42
 for Dishwasher (NOSEM) C1010 - C5000 - C5010
 C5020 - NC501
 for Dishwasher (SO.WE.BO.) ONE - 701 - 752 - 824
 for Dishwasher (SOTAL) F600
 for Dishwasher (STORME) LT500M
 for Dishwasher (UNIC) A410E
 for Glasswasher/Cupwasher (AFI) A35Z2
 for Glasswasher/Cupwasher (NOSEM) NC201 - NR101
 for Glasswasher/Cupwasher (SO.WE.BO.) 742
 for Glasswasher/Cupwasher (SOTAL) C230



STORME

3324004 PLUG FOR RINSE AID CONTAINER ø 2x80 mm


for Dishwasher (AFI) A600
 for Dishwasher (EUROSYSTEM) PRO400
 for Dishwasher (HILTA) S41 - S42
 for Dishwasher (NOSEM) C1010 - C5000 - C5010
 C5020 - NC501
 for Dishwasher (SO.WE.BO.) ONE - 701 - 752 - 824
 for Dishwasher (SOTAL) F600
 for Dishwasher (STORME) LT500M
 for Dishwasher (UNIC) A410E
 for Glasswasher/Cupwasher (AFI) A35Z2
 for Glasswasher/Cupwasher (NOSEM) NC201 - NR101
 for Glasswasher/Cupwasher (SO.WE.BO.) 742
 for Glasswasher/Cupwasher (SOTAL) C230



STORME

3439001 RINSE AID CONTAINER

for Dishwasher (AFI) A600
 for Dishwasher (EUROSYSTEM) PRO400
 for Dishwasher (HILTA) S41 - S42
 for Dishwasher (NOSEM) C1010 - C5000 - C5010
 C5020 - NC501
 for Dishwasher (SO.WE.BO.) ONE - 701 - 752 - 824
 for Dishwasher (SOTAL) F600
 for Dishwasher (STORME) LT500M
 for Dishwasher (UNIC) A410E
 for Glasswasher/Cupwasher (AFI) A35Z2
 for Glasswasher/Cupwasher (NOSEM) NC201 - NR101
 for Glasswasher/Cupwasher (SO.WE.BO.) 742
 for Glasswasher/Cupwasher (SOTAL) C230



STORME

Rinse aid pumps and accessories

3090070 HYDRAULIC RINSE AID INJECTOR IB1

with smooth connecting tube ø 10 mm
 flow rate regulator



STORME

3090073 INJECTOR DIAPHRAGM

for Dishwasher (SO.WE.BO.) NK6.2P - 601CQ - 601CT
 661CQ - 661CT - 824
 for Glasswasher/Cupwasher (SO.WE.BO.) 712CQ
 712CT



STORME



Suitable for:

3090072 INJECTOR NON-RETURN VALVE

for Dishwasher (SO.WE.BO.) NK6.2P - QUATTRO
601CQ - 601CT - 661CQ - 661CT - 824
for Glasswasher/Cupwasher (SO.WE.BO.) 712CQ
712CT



STORME



Suitable for:

STORME

Sleeves

3248177 DRAIN HOSE FOR TANK

internal \varnothing 38 mm
overall length 455 mm
for Dishwasher (AFI) A600
for Dishwasher (EUROSYSTEM) PRO400
for Dishwasher (HILTA) S41 - S42
for Dishwasher (IME OMNIWASH) 4Q82
for Dishwasher (NOSEM) C5000 - C5010 - C5020
NC501
for Dishwasher (NUOVA SIMONELLI) KIARA6
for Dishwasher (SAB ITALIA) C50H
for Dishwasher (SO.WE.BO.) 824
for Dishwasher (SOTAL) F600ECO
for Dishwasher (STORME) LT500
for Dishwasher (UNIC) A410E



3349479 DRAIN PUMP INLET HOSE

internal \varnothing 30 and 37 mm
overall length 160 mm
for Dishwasher (AFI) A600
for Dishwasher (EUROSYSTEM) PRO400
for Dishwasher (HILTA) S41 - S42
for Dishwasher (IME OMNIWASH) 4Q82
for Dishwasher (NOSEM) C5000 - C5010 - C5020
NC501
for Dishwasher (NUOVA SIMONELLI) KIARA6
for Dishwasher (SAB ITALIA) C50H
for Dishwasher (SO.WE.BO.) 824
for Dishwasher (SOTAL) F600ECO
for Dishwasher (STORME) LT500
for Dishwasher (UNIC) A410E



STORME

STORME

3248171 INLET HOSE

internal \varnothing 43 mm
overall length 335 mm
for Dishwasher (IME OMNIWASH) SEI1PCQ - SEI2PCQ
for Dishwasher (NUOVA SIMONELLI) SEI1PCQ - SEI2PCQ
for Dishwasher (SAB ITALIA) K5.2P
for Dishwasher (UNIC) A61A - A61B
for Dishwasher hood type (AFI) A1000L
for Dishwasher hood type (EUROSYSTEM) PRO600
for Dishwasher hood type (HILTA) W13 - W14 - W15
for Dishwasher hood type (NOSEM) K601 - K602
for Dishwasher hood type (NUOVA SIMONELLI) LTM1500
LTM1600
for Dishwasher hood type (SAB ITALIA) K5.1P
for Dishwasher hood type (SO.WE.BO.) 6.1P - 6.2P
6.2PB



3248173 INLET HOSE

internal \varnothing 43 mm
overall length 485 mm
for Dishwasher (IME OMNIWASH) SEI1PCQ - SEI2PCQ
4SA
for Dishwasher (SAB ITALIA) K5.2P
for Dishwasher (UNIC) A61A - A61B
for Dishwasher hood type (AFI) A1000L
for Dishwasher hood type (EUROSYSTEM) PRO600
for Dishwasher hood type (HILTA) W13 - W14 - W15
for Dishwasher hood type (IME OMNIWASH) SEI2P
for Dishwasher hood type (NOSEM) K601 - K602
for Dishwasher hood type (NUOVA SIMONELLI) LTM1500
LTM1600
for Dishwasher hood type (SAB ITALIA) K5.1P
for Dishwasher hood type (SO.WE.BO.) 6.1P - 6.2P



STORME

STORME



Suitable for:

STORME



3248174 INLET HOSE

internal \varnothing 30 mm - 37 mm
 for Dishwasher (SO.WE.BO.) ONE - 601 - 701 - 752
 for Glasswasher/Cupwasher (AFI) A35 - A35Z2 - A36
 for Glasswasher/Cupwasher (EUROSYSTEM) PRO100
 PRO200
 for Glasswasher/Cupwasher (HILTA) RB10 - RB22
 SB10 - SB22
 for Glasswasher/Cupwasher (IME OMNIWASH)
 Series DUE - JA35 - JA36 - JA40 - JA41
 Series JOLLY - Series UNO
 for Glasswasher/Cupwasher (NOSEM) C2010L - C4010L
 NC201 - NR101 - R1010L
 for Glasswasher/Cupwasher (NUOVA SIMONELLI) KIARA1
 KIARA2 - KIARA4
 for Glasswasher/Cupwasher (SAB ITALIA) C35 - C36



STORME

3248023 OUTLET HOSE

internal \varnothing 30 mm
 overall length 200 mm
 for Dishwasher (IME OMNIWASH) CL - CS
 for Dishwasher (SO.WE.BO.) CL - CS - DUE - UNO
 601 - 701 - 752
 for Glasswasher/Cupwasher (AFI) A35 - A35Z2 - A36
 for Glasswasher/Cupwasher (EUROSYSTEM) PRO100
 PRO200
 for Glasswasher/Cupwasher (HILTA) RB10 - RB22
 SB10 - SB22
 for Glasswasher/Cupwasher (IME OMNIWASH) DUE
 JA35 - JA36 - JA40 - JA41 - JOLLY - UNO
 for Glasswasher/Cupwasher (NOSEM) C2010L - C4010L
 NC201 - NR101 - R1010L
 for Glasswasher/Cupwasher (NUOVA SIMONELLI) KIARA1



STORME

Suitable for:

3248175 INLET HOSE

internal \varnothing 44 mm
 overall length 280 mm
 for Dishwasher (AFI) A600
 for Dishwasher (EUROSYSTEM) PRO400
 for Dishwasher (HILTA) S41 - S42
 for Dishwasher (IME OMNIWASH) 4Q82
 for Dishwasher (NOSEM) C5000 - C5010 - C5020
 NC501
 for Dishwasher (NUOVA SIMONELLI) KIARA6
 for Dishwasher (SAB ITALIA) C50H
 for Dishwasher (SO.WE.BO.) 824
 for Dishwasher (SOTAL) F600ECO
 for Dishwasher (STORME) LT500
 for Dishwasher (UNIC) A410E



STORME

3248045 OUTLET HOSE

\varnothing internal 36 mm
 overall length 320 mm
 for Dishwasher (AFI) A600
 for Dishwasher (EUROSYSTEM) PRO400
 for Dishwasher (HILTA) S41 - S42
 for Dishwasher (IME OMNIWASH) QUATTROBA
 QUATTROQ82 - QUATTROSA - QUATTROT
 for Dishwasher (NOSEM) C5000 - C5010 - C5020
 NC501
 for Dishwasher (NUOVA SIMONELLI) KIARA6
 for Dishwasher (SAB ITALIA) C50H
 for Dishwasher (SO.WE.BO.) 824
 for Dishwasher (SOTAL) F600ECO
 for Dishwasher (STORME) LT500
 for Dishwasher (UNIC) A410E



STORME

3248172 OUTLET HOSE

internal \varnothing 30 and 40 mm
 overall length 490 mm
 for Dishwasher (IME OMNIWASH) SEI1PCQ - SEI2PCQ
 for Dishwasher (SAB ITALIA) K5.2P
 for Dishwasher (UNIC) A61A - A61B
 for Dishwasher hood type (AFI) A1000L
 for Dishwasher hood type (EUROSYSTEM) PRO600
 for Dishwasher hood type (HILTA) W13 - W14 - W15
 for Dishwasher hood type (NOSEM) K601 - K602
 for Dishwasher hood type (NUOVA SIMONELLI) LTM1500
 LTM1600
 for Dishwasher hood type (SAB ITALIA) K5.1P
 for Dishwasher hood type (SO.WE.BO.) 6.1P - 6.2P
 6.2PB
 for Dishwasher hood type (SOTAL) C1300



STORME

3349477 PUMP OUTLET HOSE

internal \varnothing 29-40 mm
 overall length 1275 mm
 for Dishwasher (IME OMNIWASH) SEI1PCQ - SEI2PCQ
 for Dishwasher (SAB ITALIA) K5.2P
 for Dishwasher (UNIC) A61A - A61B
 for Dishwasher hood type (AFI) A1000L
 for Dishwasher hood type (EUROSYSTEM) PRO600
 for Dishwasher hood type (HILTA) W13 - W14 - W15
 for Dishwasher hood type (NOSEM) K601 - K602
 for Dishwasher hood type (NUOVA SIMONELLI) LTM1500
 LTM1600
 for Dishwasher hood type (SAB ITALIA) K5.1P
 for Dishwasher hood type (SO.WE.BO.) 6.1P - 6.2P
 6.2PB
 for Dishwasher hood type (SOTAL) C1300



STORME

3250211 HOOD LIFTING SPRING 925 mm

for OMNIWASH SEI 1PCQ-2PCQ-2PCQB
 for SIMONELLI LTM1500-LTM1600



STORME

Suitable for:

3248179 OUTLET HOSE

internal \varnothing 25 mm
 overall length 370 mm
 for Dishwasher (SO.WE.BO.) ONE - 601 - 701 - 752
 for Glasswasher/Cupwasher (AFI) A35 - A35Z2 - A36
 for Glasswasher/Cupwasher (EUROSYSTEM) PRO100
 PRO200
 for Glasswasher/Cupwasher (HILTA) RB10 - RB22
 SB10 - SB22
 for Glasswasher/Cupwasher (IME OMNIWASH)
 Series DUE - Series J - Series JOLLY - Series UNO
 for Glasswasher/Cupwasher (NOSEM) C2010L - C4010L
 NC201 - NR101 - R1010L
 for Glasswasher/Cupwasher (NUOVA SIMONELLI) KIARA1
 KIARA2 - KIARA4
 for Glasswasher/Cupwasher (SAB ITALIA) C35 - C36



STORME

3248176 TOP/BOTTOM OUTLET HOSE

internal \varnothing 35 - 37 - 40 mm
 overall length 1400 mm
 for Dishwasher (AFI) A600
 for Dishwasher (EUROSYSTEM) PRO400
 for Dishwasher (HILTA) S41 - S42
 for Dishwasher (IME OMNIWASH) 4Q82
 for Dishwasher (NOSEM) C5000 - C5010 - C5020
 NC501
 for Dishwasher (NUOVA SIMONELLI) KIARA6
 for Dishwasher (SAB ITALIA) C50H
 for Dishwasher (SO.WE.BO.) 824
 for Dishwasher (SOTAL) F600ECO
 for Dishwasher (STORME) LT500
 for Dishwasher (UNIC) A410E



STORME

Springs

3318013 SPRING HOOK PULLEY

for OMNIWASH SEI 1PCQ-2PCQ-2PCQB
 for SIMONELLI LTM1500-LTM1600



STORME



Suitable for:

3053526 STAINLESS STEEL TIE ROD

for OMNIWASH SEI 1PCQ-2PCQ-2PCQB
for SIMONELLI LTM1500-LTM1600



STORME




Suitable for:

STORME

Switches

3319195 BLACK CHANGE-OVER BUTTON WITH SERIGRAPHY

for Dishwasher (AFI) A600
for Dishwasher (EUROSYSTEM) PRO400
for Dishwasher (IME OMNIWASH) 4Q82
for Dishwasher (NOSEM) C5000 - C5010 - C5020
NC501
for Dishwasher (NUOVA SIMONELLI) KIARA6
for Dishwasher (SAB ITALIA) C50H
for Dishwasher (SO.WE.BO.) 824
for Dishwasher (STORME) LT500T



STORME

3319399 BLACK SILK-SCREEN PR.PUSH-BUTTON

for Dishwasher (NOSEM) K602S
for Dishwasher (SAB ITALIA) K5.2P
for Dishwasher (UNIC) A61A - A61B
for Dishwasher hood type (AFI) A1000L
for Dishwasher hood type (HILTA) W13 - W14 - W15
for Dishwasher hood type (IME OMNIWASH) SEI1P
SEI2P
for Dishwasher hood type (NOSEM) K601
for Dishwasher hood type (NUOVA SIMONELLI) LTM1500
for Dishwasher hood type (SAB ITALIA) K5.1P
for Dishwasher hood type (SO.WE.BO.) 6.1P - 6.2P
for Dishwasher hood type (SOTAL) C1300
for Dishwasher hood type (STORME) L501 - L502
for Dishwasher hood type (UNIC) A61



STORME

3319400 BLACK SILK-SCREEN PR.PUSH-BUTTON

for Dishwasher (NOSEM) K602S
for Dishwasher (SAB ITALIA) K5.2P
for Dishwasher (STORME) A61A - A61B
for Dishwasher hood type (AFI) A1000L
for Dishwasher hood type (HILTA) W13 - W14 - W15
for Dishwasher hood type (IME OMNIWASH) SEI1P
SEI2P
for Dishwasher hood type (NOSEM) K601
for Dishwasher hood type (NUOVA SIMONELLI) LTM1500
for Dishwasher hood type (SAB ITALIA) K5.1P
for Dishwasher hood type (SO.WE.BO.) 6.1P - 6.2P
for Dishwasher hood type (STORME) L501 - L502
for Dishwasher hood type (UNIC) A61



STORME

3319404 BLACK SILK-SCREEN PR.PUSH-BUTTON

for Dishwasher (NOSEM) K602S
for Dishwasher (SAB ITALIA) K5.2P
for Dishwasher (UNIC) A61A - A61B
for Dishwasher hood type (AFI) A1000L
for Dishwasher hood type (HILTA) W13 - W15
for Dishwasher hood type (IME OMNIWASH) SEI1P
SEI2P
for Dishwasher hood type (NOSEM) K601
for Dishwasher hood type (SAB ITALIA) K5.1P
for Dishwasher hood type (SO.WE.BO.) 6.1P - 6.2P
for Dishwasher hood type (STORME) L501 - L502
for Dishwasher hood type (UNIC) A61



STORME

3319405 BLACK SILK-SCREEN PR.PUSH-BUTTON

for Dishwasher (NOSEM) K602S
 for Dishwasher (SAB ITALIA) K5.2P
 for Dishwasher (UNIC) A61A - A61B
 for Dishwasher hood type (AFI) A1000L
 for Dishwasher hood type (HILTA) W13 - W15
 for Dishwasher hood type (IME OMNIWASH) SEI1P SEI2P
 for Dishwasher hood type (NOSEM) K601
 for Dishwasher hood type (SAB ITALIA) K5.1P
 for Dishwasher hood type (SO.WE.BO.) 6.1P - 6.2P
 for Dishwasher hood type (STORME) L501 - L502
 for Dishwasher hood type (UNIC) A61



STORME

3319130 GREEN BIPOLAR CHANGE OVER SWITCH 250V 16


with indicator lamp
 mounting hole 12x34 mm
 for Dishwasher (SO.WE.BO.) 601
 for Glasswasher/Cupwasher (AFI) A35 - A36
 for Glasswasher/Cupwasher (EUROSYSTEM) PRO100 PRO200
 for Glasswasher/Cupwasher (HILTA) RB10 - RB22 SB10 - SB22
 for Glasswasher/Cupwasher (IME OMNIWASH) DUECL DUECS - UNOCL - UNOCS
 for Glasswasher/Cupwasher (NOSEM) C2010L - C4010L R1010L
 for Glasswasher/Cupwasher (NUOVA SIMONELLI) KIARA1 KIARA2 - KIARA4
 for Glasswasher/Cupwasher (SAB ITALIA) C35 - C36



STORME

3319627 DOUBLE CHANGE OVER SWITCH 16A 250V

for Dishwasher (CONTI) CM5000
 for Dishwasher (ELETTROBAR) E50 - E51 - E52
 for Dishwasher (EUROSYSTEM) A600
 for Dishwasher (SAB ITALIA) K5.2P - K6.1P
 for Dishwasher (SOTAL) C13001P
 for Dishwasher (UNIC) A61A
 for Dishwasher hood type (AFI) A1000L
 for Dishwasher hood type (HILTA) W13 - W15
 for Dishwasher hood type (IME OMNIWASH) SEI1P SEI2P
 for Dishwasher hood type (NOSEM) K601 - K602
 for Dishwasher hood type (NUOVA SIMONELLI) LTM1500
 for Dishwasher hood type (SO.WE.BO.) 6.1P - 6.2PB
 for Dishwasher hood type (SOTAL) C1300
 for Dishwasher hood type (UNIC) A61



STORME

3319175 GREEN CHANGE OVER SWITCH 16A 24V

with indicator lamp
 max temperature 120°C
 mounting hole 22x30 mm
 for Dishwasher hood type (IME OMNIWASH) SEI2P
 for Dishwasher hood type (STORME) L502



STORME



Suitable for:

STORME



Suitable for:

3319172 GREEN WARM/COLD BIPOLAR SWITCH


16(6)A/250V
 for Dishwasher (AFI) A600 - A900
 for Dishwasher (EUROSYSTEM) PRO400
 for Dishwasher (HILTA) S41 - S42
 for Dishwasher (IME OMNIWASH) 4Q82
 for Dishwasher (NUOVA SIMONELLI) KIARA6
 for Dishwasher (SAB ITALIA) C50H
 for Dishwasher (SO.WE.BO.) 1342 - 824
 for Dishwasher (SOTAL) F600
 for Dishwasher (STORME) LT500M - LT500T
 for Dishwasher (UNIC) A410E
 for Glasswasher/Cupwasher (SO.WE.BO.) 742



STORME

3319524 ON/OFF SWITCH

with support
 for Dishwasher (NOSEM) K602S
 for Dishwasher (SAB ITALIA) K5.2P
 for Dishwasher hood type (HILTA) W14
 for Dishwasher hood type (IME OMNIWASH) SEI2P
 for Dishwasher hood type (SO.WE.BO.) 6.2P
 for Dishwasher hood type (SOTAL) C1300
 for Dishwasher hood type (STORME) L502



STORME

3057282 OPEN CONTACT 230V - 6A

for Dishwasher (NOSEM) K602S
 for Dishwasher (SAB ITALIA) K5.2P
 for Dishwasher (UNIC) A61A
 for Dishwasher hood type (HILTA) W14
 for Dishwasher hood type (IME OMNIWASH) SEI1P
 for Dishwasher hood type (SO.WE.BO.) 6.1P - 6.2PA
 for Dishwasher hood type (SOTAL) C1300
 for Dishwasher hood type (STORME) L502



STORME

STORME LF-3454035

3319174 ORANGE BIPOLAR PUSH-BUTTON 16A 250V

mounting hole 30x22 mm
 for Dishwasher (AFI) A600
 for Dishwasher (EUROSYSTEM) PRO400
 for Dishwasher (HILTA) S41 - S42
 for Dishwasher (IME OMNIWASH) 4Q82
 for Dishwasher (NOSEM) C5000 - C5010 - C5020
 NC501
 for Dishwasher (NUOVA SIMONELLI) KIARA6
 for Dishwasher (SAB ITALIA) C50H
 for Dishwasher (SO.WE.BO.) 701 - 752 - 824
 for Dishwasher (SOTAL) F600ECO
 for Dishwasher (STORME) LT500M - LT500T
 for Dishwasher (UNIC) A410E
 for Glasswasher/Cupwasher (AFI) A35Z2
 for Glasswasher/Cupwasher (NOSEM) NC201 - NR101



STORME

3319171 ORANGE BIPOLAR PUSH-BUTTON 24V

mounting hole 30x22 mm
 for Dishwasher hood type (IME OMNIWASH) SEI2P
 for Dishwasher hood type (STORME) L502



STORME

Suitable for:

3319173 ORANGE BIPOLAR SWITCH

16(6)A/250V
for drain pump
for Dishwasher (AFI) A600 - A900
for Dishwasher (EUROSYSTEM) PRO400
for Dishwasher (HILTA) S41 - S42
for Dishwasher (IME OMNIWASH) 4Q82
for Dishwasher (NUOVA SIMONELLI) KIARA6
for Dishwasher (SAB ITALIA) C50H
for Dishwasher (SO.WE.BO.) 1342 - 824
for Dishwasher (SOTAL) F600
for Dishwasher (STORME) LT500M
for Dishwasher (UNIC) A410E
for Glasswasher/Cupwasher (SO.WE.BO.) 742



STORME

Suitable for:

3319176 ORANGE REGENERATION BIPOLAR SWITCH

contact capacity 10(4)A 250V
for Dishwasher (AFI) A600 - A900
for Dishwasher (EUROSYSTEM) PRO400
for Dishwasher (HILTA) S41 - S42
for Dishwasher (IME OMNIWASH) 4Q82
for Dishwasher (NUOVA SIMONELLI) KIARA6
for Dishwasher (SAB ITALIA) C50H
for Dishwasher (SO.WE.BO.) 1342 - 824
for Dishwasher (SOTAL) F600
for Dishwasher (STORME) LT500M - LT500T
for Dishwasher (UNIC) A41
for Glasswasher/Cupwasher (SO.WE.BO.) 742



STORME

3319011 RED TWO-POLE PUSH-BUTTON 16A 250V


normally closed
with indicator lamp and push-button cap
max temperature 120°C
mounting hole 22x30 mm



STORME

3319523 SWITCH 3 POSITIONS

with support
for Dishwasher (NOSEM) K6025
for Dishwasher (SAB ITALIA) K5.2P
for Dishwasher (SOTAL) C1300
for Dishwasher (UNIC) A61A
for Dishwasher hood type (HILTA) W14
for Dishwasher hood type (IME OMNIWASH) SEI2P
for Dishwasher hood type (NOSEM) K602
for Dishwasher hood type (SO.WE.BO.) 6.1P - 6.2PA
for Dishwasher hood type (STORME) L502




STORME LF-3057292

STORME

3454040 NORMALLY CLOSED CONTACT 12A 400V

for Dishwasher hood type (AFI) A1000L
for Dishwasher hood type (EUROSYSTEM) PRO600
for Dishwasher hood type (HILTA) W13 - W14 - W15
for Dishwasher hood type (IME OMNIWASH) SEI1P
SEI2P
for Dishwasher hood type (NOSEM) K601 - K602
for Dishwasher hood type (NUOVA SIMONELLI) LTM1500
LTM1600
for Dishwasher hood type (SAB ITALIA) K5.1P
for Dishwasher hood type (SO.WE.BO.) 6.1P - 6.2P
6.2PB
for Dishwasher hood type (SOTAL) C1300
for Dishwasher hood type (STORME) L501 - L502
for Dishwasher hood type (UNIC) A61



STORME



Suitable for:

STORME



3319132 YELLOW RINSE BIPOLAR SWITCH

bipolar switch
with indicator lamp 16A 250V
mounting hole 12x34 mm
for Dishwasher (SO.WE.BO.) 601
for Glasswasher/Cupwasher (AFI) A35 - A36
for Glasswasher/Cupwasher (EUROSYSTEM) PRO100
PRO200
for Glasswasher/Cupwasher (HILTA) RB10 - RB22
SB10 - SB22
for Glasswasher/Cupwasher (IME OMNIWASH) DUECL
DUECS - UNOCL - UNOCS
for Glasswasher/Cupwasher (NOSEM) C2010L - C4010L
R1010L
for Glasswasher/Cupwasher (NUOVA SIMONELLI) KIARA1
KIARA2 - KIARA4



STORME

Suitable for:

3319131 YELLOW START BIPOLAR SWITCH 250V 16A

bipolar switch
with indicator lamp
mounting hole 12x34 mm
for Dishwasher (SO.WE.BO.) 601
for Glasswasher/Cupwasher (AFI) A35 - A36
for Glasswasher/Cupwasher (EUROSYSTEM) PRO100
PRO200
for Glasswasher/Cupwasher (HILTA) RB10 - RB22
SB10 - SB22
for Glasswasher/Cupwasher (IME OMNIWASH) DUECL
DUECS - UNOCL - UNOCS
for Glasswasher/Cupwasher (NOSEM) C2010L - C4010L
R1010L
for Glasswasher/Cupwasher (NUOVA SIMONELLI) KIARA1
KIARA2 - KIARA4




STORME

Thermostats

3444246 SAFETY THERMOSTAT FOR BOILER 100°C


4 contacts 16A 250V
for Dishwasher (AFI) A600 - A900
for Dishwasher (SAB ITALIA) C50H
for Dishwasher (SO.WE.BO.)
for Dishwasher (UNIVERBAR) BRAMA - CASTA - COSMO
LOGOS - LOGOSD - MIDI50 - MIDI50D - OMEGA
OMEGAD - SINCRO - SINCROD - TOP
for Dishwasher hood type (IME OMNIWASH) SEI1P
SEI2P
for Dishwasher hood type (UNIVERBAR) COMPACT
for Glasswasher/Cupwasher (AFI) A35 - A35Z2 - A36
for Glasswasher/Cupwasher (NOSEM) R1010
for Glasswasher/Cupwasher (SAB ITALIA) C35 - C36
for Glasswasher/Cupwasher (UNIVERBAR) BET37
BET37D - BET40 - BET40D - ERGON - ERGOND



STORME

3744070 SAFETY THERMOSTAT FOR TANK 85°C

4 contacts 16A 250V
for Dishwasher hood type (AFI) A1000L
for Dishwasher hood type (EUROSYSTEM) PRO600
for Dishwasher hood type (HILTA) W13 - W15
for Dishwasher hood type (IME OMNIWASH) SEI2P
SEI2PS
for Dishwasher hood type (NOSEM) K601 - K602
for Dishwasher hood type (NUOVA SIMONELLI) LTM1500
LTM1600
for Dishwasher hood type (SAB ITALIA) K5.1P
for Dishwasher hood type (SO.WE.BO.) 6.1P - 6.2P
for Dishwasher hood type (SOTAL) C1300
for Dishwasher hood type (STORME) L501 - L502
for Dishwasher hood type (UNIC) A61




STORME



Suitable for:


3444268 SINGLE-PHASE THERMOSTAT 0-90°C
 covered capillary 1000 mm
 bulb \varnothing 6.5x95 mm
 15A 250V
 D shaft \varnothing 6x4.6 mm
 for Dishwasher (IME OMNIWASH)
 for Dishwasher (RANCILIO) - Series LS
 for Glasswasher/Cupwasher (RANCILIO) - Series LT



STORME

Suitable for:


3444269 SINGLE-PHASE THERMOSTAT 52°C
 covered capillary 1000 mm
 bulb \varnothing 6.5x95 mm
 15A 250V
 for Dishwasher (AFI) A600 - A900
 for Dishwasher (IME OMNIWASH)
 for Dishwasher (SAB ITALIA) C50H
 for Dishwasher (SO.WE.BO.)
 for Glasswasher/Cupwasher (AFI) A35 - A35Z2 - A36
 for Glasswasher/Cupwasher (NOSEM) R1010
 for Glasswasher/Cupwasher (SAB ITALIA) C35 - C36



STORME


Timers

3446200 PROGRAMMER P26 2 CAMS
 cycle 120 seconds, 230V 50Hz, without pin
 for DRAIN PUMP
 for Dishwasher (EUROSYSTEM) PRO400
 for Dishwasher (HILTA) S41 - S42
 for Dishwasher (IME OMNIWASH) 4Q82
 for Dishwasher (NOSEM) C5000 - C5010 - C5020
 NC501
 for Dishwasher (NUOVA SIMONELLI) KIARA 6CF
 for Dishwasher (SAB ITALIA) C50H
 for Dishwasher (SO.WE.BO.) 824
 for Dishwasher (SOTAL) F600ECO
 for Dishwasher (STORME) LT5 - LT500M
 for Glasswasher/Cupwasher (AFI) A35Z2




STORME

3322261 PROGRAMMER P265 3 CAMS
 cycle 4 minutes
 230V 50/60Hz
 counter-clockwise rotation
 D-shaped pin \varnothing 6x4.6 mm
 for Dishwasher (NUOVA SIMONELLI) KIARA6CF
 for Dishwasher (SAB ITALIA) C50H
 for Dishwasher (SO.WE.BO.) 1342 - 701 - 752 - 824
 for Dishwasher (STORME) LT500T
 for Glasswasher/Cupwasher (AFI) A35Z2
 for Glasswasher/Cupwasher (IME OMNIWASH) DUE - UNO
 for Glasswasher/Cupwasher (SOTAL) C230



STORME

3322260 PROGRAMMER 7805DV 5 CAMS
 50Hz - without pin
 1° cycle 6" - 2° cycle 180"
 for Dishwasher (IME OMNIWASH) GL1040 - GL1240
 SEI1PCQ
 for Dishwasher (SAB ITALIA) K1.5P
 for Dishwasher (UNIC) A61A
 for Dishwasher hood type (AFI) A1000L
 for Dishwasher hood type (HILTA) W13
 for Dishwasher hood type (NOSEM) K601
 for Dishwasher hood type (NUOVA SIMONELLI) LTM1500
 for Dishwasher hood type (SO.WE.BO.) 6.1P
 for Dishwasher hood type (STORME) L501



STORME

3446199 PROGRAMMER 7805DV 5 CAMS
 1° cycle 6 seconds - 2° cycle 135 seconds
 230V 50Hz
 for Dishwasher (IME OMNIWASH) 6.2PS
 for Dishwasher (NOSEM) K602S
 for Dishwasher (SAB ITALIA) K5.2P
 for Dishwasher (UNIC) A61A
 for Dishwasher hood type (HILTA) W14
 for Dishwasher hood type (SO.WE.BO.) 6.2P
 for Dishwasher hood type (SOTAL) C1300
 for Dishwasher hood type (STORME) L502



STORME




Suitable for:

STORME



3322225 TIMER P25 230V 3 CAMS

cycle 120 seconds
 230V 50/60HZ
 without shaft
 for Dishwasher (NOSEM) R101L
 for Dishwasher (NUOVA SIMONELLI) KIARA4CF
 KIARA4CG
 for Glasswasher/Cupwasher (EUROSYSTEM) PRO200
 for Glasswasher/Cupwasher (HILTA) RB22 - SB22
 for Glasswasher/Cupwasher (IME OMNIWASH) DUE - UNO
 for Glasswasher/Cupwasher (NOSEM) C4010L
 for Glasswasher/Cupwasher (SO.WE.BO.) 712
 for Glasswasher/Cupwasher (STORME) ME400
 for Glasswasher/Cupwasher (UNIC) A20 - A21



STORME

3322147 TIMER P26 5 CAMS

230V 50/60Hz
 1st cycle: 4 minutes
 2nd cycle: 40 seconds
 for Dishwasher (AFI) A900
 for Dishwasher (EUROSYSTEM) PRO400
 for Dishwasher (HILTA) S42
 for Dishwasher (IME OMNIWASH) DUE Q/82
 QUATTROQ82 - UNOQ82
 for Dishwasher (NOSEM) C5010 - NC501
 for Dishwasher (NUOVA SIMONELLI) KIARA
 for Dishwasher (SAB ITALIA) C50H
 for Dishwasher (SO.WE.BO.) 1342 - 824
 for Dishwasher (STORME) LT500T




STORME

Suitable for:

3322203 TIMER P255 3 CAMS

230V 50/60Hz
 cycle 150 seconds
 without pin
 for Dishwasher (NUOVA SIMONELLI) KIARA1CF
 KIARA1CG - KIARA2CF
 for Dishwasher (SO.WE.BO.) 601
 for Dishwasher (UNIC) A10 - A11
 for Glasswasher/Cupwasher (AFI) A35 - A36
 for Glasswasher/Cupwasher (EUROSYSTEM) PRO100
 for Glasswasher/Cupwasher (HILTA) RB10 - SB10
 for Glasswasher/Cupwasher (IME OMNIWASH) JOLLYA
 JOLLYAQ - JOLLYAT - JOLLYQ - JOLLYT
 for Glasswasher/Cupwasher (NOSEM) C2010L - R1010L
 for Glasswasher/Cupwasher (SAB ITALIA) C35 - C36
 for Glasswasher/Cupwasher (SO.WE.BO.) 600 - 631



STORME

3322146 TIMER 7807DV 7 CAMS

24V 50Hz
 cycle: 6-180 seconds
 for Dishwasher (IME OMNIWASH) SEI2PCQB
 for Dishwasher (SAB ITALIA) K5.2P
 for Dishwasher (STORME) L502BT
 for Dishwasher hood type (EUROSYSTEM) PRO600
 for Dishwasher hood type (HILTA) W15
 for Dishwasher hood type (NOSEM) K602
 for Dishwasher hood type (NUOVA SIMONELLI) LTM1600
 for Dishwasher hood type (SO.WE.BO.) 6.2PB
 for Dishwasher hood type (SOTAL) C1300



STORME



Wash and rinse arms and accessories

3243532 ARM ASSEMBLY SPINDLE 72 mm


for Dishwasher (SO.WE.BO.) 601 - 701 - 752
 for Glasswasher/Cupwasher (AFI) A35 - A35Z2 - A36
 for Glasswasher/Cupwasher (EUROSYSTEM) PRO100
 PRO200
 for Glasswasher/Cupwasher (HILTA) RB10 - RB22
 SB10 - SB22
 for Glasswasher/Cupwasher (IME OMNIWASH) DUEAQ
 JA35 - JA36 - JA40 - JA41 - JOLLYQ - JOLLYT
 UNOQ - UNOQ
 for Glasswasher/Cupwasher (NOSEM) C2010L - C4010L
 NC201 - NR101 - R1010
 for Glasswasher/Cupwasher (NUOVA SIMONELLI) KIARA1
 KIARA2 - KIARA4
 for Glasswasher/Cupwasher (SAB ITALIA) C35 - C36
 for Glasswasher/Cupwasher (SO.WE.BO.) 600 - 631



STORME

3743265 BOTTOM RING NUT

for Dishwasher (NOSEM) K602S
 for Dishwasher (SAB ITALIA) K5.2P
 for Dishwasher (SOTAL) C13001P
 for Dishwasher (STORME) L502BT
 for Dishwasher (UNIC) A61A - A61B
 for Dishwasher hood type (AFI) A1000L
 for Dishwasher hood type (EUROSYSTEM) PRO600
 for Dishwasher hood type (HILTA) W13 - W14 - W15
 for Dishwasher hood type (IME OMNIWASH) SEI1P
 SEI2P
 for Dishwasher hood type (NOSEM) K601 - K602
 for Dishwasher hood type (NUOVA SIMONELLI) LTM1500
 LTM1600
 for Dishwasher hood type (SAB ITALIA) K5.1P
 for Dishwasher hood type (SO.WE.BO.) 6.1P - 6.2P



STORME

3743646 BOTTOM WASH ARM ASSEMBLY SUPPORT CT

for Dishwasher (AFI) A600
 for Dishwasher (HILTA) S42
 for Dishwasher (IME OMNIWASH) 4Q82
 for Dishwasher (NOSEM) C2010
 for Dishwasher (SAB ITALIA) C50H
 for Dishwasher (STORME) LT500T
 for Glasswasher/Cupwasher (AFI) A35 - A35Z2 - A36
 for Glasswasher/Cupwasher (EUROSYSTEM) PRO100
 PRO200
 for Glasswasher/Cupwasher (HILTA) RB10 - RB22
 SB10 - SB22
 for Glasswasher/Cupwasher (IME OMNIWASH) DUEAT
 JOLLYAT - JOLLYT - UNOAT - UNOT
 for Glasswasher/Cupwasher (NOSEM) C4010L - R1010
 for Glasswasher/Cupwasher (NUOVA SIMONELLI) KIARA1



STORME

3743200 COMPLETE LOWER HUB SUPPORT

for Dishwasher (AFI) A600 - A900
 for Dishwasher (EUROSYSTEM) PRO400
 for Dishwasher (HILTA) S41 - S42
 for Dishwasher (IME OMNIWASH) QUATTROQ - TREQ
 4Q82
 for Dishwasher (NOSEM) C5000 - C5010 - C5020
 K602S - NC501
 for Dishwasher (SAB ITALIA) C50H - K5.2P
 for Dishwasher (SOTAL) C130001P
 for Dishwasher hood type (AFI) A1000L
 for Dishwasher hood type (HILTA) W13 - W14 - W15
 for Dishwasher hood type (IME OMNIWASH) SEI1P
 SEI2P
 for Dishwasher hood type (NOSEM) K601 - K602
 for Dishwasher hood type (SAB ITALIA) K5.1P



STORME



Suitable for:

STORME



3743054 COMPLETE WATER INLET FITTING

for Dishwasher (AFI) A600
 for Dishwasher (EUROSYSTEM) PRO400
 for Dishwasher (HILTA) S41 - S42
 for Dishwasher (IME OMNIWASH) 4Q82
 for Dishwasher (NOSEM) C5000 - C5010 - C5020
 NC501
 for Dishwasher (NUOVA SIMONELLI) KIARA6
 for Dishwasher (SAB ITALIA) C50H
 for Dishwasher (SO.WE.BO.) 824
 for Dishwasher (SOTAL) F600
 for Dishwasher (STORME) LT500
 for Dishwasher (UNIC) A410E
 for Glasswasher/Cupwasher (SO.WE.BO.) ONECQ
 ONECT



STORME

3243527 LOWER SUPPORT SHORT MODEL

for Dishwasher (SO.WE.BO.) 601 - 701 - 752
 for Glasswasher/Cupwasher (AFI) A35 - A35Z2 - A36
 for Glasswasher/Cupwasher (EUROSYSTEM) PRO100
 PRO200
 for Glasswasher/Cupwasher (HILTA) RB10 - RB22
 SB10 - SB22
 for Glasswasher/Cupwasher (IME OMNIWASH) DUEAQ
 DUECL - DUECS - JA35 - JA36 - JA40 - JA41
 JOLLYQ - JOLLYT - UNO AQ - UNOCL - UNOCS - UNOQ
 for Glasswasher/Cupwasher (NOSEM) C2010L - C4010L
 NC201 - NR101 - R1010
 for Glasswasher/Cupwasher (NUOVA SIMONELLI) KIARA1
 KIARA2 - KIARA4
 for Glasswasher/Cupwasher (SAB ITALIA) C35 - C36
 for Glasswasher/Cupwasher (SO.WE.BO.) 600 - 631




STORME

Suitable for:

3243526 LOWER RINSE SUPPORT

for Dishwasher (AFI) A600
 for Dishwasher (EUROSYSTEM) PRO400
 for Dishwasher (HILTA) S41 - S42
 for Dishwasher (IME OMNIWASH) 4Q82
 for Dishwasher (NOSEM) C5000 - C5010 - C5020
 NC501
 for Dishwasher (NUOVA SIMONELLI) KIARA6
 for Dishwasher (SAB ITALIA) C50H
 for Dishwasher (SO.WE.BO.) 824
 for Dishwasher (SOTAL) F600
 for Dishwasher (STORME) LT500
 for Dishwasher (UNIC) A410E
 for Glasswasher/Cupwasher (NOSEM) NR101
 for Glasswasher/Cupwasher (SO.WE.BO.) ONECQ
 ONECT



STORME

3743056 RINSE CONNECTION

for Dishwasher (SO.WE.BO.) 601
 for Glasswasher/Cupwasher (IME OMNIWASH) JOLLYA
 JOLLYQ
 for Glasswasher/Cupwasher (SO.WE.BO.) 600 - 631
 661 - 691




STORME



3743602 LOWER/UPPER WASH ARM

length 200 mm with jets
 for Dishwasher (SO.WE.BO.) 601 - 701 - 752
 for Glasswasher/Cupwasher (AFI) A35 - A35Z2 - A36
 for Glasswasher/Cupwasher (EUROSYSTEM) PRO100
 PRO200
 for Glasswasher/Cupwasher (HILTA) RB10 - RB22
 SB10 - SB22
 for Glasswasher/Cupwasher (IME OMNIWASH) DUEAQ
 JA35 - JA36 - JA40 - JA41 - JOLLYAQ - JOLLYQ
 UNOAT - UNOQ
 for Glasswasher/Cupwasher (NOSEM) C2010L - C4010L
 NC201 - NR101 - R1010
 for Glasswasher/Cupwasher (NUOVA SIMONELLI) KIARA1
 KIARA2 - KIARA4
 for Glasswasher/Cupwasher (SAB ITALIA) C35 - C36



STORME

3743267 RINSE ARM CAP

for Dishwasher (AFI) A600
 for Dishwasher (EUROSYSTEM) PRO400
 for Dishwasher (HILTA) S41 - S42
 for Dishwasher (IME OMNIWASH) 4Q82
 for Dishwasher (NOSEM) C5000 - C5010 - C5020
 NC501
 for Dishwasher (SAB ITALIA) C50H
 for Glasswasher/Cupwasher (AFI) A35 - A35Z2 - A36
 for Glasswasher/Cupwasher (EUROSYSTEM) PRO100
 PRO200
 for Glasswasher/Cupwasher (HILTA) RB10 - RB22
 SB10 - SB22
 for Glasswasher/Cupwasher (IME OMNIWASH) DUEAQ
 JOLLYAQ - JOLLYQ - UNOAT - UNOQ
 for Glasswasher/Cupwasher (NOSEM) C2010L - C4010L



STORME

3743510 LOWER/UPPER WASH ARM

length 200 mm
 for Glasswasher/Cupwasher (AFI) A35 - A35Z2 - A36
 for Glasswasher/Cupwasher (EUROSYSTEM) PRO100
 PRO200
 for Glasswasher/Cupwasher (HILTA) RB10 - RB22
 SB10 - SB22
 for Glasswasher/Cupwasher (IME OMNIWASH) DUEAT
 JA35 - JA36 - JA40 - JA41 - JOLLYAT - JOLLYT
 UNOAT - UNOT
 for Glasswasher/Cupwasher (NOSEM) C2010L - C4010L
 NC201 - NR101 - R1010
 for Glasswasher/Cupwasher (NUOVA SIMONELLI) KIARA1
 KIARA2 - KIARA4
 for Glasswasher/Cupwasher (SAB ITALIA) C35 - C36



STORME

3743624 RINSE ARM WITH NOZZLES AND RING NUTS

for Dishwasher (SO.WE.BO.) 601 - 701 - 752
 for Glasswasher/Cupwasher (AFI) A35 - A35Z2 - A36
 for Glasswasher/Cupwasher (EUROSYSTEM) PRO100
 PRO200
 for Glasswasher/Cupwasher (HILTA) RB10 - RB22
 SB10 - SB22
 for Glasswasher/Cupwasher (IME OMNIWASH) DUEAQ
 JA35 - JA36 - JA40 - JA41 - JOLLYAQ - JOLLYQ
 UNOAT - UNOQ
 for Glasswasher/Cupwasher (NOSEM) C2010L - C4010L
 NC201 - NR101 - R1010
 for Glasswasher/Cupwasher (NUOVA SIMONELLI) KIARA1
 KIARA2 - KIARA4
 for Glasswasher/Cupwasher (SAB ITALIA) C35 - C36
 for Glasswasher/Cupwasher (SO.WE.BO.) 600 - 631



STORME



Suitable for:

STORME



3743565 RINSE ROD SUPPORT EXTENSION OT

for Dishwasher (AFI) A600
 for Dishwasher (EUROSYSTEM) PRO400
 for Dishwasher (HILTA) S41 - S42
 for Dishwasher (IME OMNIWASH) 4Q82
 for Dishwasher (NOSEM) C5000 - C5010 - C5020
 NC501
 for Dishwasher (SAB ITALIA) C50H
 for Glasswasher/Cupwasher (AFI) A35 - A35Z2 - A36
 for Glasswasher/Cupwasher (EUROSYSTEM) PRO100
 PRO200
 for Glasswasher/Cupwasher (HILTA) RB10 - RB22
 SB10 - SB22
 for Glasswasher/Cupwasher (IME OMNIWASH) DUEAT
 JA35 - JA36 - JA40 - JA41 - JOLLYAT - JOLLYT
 UNOAT - UNOT



STORME

3243529 SPINDLE EXTENSION

for Dishwasher (SO.WE.BO.) 601 - 701 - 752
 for Glasswasher/Cupwasher (AFI) A35 - A35Z2 - A36
 for Glasswasher/Cupwasher (EUROSYSTEM) PRO100
 PRO200
 for Glasswasher/Cupwasher (HILTA) RB10 - RB22
 SB10 - SB22
 for Glasswasher/Cupwasher (IME OMNIWASH) DUEAQ
 JA35 - JA36 - JA40 - JA41 - JOLLYQ - JOLLYT
 UNOAQ - UNOQ
 for Glasswasher/Cupwasher (NOSEM) C2010L - C4010L
 NC201 - NR101 - R1010
 for Glasswasher/Cupwasher (NUOVA SIMONELLI) KIARA1
 KIARA2 - KIARA4
 for Glasswasher/Cupwasher (SAB ITALIA) C35 - C36
 for Glasswasher/Cupwasher (SO.WE.BO.) 600 - 631



STORME

Suitable for:

3743059 RINSE SHAFT SUPPORT

for Dishwasher (AFI) A600
 for Dishwasher (EUROSYSTEM) PRO400
 for Dishwasher (HILTA) S41 - S42
 for Dishwasher (IME OMNIWASH) 4Q82E
 for Dishwasher (NOSEM) C5000 - C5010 - C5020
 NC501
 for Dishwasher (NUOVA SIMONELLI) KIARA6
 for Dishwasher (SAB ITALIA) C50H
 for Dishwasher (SO.WE.BO.) 601 - 701 - 752 - 824
 for Dishwasher (SOTAL) F600ECO
 for Dishwasher (STORME) LT500
 for Dishwasher (UNIC) A410E
 for Glasswasher/Cupwasher (AFI) A35 - A35Z2 - A36
 for Glasswasher/Cupwasher (EUROSYSTEM) PRO100
 PRO200



STORME

3743269 TOP RINSE ARM FITTING

for Dishwasher hood type (IME OMNIWASH) SEI1P
 SEI2P



STORME

3743645 TOP WASH ARM ASSEMBLY JET SUPPORT CT

for Dishwasher (AFI) A600
 for Dishwasher (HILTA) S42
 for Dishwasher (IME OMNIWASH) 4Q82
 for Dishwasher (NOSEM) C2010
 for Dishwasher (SAB ITALIA) C50H
 for Dishwasher (STORME) LT500T
 for Glasswasher/Cupwasher (AFI) A35 - A35Z2 - A36
 for Glasswasher/Cupwasher (EUROSYSTEM) PRO100
 PRO200
 for Glasswasher/Cupwasher (HILTA) RB10 - RB22
 SB10 - SB22
 for Glasswasher/Cupwasher (IME OMNIWASH) DUEAT
 JOLLYAT - JOLLYT - UNOAT - UNOT
 for Glasswasher/Cupwasher (NOSEM) C4010L - R1010
 for Glasswasher/Cupwasher (NUOVA SIMONELLI) KIARA1



STORME

3743603 UPPER WASH ARM

height 145 mm - length 235 mm
 for Glasswasher/Cupwasher (IME OMNIWASH) DUEAT



STORME

3243533 UPPER WASH ARM ASSEMBLY SUPPORT

for Dishwasher (AFI) A600
 for Dishwasher (EUROSYSTEM) PRO400
 for Dishwasher (HILTA) S41 - S42
 for Dishwasher (IME OMNIWASH) 4Q82
 for Dishwasher (NOSEM) C5000 - C5010 - C5020
 NC501
 for Dishwasher (NUOVA SIMONELLI) KIARA6
 for Dishwasher (SAB ITALIA) C50H
 for Dishwasher (SO.WE.BO.) 824
 for Dishwasher (SOTAL) F600
 for Dishwasher (STORME) LT500
 for Dishwasher (UNIC) A410E
 for Glasswasher/Cupwasher (NOSEM) NR101
 for Glasswasher/Cupwasher (SO.WE.BO.) ONECQ
 ONECT



STORME

3243515 CORK GASKET ø 85 mm

for Dishwasher (AFI) A600
 for Dishwasher (EUROSYSTEM) PRO400
 for Dishwasher (HILTA) S41 - S42
 for Dishwasher (IME OMNIWASH) 4Q82
 for Dishwasher (NOSEM) C5000 - C5010 - C5020
 NC501
 for Dishwasher (NUOVA SIMONELLI) KIARA6
 for Dishwasher (SAB ITALIA) C50H
 for Dishwasher (SO.WE.BO.) 824
 for Dishwasher (SOTAL) F600
 for Dishwasher (STORME) LT500
 for Dishwasher (UNIC) A410E
 for Glasswasher/Cupwasher (NOSEM) NR101
 for Glasswasher/Cupwasher (SO.WE.BO.) ONECQ
 ONECT




STORME



Suitable for:

3243514 UPPER RING NUT \varnothing 110 mm

for Dishwasher (AFI) A600
 for Dishwasher (EUROSYSTEM) PRO400
 for Dishwasher (HILTA) C5000 - C5010 - C5020
 NC501 - S41 - S42
 for Dishwasher (IME OMNIWASH) 4Q82
 for Dishwasher (NUOVA SIMONELLI) KIARA6
 for Dishwasher (SAB ITALIA) C50H
 for Dishwasher (SO.WE.BO.) 824
 for Dishwasher (SOTAL) F600
 for Dishwasher (STORME) LT500
 for Dishwasher (UNIC) A410E
 for Glasswasher/Cupwasher (NOSEM) NR101
 for Glasswasher/Cupwasher (SO.WE.BO.) ONECQ
 ONECT



STORME



Suitable for:

STORME

3243486 WASH AND RINSE ARM ASSEMBLY

length 500 mm
 for Dishwasher (AFI) A600
 for Dishwasher (EUROSYSTEM) PRO400
 for Dishwasher (HILTA) S41 - S42
 for Dishwasher (IME OMNIWASH) 4Q82
 for Dishwasher (NOSEM) C5000 - C5010 - C5020
 NC501
 for Dishwasher (NUOVA SIMONELLI) KIARA6
 for Dishwasher (SAB ITALIA) C50H
 for Dishwasher (SO.WE.BO.) 824
 for Dishwasher (SOTAL) F600
 for Dishwasher (STORME) LT500
 for Dishwasher (UNIC) A410E
 for Glasswasher/Cupwasher (NOSEM) NR101
 for Glasswasher/Cupwasher (SO.WE.BO.) ONECQ



STORME

3501166 LEFT-HAND WASH JET

for Glasswasher/Cupwasher (AFI) A35 - A35Z2 - A36
 for Glasswasher/Cupwasher (EUROSYSTEM) PRO100
 PRO200
 for Glasswasher/Cupwasher (HILTA) RB10 - RB22
 SB10 - SB22
 for Glasswasher/Cupwasher (IME OMNIWASH) DUEAQ
 DUEAT - JA35 - JA36 - JA40 - JA41 - JOLLYAQ
 JOLLYAT - UNO AQ - UNOAT - UNOQ - UNOT
 for Glasswasher/Cupwasher (NOSEM) C2010L - C4010L
 NC201 - NR101 - R1010
 for Glasswasher/Cupwasher (NUOVA SIMONELLI) KIARA1
 KIARA2 - KIARA4
 for Glasswasher/Cupwasher (SAB ITALIA) C35 - C36
 for Glasswasher/Cupwasher (SOTAL) C230 - EC195
 EC255 - ER195 - ER255



STORME



Suitable for:

3243497 LEFTHAND RINSE ARM

complete with jets
 for Dishwasher (AFI) A600 - A900
 for Dishwasher (EUROSYSTEM) PRO400
 for Dishwasher (HILTA) S41 - S42
 for Dishwasher (IME OMNIWASH) QUATTROBA
 QUATTROSA - 4Q82
 for Dishwasher (NOSEM) C5000 - C5010 - C5020
 K602S - NC401 - NC501
 for Dishwasher (SAB ITALIA) C50H - K5.2P
 for Dishwasher hood type (AFI) A1000L
 for Dishwasher hood type (EUROSYSTEM) PRO600
 for Dishwasher hood type (HILTA) W13 - W14 - W15
 for Dishwasher hood type (IME OMNIWASH) SEI1P
 SEI2P
 for Dishwasher hood type (NOSEM) K601 - K602



STORME

3186181 O-RING 03068 EPDM

for Dishwasher (SO.WE.BO.) 601 - 701 - 752
 for Dishwasher (SOTAL) ER225
 for Glasswasher/Cupwasher (AFI) A35 - A35Z2 - A36
 for Glasswasher/Cupwasher (COMENDA) - Series B
 for Glasswasher/Cupwasher (EUROSYSTEM) PRO100
 PRO200
 for Glasswasher/Cupwasher (HILTA) RB10 - RB22
 SB10 - SB22
 for Glasswasher/Cupwasher (IME OMNIWASH) DUE
 JA35 - JA36 - JA40 - JA41 - JOLLY - UNO
 for Glasswasher/Cupwasher (NOSEM) C2010L - C4010L
 NC201 - NR101 - R1010
 for Glasswasher/Cupwasher (NUOVA SIMONELLI) KIARA1
 KIARA2 - KIARA4
 for Glasswasher/Cupwasher (SAB ITALIA) C35 - C36



STORME

STORME



Suitable for:

3243501 LEFTHAND WASH ARM

complete with jets
 for Dishwasher (AFI) A600
 for Dishwasher (EUROSYSTEM) PRO400
 for Dishwasher (HILTA) S41 - S42
 for Dishwasher (IME OMNIWASH) QUATTROBA
 QUATTROSA - 4Q82
 for Dishwasher (NOSEM) C5000 - C5010 - C5020
 NC401 - NC501
 for Dishwasher (NUOVA SIMONELLI) KIARA6
 for Dishwasher (SAB ITALIA) C50H
 for Dishwasher (SO.WE.BO.) 824
 for Dishwasher (SOTAL) C13001P - F600
 for Dishwasher hood type (AFI) A1000L
 for Dishwasher hood type (EUROSYSTEM) PRO600
 for Dishwasher hood type (HILTA) W13



STORME

1186356 O-RING 03075 EPDM

for Dishwasher (AFI) A600 - A900
 for Dishwasher (ANGELO PO) L40 - L40S - L60
 for Dishwasher (EUROSYSTEM) PRO400
 for Dishwasher (HILTA) S41 - S42
 for Dishwasher (NOSEM) C5000 - C5010 - C5020
 K602S - NC401
 for Dishwasher hood type (AFI) A1000L
 for Dishwasher hood type (ANGELO PO) L100 - L80
 for Dishwasher hood type (EUROSYSTEM) PRO600
 for Dishwasher hood type (HILTA) W13 - W14 - W15
 for Dishwasher hood type (NOSEM) K601 - K602
 for Glasswasher/Cupwasher (AFI) A35 - A35Z2 - A36
 for Glasswasher/Cupwasher (EUROSYSTEM) PRO100
 PRO200
 for Glasswasher/Cupwasher (HILTA) RB10 - RB22



STORME



Suitable for:

3501165 RIGHT-HAND WASH JET

for Glasswasher/Cupwasher (AFI) A35 - A35Z2 - A36
 for Glasswasher/Cupwasher (EUROSYSTEM) PRO100
 PRO200
 for Glasswasher/Cupwasher (HILTA) RB10 - RB22
 SB10 - SB22
 for Glasswasher/Cupwasher (IME OMNIWASH) DUEAQ
 DUEAT - JA35 - JA36 - JA40 - JA41 - JOLLYAQ
 JOLLYAT - UNO AQ - UNOAT - UNOQ - UNOT
 for Glasswasher/Cupwasher (NOSEM) C2010L - C4010L
 NC201 - NR101 - R1010
 for Glasswasher/Cupwasher (NUOVA SIMONELLI) KIARA1
 KIARA2 - KIARA4
 for Glasswasher/Cupwasher (SAB ITALIA) C35 - C36
 for Glasswasher/Cupwasher (SOTAL) C230 - EC195
 EC255 - ER195 - ER255



STORME

3243502 RIGHTHAND WASH ARM

complete with jets
 for Dishwasher (AFI) A600
 for Dishwasher (EUROSYSTEM) PRO400
 for Dishwasher (HILTA) S41 - S42
 for Dishwasher (IME OMNIWASH) QUATTROBA
 QUATTROSA - 4Q82
 for Dishwasher (NOSEM) C5000 - C5010 - C5020
 NC401 - NC501
 for Dishwasher (NUOVA SIMONELLI) KIARA6
 for Dishwasher (SAB ITALIA) C50H
 for Dishwasher (SOTAL) C13001P - F600
 for Dishwasher hood type (AFI) A1000L
 for Dishwasher hood type (EUROSYSTEM) PRO600
 for Dishwasher hood type (HILTA) W13
 for Dishwasher hood type (IME OMNIWASH) SEI1P



STORME


STORME



Suitable for:

3243496 RIGHTHAND RINSE ARM

complete with jets
 for Dishwasher (AFI) A600 - A900
 for Dishwasher (EUROSYSTEM) PRO400
 for Dishwasher (HILTA) S41 - S42
 for Dishwasher (IME OMNIWASH) QUATTROBA
 QUATTROSA - 4Q82
 for Dishwasher (NOSEM) C5000 - C5010 - C5020
 NC401 - NC501
 for Dishwasher (SAB ITALIA) K5.2P
 for Dishwasher hood type (AFI) A1000L
 for Dishwasher hood type (EUROSYSTEM) PRO600
 for Dishwasher hood type (HILTA) W13 - W14 - W15
 for Dishwasher hood type (IME OMNIWASH) SEI1P
 SEI2P
 for Dishwasher hood type (NOSEM) K601 - K602



STORME

3501168 RINSE JET

for Glasswasher/Cupwasher (AFI) A35 - A35Z2 - A36
 for Glasswasher/Cupwasher (EUROSYSTEM) PRO100
 PRO200
 for Glasswasher/Cupwasher (HILTA) RB10 - RB22
 SB10 - SB22
 for Glasswasher/Cupwasher (IME OMNIWASH) DUEAQ
 DUEAT - JA35 - JA36 - JA40 - JA41 - JOLLYAQ
 JOLLYAT - UNO AQ - UNOAT - UNOQ - UNOT
 for Glasswasher/Cupwasher (NOSEM) C2010L - C4010L
 NC201 - NR101 - R1010L
 for Glasswasher/Cupwasher (NUOVA SIMONELLI) KIARA1
 KIARA2 - KIARA4
 for Glasswasher/Cupwasher (SAB ITALIA) C35 - C36
 for Glasswasher/Cupwasher (SOTAL) C230 - EC195
 EC255 - ER195 - ER255



STORME



Suitable for:

3243488 RINSE JET CAP

for Dishwasher (AFI) A600 - A900
 for Dishwasher (EUROSYSTEM) PRO400
 for Dishwasher (HILTA) S41 - S42
 for Dishwasher (IME OMNIWASH) 4Q82
 for Dishwasher (NOSEM) C5000 - C5010 - C5020
 K602S - NC401 - NC501
 for Dishwasher (SAB ITALIA) C50H - K5.2P
 for Dishwasher hood type (AFI) A1000L
 for Dishwasher hood type (EUROSYSTEM) PRO600
 for Dishwasher hood type (HILTA) W13 - W14 - W15
 for Dishwasher hood type (IME OMNIWASH) SEI1P
 SEI2P
 for Dishwasher hood type (NOSEM) K601 - K602
 for Glasswasher/Cupwasher (NOSEM) NR101



STORME

3243493 WASH AND RINSE ARM ASSEMBLY BOSS

complete with bushings
 for Dishwasher (IME OMNIWASH) QUATTROBA
 QUATTROSA - 4Q82
 for Dishwasher (NOSEM) NC101
 for Dishwasher (SO.WE.BO.) 601 - 701 - 752
 for Dishwasher (SOTAL) EC225 - ER225
 for Dishwasher hood type (IME OMNIWASH) SEI1P
 SEI2P
 for Glasswasher/Cupwasher (AFI) A35 - A35Z2 - A36
 for Glasswasher/Cupwasher (EUROSYSTEM) PRO100
 PRO200
 for Glasswasher/Cupwasher (HILTA) RB10 - RB22
 SB10 - SB22
 for Glasswasher/Cupwasher (IME OMNIWASH) DUEAQ
 DUEAT - JA35 - JA36 - JA40 - JA41 - JOLLYQ



STORME

STORME



Suitable for:

3501169 RINSE JET RING

for Glasswasher/Cupwasher (AFI) A35 - A35Z2 - A36
 for Glasswasher/Cupwasher (EUROSYSTEM) PRO100
 PRO200
 for Glasswasher/Cupwasher (HILTA) RB10 - RB22
 SB10 - SB22
 for Glasswasher/Cupwasher (IME OMNIWASH) DUEAQ
 DUEAT - JA35 - JA36 - JA40 - JA41 - JOLLYAQ
 JOLLYAT - UNO AQ - UNOAT - UNOQ - UNOT
 for Glasswasher/Cupwasher (NOSEM) C2010L - C4010L
 NC201 - NR101 - R1010L
 for Glasswasher/Cupwasher (NUOVA SIMONELLI) KIARA1
 KIARA2 - KIARA4
 for Glasswasher/Cupwasher (SAB ITALIA) C35 - C36
 for Glasswasher/Cupwasher (SOTAL) C230 - EC195
 EC255 - ER195 - ER255



STORME

3501167 WASH JETS RING

for Dishwasher (AFI) A600 - A900
 for Dishwasher (EUROSYSTEM) PRO400
 for Dishwasher (HILTA) S41 - S42
 for Dishwasher (NOSEM) C5000 - C5010 - C5020
 NC401
 for Dishwasher hood type (AFI) A1000L
 for Dishwasher hood type (EUROSYSTEM) PRO600
 for Dishwasher hood type (HILTA) W13 - W14 - W15
 for Dishwasher hood type (NOSEM) K601 - K602
 K602S
 for Dishwasher hood type (STORME) L501 - L502
 for Glasswasher/Cupwasher (AFI) A35 - A35Z2 - A36
 for Glasswasher/Cupwasher (EUROSYSTEM) PRO100
 PRO200
 for Glasswasher/Cupwasher (HILTA) RB10 - RB22



STORME



Suitable for:

STORME



3243491 WASH AND RINSE ARM ASSEMBLY

length 500 mm
 for Dishwasher (AFI) A900
 for Dishwasher (EUROSYSTEM) PRO400
 for Dishwasher (IME OMNIWASH) QUATTROBA QUATTROSA
 for Dishwasher (NOSEM) K602S
 for Dishwasher (SAB ITALIA) K5.2P
 for Dishwasher (SO.WE.BO.) 1342
 for Dishwasher (UNIC) A61A
 for Dishwasher hood type (HILTA) W14 - W15
 for Dishwasher hood type (IME OMNIWASH) SEI2P
 for Dishwasher hood type (NOSEM) K602
 for Dishwasher hood type (NUOVA SIMONELLI) LTM1600
 for Dishwasher hood type (SO.WE.BO.) 6.2PA - 6.2PB
 for Dishwasher hood type (UNIC) A61



STORME

3243499 LEFTHAND WASH ARM

complete with jets
 for Dishwasher (AFI) A900
 for Dishwasher (EUROSYSTEM) PRO400
 for Dishwasher (NOSEM) K602S
 for Dishwasher (SAB ITALIA) K5.2P
 for Dishwasher (SO.WE.BO.) 1342
 for Dishwasher (STORME) L502BT
 for Dishwasher (UNIC) A61A
 for Dishwasher hood type (HILTA) W14 - W15
 for Dishwasher hood type (IME OMNIWASH) SEI2P
 for Dishwasher hood type (NOSEM) K602
 for Dishwasher hood type (NUOVA SIMONELLI) LTM1600
 for Dishwasher hood type (SO.WE.BO.) 6.2PA - 6.2PB
 for Dishwasher hood type (SOTAL) C1300
 for Dishwasher hood type (STORME) L502



STORME

3243497

LEFTHAND RINSE ARM

complete with jets
 for Dishwasher (AFI) A600 - A900
 for Dishwasher (EUROSYSTEM) PRO400
 for Dishwasher (HILTA) S41 - S42
 for Dishwasher (IME OMNIWASH) QUATTROBA QUATTROSA - 4Q82
 for Dishwasher (NOSEM) C5000 - C5010 - C5020 K602S - NC401 - NC501
 for Dishwasher (SAB ITALIA) C50H - K5.2P
 for Dishwasher hood type (AFI) A1000L
 for Dishwasher hood type (EUROSYSTEM) PRO600
 for Dishwasher hood type (HILTA) W13 - W14 - W15
 for Dishwasher hood type (IME OMNIWASH) SEI1P SEI2P
 for Dishwasher hood type (NOSEM) K601 - K602



STORME

3243492

LEFTHAND WASH JET LARGE MODEL

for Dishwasher (AFI) A900
 for Dishwasher (EUROSYSTEM) PRO400
 for Dishwasher (NOSEM) K602S
 for Dishwasher (SAB ITALIA) K5.2P
 for Dishwasher (SO.WE.BO.) 1342
 for Dishwasher (STORME) L502BT
 for Dishwasher (UNIC) A61A
 for Dishwasher hood type (EUROSYSTEM) PRO600
 for Dishwasher hood type (HILTA) W14 - W15
 for Dishwasher hood type (NOSEM) K602
 for Dishwasher hood type (NUOVA SIMONELLI) LTM1600
 for Dishwasher hood type (SO.WE.BO.) 6.2PA - 6.2PB
 for Dishwasher hood type (SOTAL) C1300
 for Dishwasher hood type (STORME) L502
 for Dishwasher hood type (UNIC) A61




STORME



Suitable for:

3243496 RIGHTHAND RINSE ARM

complete with jets
 for Dishwasher (AFI) A600 - A900
 for Dishwasher (EUROSYSTEM) PRO400
 for Dishwasher (HILTA) S41 - S42
 for Dishwasher (IME OMNIWASH) QUATTROBA
 QUATTROSA - 4Q82
 for Dishwasher (NOSEM) C5000 - C5010 - C5020
 NC401 - NC501
 for Dishwasher (SAB ITALIA) K5.2P
 for Dishwasher hood type (AFI) A1000L
 for Dishwasher hood type (EUROSYSTEM) PRO600
 for Dishwasher hood type (HILTA) W13 - W14 - W15
 for Dishwasher hood type (IME OMNIWASH) SEI1P
 SEI2P
 for Dishwasher hood type (NOSEM) K601 - K602



STORME

3243487 RIGHTHAND WASH JET LARGE MODEL

for Dishwasher (AFI) A900
 for Dishwasher (NOSEM) K602S
 for Dishwasher (SAB ITALIA) K5.2P
 for Dishwasher (SO.WE.BO.) 1342
 for Dishwasher (STORME) L502BT
 for Dishwasher hood type (EUROSYSTEM) PRO600
 for Dishwasher hood type (HILTA) W14 - W15
 for Dishwasher hood type (IME OMNIWASH) SEI2P
 for Dishwasher hood type (NOSEM) K602
 for Dishwasher hood type (NUOVA SIMONELLI) LTM1600
 for Dishwasher hood type (SO.WE.BO.) 6.2PA - 6.2PB
 for Dishwasher hood type (SOTAL) C1300
 for Dishwasher hood type (STORME) L502



STORME

STORME

Suitable for:

3243498 RIGHTHAND WASH ARM

complete with jets
 for Dishwasher (AFI) A900
 for Dishwasher (EUROSYSTEM) PRO400
 for Dishwasher (NOSEM) K602S
 for Dishwasher (SAB ITALIA) K5.2P
 for Dishwasher (SO.WE.BO.) 1342
 for Dishwasher (STORME) L502BT
 for Dishwasher (UNIC) A61A
 for Dishwasher hood type (HILTA) W14 - W15
 for Dishwasher hood type (IME OMNIWASH) SEI2P
 for Dishwasher hood type (NOSEM) K602
 for Dishwasher hood type (NUOVA SIMONELLI) LTM1600
 for Dishwasher hood type (SO.WE.BO.) 6.2PA - 6.2PB
 for Dishwasher hood type (SOTAL) C1300
 for Dishwasher hood type (STORME) L502



STORME

3501168 RINSE JET

for Glasswasher/Cupwasher (AFI) A35 - A35Z2 - A36
 for Glasswasher/Cupwasher (EUROSYSTEM) PRO100
 PRO200
 for Glasswasher/Cupwasher (HILTA) RB10 - RB22
 SB10 - SB22
 for Glasswasher/Cupwasher (IME OMNIWASH) DUEAQ
 DUEAT - JA35 - JA36 - JA40 - JA41 - JOLLYAQ
 JOLLYAT - UNOQA - UNOAT - UNOQ - UNOT
 for Glasswasher/Cupwasher (NOSEM) C2010L - C4010L
 NC201 - NR101 - R1010L
 for Glasswasher/Cupwasher (NUOVA SIMONELLI) KIARA1
 KIARA2 - KIARA4
 for Glasswasher/Cupwasher (SAB ITALIA) C35 - C36
 for Glasswasher/Cupwasher (SOTAL) C230 - EC195
 EC255 - ER195 - ER255



STORME





Suitable for:

3243488 RINSE JET CAP

for Dishwasher (AFI) A600 - A900
 for Dishwasher (EUROSYSTEM) PRO400
 for Dishwasher (HILTA) S41 - S42
 for Dishwasher (IME OMNIWASH) 4Q82
 for Dishwasher (NOSEM) C5000 - C5010 - C5020
 K602S - NC401 - NC501
 for Dishwasher (SAB ITALIA) C50H - K5.2P
 for Dishwasher hood type (AFI) A1000L
 for Dishwasher hood type (EUROSYSTEM) PRO600
 for Dishwasher hood type (HILTA) W13 - W14 - W15
 for Dishwasher hood type (IME OMNIWASH) SEI1P
 SEI2P
 for Dishwasher hood type (NOSEM) K601 - K602
 for Glasswasher/Cupwasher (NOSEM) NR101



STORME

3243530 SPINDLE EXTENSION

for Dishwasher (AFI) A600 - A900
 for Dishwasher (EUROSYSTEM) PRO400
 for Dishwasher (HILTA) S41 - S42
 for Dishwasher (IME OMNIWASH) QUATTROQ - TREQ
 4Q82
 for Dishwasher (NOSEM) K602S
 for Dishwasher (SAB ITALIA) C50H - K5.2P
 for Dishwasher (SOTAL) C130001P
 for Dishwasher hood type (AFI) A1000L
 for Dishwasher hood type (HILTA) W13 - W14 - W15
 for Dishwasher hood type (IME OMNIWASH) SEI1P
 SEI2P
 for Dishwasher hood type (NOSEM) K601 - K602
 for Dishwasher hood type (SAB ITALIA) K5.1P
 for Dishwasher hood type (SOTAL) C1300



STORME

STORME



Suitable for:

3501169 RINSE JET RING

for Glasswasher/Cupwasher (AFI) A35 - A35Z2 - A36
 for Glasswasher/Cupwasher (EUROSYSTEM) PRO100
 PRO200
 for Glasswasher/Cupwasher (HILTA) RB10 - RB22
 SB10 - SB22
 for Glasswasher/Cupwasher (IME OMNIWASH) DUEAQ
 DUEAT - JA35 - JA36 - JA40 - JA41 - JOLLYAQ
 JOLLYAT - UNOQAQ - UNOAT - UNOQ - UNOT
 for Glasswasher/Cupwasher (NOSEM) C2010L - C4010L
 NC201 - NR101 - R1010L
 for Glasswasher/Cupwasher (NUOVA SIMONELLI) KIARA1
 KIARA2 - KIARA4
 for Glasswasher/Cupwasher (SAB ITALIA) C35 - C36
 for Glasswasher/Cupwasher (SOTAL) C230 - EC195
 EC255 - ER195 - ER255



STORME

3243516 UPPER WASH ARM ASSEMBLY SUPPORT

for Dishwasher (AFI) A600 - A900
 for Dishwasher (EUROSYSTEM) PRO400
 for Dishwasher (HILTA) S41 - S42
 for Dishwasher (IME OMNIWASH) 4Q82
 for Dishwasher (NOSEM) C5000 - K602S - NC401
 for Dishwasher (NUOVA SIMONELLI) KIARA6
 for Dishwasher (SAB ITALIA) C50H - K5.2P
 for Dishwasher hood type (AFI) A1000L
 for Dishwasher hood type (EUROSYSTEM) PRO600
 for Dishwasher hood type (HILTA) W13 - W14 - W15
 for Dishwasher hood type (IME OMNIWASH) SEI1P
 SEI2P
 for Dishwasher hood type (NOSEM) K601 - K602
 for Dishwasher hood type (NUOVA SIMONELLI) LTM1500
 LTM1600



STORME



Suitable for:

3243493 WASH AND RINSE ARM ASSEMBLY BOSS

complete with bushings
 for Dishwasher (IME OMNIWASH) QUATTROBA
 QUATTROSA - 4Q82
 for Dishwasher (NOSEM) NC101
 for Dishwasher (SO.WE.BO.) 601 - 701 - 752
 for Dishwasher (SOTAL) EC225 - ER225
 for Dishwasher hood type (IME OMNIWASH) SEI1P
 SEI2P
 for Glasswasher/Cupwasher (AFI) A35 - A35Z2 - A36
 for Glasswasher/Cupwasher (EUROSYSTEM) PRO100
 PRO200
 for Glasswasher/Cupwasher (HILTA) RB10 - RB22
 SB10 - SB22
 for Glasswasher/Cupwasher (IME OMNIWASH) DUEAQ
 DUEAT - JA35 - JA36 - JA40 - JA41 - JOLLYQ



STORME

3501167 WASH JETS RING

for Dishwasher (AFI) A600 - A900
 for Dishwasher (EUROSYSTEM) PRO400
 for Dishwasher (HILTA) S41 - S42
 for Dishwasher (NOSEM) C5000 - C5010 - C5020
 NC401
 for Dishwasher hood type (AFI) A1000L
 for Dishwasher hood type (EUROSYSTEM) PRO600
 for Dishwasher hood type (HILTA) W13 - W14 - W15
 for Dishwasher hood type (NOSEM) K601 - K602
 K602S
 for Dishwasher hood type (STORME) L501 - L502
 for Glasswasher/Cupwasher (AFI) A35 - A35Z2 - A36
 for Glasswasher/Cupwasher (EUROSYSTEM) PRO100
 PRO200
 for Glasswasher/Cupwasher (HILTA) RB10 - RB22



STORME

STORME



Suitable for:

3243531 WASH ARM ASSEMBLY SPINDLE 85 mm

for Dishwasher (AFI) A900
 for Dishwasher (EUROSYSTEM) PRO400
 for Dishwasher (IME OMNIWASH) QUATTROQ - TREQ
 4Q82
 for Dishwasher (NOSEM) K602S
 for Dishwasher (SAB ITALIA) K5.2P
 for Dishwasher (SO.WE.BO.) 1342
 for Dishwasher (SOTAL) C130001P
 for Dishwasher hood type (AFI) A1000L
 for Dishwasher hood type (HILTA) W13 - W14 - W15
 for Dishwasher hood type (IME OMNIWASH) SEI1P
 SEI2P
 for Dishwasher hood type (NOSEM) K601 - K602
 for Dishwasher hood type (NUOVA SIMONELLI) LTM1500
 LTM1600



STORME



Suitable for:

STORME



3243524 WASH ARM ASSEMBLY LOCKING NUT

for Dishwasher (SO.WE.BO.) 601 - 701 - 752
 for Glasswasher/Cupwasher (AFI) A35 - A35Z2 - A36
 for Glasswasher/Cupwasher (EUROSYSTEM) PRO100
 PRO200
 for Glasswasher/Cupwasher (HILTA) RB10 - RB22
 SB10 - SB22
 for Glasswasher/Cupwasher (IME OMNIWASH) DUEAQ
 DUEAT - JA35 - JA36 - JA40 - JA41 - JOLLYQ
 JOLLYT - UNOQ - UNOT
 for Glasswasher/Cupwasher (NOSEM) C2010L - C4010L
 NC201 - NR101 - R1010
 for Glasswasher/Cupwasher (NUOVA SIMONELLI) KIARA1
 KIARA2 - KIARA4
 for Glasswasher/Cupwasher (SAB ITALIA) C35 - C36
 for Glasswasher/Cupwasher (SO.WE.BO.) 600 - 631



STORME

3743562 WASH ARM CT MOD.2/4 WHITE

for Dishwasher (AFI) A600
 for Dishwasher (EUROSYSTEM) PRO400
 for Dishwasher (HILTA) S41 - S42
 for Dishwasher (IME OMNIWASH) 4Q82
 for Dishwasher (NOSEM) C5000 - C5010 - C5020
 NC501
 for Dishwasher (NUOVA SIMONELLI) KIARA6
 for Dishwasher (SAB ITALIA) C50H
 for Dishwasher (SO.WE.BO.) 824
 for Dishwasher (SOTAL) F600ECO
 for Dishwasher (STORME) LT500
 for Dishwasher (UNIC) A410E



STORME

Suitable for:

3743322 WASH ARM ASSEMBLY 310 mm

for Dishwasher (SO.WE.BO.) 601 - 701 - 752
 for Glasswasher/Cupwasher (AFI) A35 - A35Z2 - A36
 for Glasswasher/Cupwasher (EUROSYSTEM) PRO100
 PRO200
 for Glasswasher/Cupwasher (HILTA) RB10 - RB22
 SB10 - SB22
 for Glasswasher/Cupwasher (IME OMNIWASH) JA35
 JA350 - JA36 - JA360 - JOLLYAQ - JOLLYQ - J35
 J350 - J36 - J360
 for Glasswasher/Cupwasher (NOSEM) C2010L - C4010L
 NC201 - NR101 - R1010
 for Glasswasher/Cupwasher (NUOVA SIMONELLI) KIARA1
 KIARA2 - KIARA4
 for Glasswasher/Cupwasher (SAB ITALIA) C35 - C36
 for Glasswasher/Cupwasher (SO.WE.BO.) 600 - 631



STORME

3743264 WASH ARM 200 mm

for Dishwasher (SO.WE.BO.) 601 - 701 - 752
 for Glasswasher/Cupwasher (AFI) A35 - A35Z2 - A36
 for Glasswasher/Cupwasher (EUROSYSTEM) PRO100
 PRO200
 for Glasswasher/Cupwasher (HILTA) RB10 - RB22
 SB10 - SB22
 for Glasswasher/Cupwasher (IME OMNIWASH) JA35
 JA350 - JA36 - JA360 - JOLLYAQ - JOLLYQ - J35
 J350 - J36 - J360
 for Glasswasher/Cupwasher (NOSEM) C2010L - C4010L
 NC201 - NR101 - R1010
 for Glasswasher/Cupwasher (NUOVA SIMONELLI) KIARA1
 KIARA2 - KIARA4
 for Glasswasher/Cupwasher (SAB ITALIA) C35 - C36
 for Glasswasher/Cupwasher (SO.WE.BO.) 600 - 631



STORME



3743576 WASH ARM 4CT MOULD 24

for Dishwasher (AFI) A600
 for Dishwasher (EUROSYSTEM) PRO400
 for Dishwasher (HILTA) S41 - S42
 for Dishwasher (IME OMNIWASH) 4Q82
 for Dishwasher (NOSEM) C5000 - C5010 - C5020
 NC501
 for Dishwasher (NUOVA SIMONELLI) KIARA6
 for Dishwasher (SAB ITALIA) C50H
 for Dishwasher (SO.WE.BO.) 824
 for Dishwasher (SOTAL) 600ECO
 for Dishwasher (STORME) LT500
 for Dishwasher (UNIC) A410E



STORME

3743055 WASH COLUMN 380 mm

for Dishwasher (SO.WE.BO.) 601 - 701 - 752
 for Glasswasher/Cupwasher (AFI) A35 - A35Z2 - A36
 for Glasswasher/Cupwasher (EUROSYSTEM) PRO100
 PRO200
 for Glasswasher/Cupwasher (HILTA) RB10 - RB22
 SB10 - SB22
 for Glasswasher/Cupwasher (IME OMNIWASH) DUEAQ
 DUEAT - JA35 - JA36 - JA40 - JA41 - JOLLYQ
 JOLLYT - UNOQ - UNOT
 for Glasswasher/Cupwasher (NOSEM) C2010L - C4010L
 NC201 - NR101 - R1010
 for Glasswasher/Cupwasher (NUOVA SIMONELLI) KIARA1
 KIARA2 - KIARA4
 for Glasswasher/Cupwasher (SAB ITALIA) C35 - C36
 for Glasswasher/Cupwasher (SO.WE.BO.) 600 - 631



STORME

Suitable for:

3743568 WASH COLUMN EXTENSION

for Dishwasher (SO.WE.BO.) 601 - 701 - 752
 for Glasswasher/Cupwasher (AFI) A35 - A35Z2 - A36
 for Glasswasher/Cupwasher (EUROSYSTEM) PRO100
 PRO200
 for Glasswasher/Cupwasher (HILTA) RB10 - RB22
 SB10 - SB22
 for Glasswasher/Cupwasher (IME OMNIWASH) DUEAT
 JA35 - JA36 - JA40 - JA41 - JOLLYAT - JOLLYT
 UNOAT - UNOT
 for Glasswasher/Cupwasher (NOSEM) C2010L - C4010L
 NC201 - NR101 - R1010
 for Glasswasher/Cupwasher (NUOVA SIMONELLI) KIARA1
 KIARA2 - KIARA4
 for Glasswasher/Cupwasher (SAB ITALIA) C35 - C36
 for Glasswasher/Cupwasher (SO.WE.BO.) 600 - 631



STORME

3743524 WASH ARM EXTENSION

for Dishwasher (SO.WE.BO.) 601 - 701 - 752
 for Glasswasher/Cupwasher (AFI) A35 - A35Z2 - A36
 for Glasswasher/Cupwasher (EUROSYSTEM) PRO100
 PRO200
 for Glasswasher/Cupwasher (HILTA) RB10 - RB22
 SB10 - SB22
 for Glasswasher/Cupwasher (IME OMNIWASH) DUEAT
 JA40 - JA41 - JOLLYAT - JOLLYT - UNOAT - UNOT
 for Glasswasher/Cupwasher (NOSEM) C2010L - C4010L
 NC201 - NR101 - R1010
 for Glasswasher/Cupwasher (NUOVA SIMONELLI) KIARA1
 KIARA2 - KIARA4
 for Glasswasher/Cupwasher (SAB ITALIA) C35 - C36
 for Glasswasher/Cupwasher (SO.WE.BO.) 600 - 631
 661 - 691 - 712 - 742



STORME



Suitable for:

STORME



3743057 WATER INLET SUPPORT

for Dishwasher (SO.WE.BO.) 601 - 701 - 752
 for Glasswasher/Cupwasher (AFI) A35 - A35Z2 - A36
 for Glasswasher/Cupwasher (EUROSYSTEM) PRO100
 PRO200
 for Glasswasher/Cupwasher (HILTA) RB10 - RB22
 SB10 - SB22
 for Glasswasher/Cupwasher (IME OMNIWASH) DUEAQ
 DUEAT - JA35 - JA36 - JA40 - JA41 - JOLLYQ
 JOLLYT - UNOQ - UNOT
 for Glasswasher/Cupwasher (NOSEM) C2010L - C4010L
 NC201 - NR101 - R1010
 for Glasswasher/Cupwasher (NUOVA SIMONELLI) KIARA1
 KIARA2 - KIARA4
 for Glasswasher/Cupwasher (SAB ITALIA) C35 - C36
 for Glasswasher/Cupwasher (SO.WE.BO.) 600 - 631



STORME

3186847 OR GASKET 03131 EPDM

for Dishwasher (SO.WE.BO.) 601 - 701 - 752
 for Glasswasher/Cupwasher (AFI) A35 - A35Z2 - A36
 for Glasswasher/Cupwasher (EUROSYSTEM) PRO100
 PRO200
 for Glasswasher/Cupwasher (HILTA) RB10 - RB22
 SB10 - SB22
 for Glasswasher/Cupwasher (IME OMNIWASH) DUECL
 DUECS - JA35 - JA36 - JA40 - JA41 - JOLLY
 UNOCL - UNOCS
 for Glasswasher/Cupwasher (NOSEM) C2010L - C4010L
 NC201 - NR101 - R1010
 for Glasswasher/Cupwasher (NUOVA SIMONELLI) KIARA1
 KIARA2 - KIARA4
 for Glasswasher/Cupwasher (SAB ITALIA) C35 - C36
 for Glasswasher/Cupwasher (SO.WE.BO.) 600 - 631



STORME

Suitable for:

3743058 GAS NUT \varnothing 1"

for Dishwasher (SO.WE.BO.) 601 - 701 - 752
 for Glasswasher/Cupwasher (AFI) A35 - A35Z2 - A36
 for Glasswasher/Cupwasher (EUROSYSTEM) PRO100
 PRO200
 for Glasswasher/Cupwasher (HILTA) RB10 - RB22
 SB10 - SB22
 for Glasswasher/Cupwasher (IME OMNIWASH) DUEAQ
 DUEAT - JA35 - JA36 - JA40 - JA41 - JOLLYQ
 JOLLYT - UNOQ - UNOT
 for Glasswasher/Cupwasher (NOSEM) C2010L - C4010L
 NC201 - NR101 - R1010
 for Glasswasher/Cupwasher (NUOVA SIMONELLI) KIARA1
 KIARA2 - KIARA4
 for Glasswasher/Cupwasher (SAB ITALIA) C35 - C36
 for Glasswasher/Cupwasher (SO.WE.BO.) 600 - 631



STORME

Wash jets and accessories

3501255 RINSE JET COMPLETE



STORME



Wash jets and accessories

3501161 WASH JET

for Dishwasher (AFI) A600
 for Dishwasher (EUROSYSTEM) PRO400
 for Dishwasher (HILTA) C5000 - C5010 - C5020
 NC501 - S41 - S42
 for Dishwasher (IME OMNIWASH) 4Q82
 for Dishwasher (SAB ITALIA) C50H
 for Dishwasher (STORME) LT500T
 for Glasswasher/Cupwasher (AFI) A35Z2 - A36
 for Glasswasher/Cupwasher (EUROSYSTEM) PRO100
 PRO200
 for Glasswasher/Cupwasher (HILTA) C2010L - RB10
 RB22 - R1010 - SB10 - SB22
 for Glasswasher/Cupwasher (IME OMNIWASH) DUEAQ
 DUEAT - JOLLYAQ - JOLLYAT - UNOQAQ - UNOAT
 UNOQ - UNOT



STORME

3501162 WASH JET

for Dishwasher (AFI) A600
 for Dishwasher (EUROSYSTEM) PRO400
 for Dishwasher (HILTA) S41 - S42
 for Dishwasher (IME OMNIWASH) 4Q82
 for Dishwasher (NOSEM) C5000 - C5010 - C5020
 NC501
 for Dishwasher (SAB ITALIA) C50H
 for Dishwasher (STORME) LT500T
 for Glasswasher/Cupwasher (AFI) A35 - A35Z2 - A36
 for Glasswasher/Cupwasher (EUROSYSTEM) PRO100
 PRO200
 for Glasswasher/Cupwasher (HILTA) RB10 - RB22
 SB10 - SB22
 for Glasswasher/Cupwasher (IME OMNIWASH) DUEAQ
 DUEAT - JOLLYAQ - JOLLYAT - UNOQAQ - UNOAT




STORME

Washing baskets and accessories

3055691 ROUND RACK SUPPORT ø 280 mm


for Dishwasher (AFI) A600 - A900
 for Dishwasher (EUROSYSTEM) PRO400
 for Dishwasher (HILTA) S41 - S42
 for Dishwasher (NOSEM) C2050 - C5000 - C5010
 NC501
 for Dishwasher hood type (AFI) A1000L
 for Dishwasher hood type (EUROSYSTEM) PRO600
 for Dishwasher hood type (HILTA) W13 - W14 - W15
 for Dishwasher hood type (NOSEM) K601 - K602
 for Glasswasher/Cupwasher (AFI) A35 - A35Z2 - A36
 for Glasswasher/Cupwasher (EUROSYSTEM) PRO100
 PRO200
 for Glasswasher/Cupwasher (HILTA) RB10 - RB22
 SB10 - SB22
 for Glasswasher/Cupwasher (NOSEM) C2010L - C4010L



STORME

3528051 BASKET SUPPORT NUT

for Dishwasher (AFI) A600 - A900
 for Dishwasher (EUROSYSTEM) PRO400
 for Dishwasher (HILTA) S41 - S42
 for Dishwasher (NOSEM) C2050 - C5000 - C5010
 NC501
 for Dishwasher hood type (AFI) A1000L
 for Dishwasher hood type (EUROSYSTEM) PRO600
 for Dishwasher hood type (HILTA) W13 - W14 - W15
 for Dishwasher hood type (NOSEM) K601 - K602
 for Glasswasher/Cupwasher (AFI) A35 - A35Z2 - A36
 for Glasswasher/Cupwasher (EUROSYSTEM) PRO100
 PRO200
 for Glasswasher/Cupwasher (HILTA) RB10 - RB22
 SB10 - SB22
 for Glasswasher/Cupwasher (NOSEM) C2010L - C4010L



STORME



Suitable for:

3324007 ROTATING SUPPORT PIN CT WITH BALL 1-2

for Dishwasher (AFI) A600 - A900
 for Dishwasher (EUROSYSTEM) PRO400
 for Dishwasher (HILTA) S41 - S42
 for Dishwasher (NOSEM) C2050 - C5000 - C5010 NC501
 for Dishwasher hood type (AFI) A1000L
 for Dishwasher hood type (EUROSYSTEM) PRO600
 for Dishwasher hood type (HILTA) W13 - W14 - W15
 for Dishwasher hood type (NOSEM) K601 - K602
 for Glasswasher/Cupwasher (AFI) A35 - A35Z2 - A36
 for Glasswasher/Cupwasher (EUROSYSTEM) PRO100 PRO200
 for Glasswasher/Cupwasher (HILTA) RB10 - RB22 SB10 - SB22
 for Glasswasher/Cupwasher (NOSEM) C2010L - C4010L



STORME

3241838 S/STEEL TURNTABLE DISK 1-2

for Dishwasher (AFI) A600 - A900
 for Dishwasher (EUROSYSTEM) PRO400
 for Dishwasher (HILTA) S41 - S42
 for Dishwasher (NOSEM) C2050 - C5000 - C5010 NC501
 for Dishwasher hood type (AFI) A1000L
 for Dishwasher hood type (EUROSYSTEM) PRO600
 for Dishwasher hood type (HILTA) W13 - W14 - W15
 for Dishwasher hood type (NOSEM) K601 - K602
 for Glasswasher/Cupwasher (AFI) A35 - A35Z2 - A36
 for Glasswasher/Cupwasher (EUROSYSTEM) PRO100 PRO200
 for Glasswasher/Cupwasher (HILTA) RB10 - RB22 SB10 - SB22
 for Glasswasher/Cupwasher (NOSEM) C2010L - C4010L



STORME

STORME



Suitable for:

3055668 ROTATING SUPPORT SHAFT SPACER 1-2

for Dishwasher (AFI) A600 - A900
 for Dishwasher (EUROSYSTEM) PRO400
 for Dishwasher (HILTA) S41 - S42
 for Dishwasher (NOSEM) C2050 - C5000 - C5010 NC501
 for Dishwasher hood type (AFI) A1000L
 for Dishwasher hood type (EUROSYSTEM) PRO600
 for Dishwasher hood type (HILTA) W13 - W14 - W15
 for Dishwasher hood type (NOSEM) K601 - K602
 for Glasswasher/Cupwasher (AFI) A35 - A35Z2 - A36
 for Glasswasher/Cupwasher (EUROSYSTEM) PRO100 PRO200
 for Glasswasher/Cupwasher (HILTA) RB10 - RB22 SB10 - SB22
 for Glasswasher/Cupwasher (NOSEM) C2010L - C4010L



STORME

3250227 SEEGER FOR ROTATING SUPPORT SHAFT

for Dishwasher (AFI) A600 - A900
 for Dishwasher (EUROSYSTEM) PRO400
 for Dishwasher (HILTA) S41 - S42
 for Dishwasher (NOSEM) C2050 - C5000 - C5010 NC501
 for Dishwasher hood type (AFI) A1000L
 for Dishwasher hood type (EUROSYSTEM) PRO600
 for Dishwasher hood type (HILTA) W13 - W14 - W15
 for Dishwasher hood type (NOSEM) K601 - K602
 for Glasswasher/Cupwasher (AFI) A35 - A35Z2 - A36
 for Glasswasher/Cupwasher (EUROSYSTEM) PRO100 PRO200
 for Glasswasher/Cupwasher (HILTA) RB10 - RB22 SB10 - SB22
 for Glasswasher/Cupwasher (NOSEM) C2010L - C4010L



STORME

The data herewith contained may change without notice and LF SpA cannot be held responsible for possible errors stated or resulting by the use of this document. All rights reserved. No part of this publication may be reproduced without written permission by LF SpA.



LF SpA
via Voltri, 80 - 47522 Cesena (FC) ITALIA
Tel. +39 0547 34 11 11 - Fax +39 0547 34 11 10
www.lfricambi724.it - www.lfricambi724.mobi
info@lfricambi.it
Export Dept.: Tel. +39 0547 34 11 50 - Fax: +39 0547 34 11 55
www.lfspareparts724.com - www.lfspareparts724.mobi
export@lfspaceparts.com

FRANCE



EPGC Sas
13, Rue des Forts - 59960 Neuville en Ferrain
Tél. +33 (0)3 20 25 06 21
Fax +33 (0)3 20 25 34 12
www.epgc.com
www.epgc724.mobi
epgc@epgc.com

DEUTSCHLAND



LF GmbH
Junkersstrasse, 1 - D-82178 Puchheim - München
Tel. +49 89 89 45 78 66
Fax +49 89 89 45 78 88
www.lfersatzteile724.de
www.lfersatzteile724.mobi
info@lfersatzteile.de

SCHWEIZ



LF GmbH Verkaufsbüro
Sennweidstrasse, 45 - CH-6312 Steinhausen
Tel. +41 (0)41 760 15 80-1
Fax +41 (0)41 760 15 85
www.lfersatzteile724.ch
www.lfersatzteile724.mobi
info@lfersatzteile.ch

ESPAÑA



LF Repuestos Horeca S.L.U.
Calle Ciudad Real, 10 - 45517 Escalonilla - Toledo
Tif. +34 91 477 91 00
Fax +34 91 477 90 81
www.lfrepuestos724.es
www.lfrepuestos724.mobi
info@lfrepuestos.es

UNITED KINGDOM



LF Spare Parts Ltd.
A10a Lakeside Business Park, Broadway Lane
South Cerney, Gloucestershire GL7 5XL
Tel. +44 (0)1285 86 16 25
Fax +44 (0)1285 86 39 49
www.lfspareparts724.co.uk
www.lfspareparts724.mobi
info@lfspaceparts.co.uk

RUSSIA



OOO LF
ul, Anatoliya Zhivova, 8 - office 1 - 123100 Moscow
Tel. +7 499 259 85 75
Fax +7 495 725 26 53
www.lfspareparts724.ru
www.lfspareparts724.mobi
info@lfspaceparts.ru

CHINA



LF China
Room 102, House 8, Lane 725, Mao Tai Rd.
Changning Dist. - 200336 Shanghai
Tel. +86 (0)21 33 53 66 31
Fax +86 (0)21 33 53 66 32
www.lfspareparts724.com
www.lfspareparts724.mobi
china@lfspaceparts.com