



Spare parts for:

Warewashing equipment



Suitable for:

ADLER



This catalogue is automatically generated.
Therefore, the sequence of the items might
not be always shown at best.

Updates will be issued in case of additions
and/or amendments.

Suitable universal spare parts may not be included





Suitable for:

ADLER



Suitable for:

Air Chambers

3060022 AIR CHAMBER \varnothing 50x85 mm

for Dishwasher (ADLER) CF235 - CF50 - DL240 DS600
 for Dishwasher (WHIRLPOOL) F360 - F650
 for Dishwasher hood type (ADLER) CF1000 - CF1201 DS1200
 for Dishwasher hood type (WHIRLPOOL) F1201A
 for Glasswasher/Cupwasher (ADLER) CF35/1 - CF40 COMPACT - DSF101 - DSF103 - DSF11 - DSF13 DS101 - DS103 - DS201 - DS203
 for Glasswasher/Cupwasher (WHIRLPOOL) D110 - D111 D210 - D211 - D310 - D311 - F30 - F300 - F312 F35 - F40 - F400 - F41 - F410



ADLER 10528

3060047 HEXAGONAL LOW NUT M10 UNI 5589

for Dishwasher (MACH) MS351 - MS353 - MS400B MS400E - MS400T - MS451 - MS453 - MS500B MS500E - MS500T - MS800B - MS800T
 for Dishwasher hood type (MACH) MS900
 for Glasswasher/Cupwasher (MACH) MB520 - MB530 MB535 - MB630 - MB930
 for Pan washing machine (MACH) MLP50



ADLER 10424

ADLER 60212

1186304 O-RING 0112 EPDM



ADLER 60050

Boilers

3024030 BOILER \varnothing 160x415 mm

for Dishwasher (ADLER) CF50



ADLER 15585

ADLER 15696

3024057 BOILER \varnothing 160x500 mm

for Dishwasher (ADLER) DS1200A
 for Dishwasher hood type (ADLER) CF1201 - DS1200



ADLER 15697

3755048 BOILER HEATING ELEMENT 9000W 230/400V

immersed length 390 mm
 complete with gasket (3186191)
 for Dishwasher hood type (ADLER) CF1000 - CF1201A DS1200
 for Dishwasher hood type (WHIRLPOOL) F1000 F1201A



ADLER 20084



Clamps

3449401 DOUBLE-WIRE CLAMP 7-7.5 - 100 PCS
for hoses \varnothing 7÷7.5 mm



ADLER 60078

3449462 HOSE CLAMP 12-20
for hoses \varnothing 12÷20 mm
made of stainless steel AISI 304
height 9 mm and screw E7
for Glasswasher/Cupwasher (ADLER) DSF101



ADLER 60081

3449453 HOSE CLAMP 25-40
for pipes \varnothing 25÷40 mm
made of stainless steel AISI 304
height 9 mm and screw E7



ADLER 60082

Descaling powders for dishwashers

3094005 4 COLUMN SCALE REMOVER
width 165 mm - length 390 mm
for Dishwasher (ADLER) CF50
for Dishwasher (COMENDA) FC53 - FC54 - LF320A
LF323A - LF350A - LF400A - LF450A
for Dishwasher (ELFRAMO)
for Dishwasher (KOMEL)
for Dishwasher (LAMBER)
for Dishwasher (UNIVERBAR) LOGOSD - MIDI50D
OMEGAD - SINCROD
for Glasswasher/Cupwasher (COMENDA) BC25A - BC30A
BHC25 - BHC30 - BR20A - BR25A - B12T - B14T
B16T - B19T - FC43A
for Glasswasher/Cupwasher (MEIKO) ECOSTAR545D
for Glasswasher/Cupwasher (UNIVERBAR) BET37D
BET40D - ERGOND - MIDI40D - MINIBETD



ADLER 10444

3010138 WATER SOFTENER SUPPORT
distance between mounting holes 195 mm
for Dishwasher (WHIRLPOOL) AGB652 - AGB653
for Glasswasher/Cupwasher (WHIRLPOOL) AGB643
AGB644 - AGB647





Suitable for:

ADLER

Suitable for:



Door catches

3398050 COMPLETE DOOR CATCH
for all models



ADLER 10414

3398064 DOOR CATCH HOUSING
for CF50-CF40-A400-DL240-DS600



ADLER 12054

3398065 DOOR CATCH PLATE
for CF50-A400-DL240



ADLER 12053

3398059 DOOR LOCKING CATCH
for CF50-A400-DL240-DS600



ADLER 12049

3398063 DOOR CATCH LOCKING UNIT
for CF50-A400-DL240-DS600



ADLER 12050

3398058 DOOR CATCH SPRING \varnothing 6x40 mm
for CF50-CF40-A400-DL240-DS600



ADLER 12052

3398055 DOOR CATCH LOCKING PIN \varnothing 5x22 mm
for CF50-A400-DL240-DS600



ADLER 12051

Drain assembly

3316112 BRASS DRAIN ASSEMBLY 1"1/4
for CF50



ADLER 10347

3186238 O-RING 0146 EPDM
for Dishwasher (CIMBALI) F3E - F6E
for Dishwasher (HEMERSON) P43E - P60E
for Glasswasher/Cupwasher (RANCILIO) LT105 - LT205



ADLER 60055



ADLER



Suitable for:

3316111 CURVED DRAIN ASSEMBLY 1"1/2
for DISHWASHER ADLER DS400/DS410/DS600
for DISHWASHER WHIRLPOOL F400/F410/F650



ADLER 12027

Suitable for:

3316113 DRAIN ASSEMBLY NUT 1"1/2



ADLER 12028

3316109 OVERFLOW DRAIN ASSEMBLY
for DS600-DS1000-DS1200



ADLER 12195

3316110 EPDM O-RING GASKET 04237
for drain assembly



ADLER 60075

3243139 O-RING 02025 EPDM
for Dishwasher (BONNET) INO3F
for Dishwasher (ZANUSSI) LS32 - LS360 - LS365
LS500 - LS540 - LS7
for Dishwasher conveyor type (ZANUSSI) CT92
for Dishwasher hood type (ZANUSSI) LS1080 - LS720
LS8 - LS860



3528114 SUPPORT/DRAIN ASS'Y FASTENING SCREW
thread \varnothing 6x10 mm



ADLER 12055

3316114 OVERFLOW DRAIN ASSEMBLY 1"
for CF35-CF40-CF235-DL240-DS101-DS103-DS201



ADLER 10346

3186265 O-RING \varnothing 32x3 mm
for Dishwasher (ADLER) DL240
for Glasswasher/Cupwasher (ADLER) CF35 - CF40



ADLER 60063

3316115 RING NUT FOR DRAIN ASSEMBLY 1"
for CF35-CF40-CF235-DL240-DS101-DS103-DS201



ADLER 10430



Suitable for:

ADLER



Suitable for:

Drain hoses

3450158 DRAIN PIPE \varnothing 25x1700 mm
for ADLER CF40
for WHIRLPOOL F40-F41



ADLER 60556

3450038 DRAIN PIPE \varnothing 34x2000 mm
muff internal \varnothing 33 mm
max temperature 90°C



ADLER 60561

3450162 DRAIN PUMP OUTLET PIPE 415 mm
 \varnothing internal 20/23 mm
for F360DP-CF50DP



ADLER 15634

3349042 DRAIN FITTING
for A350-A1080-CF50-CF1000



ADLER 10350


ADLER 10351

3349043 DRAIN FITTING
for B100-B203-CF103-DS600



ADLER 10349

3450176 PVC \varnothing 4x7 mm - 150 m



ADLER 60563

3450623 PVC PIPE \varnothing 4x7 mm - 10 m
external \varnothing 7 mm
internal \varnothing 4 mm



ADLER 60563

3450297 RUBBER HOSE \varnothing 11x19 mm - 5 m
temperature -30°+110°C
operating pressure 10 bar
burst pressure 40 bar
non-toxic rubber hose
external \varnothing 19 mm
internal \varnothing 11 mm
5-m bundles
for 50-m bundles see 3450197



ADLER 60565

3450197 RUBBER HOSE \varnothing 11x19 mm - 50 m
temperature -30°+110°C
operating pressure 10 bar
burst pressure 40 bar
non-toxic rubber hose
external \varnothing 19 mm
internal \varnothing 11 mm
50-m bundles
for 5-m bundles see 3450297



ADLER 60565



ADLER



Suitable for:

3450118 RUBBER PIPE 8x15 mm INDUSTRIA 10
sold per meter



ADLER 60555

Suitable for:

3450156 WASH OUTLET TOP PIPE 1000 mm
width hose 300 mm
internal \varnothing 33/ 40 mm
for DS1200



ADLER 15522

Drain plugs

3448193 OVERFLOW PIPE \varnothing 25x90 mm
for CF35-CF40-CF235-COMPACT-DL240-DS101-DS103-
DS201



ADLER 10275

3448192 OVERFLOW PIPE \varnothing 27x173 mm



ADLER 12025

3448190 OVERFLOW FILTER COVER



ADLER 12022

3448191 OVERFLOW PIPE \varnothing 33x120 mm
made of chrome plated brass
for CF1000



ADLER 10277

3528079 COUNTERS.CROSS-SLOT.SCREW M5x35 UNI 7688



ADLER 60179

3448250 OVERFLOW PIPE \varnothing 35x115 mm
STAINLESS steel made
for CF50-CF70



ADLER 15017



Suitable for:

3448304 STAIN.STEEL OVERFLOW PIPE \varnothing 30x235 mm
for ADLER CF1000-CF1201A-DS600-DS1000-DS1200
for WHIRLPOOL F1201A



ADLER 15013

ADLER 15035

Suitable for:

3316110 EPDM O-RING GASKET 04237
for drain assembly



ADLER 60075

Electrical gas valves and accessories

3526196 BACKFLOW CHECK VALVE
for all models
for Dishwasher (ADLER) DS400
for Glasswasher/Cupwasher (WHIRLPOOL) F400



ADLER 12135

Filters

3160319 FILER ROD
for Dishwasher hood type (ADLER) CF1000




ADLER 10412

3160216 INLET FILTER \varnothing 70 mm
for Dishwasher (ADLER) F300 - F312 - F35 - F41
for Glasswasher/Cupwasher (ADLER) CF35 - CF40
COMPACT - DSF101 - DSF103



ADLER 11404

3160200 FILTER LOCKING NUT
for Dishwasher (ADLER) CF50 - F360
for Glasswasher/Cupwasher (ADLER) CF40



ADLER 11998



Suitable for:

3160215 INLET FITTING 1"1/4
 for Dishwasher (ADLER) B40 - B41 - DL240
 for Glasswasher/Cupwasher (ADLER) B101 - CF35
 COMPACT - DSF101 - DSF103 - DS101 - DS103
 DS11 - DS13 - DS201 - DS203 - DS21 - DS23
 for Glasswasher/Cupwasher (WHIRLPOOL) D110 - D111
 D210 - D211 - F30 - F300 - F312 - F35 - F41



ADLER 10344

3160194 FILTER LOCKING SHAFT 58 mm
 thread \varnothing 6 mm
 for Dishwasher (ADLER) B40 - B41 - CF50
 for Dishwasher (WHIRLPOOL) F360
 for Glasswasher/Cupwasher (ADLER) B101 - COMPACT
 DS101 - DS103 - DS11 - DS13 - DS201 - DS203
 DS21 - DS23
 for Glasswasher/Cupwasher (WHIRLPOOL) D110 - D111
 D210 - D211 - F30



ADLER 10409

3160198 RING NUT FOR SUCTION BOSS 1"1/4
 for IRINOX CHILLER LCS1
 per LAVASTOVIGLIE KF



ADLER 10431

3160193 PLASTIC FILTER \varnothing 70 mm
 for Dishwasher (ADLER) B40 - B41
 for Glasswasher/Cupwasher (ADLER) B101 - COMPACT
 DS101 - DS103 - DS11 - DS13 - DS201 - DS21
 for Glasswasher/Cupwasher (WHIRLPOOL) D110 - D111
 D210 - D211 - F30



ADLER 10295

Suitable for:

3160195 FILTER LOCKING SHAFT \varnothing 6 mm
 length 42 mm
 for Dishwasher (ADLER) DL240
 for Glasswasher/Cupwasher (ADLER) CF35 - CF40
 DSF101 - DSF103
 for Glasswasher/Cupwasher (WHIRLPOOL) F300 - F312
 F35 - F41



ADLER 11409

3186238 O-RING 0146 EPDM
 for Dishwasher (CIMBALI) F3E - F6E
 for Dishwasher (HEMERSON) P43E - P60E
 for Glasswasher/Cupwasher (RANCILIO) LT105 - LT205



ADLER 60055

3160318 STAINLESS STEEL FILTER \varnothing 110x80 mm
 for Dishwasher (ADLER) CF50 - DS600
 for Dishwasher (WHIRLPOOL) F650



ADLER 12128



Suitable for:

ADLER



Suitable for:

3160340 STAINLESS STEEL ROD FOR FILTER
for Dishwasher (ADLER) CF50




ADLER 11994

3160474 TANK INLET FILTER Ø 155 H65 mm
for Dishwasher (ADLER) CF50
for Dishwasher (WHIRLPOOL) F360



ADLER 10298

3160200 FILTER LOCKING NUT
for Dishwasher (ADLER) CF50 - F360
for Glasswasher/Cupwasher (ADLER) CF40



ADLER 11998

3160194 FILTER LOCKING SHAFT 58 mm
thread Ø 6 mm
for Dishwasher (ADLER) B40 - B41 - CF50
for Dishwasher (WHIRLPOOL) F360
for Glasswasher/Cupwasher (ADLER) B101 - COMPACT
DS101 - DS103 - DS11 - DS13 - DS201 - DS203
DS21 - DS23
for Glasswasher/Cupwasher (WHIRLPOOL) D110 - D111
D210 - D211 - F30



ADLER 10409

Gaskets and seals

1186360 FLAT EPDM GASKET Ø 18x12x2 mm



ADLER 60001

1186424 O-RING GASKET 02062 EPDM



ADLER 60071

Guides

3189054 HOOD SLIDEWAY 625 mm
for Dishwasher (WHIRLPOOL) F1200A
for Dishwasher hood type (ADLER) DS1200



ADLER 15613



Handles

3242028 HANDLE LEFT HEAD



ADLER 10523

3242029 HANDLE RIGHT HEAD



ADLER 10565

Heating elements

3455340 BOILER HEATING ELEMENT 8745W 400V

immersed length 430 mm
oval flange mounting distance 75 mm
with gasket 3186191
for Dishwasher (ADLER) DS600
for Dishwasher (WHIRLPOOL) F650



ADLER 20506

3455318 HEAT.ELEM.F/TANK 2000W 230V

immersed length 300 mm
for Dishwasher (ADLER) DS400 - DS410
for Dishwasher (WHIRLPOOL) F650



ADLER 20504


3355386 HEATING ELEM. F/WASH TANK 4000W 220/380V

immersed length 290 mm
connection \varnothing 1"1/2 (48 mm)
complete with gasket (1186931)
upon request nut (3528003) and washer (35280049)
for Dishwasher (ADLER) A500
for Dishwasher (CODIGEL) CD500
for Dishwasher (DIMCO) DI480
for Dishwasher hood type (ADLER) CF1000 - CF1201A
DS1200
for Dishwasher hood type (WHIRLPOOL) F1000
F1201A



ADLER 20075

1186931 GASKET O-RING 0152 GREEN VITON



ADLER 60010

3355388 NUT FOR TANK ELEMENT 1"1/2

nut \varnothing 1"1/2



ADLER 10433



Suitable for:

ADLER



3355382 HEATING ELEMENT F/BOILER 2800W 220/380V

immersed length 335 mm
complete with gasket (3186191)
for Dishwasher (ADLER) A350 - A500 - B300
for Dishwasher (CODIGEL) CD500
for Dishwasher (DIMCO) DI480



ADLER 20072

3355383 HEATING ELEMENT F/BOILER 6000W 220/380V

immersed length 350 mm
complete with gasket (3186191)
for Dishwasher (ADLER) A720
for Dishwasher hood type (ADLER) A900



ADLER 20080

3355377 HEATING ELEMENT FOR BOILER 2400W 230V

immersed length 260 mm
complete with gasket (3186191)
for Dishwasher (ADLER) B40 - B41 - DS400 - DS410
for Glasswasher/Cupwasher (ADLER) B100 - B200
CF35 - CF40 - COMPACT - DSF101 - DSF103
DS101 - DS103 - DS201 - DS203
for Glasswasher/Cupwasher (WHIRLPOOL) D110 - D111
D210 - D211 - F30 - F300 - F312 - F35 - F40
F400 - F41 - F410



ADLER 20069

Suitable for:

3186191 VITON GASKET FOR HEATING ELEMENT

sizes 52x41x6 mm
for Dishwasher (ADLER) A350 - A500 - A720 - B300
B40 - B41
for Dishwasher hood type (ADLER) A900
for Glasswasher/Cupwasher (ADLER) B100 - B200



ADLER 60009

3186191 VITON GASKET FOR HEATING ELEMENT

sizes 52x41x6 mm
for Dishwasher (ADLER) A350 - A500 - A720 - B300
B40 - B41
for Dishwasher hood type (ADLER) A900
for Glasswasher/Cupwasher (ADLER) B100 - B200



ADLER 60009

3186191 VITON GASKET FOR HEATING ELEMENT

sizes 52x41x6 mm
for Dishwasher (ADLER) A350 - A500 - A720 - B300
B40 - B41
for Dishwasher hood type (ADLER) A900
for Glasswasher/Cupwasher (ADLER) B100 - B200



ADLER 60009



ADLER



Suitable for:

Suitable for:

3355379 HEATING ELEMENT FOR WASH TANK 2000W 220V

immersed length 275 mm
connection \varnothing 1" (33 mm)
complete with gasket (3186009)
for Dishwasher (CODIGEL)
for Dishwasher (DIMCO) DI310
for Dishwasher (NOSEM)
for Glasswasher/Cupwasher (ADLER) CF35 - CF40
DSF101 - DSF103 - DS101 - DS103 - DS201
DS203
for Glasswasher/Cupwasher (WHIRLPOOL) D110 - D111
D210 - D211 - D310 - D311 - F300 - F312 - F35
F40 - F41

3186009 ASBESTOS FREE FLAT GASKET \varnothing 45x33x2 mm



ADLER 20070

ADLER 60005

3355381 FIXING NUT nut \varnothing 1"



ADLER 10426

3355385 HEATING ELEMENT FOR WASH TANK 2800W 220V

immersed length 245 mm
connection \varnothing 1"1/2 (48 mm)
complete with gasket (1186931)
for Dishwasher (ADLER) A350 - A500 - A720 - B300
CF50ADP - DS600
for Dishwasher (CODIGEL) CD500
for Dishwasher (DIMCO) DI480
for Dishwasher (WHIRLPOOL) F650

1186931 GASKET O-RING 0152 GREEN VITON



ADLER 20088

ADLER 60010

3355388 NUT FOR TANK ELEMENT 1"1/2 nut \varnothing 1"1/2



ADLER 10433



Suitable for:

ADLER



Suitable for:

3755049 TANK HEATING ELEMENT 2000W 230V

immersed length 240 mm
width 34 mm
fitting \varnothing 10 mm
for Dishwasher (ADLER) CF235
for Glasswasher/Cupwasher (ADLER) COMPACT
for Glasswasher/Cupwasher (WHIRLPOOL) F30



ADLER 20556

Hinges

3053197 LEFT HINGE

for Dishwasher (ADLER) A400 - CF50 - DS600
for Dishwasher (WHIRLPOOL) F360 - F650
for Glasswasher/Cupwasher (WHIRLPOOL) F400 - F410



ADLER 10421

3053196 RIGHT HINGE

for Dishwasher (ADLER) A400 - CF50 - DS600
for Dishwasher (WHIRLPOOL) F360 - F650
for Glasswasher/Cupwasher (WHIRLPOOL) F400 - F410



ADLER 10598

3053198 RIGHT/LEFT HINGE

for Glasswasher/Cupwasher (ADLER) CF35 - CF40
COMPACT
for Glasswasher/Cupwasher (WHIRLPOOL) F30 - F35
F40 - F41



ADLER 15562

3053195 HINGE PIN \varnothing 10x47 mm



ADLER 15006

3053194 HINGE PIN BUSHING



ADLER 10438

3053193 HINGE TEFLON GASKET

external \varnothing 16 mm
internal \varnothing 10 mm



ADLER 10609



Hose-end fittings

3315018 ELBOW HOSE END FITTING \varnothing 11 mm
 thread \varnothing 16 mm
 for Dishwasher (ADLER) CF50 - DS600
 for Dishwasher (WHIRLPOOL) F360 - F650
 for Dishwasher hood type (ADLER) CF1200 - CF1201A
 DS1200
 for Dishwasher hood type (WHIRLPOOL) F1000
 F1201A
 for Glasswasher/Cupwasher (ADLER) CF35 - CF40
 COMPACT
 for Glasswasher/Cupwasher (WHIRLPOOL) F30 - F35
 F40



ADLER 12021

3315019 3-WAYS HOSE END FITTING \varnothing 12 mm
 for Dishwasher hood type (ADLER) CF1000 - CF1201A
 DS1200
 for Dishwasher hood type (WHIRLPOOL) F1000 - F1201
 for Glasswasher/Cupwasher (ADLER) CF35 - CF40
 for Glasswasher/Cupwasher (WHIRLPOOL) F35 - F40
 F41



ADLER 12076

3315017 4-WAYS HOSE END FITTING \varnothing 12 mm
 for Dishwasher (ADLER) CF50 - DS600
 for Dishwasher (WHIRLPOOL) F360 - F650
 for Glasswasher/Cupwasher (ADLER) CF35 - CF40
 COMPACT
 for Glasswasher/Cupwasher (WHIRLPOOL) F30 - F35
 F40 - F400 - F410



ADLER 12040

Inlet hoses

3090734 PVC HOSE \varnothing 5x8 mm - 10 m
 food-safe



ADLER 60564

3090234 PVC HOSE \varnothing 5x8 mm - 100 m
 food-safe



3449298 PVC HOSE CRISTAL \varnothing 4x6 mm
 sold per meter
 for Dishwasher (ADLER) CF50



ADLER 60554



Suitable for:

ADLER



Suitable for:

Interference suppression filters


3160099 INTERFERENCE SUPPRESSION FILTER 0,47µF



ADLER 20018

3160489 RADIO FREQUENCY INTERFERENCE FILTER 250V


for Dishwasher (ADLER) CF50 - DS600
for Dishwasher (WHIRLPOOL) F360 - F650
for Dishwasher hood type (ADLER) CF1000 - CF1201
for Dishwasher hood type (WHIRLPOOL) F1000 - F1201
for Glasswasher/Cupwasher (WHIRLPOOL) F400 - F410



ADLER 20018

Ironmongery (screws,nuts,washers)

1349042 BRASS NUT \varnothing 3/8"



ADLER 10428

3528112 S/S SCREW T.E. M6x16 UNI 5739 DIN 24017



ADLER 60136

3528010 STAINL.STEEL SCREW WASHER M6 UNI 6592
dimensions \varnothing 12x6.4x1.6 mm



ADLER 60234

1186504 WASHER \varnothing 18x10x2 mm
for Dishwasher hood type (EMMEPI) LS130/90
for Dishwasher hood type (SILANOS) E1000 - N1000
N1300
for Dishwasher hood type (WHIRLPOOL) AGB664
AGB665 - AGB668



ADLER 60238

Lamps

3221110 GREEN INDICATOR LAMP 230V
head \varnothing 7 mm - hole \varnothing 8 mm - 120°C
wire connection length 210 mm



ADLER 20621

ADLER 20622

ADLER 20622+20621

3221098 GREEN LAMP RECEPTACLE
for DS11/13/101/103-CF35-CF40/235/1000-DL240-DS600



ADLER 20010



Suitable for:

Suitable for:

Microswitches

3240217 CHANGE-OVER MICROSWITCH N16

contact capacity 16(4)A 250V
 for Dishwasher hood type (ADLER) CF1000 - CF1201
 DS1200
 for Dishwasher hood type (WHIRLPOOL) F1000 - F1201
 for Glasswasher/Cupwasher (ADLER) DSF101 - DSF103
 DS101 - DS103 - DS201 - DS203
 for Glasswasher/Cupwasher (WHIRLPOOL) D110 - D111
 D210 - D211 - D310 - D311 - F300 - F312



ADLER 20034

3240218 DOOR MICROSWITCH

double microswitch 16A 250V
 for Dishwasher (ADLER) CF50 - DS400 - DS650
 for Dishwasher (WHIRLPOOL) F360 - F650
 for Glasswasher/Cupwasher (ADLER) CF35 - CF35/DP
 CF35/1 - CF35/1DP - CF40/1DL - CF40/1DP
 CF40DL - CF50DPPD
 for Glasswasher/Cupwasher (WHIRLPOOL) F30 - F35
 F40 - F41 - F410



ADLER 20035

3240668 DOOR MICROSWITCH 16A 250V

for Dishwasher (ADLER) B300F
 for Glasswasher/Cupwasher (ADLER) B100 - DSF101
 DS101 - DS103 - DS201 - DS203
 for Glasswasher/Cupwasher (WHIRLPOOL) D110 - D111
 D210 - D211 - D310 - D311 - F312



ADLER 11380

3398061 THREADED MICROSWITCH HOUSING

for Dishwasher (ADLER) CF50 - CF50A400 - DL240
 DS600
 for Glasswasher/Cupwasher (ADLER) CF40



ADLER 10415

3398067 DOOR MICROSWITCH BALL

for CF50-A400-DL240-DS600



ADLER 60258

3398070 DOOR MICROSWITCH END CAP

for CF50-A400-DL240-DS600



ADLER 10458

3398066 DOOR MICROSWITCH GASKET

for Dishwasher (ADLER) A400 - CF50 - DL240 - DS600



ADLER 60012



Suitable for:

3398062 DOOR MICROSWITCH NUT
for CF50-A400-DL240-DS600



ADLER 10435

3398069 DOOR MICROSWITCH SPRING
for CF50-A400-DL240-DS600



ADLER 10470

ADLER



Suitable for:

3398068 DOOR MICROSWITCH PIN
for CF50-A400-DL240-DS600



ADLER 10489

Pressure switches

3320082 PRESSURE SWITCH 100/18 mm 250V 16A
1 level
operating temperature max 85°C



ADLER 20192

3320147 PRESSURE SWITCH 115/40 mm 16A 250V
for A500-A720-A1080-CF1000-F1201



ADLER 20059

3320079 PRESSURE SWITCH 155/40 mm 250V 16A
1 level
operating temperature max 85°C



ADLER 20525

3320029 PRESSURE SWITCH 40/20 mm 250V 16A
1 level
max operating temperature 85°C
for DISHWASHER



ADLER 20053

3320030 PRESSURE SWITCH 55/20 mm 250V 16A
1 level
max operating temperature 85°C
for DISHWASHER
for Dishwasher hood type (BONNET) INO60



ADLER 20057

ADLER 20058



Pumps

3122574 DRAIN ELECTRIC PUMP 100W 220V 50Hz
WITH SEAL ON SHAFT TYPE 6x22x7 in NBR
inlet external \varnothing 24 mm - outlet external \varnothing 24 mm



ADLER 40023

3122747 ELECTR.PUMP FIR 2265SX 0.75HP 230V 50Hz
inlet external \varnothing 40 mm - outlet external \varnothing 45 mm
motor revolutions 2800
0.75HP 230V 50Hz 4A - capacitor 16uf
for Dishwasher (ADLER) CF50
for Dishwasher (WHIRLPOOL) F360




ADLER 40233

3122788 ELECTR/PUMP FIR 4217/ASX 1HP 230/400V
inlet external \varnothing 45 mm - outlet external \varnothing 42 mm
motor revolutions 2800
1HP 230/400V 3.8/2.2A 50Hz
for Dishwasher hood type (ADLER) CF1000



ADLER 40254

3122297 GASKET 4247



ADLER

3122021 PUMP HOUSING
inlet external \varnothing 45 mm
outlet external \varnothing 40 mm



ADLER

3122318 ELECTRIC PUMP FIR 1267/ASX 0.25HP 230V
inlet external \varnothing 30 mm - outlet external \varnothing 30 mm
2700 motor revolutions
0.25HP 230V 50Hz 1.4A - capacitor 10 μ F
for Glasswasher/Cupwasher (ADLER) CF35 - CF40DL
LN10 - LN11 - LN12 - LN13
for Glasswasher/Cupwasher (WHIRLPOOL) F35 - F40



ADLER 40001

3122061 PUMP HOUSING
inlet external \varnothing 30 mm
outlet external \varnothing 30 mm



ADLER 40227



Suitable for:

ADLER



Suitable for:

3122007 ELECTRIC PUMP GRE 604215
 WITH TEFLON ROTATING MECHANICAL SEAL WITH BASIS
 OF ALUMINUM
 100W 230V 50Hz
 connections \varnothing 24 mm
 for old models
 for Dishwasher (ADLER) CF50DP
 for Dishwasher (WHIRLPOOL) F360DP



3122002 ELECTROPUMP ROTATING SEAL
 outlet \varnothing 24 mm
 ceramic part internal \varnothing 10 mm
 part with spring internal \varnothing 6 mm



ADLER 40093

3122432 ELECTRO-PUMP AP 1629030SX 0,30HP 230V
 inlet external \varnothing 32 mm - outlet external \varnothing 31 mm
 motor revolutions 2800
 0.30HP 230V 50Hz - capacitor 10 μ f
 for Dishwasher (SO.WE.BO.) 601 - 701
 for Glasswasher/Cupwasher (AFI) A35 - A35Z2 - A36
 for Glasswasher/Cupwasher (EUROSYSTEM) PRO100
 PRO200
 for Glasswasher/Cupwasher (HILTA) RB10 - RB22
 SB10 - SB22
 for Glasswasher/Cupwasher (IME OMNIWASH) JOLLY
 UNOA - UNOQ - UNOT
 for Glasswasher/Cupwasher (NOSEM) C2010L - C4010L
 NR101 - R1010
 for Glasswasher/Cupwasher (NUOVA SIMONELLI) KIARA1
 for Glasswasher/Cupwasher (SAB ITALIA) C35 - C36



3122511 GASKET



ADLER

3122512 IMPELLER \varnothing 83 mm
 fitting \varnothing 9 mm - total height 52 mm



3122024 MECHANICAL SEAL \varnothing 12mm INNER SURFACE 8mm
 for Dishwasher (ELFRAMO)



3122500 ELECTRO-PUMP AP 902SX 0,10HP 230V 50Hz
 inlet external \varnothing 28 mm - outlet external \varnothing 28 mm
 motor revolutions 2600 - flowrate 80 l/min.
 0.10Hp 230V 1.1A - capacitor 6.3 μ f



3122556 IMPELLER \varnothing 72 mm



ADLER



Suitable for:

3122058 MECHANICAL SEAL \varnothing 11mm INNER SURFACE 8mm



ADLER 40030

3122501 PUMP HOUSING

inlet external \varnothing 28 mm
outlet external \varnothing 28 mm



ADLER



Suitable for:

1186237 O-RING 03300 EPDM

for Glasswasher/Cupwasher (ELFRAMO) BD14 - B14
B15



3122185 ELECTRO-PUMP FIR 1204DX 2HP 240/415V

inlet external \varnothing 63 mm - outlet external \varnothing 54 mm
motor revolutions 2800 - flowrate 500 L/min
2Hp 240/415V 50Hz 5.9/3.4A
for Dishwasher (BONNET) INO20
for Dishwasher conveyor type (COMENDA) - Series AC
Series ACS
for Dishwasher hood type (COMENDA) C140 - C33
C34
for Dishwasher hood type (DIHR) GASTRO1200 - G12S
for Dishwasher hood type (SILANOS) 1300
for Warewasher (COMENDA) GE100 - GE115 - GE60
GE65



3122247 IMPELLER \varnothing 116 mm



ADLER 40015

3122024 MECHANICAL SEAL \varnothing 12mm INNER SURFACE 8mm

for Dishwasher (ELFRAMO)



3122047 PUMP HOUSING

inlet external \varnothing 63 mm
outlet external \varnothing 54 mm



3122026 PUMP HOUSING SEAL






Suitable for:

Suitable for:

3122384 ELECTRO-PUMP FIR 1266SX 0,50HP 230V 50Hz
inlet external \varnothing 45 mm - outlet external \varnothing 40 mm
motor revolutions 2800
0.50HP 230V 50Hz 2.6A - capacitor 12.5 μ f

3122297 GASKET 4247



ADLER 40016

ADLER

3122082 PUMP HOUSING
inlet external \varnothing 45 mm
outlet external \varnothing 40 mm
for Dishwasher (BONNET) INO6



3122766 ELECTRO-PUMP FIR 1267SX 0,25HP 230V 50Hz
inlet external \varnothing 30 mm - outlet external \varnothing 30 mm
motor revolutions 2700
0.25HP 230V 50Hz 1.4A - capacitor 10 μ F
for Glasswasher/Cupwasher (ADLER) CF35
for Glasswasher/Cupwasher (WHIRLPOOL) CF40DL - F35
F40



ADLER 40204

3122319 ELECTRO-PUMP FIR 1268/ASX 0,30HP 230V
inlet external \varnothing 30 mm - outlet external \varnothing 30 mm
motor revolutions 2700
0.30HP 230V 50Hz 1.5A - capacitor 10 μ F
for Glasswasher/Cupwasher (ADLER) CF40

3122061 PUMP HOUSING
inlet external \varnothing 30 mm
outlet external \varnothing 30 mm




ADLER 40259

Suitable for:

Suitable for:

3122383 ELECTRO-PUMP FIR 1270SX 0,75HP 230V 50Hz
 inlet external \varnothing 45 mm - outlet external \varnothing 40 mm
 motor revolutions 2800
 0.75HP 230V 50Hz 4A - capacitor 12.5 μ f

3122297 GASKET 4247



ADLER 40006

ADLER

3122082 PUMP HOUSING
 inlet external \varnothing 45 mm
 outlet external \varnothing 40 mm
 for Dishwasher (BONNET) INO6



3122188 ELECTRO-PUMP FIR 1295SX 1,2HP 230/400V
 inlet external \varnothing 63 mm - outlet external \varnothing 48 mm
 motor revolutions 2800 - flowrate 300 L/min
 1.2HP 230/400V 50Hz 3.8/2.2A
 for Dishwasher hood type (MACH) MS900 - MS900E

3122161 IMPELLER \varnothing 117 mm



ADLER 40009

3122024 MECHANICAL SEAL \varnothing 12mm INNER SURFACE 8mm
 for Dishwasher (ELFRAMO)

3122027 PUMP HOUSING
 inlet external \varnothing 63 mm
 outlet external \varnothing 48 mm



3122026 PUMP HOUSING SEAL





Suitable for:

ADLER



3122038 ELECTRO-PUMP FIR 2212SX 0,10HP 230V 50Hz
 inlet external \varnothing 28 mm - outlet external \varnothing 28 mm
 motor revolutions 2700 - flowrate 80 L/min
 0.10Hp 230V 1.1A - capacitor 5 μ f
 for Dishwasher (DIHR) GS35 - GS37
 for Dishwasher (OLIS) OLDS35 - OLG537
 for Dishwasher hood type (OLIS) OLG11S - OLHT12
 for Glasswasher/Cupwasher (DIHR) DERBYCF




ADLER 40244

3122332 COUPLING GASKET \varnothing 43x27x10 mm



3122040 IMPELLER \varnothing 72 mm



3186271 OR-GASKET 04312 EPDM
 for Dishwasher (ELFRAMO) D30 - D40 - D80
 for Dishwasher (KOMEL) F93 - F94 - F98
 for Dishwasher hood type (ELFRAMO) C33
 for Dishwasher hood type (KOMEL) K8033
 for Glasswasher/Cupwasher (ELFRAMO) BD11 - BD14
 BD15
 for Glasswasher/Cupwasher (KOMEL) F88 - F89 - F91



Suitable for:

3068008 CAPACITOR μ F 5 450V 50/60Hz
 operating temperature -25+85°C
 in compliance with EEC 93/68 and EEC 92/31 regulat



3122733 IMPELLER \varnothing 63 mm



3122058 MECHANICAL SEAL \varnothing 11mm INNER SURFACE 8mm



ADLER 40030

3122042 PUMP HOUSING
 inlet external \varnothing 28 mm
 outlet external \varnothing 28 mm





ADLER



Suitable for:

3122326 ELECTRO-PUMP FIR 2265SX 0,75HP 230V 50Hz
 inlet external \varnothing 45 mm - outlet external \varnothing 40 mm
 motor revolutions 2800
 0.75HP 230V 50Hz 4A - capacitor 16 μ F
 for Dishwasher (ADLER) CF50 - DS600
 for Dishwasher (WHIRLPOOL) F650



ADLER 40224

Suitable for:

3122768 ELECTRO-PUMP FIR 4217/ASX 0.75HP 400V
 inlet external \varnothing 45 mm - outlet external \varnothing 40 mm
 motor revolutions 2800
 for Dishwasher hood type (ADLER) CF1000 - CF1201A
 DS1200
 for Dishwasher hood type (WHIRLPOOL) F1000
 F1201A



ADLER 40228


Relays

3351032 POWER RELAY 66.82 30A 250V
 for LC80-LC140-LC1000-LC1500-LC1700-LC2000
 LC2300-LC2300TR-LC2600-LC2800
 for mod. till 06/12
 for FIORENZATO MC F5-F6
 for RENEKA VIVAE-VIVAS-VIVA-LC-XL-PLUS-PRESTIGE
 MOSAIC
 for NUOVA SIMONELLI APPIACOMPACT



ADLER 20669

3351004 RELAY 56.32 12A 230V 50/60Hz
 2 switching contacts
 for ZANUSSI DISHWASHER LS7-LV70-Z70-LB1-LB2
 for LINEA BLANCA DISHWASHER LC80-LC140-LC1000
 LC1500-LC1700-LC2000-LC2300-LC2300TR-LC2600-LC2800
 LC3800-LC4200
 for NUOVA SIMONELLI SUPERAUTOMATIC MASTER



ADLER 20067

Remote control switches

3446561 CONTACTOR LOVATO BF0910A
 9A 400V 4.2Kw
 coil 230V 50/60Hz
 3 normally open contacts
 for Dishwasher (ADLER) DS400 - DS410 - DS600
 for Dishwasher (WHIRLPOOL) F650
 for Glasswasher/Cupwasher (WHIRLPOOL) F400 - F410



ADLER 20104

ADLER 20105

3446552 CONTACTOR LOVATO BG0610A
 coil 6A 230V 50/60Hz 2.2Kw
 3 normally open contacts
 1 normally open auxiliary contact
 for Glasswasher/Cupwasher (ADLER) CF40 - COMPACT
 for Glasswasher/Cupwasher (WHIRLPOOL) F30 - F41



ADLER 20538



Suitable for:

ADLER



Suitable for:

Rinse aid containers and accessories

3066042 COMPLETE ADDITIVE TANK

for Dishwasher (ADLER) CF50 - CF50A - DS400
DS410 - DS600
for Dishwasher (WHIRLPOOL) F360 - F650
for Glasswasher/Cupwasher (WHIRLPOOL) F400 - F410



ADLER 10368

3066048 DETERGENT CONTAINER

for Dishwasher (ADLER) DS401 - DS401PD
for Glasswasher/Cupwasher (ADLER) DSF101 - DSF103
DSF11 - DSF13 - DS101 - DS103 - DS11 - DS13
DS201 - DS203 - DS21 - DS23



ADLER 10371

Rinse aid pumps and accessories

3090354 ELBOW FITTING FOR HOSE 4x6

for tank inlet
in stainless steel
for Dishwasher (HILTA) W13T



ADLER 20552

3090025 HYDRAULIC RINSE AID INJECTOR MODEL 1000

for rinse aid
delivery connector for boiler, olive connection,
pipe \varnothing 4x6 mm
teflon ball
stainless steel spring for diaphragm, wire \varnothing 1 mm
silicon valve
silicon diaphragm
pump connection fitting, olive connection,
pipe \varnothing 6x8 mm
inlet fitting with connection
for flexible pipe \varnothing 4x6 mm



ADLER 20003

3090055 DIAPHRAGM MOD. DA 1011



ADLER 10562

3090221 SILICONE VALVE F/DISPENSER MOD.1000





ADLER



Suitable for:

Suitable for:

3090016 HYDRAULIC RINSE AID INJECTOR MODEL 3000
 for rinse aid
 with inspectionable filter
 for Dishwasher (ADLER) DS400 - DS410 - DS600
 for Dishwasher (WHIRLPOOL) F650
 for Glasswasher/Cupwasher (ADLER) CF35 - CF40
 DSF101 - DSF103 - DS101 - DS103 - DS201
 DS203
 for Glasswasher/Cupwasher (NOSEM) NA400
 for Glasswasher/Cupwasher (WHIRLPOOL) D110 - D111
 D210 - D211 - D310 - D311 - F300 - F312 - F35
 F40 - F400 - F41 - F410



ADLER 20199

ADLER 40145

3090017 INLET FILTER MODEL 3000



ADLER 10446

3090018 T-FITTING BLACK



ADLER

3090029 PERISTALTIC DETERGENT PUMP G200 230V50Hz
 detergent flow rate 0.777 gr per second
 max flow rate 2 l/hour (equivalent to 2000 cm³)
 for DISHWASHER (500 DISHES PER HOUR)



ADLER 20128

ADLER 20588

3090056 DIAPHRAGM MOD. DA 3010



ADLER 40147

3090003 INLET VALVE FOR RINSE AID INJECTOR
 for Dishwasher (BONNET) IN08
 for Dishwasher (COMENDA) F20 - F45
 for Dishwasher (JEMI) GS-8/2 - GS-8/2D - GS-9/2
 GS-9/2D
 for Dishwasher hood type (JEMI) GS-100 - GS-83
 for Glasswasher/Cupwasher (BONNET) IN07F - VR1000R
 for Glasswasher/Cupwasher (COMENDA) B11T
 for Glasswasher/Cupwasher (ELETTROBAR) S621 - S636



ADLER 40044

3090032 ELBOW FOR TANK INLET
 complete
 for Dishwasher (ELFRAMO) D30 - D40 - D80
 for Dishwasher hood type (ELFRAMO) C44 - C66
 for Dishwasher hood type (KOMEL) K8044 - K8066
 for Glasswasher/Cupwasher (ELFRAMO) BD14 - B11
 B14 - B15
 for Pan washing machine (ELFRAMO) LP60 - LP70





Suitable for:

3090033 FOOT VALVE WITH NON RETURN
with filter and STAINLESS steel ring



3090018 T-FITTING BLACK



ADLER

3090061 PERISTALTIC PUMP KIT G43 230V 50Hz
for liquid detergent
max flow rate 3 l/h
time-break regulation
this KIT for DISHWASHERS includes: PVC hose
inlet connector for tank, nylon clamps,
foot valve with filter and stainless steel ring,
mounting brackets, washers M4



ADLER 20545

ADLER

Suitable for:

3090017 INLET FILTER MODEL 3000



ADLER 10446

3090057 THERMOPLASTIC PIPE 5x8 mm 55SH
replacement for pumps G200-G250-G252-G40-D25-G8
G82-G15-G40-G40D-G50D-G600
complete with connectors new version



3090090 THERMOPLASTIC PIPE 6.2x10.2 mm 45SH
for G43-G45-G53-G54-G55-G300



Salt container and accessories

3067001 SALT CONTAINER



ADLER 10370

3067016 FUNNEL FOR SALT INTAKE
external \varnothing 93 mm hole \varnothing 27 mm





Suitable for:

3067002 GASKET FOR CONTAINER

external \varnothing 82 mm
internal \varnothing 64 mm
thickness 3 mm



3067007 SALT CONTAINER CAP



ADLER

ADLER



Suitable for:

3067198 O-RING 04162 EPDM

for Dishwasher (AFI) A600
for Dishwasher (EUROSYSTEM) PRO400
for Dishwasher (HILTA) S41 - S42
for Dishwasher (IME OMNIWASH) 4Q82
for Dishwasher (LAMBER) 040F - 045F
for Dishwasher (NOSEM) C5000 - C5010 - NC501
for Dishwasher (NUOVA SIMONELLI) KIARA6
for Dishwasher (SAB ITALIA) C50H
for Dishwasher (SO.WE.BO.)
for Dishwasher (SOTAL) F600
for Glasswasher/Cupwasher (AFI) A35Z2
for Glasswasher/Cupwasher (ELETTROBAR) 35F - 350F
40F - 400F
for Glasswasher/Cupwasher (IME OMNIWASH) JA40
JA41 - UNO



3067005 SALT CONTAINER RING NUT



Sleeves

3248096 INLET HOSE

external \varnothing 55 mm
internal \varnothing 45 mm
for Dishwasher (ADLER) DS400 - DS600



ADLER 12030

3248098 INLET HOSE

external \varnothing 36 mm
internal \varnothing 26 mm
for Glasswasher/Cupwasher (ADLER) CF40



ADLER 15563

3248099 INLET HOSE

external \varnothing 43 mm
internal \varnothing 33 mm
for Glasswasher/Cupwasher (ADLER) CF35 - CF40



ADLER 15564

3248097 OUTLET HOSE

external \varnothing 50 mm
internal \varnothing 39 mm
for Dishwasher (ADLER) CF50



ADLER 12127



Suitable for:

ADLER



3248127 OUTLET HOSE
 internal \varnothing 38 e 33 mm
 for Dishwasher hood type (ADLER) CF1000 - CF1201
 DS1200
 for Dishwasher hood type (WHIRLPOOL) F1000
 F1201A



ADLER 15589

3248094 OUTLET HOSE 130 mm
 external \varnothing 48 e 40 mm
 internal \varnothing 41 e 31 mm
 for Dishwasher (ADLER) DL240
 for Glasswasher/Cupwasher (ADLER) CF40



ADLER 16003

3248095 OUTLET HOSE 56 mm
 external \varnothing 49 mm
 internal \varnothing 38 mm
 for Dishwasher (ADLER) A350 - A500 - DS600



ADLER 10534

Solenoid valves

3120005 SOLENOID VALVE 329 220/240V \varnothing 10 mm
 solenoid valve 180° - 220/240V 50/60Hz - max 90°C
 inlet 3/4" - outlet \varnothing 10 mm



ADLER 20006

ADLER 20007

3120000 FILTER FOR INLET SOLENOID VALVE ELBI



3120021 INLET PRESSURE REDUCER 12 L/min BLACK



3120022 INLET PRESSURE REDUCER 16 L/min BLACK



3120019 INLET PRESSURE REDUCER 5.5 L/min BLACK



3120037 OUTLET REDUCER ELBI 0.25 L/min GREEN
 for ELBI solenoid valve
 face value +/- 25%





Suitable for:

3120202 **OUTLET REDUCER ELBI 0.35 L/min YELLOW**
for ELBI solenoid valve
face value +/- 25%



3120016 **OUTLET REDUCER ELBI 1.2 L/min NEUTRAL**
for ELBI solenoid valve
face value +/- 25%



3120017 **OUTLET REDUCER ELBI 2.5 L/min ORANGE**
for ELBI solenoid valve
face value +/- 25%



3120204 **OUTLET REDUCER ELBI 5.5 L/min BROWN**
for ELBI solenoid valve
face value +/- 25%



3120006 **SOLENOID VALVE 339 220/240V ø 10 mm**
solenoid valve 90° - 220/240V 50/60Hz - max 90°C
inlet 3/4" - dual outlet ø 10 mm



ADLER 20016

3120021 **INLET PRESSURE REDUCER 12 L/min BLACK**



ADLER

Suitable for:

3120015 **OUTLET REDUCER ELBI 0.5 L/min RED**
for ELBI solenoid valve
face value +/- 25%



ADLER 10558

3120203 **OUTLET REDUCER ELBI 2 L/min WHITE**
for ELBI solenoid valve
face value +/- 25%



3120201 **OUTLET REDUCER ELBI 4.7 L/min GREY**
for ELBI solenoid valve
face value +/- 25%



3120000 **FILTER FOR INLET SOLENOID VALVE ELBI**



3120022 **INLET PRESSURE REDUCER 16 L/min BLACK**





Suitable for:

3120019 INLET PRESSURE REDUCER 5.5 L/min BLACK



3120202 OUTLET REDUCER ELBI 0.35 L/min YELLOW
for ELBI solenoid valve
face value +/- 25%



3120016 OUTLET REDUCER ELBI 1.2 L/min NEUTRAL
for ELBI solenoid valve
face value +/- 25%



3120017 OUTLET REDUCER ELBI 2.5 L/min ORANGE
for ELBI solenoid valve
face value +/- 25%



3120204 OUTLET REDUCER ELBI 5.5 L/min BROWN
for ELBI solenoid valve
face value +/- 25%



ADLER

Suitable for:

3120037 OUTLET REDUCER ELBI 0.25 L/min GREEN
for ELBI solenoid valve
face value +/- 25%



3120015 OUTLET REDUCER ELBI 0.5 L/min RED
for ELBI solenoid valve
face value +/- 25%



ADLER 10558

3120203 OUTLET REDUCER ELBI 2 L/min WHITE
for ELBI solenoid valve
face value +/- 25%



3120201 OUTLET REDUCER ELBI 4.7 L/min GREY
for ELBI solenoid valve
face value +/- 25%





Suitable for:

ADLER



3120007 SOLENOID VALVE 349 220/240V \varnothing 10 mm
solenoid valve 180° - 220/240V 50/60Hz - max 90°C
inlet 3/4" - dual outlet \varnothing 10 mm



ADLER 20008

ADLER 20160

3120021 INLET PRESSURE REDUCER 12 L/min BLACK



3120000 FILTER FOR INLET SOLENOID VALVE ELBI



3120022 INLET PRESSURE REDUCER 16 L/min BLACK



3120019 INLET PRESSURE REDUCER 5.5 L/min BLACK



3120037 OUTLET REDUCER ELBI 0.25 L/min GREEN
for ELBI solenoid valve
face value +/- 25%



3120202 OUTLET REDUCER ELBI 0.35 L/min YELLOW
for ELBI solenoid valve
face value +/- 25%



3120015 OUTLET REDUCER ELBI 0.5 L/min RED
for ELBI solenoid valve
face value +/- 25%



3120016 OUTLET REDUCER ELBI 1.2 L/min NEUTRAL
for ELBI solenoid valve
face value +/- 25%



ADLER 10558

3120203 OUTLET REDUCER ELBI 2 L/min WHITE
for ELBI solenoid valve
face value +/- 25%



3120017 OUTLET REDUCER ELBI 2.5 L/min ORANGE
for ELBI solenoid valve
face value +/- 25%



3120201 OUTLET REDUCER ELBI 4.7 L/min GREY
for ELBI solenoid valve
face value +/- 25%





Suitable for:

3120204 **OUTLET REDUCER ELBI 5.5 L/min BROWN**
for ELBI solenoid valve
face value +/- 25%



ADLER



Suitable for:

Springs

3250091 **HOOD SPRING \varnothing 43x325 mm**
for CS1000-DS1200



ADLER 10563

3053191 **HOOD SPRING PIN \varnothing 8 mm**



ADLER 10586

3250088 **HOOD SPRING**



ADLER 11525

3053192 **SPRING BOTTOM LOCKING BUSH**



ADLER 10567

Switches

3319240 **BIPOLAR PUSH-BUTTON**
16(4)A 250V
for Dishwasher (ADLER) CF50 - CF50A
for Dishwasher hood type (ADLER) CF1201



ADLER 20661

3319246 **GREEN ROUND PUSH-BUTTON \varnothing 21 mm**
for Dishwasher (ADLER) CF50 - CF50A



ADLER 20667

3319245 **BLACK ROUND PUSH-BUTTON \varnothing 21 mm**
for Dishwasher (ADLER) CF50 - CF50A



ADLER 20666

3319244 **GREY ROUND PUSH-BUTTON \varnothing 21 mm**
for Dishwasher (ADLER) CF50 - CF50A



ADLER 20668



Suitable for:

3319242 PUSH-BUTTON SUPPORT
for Dishwasher (ADLER) CF50 - CF50A




ADLER 20664

3319920 BLACK TWO-POLE SWITCH 16A 250V
for Dishwasher (DIHR) GASTRO500 - GASTRO750 - G600



ADLER 20660

3319646 GREEN/ORANGE CAM
for Dishwasher (KROMO) K35 - K37 - K40 - K45 - K50
K80 - K90
for Dishwasher hood type (KROMO) K100



ADLER



Suitable for:

3319243 WHITE ROUND PUSH-BUTTON ø 21 mm
for Dishwasher (ADLER) CF50 - CF50A



ADLER 20665

3319923 BLACK/RED CAM



3319248 CYCLE START COMPLETE PUSH-BUTTON
normally open contact
240V 3A
for Dishwasher (ADLER) DL240
for Glasswasher/Cupwasher (ADLER) CF35 - CF40
COMPACT - DSF101 - DS101 - DS103 - DS201
DS203
for Glasswasher/Cupwasher (WHIRLPOOL) D110 - D111
D210 - D211 - D310 - D311 - F30 - F312 - F35
F40 - F41




ADLER 20037

ADLER 20519

ADLER 20598

3319735 DOUBLE SWITCH BLOCK (ON-OFF/SCAR)



ADLER 20500



Suitable for:

ADLER



3319012 GREEN BIPOLAR SWITCH 16A 250V
 with indicator light and switch cover
 screen printing 0 - I
 max temperature 120°C
 mounting hole 22x30 mm
 for Dishwasher (DIHR) DERBY CF - GASTRO450
 GASTRO500 - GASTRO750 - GASTRO900 - TURBOCF/LS
 for Dishwasher (UNIVERBAR)
 for Dishwasher hood type (DIHR) GASTRO115
 GASTRO1200S



ADLER 20258

Suitable for:

3319090 GREEN BIPOLAR SWITCH 16A 250V
 with indicator lamp and switch cover
 max temperature 120°C
 mounting hole 22x30 mm




ADLER 20043

3319944 GREEN BIPOLAR SWITCH 16A 250V
 with indicator light
 0-I silk-screen printing
 temperature max 120°C
 mounting hole 22x30 mm



ADLER 20528

3319419 PUSH-BUTTON PANEL 4 BUTTONS
 for Dishwasher (ADLER) A500 - DS600
 for Dishwasher (WHIRLPOOL) F650



ADLER 20062

3319239 ROLD BIPOLAR SWITCH
 16(4)A 250V



ADLER 20663

3319218 SWITCH 16(4)A 250V
 for Dishwasher (EUROFRANCE) N50Q - N50T - N58Q
 N58T - N63Q - N63T - N70Q - N70T - N82Q
 for Dishwasher (HOONVED) - Series C - Series CR
 for Dishwasher (WHIRLPOOL) AGB648 - AGB649
 AGB650 - AGB651 - AGB652 - AGB653 - AGB657
 AGB658 - AGB659
 for Glasswasher/Cupwasher (COMENDA) B11
 for Glasswasher/Cupwasher (WHIRLPOOL) AGB641
 AGB642 - AGB643 - AGB647 - AGB782 - AGB783



ADLER 20662

3319245 BLACK ROUND PUSH-BUTTON ø 21 mm
 for Dishwasher (ADLER) CF50 - CF50A



ADLER 20666



Suitable for:

3319246 GREEN ROUND PUSH-BUTTON \varnothing 21 mm
for Dishwasher (ADLER) CF50 - CF50A



ADLER 20667

3319244 GREY ROUND PUSH-BUTTON \varnothing 21 mm
for Dishwasher (ADLER) CF50 - CF50A



ADLER 20668

3319242 PUSH-BUTTON SUPPORT
for Dishwasher (ADLER) CF50 - CF50A




ADLER 20664

3319249 1 BUTTON SWITCH
250V 16(6)A
for Dishwasher (ADLER) DL240
for Glasswasher/Cupwasher (WHIRLPOOL)



ADLER 20044

3319079 3 BUTTONS PANEL
for Glasswasher/Cupwasher (ADLER) DSF101 - DSF103
DSF11 - DSF13 - DS101 - DS103 - DS11 - DS13
DS201 - DS203 - DS21 - DS23
for Glasswasher/Cupwasher (WHIRLPOOL) D111 - D211
D311 - F300 - F312



ADLER 20064

ADLER



Suitable for:

3319220 GREY BUTTON
for Dishwasher (HOONVED) - Series APS



3319219 GREY SUPPORT



3319243 WHITE ROUND PUSH-BUTTON \varnothing 21 mm
for Dishwasher (ADLER) CF50 - CF50A



ADLER 20665

3319078 2 BUTTONS PANEL
for Dishwasher (WHIRLPOOL) F360
for Glasswasher/Cupwasher (ADLER) CF35 - CF40
DSF101 - DSF103 - DSF11 - DSF13 - DS101
DS103 - DS11 - DS13 - DS201 - DS203 - DS21
DS23
for Glasswasher/Cupwasher (WHIRLPOOL) D110 - D210
D310 - F35 - F40 - F400 - F410



ADLER 20065




Suitable for:

ADLER



3319237 3 BUTTONS PANEL
 for Dishwasher (ADLER) A500 - A720
 for Dishwasher hood type (ADLER) A1080 - CF1000



ADLER 20063

3319238 3 BUTTONS PANEL
 for Dishwasher (ADLER) DL240
 for Glasswasher/Cupwasher (ADLER) CF35 - CF40
 for Glasswasher/Cupwasher (WHIRLPOOL) F40 - F400 F41



ADLER 20149

Terminal blocks

3247041 FASTON TERMINAL BLOCK 20A 450V
 for cable max 2.5 mm²
 operating temperature 85°C



ADLER 20045

3247040 TERMINAL FOR CABLE ø 4 mm



ADLER 20132

Thermostats

3444188 SINGLE-PHASE SAFETY THERMOSTAT 124°C
 covered capillary 1800 mm
 bulb ø 5x68 mm
 16A 250V
 for Dishwasher (ADLER) CF50
 for Dishwasher (WHIRLPOOL) F360 - F650
 for Dishwasher hood type (ADLER) CF1000 - CF1201 DS1200
 for Dishwasher hood type (WHIRLPOOL) F1000 - F1201
 for Glasswasher/Cupwasher (ADLER) CF40 - DSF101 DSF103 - DS101 - DS103 - DS201 - DS203
 for Glasswasher/Cupwasher (WHIRLPOOL) D110 - D111 D210 - D211 - D310 - D311 - F30 - F300 - F312 F40 - F400 - F41 - F410



ADLER 20198
ADLER 20732

ADLER 20617

ADLER 20673

3444184 SINGLE-PHASE THERMOSTAT 60°C
 covered capillary 1500 mm
 bulb ø 6x130 mm
 16A 250V
 for Dishwasher (ADLER) CF50 - DL240
 for Dishwasher (WHIRLPOOL) F360 - F650
 for Dishwasher hood type (ADLER) CF1000 - CF1201 DS1200
 for Dishwasher hood type (WHIRLPOOL) F1000 - F1201
 for Glasswasher/Cupwasher (ADLER) CF35 - CF40 DSF101 - DSF103 - DS103
 for Glasswasher/Cupwasher (WHIRLPOOL) D110 - D111 D210 - D211 - D310 - D311 - F30 - F300 - F312 F35 - F40 - F400 - F41 - F410



ADLER 20110

ADLER 20111

Suitable for:

Suitable for:

3444189 SINGLE-PHASE THERMOSTAT 85°C
 covered capillary 1500 mm
 bulb 6x170 mm
 16A 250V
 for Dishwasher (ADLER) CF50 - DL240



ADLER 20587

ADLER 20596

3444161 THERMOSTAT SINGLE-PHASE 0-90°C
 covered capillary 2150 mm
 bulb \varnothing 6.5x95 mm
 15A 250V
 D shaft \varnothing 6x4.6 mm
 for Dishwasher (WHIRLPOOL) F360 - F650
 for Dishwasher hood type (ADLER) CF1000 - CF1201
 for Dishwasher hood type (WHIRLPOOL) F1000 - F1201
 for Glasswasher/Cupwasher (ADLER) CF35 - CF40
 DSF101 - DSF103 - DSF11 - DSF13 - DS101
 DS103 - DS11 - DS13 - DS201 - DS203 - DS21
 DS23
 for Glasswasher/Cupwasher (WHIRLPOOL) D110 - D111
 D210 - D211 - D310 - D311 - F30 - F40 - F400
 F41 - F410



ADLER 20119

3394326 THERMOSTAT SHEATH



Timers

3322194 CONTROLLER D94 3 CAMS
 for rinsing
 cycle 240 seconds
 rinse 18 seconds
 230V 50/60HZ
 D-shaped pin \varnothing 6x4.6 mm
 for Dishwasher (ADLER) A350 - F1000 - F1201 - F350
 F650
 for Dishwasher (WHIRLPOOL) F360 - F650
 for Dishwasher hood type (ADLER) A1080
 for Dishwasher hood type (WHIRLPOOL) F1000 - F1201



ADLER 20095

3241350 BLACK KNOB \varnothing 45 mm
 D shaft hole 6x4.6 mm
 for Dishwasher (ADLER) DS41
 for Glasswasher/Cupwasher (ADLER) CF40 - DSF103



ADLER 10551



Suitable for:

3250215 TIMER KNOB SPRING



ADLER 10469

ADLER



Suitable for:

3322341 CONTROLLER D94 3 CAMS 230V 50HZ
3-minute cycle - 18-second rinse cycle
for Dishwasher (ADLER)



ADLER 20670

3322035 CONTROLLER 9444 3 CAMS
cycle 180 seconds
rinse 18 seconds
220V 50/60HZ
clockwise rotation
D-shaped pin \varnothing 6x4.6 mm
for Dishwasher (ADLER) B301 - B303 - B40 - B41
DS400 - DS410
for Glasswasher/Cupwasher (WHIRLPOOL) D310 - D311
F400 - F410



ADLER 20103

3250215 TIMER KNOB SPRING



ADLER 10469

3241350 BLACK KNOB \varnothing 45 mm
D shaft hole 6x4.6 mm
for Dishwasher (ADLER) DS41
for Glasswasher/Cupwasher (ADLER) CF40 - DSF103



ADLER 10551

3322229 PROGRAMMER D94 4 CAMS 2 MOTORS
1st cycle 219"
2nd cycle 140"
3rd cycle 72"
230V 50Hz
for Dishwasher hood type (ADLER) DS1200



ADLER 20559



ADLER



Suitable for:

3322034 PROGRAMMER 9444 3 CAMS

cycle 120 seconds
rinse 14 seconds
220V 50/60HZ
clockwise rotation
D shaft \varnothing 6x4.6 mm
for Glasswasher/Cupwasher (ADLER) B100 - B101
B102 - B103 - B201 - B203 - CF35 - CF40
COMPACT - DSF101 - DSF103 - DS101 - DS103
DS201 - DS203
for Glasswasher/Cupwasher (WHIRLPOOL) D110 - D111
D210 - D211 - F30 - F300 - F312 - F35 - F40
F41



ADLER 20102

3446208 CONTROLLER SHAFT

for Glasswasher/Cupwasher (ADLER) CF40 - DSF103



ADLER 20025

3322193 TIMER D94 4 CAMS

for regeneration
cycle 18 minutes
230V 50/60HZ
without shaft
for Dishwasher (ADLER) B301 - B40 - B41
for Glasswasher/Cupwasher (ADLER) DSF101 - DS101
DS103 - DS201 - DS203



ADLER 20101

Suitable for:

3241350 BLACK KNOB \varnothing 45 mm

D shaft hole 6x4.6 mm
for Dishwasher (ADLER) DS41
for Glasswasher/Cupwasher (ADLER) CF40 - DSF103



ADLER 10551

3250215 TIMER KNOB SPRING



ADLER 10469



Suitable for:

ADLER



Suitable for:

Wash and rinse arms and accessories

3743113 BOTTOM ARM ASSEMBLY SUPPORT
 for Dishwasher (ADLER) DS401 - DS412
 for Dishwasher hood type (ADLER) CF1000 - DS1200



ADLER 15031

ADLER 15031/V

3186290 O-RING 04187 EPDM
 for Dishwasher (ADLER) A350 - A500 - A720 - B300
 DS400 - DS410
 for Dishwasher (WHIRLPOOL) F360 - F650
 for Dishwasher hood type (FAGOR) FI-100 - FI-120
 FI-80
 for Dishwasher hood type (LASA) LC50 - LC65
 for Dishwasher hood type (MARENO) MLC50 - MLC65
 for Dishwasher hood type (WHIRLPOOL) F1000
 F1201A
 for Glasswasher/Cupwasher (ADLER) CF35 - CF40
 for Glasswasher/Cupwasher (ELETTROBAR) E35 - E40
 E40H - NIAGARA40
 for Glasswasher/Cupwasher (WHIRLPOOL) F30 - F35
 F40 - F400 - F41 - F410



ADLER 60076

3743114 BOTTOM ARM ASSEMBLY SUPPORT
 for Dishwasher (ADLER) DL240
 for Glasswasher/Cupwasher (ADLER) CF40 - ECO40
 for Glasswasher/Cupwasher (WHIRLPOOL) F41



ADLER 15038

ADLER 15038/V

3186290 O-RING 04187 EPDM
 for Dishwasher (ADLER) A350 - A500 - A720 - B300
 DS400 - DS410
 for Dishwasher (WHIRLPOOL) F360 - F650
 for Dishwasher hood type (FAGOR) FI-100 - FI-120
 FI-80
 for Dishwasher hood type (LASA) LC50 - LC65
 for Dishwasher hood type (MARENO) MLC50 - MLC65
 for Dishwasher hood type (WHIRLPOOL) F1000
 F1201A
 for Glasswasher/Cupwasher (ADLER) CF35 - CF40
 for Glasswasher/Cupwasher (ELETTROBAR) E35 - E40
 E40H - NIAGARA40
 for Glasswasher/Cupwasher (WHIRLPOOL) F30 - F35
 F40 - F400 - F41 - F410



ADLER 60076

3743120 BOTTOM ARM ASSEMBLY SUPPORT
 for Dishwasher (ADLER) CF50A



ADLER 15078

3743124 BOTTOM ARM ASSEMBLY SUPPORT
 for Dishwasher (ADLER) CF235
 for Glasswasher/Cupwasher (ADLER) CF35 - COMPACT
 for Glasswasher/Cupwasher (WHIRLPOOL) F30 - F35
 F40



ADLER 15018

ADLER 15018/V



Suitable for:

ADLER



3743117 BOTTOM IMPELLER SUPPORT
for Dishwasher (ADLER) DS410 - DS600
for Dishwasher (WHIRLPOOL) F650
for Glasswasher/Cupwasher (WHIRLPOOL) F400 - F410



ADLER 12008

3186290 O-RING 04187 EPDM
for Dishwasher (ADLER) A350 - A500 - A720 - B300
DS400 - DS410
for Dishwasher (WHIRLPOOL) F360 - F650
for Dishwasher hood type (FAGOR) FI-100 - FI-120
FI-80
for Dishwasher hood type (LASA) LC50 - LC65
for Dishwasher hood type (MARENO) MLC50 - MLC65
for Dishwasher hood type (WHIRLPOOL) F1000
F1201A
for Glasswasher/Cupwasher (ADLER) CF35 - CF40
for Glasswasher/Cupwasher (ELETTROBAR) E35 - E40
E40H - NIAGARA40
for Glasswasher/Cupwasher (WHIRLPOOL) F30 - F35
F40 - F400 - F41 - F410



ADLER 60076

3743675 BOTTOM WASH ARM 190 mm
without jets
for Glasswasher/Cupwasher (ADLER) B100 - DS101
DS103
for Glasswasher/Cupwasher (WHIRLPOOL) D110 - D111



ADLER 10218

3743043 COMPLETE WASH/RINSE ARM ASSEMBLY
length 490 mm
for Dishwasher (ADLER) CF50 - DS600
for Dishwasher (WHIRLPOOL) F360 - F650
for Dishwasher hood type (ADLER) CF1000 - CF1201A
DS1200
for Dishwasher hood type (WHIRLPOOL) F1000
F1201A



ADLER 12084

ADLER 12084/V

3743126 BOTTOM ARM ROD
for CF35-CF40-CF50-DL240-DS600-DS1200



ADLER 12017



Suitable for:

3743118 BUSHING FOR WASH ARM ASSEMBLY

external ø 16 mm
internal ø 12 mm
height 10 mm
for Dishwasher (ADLER) CF50 - DS401 - DS600
for Dishwasher (WHIRLPOOL) F360 - F650
for Dishwasher hood type (ADLER) CF1000 - CF1201A
DS1200
for Dishwasher hood type (WHIRLPOOL) F1000
F1201A
for Glasswasher/Cupwasher (ADLER) CF35 - CF40
COMPACT
for Glasswasher/Cupwasher (WHIRLPOOL) F30 - F35
F40 - F400 - F41 - F410



ADLER 11351

3186290 O-RING 04187 EPDM

for Dishwasher (ADLER) A350 - A500 - A720 - B300
DS400 - DS410
for Dishwasher (WHIRLPOOL) F360 - F650
for Dishwasher hood type (FAGOR) FI-100 - FI-120
FI-80
for Dishwasher hood type (LASA) LC50 - LC65
for Dishwasher hood type (MARENO) MLC50 - MLC65
for Dishwasher hood type (WHIRLPOOL) F1000
F1201A
for Glasswasher/Cupwasher (ADLER) CF35 - CF40
for Glasswasher/Cupwasher (ELETTROBAR) E35 - E40
E40H - NIAGARA40
for Glasswasher/Cupwasher (WHIRLPOOL) F30 - F35
F40 - F400 - F41 - F410



ADLER 60076

3743125 RINSE ARM END CAP

for Dishwasher (ADLER) CF50 - DL240 - DS401
DS412
for Dishwasher (WHIRLPOOL) F360 - F650
for Dishwasher hood type (WHIRLPOOL) F1000
F1201A
for Glasswasher/Cupwasher (ADLER) CF35 - CF40
COMPACT
for Glasswasher/Cupwasher (WHIRLPOOL) F30 - F35
F40 - F400 - F41 - F410



ADLER 12013

ADLER



Suitable for:

3743044 LOWER SUPPORT ASSY AND EXTENSION

for Dishwasher (ADLER) CF50 - DS600
for Dishwasher (WHIRLPOOL) F360
for Dishwasher hood type (ADLER) CF1000 - CF1201A
DS1200



ADLER 15019

ADLER 15019/V

3324032 PIN FOR BOTTOM WASH ARM ASSEMBLY


for Dishwasher (ADLER) CF50
for Dishwasher (WHIRLPOOL) F360



ADLER 15016

3743123 WASH ARM END CAP

for Dishwasher (ADLER) CF50 - DS401 - DS412
DS600
for Dishwasher (WHIRLPOOL) F360 - F650
for Dishwasher hood type (ADLER) CF1000 - CF1201A
DS1200
for Dishwasher hood type (WHIRLPOOL) F1000
F1201A
for Glasswasher/Cupwasher (ADLER) CF35 - CF40
COMPACT
for Glasswasher/Cupwasher (WHIRLPOOL) F40 - F400
F41 - F410



ADLER 12010

Suitable for:

3743127 COMPLETE WASH/RINSE ARM ASSEMBLY
 length 380 mm
 for Dishwasher (ADLER) CF235 - DL240 - DS401
 DS412
 for Glasswasher/Cupwasher (ADLER) CF35 - CF40
 COMPACT
 for Glasswasher/Cupwasher (WHIRLPOOL) F30 - F35
 F40 - F400 - F41 - F410



ADLER 12169

ADLER 12169V

Suitable for:

3743119 ARM ASSEMBLY RING NUT
 for Dishwasher (ADLER) CF50 - DL240 - DS401
 DS412 - DS600
 for Dishwasher (WHIRLPOOL) F360 - F650
 for Dishwasher hood type (ADLER) CF1000 - CF1201A
 DS1200
 for Dishwasher hood type (WHIRLPOOL) F1000
 F1201A
 for Glasswasher/Cupwasher (ADLER) CF35 - CF40
 COMPACT
 for Glasswasher/Cupwasher (WHIRLPOOL) F30 - F35
 F40 - F400 - F41 - F410



ADLER 12020

3743684 NON RETURN RING NUT PLATE
 for Dishwasher (ADLER) CF50 - DS401 - DS412
 DS600
 for Dishwasher (WHIRLPOOL) F360 - F650
 for Dishwasher hood type (ADLER) CF1000 - CF1201A
 DS1200
 for Dishwasher hood type (WHIRLPOOL) F1000
 F1201A
 for Glasswasher/Cupwasher (ADLER) CF35 - CF40
 for Glasswasher/Cupwasher (WHIRLPOOL) F30 - F35
 F40 - F400 - F41



ADLER 12019

3743255 RH RINSE ARM
 without jets
 for Dishwasher (ADLER) CF50 - DS600
 for Dishwasher (WHIRLPOOL) F360 - F650
 for Dishwasher hood type (ADLER) CF1000 - CF1201A
 DS1200
 for Dishwasher hood type (WHIRLPOOL) F1000
 F1201A



ADLER 12011

3743700 RINSE ARM
 for Dishwasher (ADLER) B301
 for Glasswasher/Cupwasher (ADLER) B203 - DS201
 DS203 - DS21 - DS23



ADLER 10206

3743252 RINSE ARM ASSEMBLY
 length 480 mm - without jets
 for Dishwasher (ADLER) A350 - A500 - A720 - L50
 for Dishwasher hood type (ADLER) A1080 - A900



ADLER 10262

3743648 RINSE ARM ASSEMBLY
 for Dishwasher (ADLER) CF101
 for Glasswasher/Cupwasher (ADLER) DSF101 - DSF103
 for Glasswasher/Cupwasher (WHIRLPOOL) F300 - F312



ADLER 11915



Suitable for:

ADLER



3743115 RINSE ARM 215 mm

without nozzles
for Dishwasher (ADLER) CF50 - DS600
for Dishwasher (WHIRLPOOL) F360 - F650



ADLER 12012

1186346 O-RING 02043 EPDM

for Dishwasher (ADLER) DS400 - DS410
for Dishwasher (WHIRLPOOL) F360 - F650
for Dishwasher hood type (WHIRLPOOL) F1000
for Glasswasher/Cupwasher (ADLER) CF35 - CF40
COMPACT
for Glasswasher/Cupwasher (WHIRLPOOL) F30 - F35
F40 - F400 - F41 - F410
for Glasswasher/Cupwasher hood type (WHIRLPOOL)
F1201A



ADLER 60073

3743125 RINSE ARM END CAP

for Dishwasher (ADLER) CF50 - DL240 - DS401
DS412
for Dishwasher (WHIRLPOOL) F360 - F650
for Dishwasher hood type (WHIRLPOOL) F1000
F1201A
for Glasswasher/Cupwasher (ADLER) CF35 - CF40
COMPACT
for Glasswasher/Cupwasher (WHIRLPOOL) F30 - F35
F40 - F400 - F41 - F410



ADLER 12013

1186803

O-RING 02037 EPDM

for Dishwasher (ADLER) DS400 - DS410
for Dishwasher (BONNET) INO3F
for Dishwasher (COMENDA) F20 - F45 - F50 - F55
F65 - F80
for Dishwasher (WHIRLPOOL) F360 - F650
for Dishwasher (ZANUSSI) LS32 - LS360 - LS365
for Dishwasher hood type (WHIRLPOOL) F1000
F1201A
for Glasswasher/Cupwasher (ADLER) CF35 - CF40
for Glasswasher/Cupwasher (COMENDA) B10 - B15
B15T - B20
for Glasswasher/Cupwasher (ELETTROBAR) E35 - E40
MISTRAL40 - NIAGARA35
for Glasswasher/Cupwasher (HOONVED) CR43 - CR48
C35 - C43 - C43E - C46E - C48



ADLER 60060

1186223

O-RING 02056 EPDM

for Dishwasher (ADLER) CF50 - DS400 - DS410
DS600
for Dishwasher (WHIRLPOOL) F360 - F650
for Dishwasher hood type (ADLER) CF1000 - CF1201A
DS1200
for Dishwasher hood type (WHIRLPOOL) F1000
F1201A
for Glasswasher/Cupwasher (ADLER) CF35 - CF40
for Glasswasher/Cupwasher (WHIRLPOOL) F30 - F35
F40 - F400 - F41 - F410



ADLER 60072

3501140

RINSE JET ø 13 mm

for Dishwasher (ADLER) CF50 - DS400 - DS410
DS600
for Dishwasher (WHIRLPOOL) F360 - F650
for Dishwasher hood type (ADLER) CF1000 - CF1201A
DS1200
for Dishwasher hood type (WHIRLPOOL) F1000
F1201A
for Glasswasher/Cupwasher (ADLER) CF35 - CF40
COMPACT
for Glasswasher/Cupwasher (WHIRLPOOL) F30 - F35
F40 - F400 - F41 - F410



ADLER 12014



Suitable for:

3501139 RINSE JET DEFLECTOR

for Dishwasher (ADLER) DS400
 for Dishwasher (SILANOS) DS410
 for Dishwasher (WHIRLPOOL) F360 - F650
 for Dishwasher hood type (WHIRLPOOL) F1000
 F1201A
 for Glasswasher/Cupwasher (ADLER) COMPACT
 for Glasswasher/Cupwasher (SILANOS) CF35 - CF40
 for Glasswasher/Cupwasher (WHIRLPOOL) F30 - F35
 F40 - F400 - F41 - F410



ADLER 12015

3743256 RINSE ROD

without jets
 for Glasswasher/Cupwasher (ADLER) B101



ADLER 10216

3743116 TOP IMPELLER SUPPORT

for Dishwasher (ADLER) DS600
 for Dishwasher (WHIRLPOOL) F650
 for Glasswasher/Cupwasher (WHIRLPOOL) F400 - F410



ADLER 12007

ADLER



Suitable for:

3743315 RINSE ROD

for Dishwasher (ADLER) D111
 for Glasswasher/Cupwasher (ADLER) B100 - B101
 B102 - B103 - DS101 - DS103 - DS11 - DS13
 for Glasswasher/Cupwasher (WHIRLPOOL) D110



ADLER 10205

3186290 O-RING 04187 EPDM

for Dishwasher (ADLER) A350 - A500 - A720 - B300
 DS400 - DS410
 for Dishwasher (WHIRLPOOL) F360 - F650
 for Dishwasher hood type (FAGOR) FI-100 - FI-120
 FI-80
 for Dishwasher hood type (LASA) LC50 - LC65
 for Dishwasher hood type (MARENO) MLC50 - MLC65
 for Dishwasher hood type (WHIRLPOOL) F1000
 F1201A
 for Glasswasher/Cupwasher (ADLER) CF35 - CF40
 for Glasswasher/Cupwasher (ELETTROBAR) E35 - E40
 E40H - NIAGARA40
 for Glasswasher/Cupwasher (WHIRLPOOL) F30 - F35
 F40 - F400 - F41 - F410



ADLER 60076



Suitable for:

ADLER



Suitable for:

3743678 TOP WASH COUPLING PIPE

ø internal 34 mm length 90 mm
for Dishwasher hood type (ADLER) CF1000 - CF1201A
DS1200
for Dishwasher hood type (WHIRLPOOL) F1000
F1201A



ADLER 15587

3743042 UPPER IMPELLER SUPPORT ASSY

for Dishwasher (ADLER) CF50
for Dishwasher (WHIRLPOOL) F360
for Dishwasher hood type (ADLER) CF1000
for Dishwasher hood type (WHIRLPOOL) F1201
for Glasswasher/Cupwasher (ADLER) CF40
for Glasswasher/Cupwasher (WHIRLPOOL) F41



ADLER 15030

ADLER 15030/V

3186290 O-RING 04187 EPDM

for Dishwasher (ADLER) A350 - A500 - A720 - B300
DS400 - DS410
for Dishwasher (WHIRLPOOL) F360 - F650
for Dishwasher hood type (FAGOR) FI-100 - FI-120
FI-80
for Dishwasher hood type (LASA) LC50 - LC65
for Dishwasher hood type (MARENO) MLC50 - MLC65
for Dishwasher hood type (WHIRLPOOL) F1000
F1201A
for Glasswasher/Cupwasher (ADLER) CF35 - CF40
for Glasswasher/Cupwasher (ELETTRORBAR) E35 - E40
E40H - NIAGARA40
for Glasswasher/Cupwasher (WHIRLPOOL) F30 - F35
F40 - F400 - F41 - F410



ADLER 60076

3743254 WASH - RINSE ARM ASSEMBLY BOSS

for Dishwasher (ADLER) CF50 - DS401 - DS412
DS600
for Dishwasher (WHIRLPOOL) F360 - F650
for Dishwasher hood type (ADLER) CF1000 - CF1201A
DS1200
for Dishwasher hood type (WHIRLPOOL) F1000
F1201A
for Glasswasher/Cupwasher (ADLER) CF35 - CF40
for Glasswasher/Cupwasher (WHIRLPOOL) F30 - F35
F40 - F400 - F41 - F410



ADLER 12009

3743251 WASH ARM ASSEMBLY

length 510 mm - without jets
for Dishwasher (ADLER) A500
for Dishwasher hood type (ADLER) A1080



ADLER 10259



Suitable for:

ADLER



3743122 WASH ARM ASSEMBLY END CAP
for Dishwasher hood type (ADLER) A1080 - A900



ADLER 10579

3186181 O-RING 03068 EPDM
for Dishwasher (SO.WE.BO.) 601 - 701 - 752
for Dishwasher (SOTAL) ER225
for Glasswasher/Cupwasher (AFI) A35 - A35Z2 - A36
for Glasswasher/Cupwasher (COMENDA) - Series B
for Glasswasher/Cupwasher (EUROSYSTEM) PRO100
PRO200
for Glasswasher/Cupwasher (HILTA) RB10 - RB22
SB10 - SB22
for Glasswasher/Cupwasher (IME OMNIWASH) DUE
JA35 - JA36 - JA40 - JA41 - JOLLY - UNO
for Glasswasher/Cupwasher (NOSEM) C2010L - C4010L
NC201 - NR101 - R1010
for Glasswasher/Cupwasher (NUOVA SIMONELLI) KIARA1
KIARA2 - KIARA4
for Glasswasher/Cupwasher (SAB ITALIA) C35 - C36



ADLER 60052

3743683 WASH ARM 220 mm
with jets
for Dishwasher (ADLER) CF50 - DS600
for Dishwasher (WHIRLPOOL) F360 - F650
for Dishwasher hood type (ADLER) CF1000 - CF1201A
DS1200
for Dishwasher hood type (WHIRLPOOL) F1000
F1201A



ADLER 12016

3743321 WASH ARM 375 mm
for Dishwasher (WHIRLPOOL) DS110 - DS111 - DS210
DS211
for Glasswasher/Cupwasher (ADLER) B100 - B101
B102 - B103 - B201 - B203 - DS101 - DS103
DS11 - DS13 - DS201 - DS203 - DS21 - DS23



ADLER 10243

3743253 WASHING UPPER ROD WITHOUT JETS
for Glasswasher/Cupwasher (ADLER) B100 - B101
B102 - B103 - DS101 - DS103



ADLER 10210



Suitable for:

ADLER



Suitable for:

Wash jets and accessories

3501092 COMPLETE RINSE JET
 for Dishwasher (ADLER) B300
 for Glasswasher/Cupwasher (ADLER) B100 - B101
 B200 - DS101 - DS103 - DS201 - DS203
 for Glasswasher/Cupwasher (WHIRLPOOL) D110 - D111
 D210 - D211 - D310 - D311



ADLER 10381
ADLER 11362

ADLER 10381+10382+60002

ADLER 10382

3501206 COMPLETE TOP WASH JET
 thread \varnothing 16 mm
 for Dishwasher (ADLER) A320 - A350



ADLER 10398

3501090 COMPLETE WASH JET
 for Glasswasher/Cupwasher (ADLER) B100 - B200
 DS101 - DS103 - DS201 - DS203
 for Glasswasher/Cupwasher (WHIRLPOOL) D110 - D111
 D210 - D211



ADLER 10383

ADLER 10383+10384

3501091 COMPLETE WASH JET
 for Dishwasher (ADLER) B300



ADLER 10385

3501093 COMPLETE WASH JET
 for Dishwasher (ADLER) B40 - B41
 for Glasswasher/Cupwasher (ADLER) B101F - B103F



ADLER 11410

3501097 COMPLETE WASH JET
 for Dishwasher (ADLER) A350
 for Dishwasher hood type (ADLER) A1080



ADLER 10391

ADLER 10394+10400

ADLER 10400+10394

3501099 EXTERNAL RINSE JET
 for Dishwasher (LAMBER)
 till 31/12/96
 01F - 040F - 045F - 050F - 075F
 for Dishwasher hood type (LAMBER)
 till 31/12/96
 L25 - 015/24L
 for Glasswasher/Cupwasher (LAMBER)
 till 31/12/96
 GS4 - GS5 - MINIBAR - SUPERQS - S200 - S240 - S280
 S510



ADLER 10388

3501098 INTERNAL RINSE JET



ADLER 10387



Suitable for:

Suitable for:

3501095 RINSE JET
 for Glasswasher/Cupwasher (ADLER) DSF101 - DSF103
 for Glasswasher/Cupwasher (WHIRLPOOL) F300 - F312

3501096 RINSE JET FOR FIXED ARMS



ADLER 10603

ADLER 10389

3501094 WASH JET DEFLECTOR
 for Dishwasher (ADLER) B40 - B41
 for Glasswasher/Cupwasher (ADLER) B101F - B103F




ADLER 10384

Washing baskets and accessories

3055228 GLASS RACK \varnothing 345x345x120 mm
 in plastic covered iron
 for Glasswasher/Cupwasher (ELFRAMO) BD11 - SQ42

3055229 GLASS RACK \varnothing 355x140 mm
 in plastic covered wire
 upper \varnothing 355 mm
 lower \varnothing 280 mm
 for Glasswasher/Cupwasher (RANCILIO) LS10 - LS11
 LS5 - Series LT



ADLER 30087

ADLER 30002

3055081 GLASS RACK \varnothing 455/390x170 mm
 in plastic covered wire
 upper \varnothing 455 mm
 lower \varnothing 390 mm
 height 170 mm

3055238 GLASS RACK 400x400x135 mm
 in plastic covered wire



ADLER 30008

ADLER 3008

ADLER 30012



ADLER



Suitable for:

3055083 ROTATING RACK SUPPORT \varnothing 292x65 mm
for basket with bottom \varnothing 280 mm
for Glasswasher/Cupwasher (ADLER) DS101 - DS103
DS201 - DS203
for Glasswasher/Cupwasher (WHIRLPOOL) D110 - D111
D210 - D211



ADLER 10454

3055105 ROTATING SUPPORT SPINDLE \varnothing 15x118 mm
overall height 118 mm
with bearings



Suitable for:

3055085 ROTATING SUPPORT SPINDLE \varnothing 15x113 mm
total height 113 mm
with bearings



ADLER 10406

3055299 ROTATING SUPPORT PIN \varnothing 32x148 mm
total height 148 mm
with bearing



ADLER 10407