



Spare parts for the professional sector: Coffee grinders



Suitable for:

BEZZERA




This catalogue is automatically generated.
Therefore, the sequence of the items might
not be always shown at best.
Updates will be issued in case of additions
and/or amendments.

Suitable universal spare parts may not be included





GRINDER ASSEMBLY BB105





BEZZERA




Position	LF code no.	Description
1	1252304	COFFEE HOPPER LID ø 185 mm
2	1252379	COFFEE HOPPER INNER PROTECTION
3	1080075	COFFEE HOPPER
4	1388501	COVER LOCK
7	1252285	GRINDING BURRS TOP HOLDER W/RING NUT
9	1251061	GRINDING BURRS OBEL-CARIMALI (PAIR) LEFT
9	1251702	GRINDING BURRS (PAIR) OBEL LH
10	1528001	COUNTERSUNK FLAT HEAD SCREWS M4x10
11	1186695	SCREW COVER RING NUT ø 126 mm
12	3060069	HEXAGONAL NUT M8 MEDIUM
13	1251113	GRINDING BURRS BOTTOM HOLDER
14	1252281	LOCKING PIN
15	1250265	LOCKING PIN SPRING
16	1528023	COUNTERSUNK FLAT HEAD SCREWS M5x16
19	3068019	CAPACITOR DUCATI ENERGIA 12,5µF
22	3060054	HEXAGONAL NUT M10 MEDIUM
23	1528023	COUNTERSUNK FLAT HEAD SCREWS M5x16
28	1252286	FILTER HOLDER FORK
34	1313106	RUBBER FOOT
35	1528001	COUNTERSUNK FLAT HEAD SCREWS M4x10
38	3319934	BIPOLEAR SWITCH ORANGE 16A 250V
43	1252283	DOSER LID
45	1090019	DOSER CYLINDER ø 120x117 mm
47	1240802	MICROSWITCH 6A 250V
50	1252280	DOSE ADJUSTMENT KNOB
51	1250266	DOSER SCRAPER
52	1343939	TOP STAR
53	1252282	DOSER SHEET
54	1343940	MIDDLE STAR
55	1250260	STAR SPRING
57	1343941	BOTTOM STAR
60	1528630	HEXAGON HEAD SCREW M5x10
61	1252278	COUNTER FOR COFFEE GRINDER
63	1250261	STROKE COUNTER SPRING
64	1252436	PIN FOR DOSER LEVER SPRING
65	1250267	PEG SPRING
66	1252437	6-TEETH PAWL
69	1250174	SHEET SPRING 89 mm
72	1252291	DOSER LEVER
73	1252292	LEVER COVER
74	1528630	HEXAGON HEAD SCREW M5x10
75	1250263	DOSER LEVER RETURN SPRING
79	1324206	COFFEE TAMPER PIN
81	1250264	ROD SPRING
87	1528630	HEXAGON HEAD SCREW M5x10
100	1385506	COFFEE TAMPER COMPLETE
101	1385507	COFFEE TAMPER COMPLETE
102	1090512	COMPLETE DISPENSER



GRINDER ASSEMBLY BB95

BB95



BEMC02




BEZZERA



Position	LF code no.	Description
1	1252304	COFFEE HOPPER LID ø 185 mm
2	1252295	COFFEE HOPPER INNER PROTECTION
2	1252379	COFFEE HOPPER INNER PROTECTION
4	1252301	COFFEE HOPPER LID
5	1080938	COFFEE HOPPER 250 gr
7	1528023	COUNTERSUNK FLAT HEAD SCREWS M5x16
9	1252299	FILTER HOLDER FORK
14	1528001	COUNTERSUNK FLAT HEAD SCREWS M4x10
15	1313106	RUBBER FOOT
19	1251062	GRINDING BURRS OBEL (PAIR) LEFT
20	3528291	CROSS HEAD FLUSH SCREW M4x8
24	1251063	GRINDING BURRS BOTTOM HOLDER
25	1324941	LOCKING PIN
31	3068010	CAPACITOR DUCATI ENERGIA 6,3µF
32	1090020	DOSER LID ø 58 mm
34	1252279	DOSER LID
35	1252276	DOSER CYLINDER
36	1252280	DOSE ADJUSTMENT KNOB
40	1250260	STAR SPRING
43	1250175	SHEET SPRING
45	1528630	HEXAGON HEAD SCREW M5x10
48	1252303	PAWL GEAR 6 TEETH
49	3060069	HEXAGONAL NUT M8 MEDIUM
53	1252297	LEVER COVER
54	1250263	DOSER LEVER RETURN SPRING



GRINDER ASSEMBLY BB90





BEZZERA




Position	LF code no.	Description
1	1252304	COFFEE HOPPER LID ø 185 mm
2	1252295	COFFEE HOPPER INNER PROTECTION
2	1252379	COFFEE HOPPER INNER PROTECTION
3	1080075	COFFEE HOPPER
6	1388501	COVER LOCK
7	1252285	GRINDING BURRS TOP HOLDER W/RING NUT
9	1251061	GRINDING BURRS OBEL-CARIMALI (PAIR) LEFT
9	1251702	GRINDING BURRS (PAIR) OBEL LH
10	1528001	COUNTERSUNK FLAT HEAD SCREWS M4x10
11	1186695	SCREW COVER RING NUT ø 126 mm
13	1251113	GRINDING BURRS BOTTOM HOLDER
14	1252281	LOCKING PIN
15	1250265	LOCKING PIN SPRING
16	1528023	COUNTERSUNK FLAT HEAD SCREWS M5x16
21	3068019	CAPACITOR DUCATI ENERGIA 12,5µF
23	1252283	DOSER LID
24	1252284	DOSER LID WITH KEY
25	1090019	DOSER CYLINDER ø 120x117 mm
27	1240802	MICROSWITCH 6A 250V
30	1252280	DOSE ADJUSTMENT KNOB
31	1250266	DOSER SCRAPER
32	1343939	TOP STAR
33	1252282	DOSER SHEET
34	1343940	MIDDLE STAR
35	1250260	STAR SPRING
37	1343941	BOTTOM STAR
40	1528630	HEXAGON HEAD SCREW M5x10
41	1252278	COUNTER FOR COFFEE GRINDER
43	1250261	STROKE COUNTER SPRING
44	1252436	PIN FOR DOSER LEVER SPRING
45	1250267	PEG SPRING
46	1252291	DOSER LEVER
47	1252292	LEVER COVER
49	1250263	DOSER LEVER RETURN SPRING
50	1528630	HEXAGON HEAD SCREW M5x10
52	1240802	MICROSWITCH 6A 250V
53	1252437	6-TEETH PAWL
56	1250174	SHEET SPRING 89 mm
58	1528630	HEXAGON HEAD SCREW M5x10
59	1252286	FILTER HOLDER FORK
61	1324206	COFFEE TAMPER PIN
63	1250264	ROD SPRING
69	1528630	HEXAGON HEAD SCREW M5x10
71	3319934	BIPOLAR SWITCH ORANGE 16A 250V
72	9014063	GREEN SINGLE-POLE PUSH-BUTTON 0.7A 250V
73	9014062	RED SINGLE-POLE PUSH-BUTTON 0.7A 250V
74	1252004	FILTER HOLDER FORK
75	1252277	COFFEE COLLECTION TRAY
76	1313106	RUBBER FOOT
77	1528001	COUNTERSUNK FLAT HEAD SCREWS M4x10
79	1351508	RELAY 10A 230V
100	1385506	COFFEE TAMPER COMPLETE
101	1385507	COFFEE TAMPER COMPLETE
102	1090512	COMPLETE DISPENSER



GRINDER ASSEMBLY BB004

BB004



BEMC04

Positions without LF code no.: upon request



BEZZERA




Position	LF code no.	Description
1	1252301	COFFEE HOPPER LID
2	1252379	COFFEE HOPPER INNER PROTECTION
4	1080938	COFFEE HOPPER 250 gr
6	1251062	GRINDING BURRS OBEL (PAIR) LEFT
7	3528291	CROSS HEAD FLUSH SCREW M4x8
14	1251063	GRINDING BURRS BOTTOM HOLDER
15	1324941	LOCKING PIN
27	3060069	HEXAGONAL NUT M8 MEDIUM
33	3068010	CAPACITOR DUCATI ENERGIA 6,3µF
38	1252279	DOSER LID
40	1252280	DOSE ADJUSTMENT KNOB
44	1250260	STAR SPRING
48	1250175	SHEET SPRING
50	1528630	HEXAGON HEAD SCREW M5x10
54	3060069	HEXAGONAL NUT M8 MEDIUM
60	1250263	DOSER LEVER RETURN SPRING



GRINDER ASSEMBLY BB003

BB003



BEMC05

Positions without LF code no.: upon request



BEZZERA




Position	LF code no.	Description
1	1252304	COFFEE HOPPER LID ø 185 mm
2	1252379	COFFEE HOPPER INNER PROTECTION
3	1080075	COFFEE HOPPER
4	1252285	GRINDING BURRS TOP HOLDER W/RING NUT
6	1251061	GRINDING BURRS OBEL-CARIMALI (PAIR) LEFT
6	1251702	GRINDING BURRS (PAIR) OBEL LH
7	1528001	COUNTERSUNK FLAT HEAD SCREWS M4x10
8	1186695	SCREW COVER RING NUT ø 126 mm
14	3319934	BIPOLAR SWITCH ORANGE 16A 250V
15	3060069	HEXAGONAL NUT M8 MEDIUM
16	1251113	GRINDING BURRS BOTTOM HOLDER
17	1252281	LOCKING PIN
18	1250265	LOCKING PIN SPRING
19	3068010	CAPACITOR DUCATI ENERGIA 6,3µF
26	1351508	RELAY 10A 230V
30	1313106	RUBBER FOOT
31	1528001	COUNTERSUNK FLAT HEAD SCREWS M4x10
39	1388501	COVER LOCK
43	1252283	DOSER LID
44	1090019	DOSER CYLINDER ø 120x117 mm
46	1240802	MICROSWITCH 6A 250V
49	1252280	DOSE ADJUSTMENT KNOB
50	1250266	DOSER SCRAPER
51	1343939	TOP STAR
52	1252282	DOSER SHEET
53	1343940	MIDDLE STAR
54	1250260	STAR SPRING
56	1343941	BOTTOM STAR
58	1252278	COUNTER FOR COFFEE GRINDER
59	1252436	PIN FOR DOSER LEVER SPRING
60	1250267	PEG SPRING
61	1252437	6-TEETH PAWL
63	1250174	SHEET SPRING 89 mm
66	1240802	MICROSWITCH 6A 250V
68	1252291	DOSER LEVER
69	1528630	HEXAGON HEAD SCREW M5x10
70	1250263	DOSER LEVER RETURN SPRING
71	1250261	STROKE COUNTER SPRING
74	1324206	COFFEE TAMPER PIN
75	1250264	ROD SPRING
76	1528630	HEXAGON HEAD SCREW M5x10



GRINDER ASSEMBLY BB012

BB012



Positions without LF code no.: upon request



BEZZERA



Position	LF code no.	Description
2	1252258	LID WITH POINTER
3	1240283	MICROSWITCH CROUZET EF83161.3
4	1252331	SUPPORT FOR MICROSWITCH
5	1252105	DOSER CYLINDER
6	1241070	DOSE ADJUSTMENT KNOB
7	1343025	TOP STAR
8	1343015	DOSE ADJUSTMENT STAR
9	1343016	DOSE CONVEYING STAR
10	1343024	STAR ASSEMBLY
11	1252196	DOSER SHEET
12	1250091	DISPENSER STAR SPRING
14	1252308	COUNTER FOR COFFEE GRINDER
16	1252343	DOSER LEVER
17	1252364	PAWL COFFEE GRINDER/DOSER
18	1252109	DISPENSER LOWER LID
19	1252108	DOSER LEVER KNOB
23	1252195	COFFEE HOPPER CLOSING SHEET
32	3319012	BIPOLAR SWITCH GREEN 16A 250V
36	1251029	GRINDING BURRS TURNING HOLDER
37	1251032	GRINDING BURRS CIMBALI (PAIR) RIGHT
45	1252345	ADJUSTMENT RING NUT
57	1186614	GASKET FOR COFFEE OUTLET OPENING
62	1251047	GRINDING BURRS PAIR CIMBALI RH
63	1252107	STROKE COUNTER SHAFT



Suitable for:

BEZZERA



Suitable for:

Adjustement rings for coffee grinder

1252345 ADJUSTMENT RING NUT



BEZZERA 0M0604005

Bodies

1186695 SCREW COVER RING NUT \varnothing 126 mm



BEZZERA 0BEB085

Brushes

1384023 BRUSH FOR CLEANING 50 mm



BEZZERA

1384001 BRUSH FOR COFFEE SHOWER



BEZZERA 7990603

1384002 BRUSH FOR MAINTENANCE



BEZZERA

1384014 BRUSH FOR SHOWER RED



BEZZERA

Capacitors, electrical

3068019 CAPACITOR DUCATI ENERGIA 12,5 μ F
450V 50/60Hz
operating temperature -25 + 85°C
lead connection 6.35x0.8 mm
 \varnothing 36xh70 mm



BEZZERA 0BEB075220



Coffee measuring spoons

1069001 PLASTIC MEASURING SPOON 20 ml



BEZZERA 5372101

1069002 STAINLESS STEEL MEASURING SPOON 20 ml



BEZZERA

Containers for coffee

1080042 COFFEE HOPPER



BEZZERA 0M0602007

1252195 COFFEE HOPPER CLOSING SHEET



BEZZERA 0M0602006

1252295 COFFEE HOPPER INNER PROTECTION



BEZZERA 0BEB04

1252379 COFFEE HOPPER INNER PROTECTION




BEZZERA 0BEB04C

1252190 COFFEE HOPPER LID




BEZZERA 0M0602002

1252301 COFFEE HOPPER LID



BEZZERA 0BDF1

1252304 COFFEE HOPPER LID ø 185 mm



BEZZERA 0BEB01

1080938 COFFEE HOPPER 250 gr



BEZZERA 0BDF2

BEZZERA 0BDF2

Counters

1252278 COUNTER FOR COFFEE GRINDER



BEZZERA 0BEB054

1252308 COUNTER FOR COFFEE GRINDER



BEZZERA 0M0603004



Suitable for:

BEZZERA



Suitable for:

Detergents

- 1092213 DETERGENT GRIND CLEANER 340 g**
 detergent for grinders cleaning
 natural grain-based ingredients
 100% biological
 please see the attached documentation for use



BEZZERA


Dosers for coffee

- 1090512 COMPLETE DISPENSER**



BEZZERA

- 1252109 DISPENSER LOWER LID**



BEZZERA 0M0603011

- 1252105 DOSER CYLINDER**




BEZZERA 0M0603001

- 1252276 DOSER CYLINDER**



BEZZERA 0BDF44

- 1090019 DOSER CYLINDER ø 120x117 mm**




BEZZERA 0BEB094

- 1252198 DOSER LID**



BEZZERA 0M0603008

- 1252279 DOSER LID**



BEZZERA 0BDF51M

- 1252283 DOSER LID**



BEZZERA 0BEB051



BEZZERA



Suitable for:

1090020 DOSER LID \varnothing 58 mm



BEZZERA 0BDF51

Suitable for:

1252284 DOSER LID WITH KEY



BEZZERA


1250266 DOSER SCRAPER



BEZZERA 0BEB050

Feet

1313106 RUBBER FOOT



BEZZERA 0BEB019

Forks for portafilter coffee grinder

1252004 FILTER HOLDER FORK



BEZZERA 0BEB033

1252286 FILTER HOLDER FORK



BEZZERA 0BEB033S

1252299 FILTER HOLDER FORK



BEZZERA 0BDF33

Gaskets and seals

1186614 GASKET FOR COFFEE OUTLET OPENING



BEZZERA 0M0301001



Suitable for:

BEZZERA



Suitable for:

Grinders

1251702 GRINDING BURRS (PAIR) OBEL LH
 GRIND BURRS "HEAVY DUTY" +70% longer life cycle compared to a standard grinding burr they do not deform less contamination of milled coffee
 ø external 63.5 mm - ø internal 37.5 mm
 thickness 9 mm - 3 fixing holes



BEZZERA

1251032 GRINDING BURRS CIMBALI (PAIR) RIGHT
 external ø 64 mm - internal ø 37 mm
 thickness 9 mm - 3 fixing holes



BEZZERA OM1501001

1251062 GRINDING BURRS OBEL (PAIR) LEFT
 external ø 50 mm - internal ø 30 mm
 thickness 8 mm - 3 fixing holes



BEZZERA OBDF8

1251061 GRINDING BURRS OBEL-CARIMALI (PAIR) LEFT
 external ø 64 mm - internal ø 38 mm
 thickness 9 mm - 3 mounting holes



BEZZERA OBEB08

1251047 GRINDING BURRS PAIR CIMBALI RH
 external ø 64 mm - internal ø 38 mm
 thickness 9 mm - 3 mounting holes



BEZZERA OM1501002

Grinding burr holders

1251063 GRINDING BURRS BOTTOM HOLDER




BEZZERA OBDF90

1251113 GRINDING BURRS BOTTOM HOLDER



BEZZERA OBEB090

1252285 GRINDING BURRS TOP HOLDER W/RING NUT



BEZZERA OBEB053

1251029 GRINDING BURRS TURNING HOLDER



BEZZERA OM0802002

BEZZERA OM0802005



Indicator lights

1221006 GREEN INDICATOR LAMP 250V
head \varnothing 14 mm - hole \varnothing 12 mm - 75°C



BEZZERA 7633608

BEZZERA 7633610

Ironmongery (screws,nuts,washers)

1528023 COUNTERSUNK FLAT HEAD SCREWS M5x16
cross recessed - stainless steel
UNI 7688 - DIN 965 - ISO 7046



BEZZERA 0BMQ40

BEZZERA 7817001

1528501 COUNTERSUNK HEAD SCREWS WITH SHELL M5x12
cross recessed - stainless steel
UNI 7689 - DIN 966 - ISO 7047



BEZZERA 7817007

1528049 CYLINDER HEAD SCREW M4x16
stainless steel - with hexagon socket
UNI 5931 - DIN 912 - ISO 4762



BEZZERA 7816004

1528630 HEXAGON HEAD SCREW M5x10
stainless steel - UNI 5739 - DIN 933 - ISO 4017



BEZZERA 0BMQ37

BEZZERA 0BMQ37CE

BEZZERA 0BMQ37E

1348813 HEXAGONAL NUT M4 MEDIUM
stainless steel - UNI 5588 - DIN 934 - ISO 4032



BEZZERA 7812601

Knobs

1241070 DOSE ADJUSTMENT KNOB



BEZZERA 0M1603002

1252280 DOSE ADJUSTMENT KNOB



BEZZERA 0BDF48

BEZZERA 0BEB048



Suitable for:

BEZZERA



Suitable for:

Levers

1252291 DOSER LEVER



BEZZERA 08EB029P

1252343 DOSER LEVER



BEZZERA 0M1603005

1252108 DOSER LEVER KNOB



BEZZERA 0M1001001

1252292 LEVER COVER



BEZZERA 08EB029A

1252297 LEVER COVER



BEZZERA 0BDF28

Locks

1388501 COVER LOCK



BEZZERA 08EB8

Microswitches, mechanical

1252258 LID WITH POINTER



BEZZERA 0M0603006

1240283 MICROSWITCH CROUZET EF83161.3
1NO+1NC 16A 250V - faston 6.3x0.8 mm
standard
operating force max 0.8N - min 0.2N



BEZZERA 0M1205004



Suitable for:

1240802 MICROSWITCH 6A 250V
contacts normally closed



BEZZERA 0BEB066MAC

Suitable for:

1252331 SUPPORT FOR MICROSWITCH



BEZZERA 0M1603001

Pawls for coffee grinder dosers

1252364 PAWL COFFEE GRINDER/DOSER



BEZZERA 0M1101003

1252303 PAWL GEAR 6 TEETH



BEZZERA 0BDF92

1252437 6-TEETH PAWL



BEZZERA 0BEB092

Pins

1252281 LOCKING PIN



BEZZERA 0BEB06

1324941 LOCKING PIN



BEZZERA 0BDF6

1252436 PIN FOR DOSER LEVER SPRING



BEZZERA 0BEB056



Suitable for:

BEZZERA



Suitable for:

Relays

1351508 RELAY 10A 230V



BEZZERA 08EB073

Springs

1250091 DISPENSER STAR SPRING



BEZZERA 0M0204004

1250263 DOSER LEVER RETURN SPRING

for BEZZERA BB105-BB95-BB90-BB004-BB003
for CARIMALI G1-GT-M JUNIOR-M1/M3
for OBEL JUNIOR-DSQ-EB-GLOBO "G"
for PAVONI ZIP
for SPAZIALE JUNIOR
for RENEKA B14




BEZZERA 08EB055

1250265 LOCKING PIN SPRING




BEZZERA 08EB05

1250267 PEG SPRING



BEZZERA 08EB057

1250264 ROD SPRING



BEZZERA 08EB041

1250175 SHEET SPRING



BEZZERA 08DF70

1250174 SHEET SPRING 89 mm



BEZZERA 08EB070

1250260 STAR SPRING

for BEZZERA BB105-BB95-BB90-BB004-BB003
for CARIMALI G1-GT-M JUNIOR-M1/M3
for OBEL JUNIOR-DSQ-EB-GLOBO "G"
for PAVONI ZIP
for SPAZIALE JUNIOR
for RENEKA B14



BEZZERA 08DF61

BEZZERA 08EB061



Suitable for:

1252107 STROKE COUNTER SHAFT



BEZZERA 0M0204003

Suitable for:

1250261 STROKE COUNTER SPRING



BEZZERA 0BEB028


Stars and spare parts

1343941 BOTTOM STAR




BEZZERA 0BEB062

1343015 DOSE ADJUSTMENT STAR



BEZZERA 0M0604001

1343016 DOSE CONVEYING STAR



BEZZERA 0M0604002

1252196 DOSER SHEET



BEZZERA 0M0903001

1252282 DOSER SHEET



BEZZERA 0BEB060

1343940 MIDDLE STAR



BEZZERA 0BEB059

1343024 STAR ASSEMBLY



BEZZERA 0M1606003

1343025 TOP STAR



BEZZERA 0M1603003

1343939 TOP STAR



BEZZERA 0BEB042



Suitable for:

BEZZERA



Suitable for:

Switches

3319012 BIPOLAR SWITCH GREEN 16A 250V
16(4)A 250V - max. temperature 120°C
with indicator lamp and push-button cap
mounting hole 22x30 mm - silk screen print 0 - I



BEZZERA 7633339

3319029 BIPOLAR SWITCH GREEN 16A 250V
16(4)A 250V - max. temperature 120°C
with indicator lamp - mounting hole 22x30 mm



BEZZERA 7633309

3319934 BIPOLAR SWITCH ORANGE 16A 250V
16(4)A 250V - max. temperature 120°C
with indicator lamp - silk screen printing 0 - I
mounting hole 22x30 mm



BEZZERA 08EB079

BEZZERA 08EB079T

BEZZERA 7633308.01

3319294 BLACK BIPOLAR SWITCH 16A 250V
16(4)A 250V - with red led indicator light
mounting hole 22x30 mm



BEZZERA 7633313

3319035 ORANGE BIPOLAR SWITCH 16A 250V
16(4)A 250V - with indicator lamp
max temperature 120°C
mounting hole 22x30 mm



BEZZERA 7633308

9014062 RED SINGLE-POLE PUSH-BUTTON 0.7A 250V
1 normally closed contact
head ø 19 mm - mounting hole ø 15 mm



BEZZERA 7635102

Tampers for coffee

1385506 COFFEE TAMPER COMPLETE



BEZZERA

1385507 COFFEE TAMPER COMPLETE



BEZZERA

1324206 COFFEE TAMPER PIN



BEZZERA 08EB045



Suitable for:


BEZZERA

Suitable for:



Trays

1252277 COFFEE COLLECTION TRAY



BEZZERA 08EB022

The data herewith contained may change without notice and LF SpA cannot be held responsible for possible errors stated or resulting by the use of this document. All rights reserved. No part of this publication may be reproduced without written permission by LF SpA.



Distributing Components, Spare Parts & Accessories in original quality worldwide

-
- LF SpA HEADQUARTERS**
via Voltri, 80 - 47522 Cesena (FC) ITALY
Tel. +39 0547 34 11 11 - Fax +39 0547 34 11 10
www.lfircambi724.it - info@lfircambi.it
Export Dept. Tel. +39 0547 34 11 50 - Fax +39 0547 34 11 55
www.lfspareparts724.com - export@lfspareparts.com
- LF SpA HOUSEHOLD COMPONENTS DIVISION**
Via Padriciano, 99 - AREA Science Park - 34149 Trieste (TS) ITALY
Tel. +39 0547 34 12 42 - Fax +39 0547 34 12 48
www.lfspareparts724.com - info@lfspareparts.com
- EPGC Sas FRANCE**
13, Rue des Forts - 59960 Neuville en Ferrain
Tel. +33 (0)3 20 25 06 21 - Fax +33 (0)3 20 25 34 12
www.epgc.com - epgc@epgc.com
- LF GmbH GERMANY**
Junkersstrasse, 3 - D-82178 Puchheim - München
Tel. +49 89 89 45 78 66 - Fax +49 89 89 45 78 88
www.lfersatzteile724.de - info@lfersatzteile.de
- LF China REPUBLIC OF CHINA**
Room 403, No.2, Huadu Mansion, Lane 422, Huanghua Rd.
Minhang Dist. - 201103 Shanghai
Tel. +86 (0)21 33 53 66 31 - Fax +86 (0)21 33 53 66 32
www.lfspareparts724.com - china@lfspareparts.com
- OOO LF RUSSIAN FEDERATION**
Ul. Anatoliya Zhivova, 8 - office 1 - 123100 Moscow
Tel./Fax +7 495 725 26 53
www.lfspareparts724.ru - info@lfspareparts.ru
- LF Repuestos Horeca S.L.U. SPAIN**
Poligono Industrial Carpetania - C/Miguel Faraday, 8 - 28906 Getafe
Tel. +34 91 477 91 00 - Fax +34 91 477 90 81
www.lfrepuestos-horeca724.es - info@lfrepuestos.es
- LF Scandinavia Aps - LF Spareparts S.p.A. DENMARK**
Nupark, 51 - 7500 Holstebro
Tel. +45 70 70 77 33
www.lfspareparts724.dk - denmark@lfspareparts.dk
- LF SpA Cesena (IT) Swiss Branch Steinhausen SWITZERLAND**
Sennweidstrasse, 45 - CH-6312 Steinhausen
Tel. +41 (0)41 760 15 80/1 - Fax +41 (0)41 760 15 85
www.lfersatzteile724.ch - info@lfersatzteile.ch
- LF Spare Parts Ltd. UNITED KINGDOM**
A10a Lakeside Business Park, Broadway Lane
South Cerney, Gloucestershire GL7 5XL
Tel. +44 (0)1285 86 16 25 - Fax +44 (0)1285 86 39 49
www.lfspareparts724.co.uk - info@lfspareparts.co.uk
- LF Central Est Europe S.r.o. CZECH REPUBLIC**
Antala Staska 1859/34
14000 Praha 4 - KRC
Tel. +420 730 156 910
www.lfspareparts724.cz - info@lfspareparts.cz
- LF SPARE PARTS INC. USA**
Legal address:
155 Office Plaza Dr - Suite A - Tallahassee, FL 32301
Business/Mailing address:
1100 South Tower, 225 Peachtree St., N.E. - Atlanta, GA 30303, USA
Tel. +1-404-525-2600 - Fax +1-404-586-3528
www.lfspareparts724.us - info@lfspareparts.us
Tel. West Coast and Midwest: 206-349-1525 Sauro
Tel. East Coast and the Caribbean: 786-817-1764 Luis
-
- AUSTRALIA AND NEW ZEALAND**
www.lfspareparts724.com
andrea.calvio@lfspareparts.com
- AUSTRIA**
www.lfersatzteile724.at
info@lfersatzteile.at
- BALKAN COUNTRIES**
www.lfspareparts724.com
matija.ramov@lfspareparts.com
- BALTIC COUNTRIES**
www.lfspareparts724.com
inara.silina@lfspareparts.com
- LATIN AMERICA AND THE CARRIBEANS**
www.lfrepuestos-horeca724.es
export@lfrepuestos.es
- POLAND**
www.lfspareparts724.pl
info@lfspareparts.pl
- SOUTH KOREA**
www.lfspareparts724.com
fabio.doni@lfspareparts.com
- TURKEY**
www.lfyedekparca724.com
export@lfspareparts.com