



## Spare parts for the professional sector: Coffee grinders



Suitable for:

# FUTURMAT-ARIETE



This catalogue is automatically generated.  
Therefore, the sequence of the items might  
not be always shown at best.  
Updates will be issued in case of additions  
and/or amendments.


*Suitable universal spare parts may not be included*





## GRINDER ASSEMBLY FP-FM

FP - FM



FSMC01



# FUTURMAT-ARIETE




Position	LF code no.	Description
2	1080501	STANDARD COFFEE HOPPER 1.5 Kg
6	1251042	GRINDING BURRS CIMBALI-FAEMA (PAIR )LH
6	1251043	GRINDING BURRS CIMBALI-FAEMA (PAIR )LH
8	1252816	SPIRAL SCREW SERIE P
8	1252822	SPIRAL SCREW SERIE M
9	1252815	LOWER BURRS HOLDER
9	1252821	LOWER BURRS HOLDER
10	1252814	ADJUSTMENT LOCKING LEVER SERIE P
10	1252820	ADJUSTMENT LOCKING LEVER SERIE M
13	1252801	DOSER LID
15	3240123	MICROSWITCH ROLD VRSRB1DA1
19	1252813	DOSER CYLINDER ø 120x65 mm
19	1252819	DOSER CYLINDER ø 120x80 mm
24	3319157	YELLOW MOMENTARY SWITCH 250V
24	3319934	BIPOLAR SWITCH ORANGE 16A 250V
26	1252803	COFFEE COLLECTION TRAY
27	3068103	STARTING CAPACITOR 88/103µF 330V
28	1351100	RELAY FOR MODEL FP
32	1252804	RELAY BASE
33	1252811	ROD SPRING
34	1252805	SCRAPER SPRING
35	1343200	UPPER STAR
36	1252806	COFFEE CLOSING SECTOR
37	1343202	MIDDLE STAR
38	1250548	SPRING ø 11x58 mm INFUSION
39	1343201	LOWER STAR
51	1252807	COUNTER FOR COFFEE GRINDER
55	1250418	DOSER LEVER RETURN SPRING
56	1252809	DOSER LEVER
59	1252808	SPRING PIN



## GRINDER ASSEMBLY RIMINI

**RIMINI**





# FUTURMAT-ARIETE




Position	LF code no.	Description
2	1080932	COMPLETE COFFEE HOPPER 2 kg
12	1252204	RECTANGULAR PLATE M6x1
14	1252205	DOSER BOTTOM LID
15	1343021	STAR ASSEMBLY
16	1343021	STAR ASSEMBLY
17	1343021	STAR ASSEMBLY
18	1385912	COFFEE TAMPER ASSEMBLY
20	1385913	COFFEE TAMPER
23	1252206	PAWL RH
25	1252208	ADJUSTMENT SCREW
26	1252209	DOSER LEVER RETURN SPRING
27	1252210	DOSER PIN
28	1252211	STAR SPRING
30	1250971	LEVER PIN SPRING
31	1252213	LEVER PIN
32	1252214	DOSER LEVER
39	1252216	COFFEE COLLECTION TRAY
40	1252217	DOSER LID
42	1252256	ADJUSTMENT RING
43	1252220	MICROSWITCH LID
44	1252221	PLASTIC RING WITH FLAP
45	1252221	PLASTIC RING WITH FLAP
47	3240123	MICROSWITCH ROLD VRSRB1DA1
49	1319935	GREEN BIPOLAR SWITCH 16A 250V
51	1313916	RUBBER FOOT
59	1251634	GRINDING BURRS CUNILL (PAIR) LEFT
59	5072455	BURR PAIR CUNILL LH
60	1251634	GRINDING BURRS CUNILL (PAIR) LEFT
60	5072455	BURR PAIR CUNILL LH
77	1250972	CONTROL SPRING
82	1252234	COFFEE HOPPER LID ø 200 mm
83	1252244	COFFEE HOPPER FILLER
111	1252244	COFFEE HOPPER FILLER
115	1252246	SPRING ADJUSTMENT PIN
116	1252247	COFFEE HOPPER INNER PROTECTION





## GRINDER ASSEMBLY CT-1

CT-1





# FUTURMAT-ARIETE




Position	LF code no.	Description
1	1080931	COMPLETE COFFEE HOPPER 1 kg
8	1252202	DOSER CYLINDER 300 gr
12	1252204	RECTANGULAR PLATE M6x1
14	1252205	DOSER BOTTOM LID
15	1343021	STAR ASSEMBLY
16	1343021	STAR ASSEMBLY
17	1343021	STAR ASSEMBLY
18	1385912	COFFEE TAMPER ASSEMBLY
20	1385913	COFFEE TAMPER
23	1252206	PAWL RH
25	1252208	ADJUSTMENT SCREW
26	1252209	DOSER LEVER RETURN SPRING
27	1252210	DOSER PIN
28	1252211	STAR SPRING
30	1250971	LEVER PIN SPRING
31	1252213	LEVER PIN
32	1252214	DOSER LEVER
41	1252218	DOSER LID
42	1252256	ADJUSTMENT RING
49	1319935	GREEN BIPOLAR SWITCH 16A 250V
51	1313916	RUBBER FOOT
59	1251634	GRINDING BURRS CUNILL (PAIR) LEFT
59	5072455	BURR PAIR CUNILL LH
60	1251634	GRINDING BURRS CUNILL (PAIR) LEFT
60	5072455	BURR PAIR CUNILL LH
77	1250972	CONTROL SPRING
82	1252234	COFFEE HOPPER LID ø 200 mm
86	1252235	COFFEE COLLECTING TRAY
111	1252244	COFFEE HOPPER FILLER
115	1252246	SPRING ADJUSTMENT PIN
116	1252247	COFFEE HOPPER INNER PROTECTION



## GRINDER ASSEMBLY CT-2

CT-2







# FUTURMAT-ARIETE




Position	LF code no.	Description
2	1080932	COMPLETE COFFEE HOPPER 2 kg
12	1252204	RECTANGULAR PLATE M6x1
14	1252205	DOSER BOTTOM LID
15	1343021	STAR ASSEMBLY
16	1343021	STAR ASSEMBLY
17	1343021	STAR ASSEMBLY
18	1385912	COFFEE TAMPER ASSEMBLY
20	1385913	COFFEE TAMPER
23	1252206	PAWL RH
25	1252208	ADJUSTMENT SCREW
26	1252209	DOSER LEVER RETURN SPRING
27	1252210	DOSER PIN
28	1252211	STAR SPRING
30	1250971	LEVER PIN SPRING
31	1252213	LEVER PIN
32	1252214	DOSER LEVER
40	1252217	DOSER LID
42	1252256	ADJUSTMENT RING
43	1252220	MICROSWITCH LID
44	1252221	PLASTIC RING WITH FLAP
45	1252221	PLASTIC RING WITH FLAP
47	3240123	MICROSWITCH ROLD VRSRB1DA1
49	1319935	GREEN BIPOLAR SWITCH 16A 250V
51	1313916	RUBBER FOOT
59	1251634	GRINDING BURRS CUNILL (PAIR) LEFT
59	5072455	BURR PAIR CUNILL LH
60	1251634	GRINDING BURRS CUNILL (PAIR) LEFT
60	5072455	BURR PAIR CUNILL LH
77	1250972	CONTROL SPRING
82	1252234	COFFEE HOPPER LID $\varnothing$ 200 mm
86	1252235	COFFEE COLLECTING TRAY
111	1252244	COFFEE HOPPER FILLER
115	1252246	SPRING ADJUSTMENT PIN
116	1252247	COFFEE HOPPER INNER PROTECTION



## GRINDER ASSEMBLY MILADY

MILADY





# FUTURMAT-ARIETE



Position	LF code no.	Description
1	1080931	COMPLETE COFFEE HOPPER 1 kg
8	1252202	DOSER CYLINDER 300 gr
12	1252204	RECTANGULAR PLATE M6x1
15	1343021	STAR ASSEMBLY
16	1343021	STAR ASSEMBLY
17	1343021	STAR ASSEMBLY
18	1385912	COFFEE TAMPER ASSEMBLY
20	1385913	COFFEE TAMPER
23	1252206	PAWL RH
25	1252208	ADJUSTMENT SCREW
26	1252209	DOSER LEVER RETURN SPRING
27	1252210	DOSER PIN
28	1252211	STAR SPRING
30	1250971	LEVER PIN SPRING
31	1252213	LEVER PIN
32	1252214	DOSER LEVER
39	1252216	COFFEE COLLECTION TRAY
41	1252218	DOSER LID
42	1252256	ADJUSTMENT RING
49	1319935	GREEN BIPOLAR SWITCH 16A 250V
51	1313916	RUBBER FOOT
59	1251634	GRINDING BURRS CUNILL (PAIR) LEFT
59	5072455	BURR PAIR CUNILL LH
60	1251634	GRINDING BURRS CUNILL (PAIR) LEFT
60	5072455	BURR PAIR CUNILL LH
77	1250972	CONTROL SPRING
82	1252234	COFFEE HOPPER LID ø 200 mm
111	1252244	COFFEE HOPPER FILLER
115	1252246	SPRING ADJUSTMENT PIN
116	1252247	COFFEE HOPPER INNER PROTECTION




# FUTURMAT-ARIETE



## GRINDER ASSEMBLY NEW FUTUR SM

**NEW FUTUR SM**



FSMC06

Positions without LF code no.: upon request



# FUTURMAT-ARIETE



Position	LF code no.	Description
12	1252204	RECTANGULAR PLATE M6x1
14	1252205	DOSER BOTTOM LID
15	1343021	STAR ASSEMBLY
16	1343021	STAR ASSEMBLY
17	1343021	STAR ASSEMBLY
18	1385912	COFFEE TAMPER ASSEMBLY
20	1385913	COFFEE TAMPER
23	1252206	PAWL RH
25	1252208	ADJUSTMENT SCREW
26	1252209	DOSER LEVER RETURN SPRING
27	1252210	DOSER PIN
28	1252211	STAR SPRING
30	1250971	LEVER PIN SPRING
31	1252213	LEVER PIN
32	1252214	DOSER LEVER
39	1252216	COFFEE COLLECTION TRAY
41	1252218	DOSER LID
42	1252256	ADJUSTMENT RING
49	1319935	GREEN BIPOLAR SWITCH 16A 250V
59	1251634	GRINDING BURRS CUNILL (PAIR) LEFT
59	5072455	BURR PAIR CUNILL LH
60	1251634	GRINDING BURRS CUNILL (PAIR) LEFT
60	5072455	BURR PAIR CUNILL LH
77	1250972	CONTROL SPRING
82	1252234	COFFEE HOPPER LID $\varnothing$ 200 mm
100	1080933	COMPLETE COFFEE HOPPER 1 kg
101	1313917	RECTANGULAR RUBBER FOOT
111	1252244	COFFEE HOPPER FILLER
115	1252246	SPRING ADJUSTMENT PIN
116	1252247	COFFEE HOPPER INNER PROTECTION





Suitable for:

# FUTURMAT-ARIETE



Suitable for:

## Adjustement rings for coffee grinder

1252256 ADJUSTMENT RING



FUTURMAT-ARIETE 26000042

## Bearings

1063906 BEARING 6203 ZZ NSK  
external  $\varnothing$  40mm - internal  $\varnothing$  17mm - thickness 12mm



FUTURMAT-ARIETE 01472604

## Brushes

1384023 BRUSH FOR CLEANING 50 mm



FUTURMAT-ARIETE

1384001 BRUSH FOR COFFEE SHOWER



FUTURMAT-ARIETE

1384002 BRUSH FOR MAINTENANCE



FUTURMAT-ARIETE

1384014 BRUSH FOR SHOWER RED



FUTURMAT-ARIETE

## Capacitors, electrical

3068006 CAPACITOR DUCATI ENERGIA 4 $\mu$ F  
450V 50/60Hz  
operating temperature -25 + 85°C  
lead connection 6.35x0.8 mm  
 $\varnothing$  28xh55 mm



FUTURMAT-ARIETE 01123000

3068014 CAPACITOR DUCATI ENERGIA 8 $\mu$ F  
450V 50/60Hz  
operating temperature -25 + 85°C  
lead connection 6.35x0.8 mm  
 $\varnothing$  32xh55 mm



FUTURMAT-ARIETE 08127200



Suitable for:

**3068095 CAPACITOR ELECTRICAL 4 $\mu$ F**  
450V 50/60Hz -  $\varnothing$  30xh51 mm



FUTURMAT-ARIETE 01123000

Suitable for:

**3068079 CAPACITOR ELECTRICAL 8 $\mu$ F**  
450V 50/60Hz -  $\varnothing$  30xh71 mm



FUTURMAT-ARIETE 08127200

**3068103 STARTING CAPACITOR 88/103 $\mu$ F 330V**



FUTURMAT-ARIETE 07273006

## Clamps

**1168011 STAINLESS STEEL CLAMP FOR FLANGE PUMP**



FUTURMAT-ARIETE 07451909

## Coffee measuring spoons

**1069001 PLASTIC MEASURING SPOON 20 ml**



FUTURMAT-ARIETE

**1069002 STAINLESS STEEL MEASURING SPOON 20 ml**



FUTURMAT-ARIETE

## Containers for coffee

**1252244 COFFEE HOPPER FILLER**



FUTURMAT-ARIETE 26000111

**1252247 COFFEE HOPPER INNER PROTECTION**



FUTURMAT-ARIETE 26000116



# FUTURMAT-ARIETE



Suitable for:

1252234 COFFEE HOPPER LID  $\varnothing$  200 mm



FUTURMAT-ARIETE 26000082

Suitable for:

1080931 COMPLETE COFFEE HOPPER 1 kg



FUTURMAT-ARIETE 26000001

1080933 COMPLETE COFFEE HOPPER 1 kg



FUTURMAT-ARIETE 26000100

1080932 COMPLETE COFFEE HOPPER 2 kg



FUTURMAT-ARIETE 26000002

1080501 STANDARD COFFEE HOPPER 1.5 Kg  
for Grinder-dispenser (FUTURMAT-ARIETE) FM - FP



FUTURMAT-ARIETE 07648306

## Counters


1252807 COUNTER FOR COFFEE GRINDER  
for Grinder-dispenser (FUTURMAT-ARIETE) FM - FP



FUTURMAT-ARIETE 07148703

## Dosers for coffee

1252205 DOSER BOTTOM LID



FUTURMAT-ARIETE 26000014

1252813 DOSER CYLINDER  $\varnothing$  120x65 mm  
for Grinder-dispenser (FUTURMAT-ARIETE) FP



FUTURMAT-ARIETE 01277003



Suitable for:


**1252819 DOSER CYLINDER  $\varnothing$  120x80 mm**  
for Grinder-dispenser (FUTURMAT-ARIETE) FM



FUTURMAT-ARIETE 01313006


Suitable for:

**1252202 DOSER CYLINDER 300 gr**  
for Grinder-dispenser (FUTURMAT-ARIETE) CT1 MILADY




FUTURMAT-ARIETE 26000008

**1252217 DOSER LID**  
for Grinder-dispenser (FUTURMAT-ARIETE) CT2 RIMINI



FUTURMAT-ARIETE 26000040

**1252218 DOSER LID**  
for Coffee grinder (FUTURMAT-ARIETE) NEW FUTUR SM  
for Grinder-dispenser (FUTURMAT-ARIETE) CT1 MILADY



FUTURMAT-ARIETE 26000041

**1252801 DOSER LID**  
for Grinder-dispenser (FUTURMAT-ARIETE) FM - FP



FUTURMAT-ARIETE 00882506

**1252811 ROD SPRING**



FUTURMAT-ARIETE 00887901

## Feet

**1313917 RECTANGULAR RUBBER FOOT**



FUTURMAT-ARIETE 26000101

**1313916 RUBBER FOOT**



FUTURMAT-ARIETE 26000051

## Grinders

**1251042 GRINDING BURRS CIMBALI-FAEMA (PAIR )LH**  
external  $\varnothing$  54 mm - internal  $\varnothing$  31 mm  
thickness 8 mm - 3 fixing holes  
for Grinder-dispenser (FUTURMAT-ARIETE) FM - FP



FUTURMAT-ARIETE 00896209

**1251043 GRINDING BURRS CIMBALI-FAEMA (PAIR )LH**  
external  $\varnothing$  62 mm - internal  $\varnothing$  38 mm  
thickness 9 mm - 3 fixing holes  
for Grinder-dispenser (FUTURMAT-ARIETE) FM - FP



FUTURMAT-ARIETE 00888008



Suitable for:

Suitable for:


**1251634 GRINDING BURRS CUNILL (PAIR) LEFT**  
 external  $\varnothing$  59 mm - internal  $\varnothing$  34 mm  
 thickness 9 mm - 3 mounting holes  
 for Grinder-dispenser (FUTURMAT-ARIETE) CT1 - CT2  
 MILADY - NEWFUTURSM - RIMINI



FUTURMAT-ARIETE 26000059/060

## Grinding burr holders

**1252815 LOWER BURRS HOLDER**  
 for Grinder-dispenser (FUTURMAT-ARIETE) FM - FP



FUTURMAT-ARIETE 01276807

**1252821 LOWER BURRS HOLDER**  
 for Grinder-dispenser (FUTURMAT-ARIETE) FM - FP



FUTURMAT-ARIETE 01310804

**1252822 SPIRAL SCREW SERIE M**



FUTURMAT-ARIETE 01310903

**1252816 SPIRAL SCREW SERIE P**



FUTURMAT-ARIETE 00898502

## Ironmongery (screws,nuts,washers)

**1528501 COUNTERSUNK HEAD SCREWS WITH SHELLM5x12**  
 cross recessed - stainless steel  
 UNI 7689 - DIN 966 - ISO 7047



FUTURMAT-ARIETE

## Knobs

**1252208 ADJUSTMENT SCREW**



FUTURMAT-ARIETE 26000025



## Levers

**1252214 DOSER LEVER**  
for Grinder-dispenser (FUTURMAT-ARIETE) MILADY  
NEWFUTURSM - RIMINI CT/1 - RIMINI CT/2



FUTURMAT-ARIETE 26000032

**1252809 DOSER LEVER**  
for Grinder-dispenser (FUTURMAT-ARIETE) FM - FP



FUTURMAT-ARIETE 07147804

## Microswitches, mechanical

**1252220 MICROSWITCH LID**



FUTURMAT-ARIETE 26000043

**3240123 MICROSWITCH ROLD VRSRB1DA1**  
16A 250V



FUTURMAT-ARIETE 10975704

FUTURMAT-ARIETE 26000047

**1252221 PLASTIC RING WITH FLAP**



FUTURMAT-ARIETE 26000044

FUTURMAT-ARIETE 26000045

## Pawls for coffee grinder dosers

**1252206 PAWL RH**



FUTURMAT-ARIETE 26000023

## Pins

**1252820 ADJUSTMENT LOCKING LEVER SERIE M**



FUTURMAT-ARIETE 01314905

**1252814 ADJUSTMENT LOCKING LEVER SERIE P**



FUTURMAT-ARIETE 00889105



# FUTURMAT-ARIETE



Suitable for:

**1252210 DOSER PIN**



FUTURMAT-ARIETE 26000027

**1252204 RECTANGULAR PLATE M6x1**



FUTURMAT-ARIETE 26000012

**1252808 SPRING PIN**



FUTURMAT-ARIETE 00883207

Suitable for:

**1252213 LEVER PIN**



FUTURMAT-ARIETE 26000031

**1252246 SPRING ADJUSTMENT PIN**  
for models up to 2009



FUTURMAT-ARIETE 26000115

## Relays

**1252804 RELAY BASE**



FUTURMAT-ARIETE 07985807

**1351100 RELAY FOR MODEL FP**



FUTURMAT-ARIETE 07985500

## Springs

**1250972 CONTROL SPRING**



FUTURMAT-ARIETE 26000077

**1252209 DOSER LEVER RETURN SPRING**



FUTURMAT-ARIETE 26000026

**1250418 DOSER LEVER RETURN SPRING**  
for FUTURMAT FP-FM



FUTURMAT-ARIETE 00883603

**1250971 LEVER PIN SPRING**



FUTURMAT-ARIETE 26000030



# FUTURMAT-ARIETE



Suitable for:

**1252805 SCRAPER SPRING**



FUTURMAT-ARIETE 07147309

Suitable for:

**1250548 SPRING  $\varnothing$  11x58 mm INFUSION**  
for delivery group



FUTURMAT-ARIETE 00884809

**1252211 STAR SPRING**



FUTURMAT-ARIETE 26000028

## Stars and spare parts

**1252806 COFFEE CLOSING SECTOR**



FUTURMAT-ARIETE 00884916

**1343201 LOWER STAR**



FUTURMAT-ARIETE 11382116

**1343202 MIDDLE STAR**



FUTURMAT-ARIETE 11382314

**1343021 STAR ASSEMBLY**



FUTURMAT-ARIETE 26000015

FUTURMAT-ARIETE 26000016

FUTURMAT-ARIETE 26000017

**1343200 UPPER STAR**



FUTURMAT-ARIETE 11382512



Suitable for:

Suitable for:

## Switches

**3319934 BIPOLAR SWITCH ORANGE 16A 250V**  
16(4)A 250V - max. temperature 120°C  
with indicator lamp - silk screen printing 0 - I  
mounting hole 22x30 mm



FUTURMAT-ARIETE 07967020

**3319779 BLOCK CONNECTIONS BLACK 22x30 mm**



**3319783 FRAME SAFETY 4 SIDES BLACK 22x30 mm**



**1319935 GREEN BIPOLAR SWITCH 16A 250V**  
16(4)A 250V  
with indicator lamp and push-button cover  
"ON-OFF" simbol screenprinted  
mounting hole 22x30 mm



FUTURMAT-ARIETE 26000049

**3319035 ORANGE BIPOLAR SWITCH 16A 250V**  
16(4)A 250V - with indicator lamp  
max temperature 120°C  
mounting hole 22x30 mm



FUTURMAT-ARIETE 07967000

FUTURMAT-ARIETE 07967010

**3319780 BLOCK CONNECTION WHITE 22x30 mm**



**3319782 FRAME SAFETY 2 SIDES BLACK 22x30 mm**



**3319501 PUSH-BUTTON PROTECTION CAP**  
external dimensions 29x36 mm  
for switches with mounting hole 22x30 mm



**3319780 BLOCK CONNECTION WHITE 22x30 mm**





# FUTURMAT-ARIETE



Suitable for:

**3319779 BLOCK CONNECTIONS BLACK 22x30 mm**



Suitable for:

**3319782 FRAME SAFETY 2 SIDES BLACK 22x30 mm**



**3319783 FRAME SAFETY 4 SIDES BLACK 22x30 mm**



**3319501 PUSH-BUTTON PROTECTION CAP**  
external dimensions 29x36 mm  
for switches with mounting hole 22x30 mm



## Tampers for coffee

**1385913 COFFEE TAMPER**



FUTURMAT-ARIETE 26000020

**1385912 COFFEE TAMPER ASSEMBLY**  
for SILENCER



FUTURMAT-ARIETE 26000018


## Trays

**1252235 COFFEE COLLECTING TRAY**  
for Grinder-dispenser (FUTURMAT-ARIETE)  
RIMINI CT/1 - RIMINI CT/2



FUTURMAT-ARIETE 26000086

**1252216 COFFEE COLLECTION TRAY**  
for Grinder-dispenser (FUTURMAT-ARIETE) MILADY  
NEWFUTURSM - RIMINI



FUTURMAT-ARIETE 26000039

**1252803 COFFEE COLLECTION TRAY**  
for Grinder-dispenser (FUTURMAT-ARIETE) FM - FP



FUTURMAT-ARIETE 07295405



The data herewith contained may change without notice and LF SpA cannot be held responsible for possible errors stated or resulting by the use of this document. All rights reserved. No part of this publication may be reproduced without written permission by LF SpA.



## Distributing Components, Spare Parts & Accessories in original quality worldwide

- 
- LF SpA HEADQUARTERS**  
via Voltri, 80 - 47522 Cesena (FC) ITALY  
Tel. +39 0547 34 11 11 - Fax +39 0547 34 11 10  
[www.lfricambi724.it](http://www.lfricambi724.it) - [info@lfricambi.it](mailto:info@lfricambi.it)  
Export Dept. Tel. +39 0547 34 11 50 - Fax +39 0547 34 11 55  
[www.lfspareparts724.com](http://www.lfspareparts724.com) - [export@lfspareparts.com](mailto:export@lfspareparts.com)
- LF SpA HOUSEHOLD COMPONENTS DIVISION**  
Via Padriciano, 99 - AREA Science Park - 34149 Trieste (TS) ITALY  
Tel. +39 0547 34 12 42 - Fax +39 0547 34 12 48  
[www.lfspareparts724.com](http://www.lfspareparts724.com) - [info@lfspareparts.com](mailto:info@lfspareparts.com)
- EPGC Sas FRANCE**  
13, Rue des Forts - 59960 Neuville en Ferrain  
Tel. +33 (0)3 20 25 06 21 - Fax +33 (0)3 20 25 34 12  
[www.epgc.com](http://www.epgc.com) - [epgc@epgc.com](mailto:epgc@epgc.com)
- LF GmbH GERMANY**  
Junkersstrasse, 3 - D-82178 Puchheim - München  
Tel. +49 89 89 45 78 66 - Fax +49 89 89 45 78 88  
[www.lfersatzteile724.de](http://www.lfersatzteile724.de) - [info@lfersatzteile.de](mailto:info@lfersatzteile.de)
- LF China REPUBLIC OF CHINA**  
Room 403, No.2, Huadu Mansion, Lane 422, Huanghua Rd.  
Minhang Dist. - 201103 Shanghai  
Tel. +86 (0)21 33 53 66 31 - Fax +86 (0)21 33 53 66 32  
[www.lfspareparts724.com](http://www.lfspareparts724.com) - [china@lfspareparts.com](mailto:china@lfspareparts.com)
- OOO LF RUSSIAN FEDERATION**  
Ul. Anatoliya Zhivova, 8 - office 1 - 123100 Moscow  
Tel./Fax +7 495 725 26 53  
[www.lfspareparts724.ru](http://www.lfspareparts724.ru) - [info@lfspareparts.ru](mailto:info@lfspareparts.ru)
- LF Repuestos Horeca S.L.U. SPAIN**  
Poligono Industrial Carpetania - C/Miguel Faraday, 8 - 28906 Getafe  
Tel. +34 91 477 91 00 - Fax +34 91 477 90 81  
[www.lfrepuestos-horeca724.es](http://www.lfrepuestos-horeca724.es) - [info@lfrepuestos.es](mailto:info@lfrepuestos.es)
- LF Scandinavia Aps - LF Spareparts S.p.A. DENMARK**  
Nupark, 51 - 7500 Holstebro  
Tel. +45 70 70 77 33  
[www.lfspareparts724.dk](http://www.lfspareparts724.dk) - [denmark@lfspareparts.dk](mailto:denmark@lfspareparts.dk)
- LF SpA Cesena (IT) Swiss Branch Steinhausen SWITZERLAND**  
Sennweidstrasse, 45 - CH-6312 Steinhausen  
Tel. +41 (0)41 760 15 80/1 - Fax +41 (0)41 760 15 85  
[www.lfersatzteile724.ch](http://www.lfersatzteile724.ch) - [info@lfersatzteile.ch](mailto:info@lfersatzteile.ch)
- LF Spare Parts Ltd. UNITED KINGDOM**  
A10a Lakeside Business Park, Broadway Lane  
South Cerney, Gloucestershire GL7 5XL  
Tel. +44 (0)1285 86 16 25 - Fax +44 (0)1285 86 39 49  
[www.lfspareparts724.co.uk](http://www.lfspareparts724.co.uk) - [info@lfspareparts.co.uk](mailto:info@lfspareparts.co.uk)
- LF Central Est Europe S.r.o. CZECH REPUBLIC**  
Antala Staska 1859/34  
14000 Praha 4 - KRC  
Tel. +420 730 156 910  
[www.lfspareparts724.cz](http://www.lfspareparts724.cz) - [info@lfspareparts.cz](mailto:info@lfspareparts.cz)
- LF SPARE PARTS INC. USA**  
Legal address:  
155 Office Plaza Dr - Suite A - Tallahassee, FL 32301  
Business/Mailing address:  
1100 South Tower, 225 Peachtree St., N.E. - Atlanta, GA 30303, USA  
Tel. +1-404-525-2600 - Fax +1-404-586-3528  
[www.lfspareparts724.us](http://www.lfspareparts724.us) - [info@lfspareparts.us](mailto:info@lfspareparts.us)  
Tel. West Coast and Midwest: 206-349-1525 Sauro  
Tel. East Coast and the Caribbean: 786-817-1764 Luis
- 
- AUSTRALIA AND NEW ZEALAND**  
[www.lfspareparts724.com](http://www.lfspareparts724.com)  
[andrea.calvio@lfspareparts.com](mailto:andrea.calvio@lfspareparts.com)
- AUSTRIA**  
[www.lfersatzteile724.at](http://www.lfersatzteile724.at)  
[info@lfersatzteile.at](mailto:info@lfersatzteile.at)
- BALKAN COUNTRIES**  
[www.lfspareparts724.com](http://www.lfspareparts724.com)  
[matija.ramov@lfspareparts.com](mailto:matija.ramov@lfspareparts.com)
- BALTIC COUNTRIES**  
[www.lfspareparts724.com](http://www.lfspareparts724.com)  
[inara.silina@lfspareparts.com](mailto:inara.silina@lfspareparts.com)
- LATIN AMERICA AND THE CARRIBEANS**  
[www.lfrepuestos-horeca724.es](http://www.lfrepuestos-horeca724.es)  
[export@lfrepuestos.es](mailto:export@lfrepuestos.es)
- POLAND**  
[www.lfspareparts724.pl](http://www.lfspareparts724.pl)  
[info@lfspareparts.pl](mailto:info@lfspareparts.pl)
- SOUTH KOREA**  
[www.lfspareparts724.com](http://www.lfspareparts724.com)  
[fabio.doni@lfspareparts.com](mailto:fabio.doni@lfspareparts.com)
- TURKEY**  
[www.lfyedekparca724.com](http://www.lfyedekparca724.com)  
[export@lfspareparts.com](mailto:export@lfspareparts.com)