



## Spare parts for the professional sector: Coffee grinders



Suitable for:

# ROSSI




This catalogue is automatically generated.  
Therefore, the sequence of the items might  
not be always shown at best.  
Updates will be issued in case of additions  
and/or amendments.

*Suitable universal spare parts may not be included*





GRINDER ASSEMBLY RR45



RO0101

Positions without LF code no.: upon request




# ROSSI



Position	LF code no.	Description
13	1252582	FILTER HOLDER FORK
14	1528631	CYLINDER HEAD SCREW M4x8
15	1390003	RELAY BOARD
17	3068019	CAPACITOR DUCATI ENERGIA 12,5µF
29	3319019	BIPOLAR SWITCH RED 16A 250V
29	3319934	BIPOLAR SWITCH ORANGE 16A 250V
31	1251011	GRINDING BURRS ASTRAL-ROSSI (PAIR) LEFT
31	1251707	GRINDING BURRS PAIR ROSSI LH
35	1252378	THREADED RING NUT 15MCx1
36	1250130	SEEGER RING J-35
38	1252376	COMPENSATION RING
52	1324933	SPRING SHAFT SEAT
63	1184012	CYLINDER HEAD SCREW M5x10
81	3240123	MICROSWITCH ROLD VRSRB1DA1
86	1528501	COUNTERSUNK HEAD SCREWS WITH SHELLM5x12
91	1528627	COUNTERSUNK FLAT HEAD SCREWS M8x20
93	1252470	COUNTER FOR COFFEE GRINDER/DOSER
102	1324932	PIN FOR MANUAL COFFEE TAMPER



GRINDER ASSEMBLY RR55-RR65







# ROSSI




Position	LF code no.	Description
5	3240123	MICROSWITCH ROLD VRSRB1DA1
8	1528501	COUNTERSUNK HEAD SCREWS WITH SHELLM5x12
12	1324933	SPRING SHAFT SEAT
23	1184012	CYLINDER HEAD SCREW M5x10
42	1528627	COUNTERSUNK FLAT HEAD SCREWS M8x20
44	1252470	COUNTER FOR COFFEE GRINDER/DOSER
65	1252583	ADJUSTMENT RING NUT
72	1528501	COUNTERSUNK HEAD SCREWS WITH SHELLM5x12
75	1251011	GRINDING BURRS ASTRAL-ROSSI (PAIR) LEFT
75	1251707	GRINDING BURRS PAIR ROSSI LH
78	1528631	CYLINDER HEAD SCREW M4x8
86	3068019	CAPACITOR DUCATI ENERGIA 12,5 $\mu$ F
96	1390003	RELAY BOARD
103	3319019	BIPOLAR SWITCH RED 16A 250V
103	3319934	BIPOLAR SWITCH ORANGE 16A 250V



COFFEE GRINDER RR55OD ON DEMAND

RR55OD





# ROSSI





Position	LF code no.	Description
14	3319019	BIPOLAR SWITCH RED 16A 250V
14	3319934	BIPOLAR SWITCH ORANGE 16A 250V
16	1251094	GRINDING BURRS PAIR ROSSI LH
17	1528631	CYLINDER HEAD SCREW M4x8
21	1252378	THREADED RING NUT 15MCx1
22	1250130	SEEGER RING J-35
24	1252376	COMPENSATION RING
25	3063005	BEARING 6202 DDU NSK
61	3068024	CAPACITOR DUCATI ENERGIA 16 $\mu$ F



GRINDER ASSEMBLY CC45

CC45








# ROSSI



Position	LF code no.	Description
11	1252583	ADJUSTMENT RING NUT
15	3319019	BIPOlar SWITCH RED 16A 250V
15	3319934	BIPOlar SWITCH ORANGE 16A 250V
25	1251011	GRINDING BURRS ASTRAL-ROSSI (PAIR) LEFT
25	1251707	GRINDING BURRS PAIR ROSSI LH
28	1528631	CYLINDER HEAD SCREW M4x8
48	3068019	CAPACITOR DUCATI ENERGIA 12,5 $\mu$ F
50	1390003	RELAY BOARD
54	3240123	MICROSWITCH ROLD VRSRB1DA1
60	1528501	COUNTERSUNK HEAD SCREWS WITH SHELLM5x12
64	1324933	SPRING SHAFT SEAT
74	1528627	COUNTERSUNK FLAT HEAD SCREWS M8x20
80	1184012	CYLINDER HEAD SCREW M5x10
93	1252470	COUNTER FOR COFFEE GRINDER/DOSER



GRINDER ASSEMBLY R80



RO0401

Positions without LF code no.: upon request



# ROSSI




Position	LF code no.	Description
3	3240123	MICROSWITCH ROLD VRSRB1DA1
13	1528627	COUNTERSUNK FLAT HEAD SCREWS M8x20
18	1252470	COUNTER FOR COFFEE GRINDER/DOSER
35	1324932	PIN FOR MANUAL COFFEE TAMPER
41	1252583	ADJUSTMENT RING NUT
47	9006081	THREE-PHASE SWITCH 10A 380V
49	1252582	FILTER HOLDER FORK
51	1251011	GRINDING BURRS ASTRAL-ROSSI (PAIR) LEFT
51	1251707	GRINDING BURRS PAIR ROSSI LH
55	3068019	CAPACITOR DUCATI ENERGIA 12,5 $\mu$ F
56	1351008	POWER RELAY FINDER 60.33.8.230.0000
56	3351007	POWER RELAY FINDER 55.32.8.230.0040



GRINDER ASSEMBLY MC

MC





# ROSSI




Position	LF code no.	Description
13	1252354	HOPPER SOCKET UNION
17	1251076	CONICAL GRINDING BURRS ROSSI (PAIR) RH
22	3319019	BIPOLAR SWITCH RED 16A 250V
22	3319934	BIPOLAR SWITCH ORANGE 16A 250V
41	1212011	PLANETARY GEAR
46	3063005	BEARING 6202 DDU NSK
59	3351007	POWER RELAY FINDER 55.32.8.230.0040
60	3068019	CAPACITOR DUCATI ENERGIA 12,5 $\mu$ F
68	3240123	MICROSWITCH ROLD VRSRB1DA1
76	1324933	SPRING SHAFT SEAT
88	1252470	COUNTER FOR COFFEE GRINDER/DOSER
116	1250123	DOSER LEVER RETURN SPRING
118	1252359	PAWL PIN





GRINDER ASSEMBLY FM

FM





# ROSSI




Position	LF code no.	Description
5	1251050	CONICAL GRINDING BURRS ROSSI (PAIR) RH



GRINDER ASSEMBLY MAC64

MAC64





# ROSSI



Position	LF code no.	Description
15	1343058	TOP STAR
16	1343055	DOSING SHEET
17	1343057	MIDDLE STAR
26	1528631	CYLINDER HEAD SCREW M4x8
29	1528627	COUNTERSUNK FLAT HEAD SCREWS M8x20
44	1240044	MICROSWITCH 0.1A 250V
50	1252416	PIN FOR PAWL $\varnothing$ 4x14 mm
53	1250123	DOSER LEVER RETURN SPRING
83	1252415	GRINDING ADJUSTMENT SCREW
85	1252414	ADJUSTMENT RING ROD
105	3351007	POWER RELAY FINDER 55.32.8.230.0040
111	3319019	BIPOlar SWITCH RED 16A 250V
113	1251094	GRINDING BURRS PAIR ROSSI LH
115	1528631	CYLINDER HEAD SCREW M4x8
118	1252378	THREADED RING NUT 15MCx1
119	1250130	SEEGER RING J-35
121	1252376	COMPENSATION RING
122	3063005	BEARING 6202 DDU NSK
129	3063005	BEARING 6202 DDU NSK
133	3068024	CAPACITOR DUCATI ENERGIA 16 $\mu$ F
141	1528631	CYLINDER HEAD SCREW M4x8
151	1528501	COUNTERSUNK HEAD SCREWS WITH SHELLM5x12



Suitable for:

# ROSSI



Suitable for:

## Bearings

**3063005 BEARING 6202 DDU NSK**  
external  $\varnothing$  35mm - internal  $\varnothing$  15mm - thickness 11mm



ROSSI M2510

ROSSI 2510

ROSSI 2524

## Capacitors, electrical

**3068019 CAPACITOR DUCATIENERGIA 12,5 $\mu$ F**  
450V 50/60Hz  
operating temperature -25 + 85°C  
lead connection 6.35x0.8 mm  
 $\varnothing$  36xh70 mm



ROSSI 3177

**3068024 CAPACITOR DUCATIENERGIA 16 $\mu$ F**  
450V 50/60Hz  
operating temperature -25 + 85°C  
lead connector 6.35x0.8 mm  
 $\varnothing$  36xh70 mm



ROSSI 3251

**3068081 CAPACITOR ELECTRICAL 12.5 $\mu$ F**  
450V 50/60Hz -  $\varnothing$  35xh71 mm



ROSSI 3177

**3068083 CAPACITOR ELECTRICAL 16 $\mu$ F**  
450V 50/60Hz -  $\varnothing$  35xh71 mm



ROSSI 3251

## Circlips

**1250130 SEEGER RING J-35**  
in plated iron - external  $\varnothing$  37.8 mm  
UNI 7437 - DIN 472  
for Grinder-dispenser (ROSSI) RR45



ROSSI 1640





---

## Containers for coffee

---

- 1080249 HOPPER ROSSI COMPLETE**  
for Grinder-dispenser (ROSSI) MC - RR45 - RR55  
RR65 - R80



ROSSI 2737

ROSSI 2737.500.1

---

## Counters

---

- 1252470 COUNTER FOR COFFEE GRINDER/DOSER**  
for dosing grinders with dosing lever on the right



ROSSI 3314

---

## Dosers for coffee

---

- 1324933 SPRING SHAFT SEAT**




ROSSI 5248

---

## Electronic printed-circuit boards

---

- 1390003 RELAY BOARD**  
for Grinder-dispenser (ROSSI) CC45 - RR45 - RR55  
RR65



ROSSI SE01160091

---

## Forks for portafilter coffee grinder

---

- 1252582 FILTER HOLDER FORK**  
for Grinder-dispenser (ROSSI) RR45 - R80



ROSSI 2722



Suitable for:

ROSSI



Suitable for:

## Gears

**1212011 PLANETARY GEAR**  
for Grinder-dispenser (ROSSI) MC



ROSSI S5591

## Grinders

**1251050 CONICAL GRINDING BURRS ROSSI (PAIR) RH**  
external  $\varnothing$  38/30 mm - internal  $\varnothing$  26/7 mm  
thickness 17/20,3 mm  
for Grinder-dispenser (ROSSI) FM



ROSSI 5200

**1251076 CONICAL GRINDING BURRS ROSSI (PAIR) RH**  
external  $\varnothing$  68/49 mm - internal  $\varnothing$  41/13 mm  
thickness 25 mm - 4 mounting holes  
inner groove for feather key  
for Grinder-dispenser (ROSSI) MC



ROSSI M5585

ROSSI 5585

**1251016 GRINDING BURRS (PAIR) ROSSI LEFT**  
external  $\varnothing$  50 mm - internal  $\varnothing$  31 mm  
thickness 8.5 mm - 3 mounting holes  
for Grinder-dispenser (ROSSI) BFD



ROSSI 5198

**1251011 GRINDING BURRS ASTRAL-ROSSI (PAIR) LEFT**  
external  $\varnothing$  64 mm - internal  $\varnothing$  38 mm  
thickness 9 mm - 3 fixing holes  
for Grinder-dispenser (ROSSI) CC45 - RR45 - RR55  
RR65 - R80



ROSSI 4433

**1251094 GRINDING BURRS PAIR ROSSI LH**  
external  $\varnothing$  63.5 mm - internal  $\varnothing$  38 mm  
thickness 9 mm - 3 mounting holes  
for Grinder-dispenser (ROSSI) MAC64 - RR550D



ROSSI 4433.64

**1251707 GRINDING BURRS PAIR ROSSI LH**  
BURRS "HEAVY DUTY" - duration increased by 70%  
compared to a standard grinding burr  
they do not deform  
lower contamination of ground coffee  
external  $\varnothing$  63,5 mm - internal  $\varnothing$  38 mm  
thickness 9 mm - 3 fixing holes




ROSSI



## Grinding burr holders

**1252583 ADJUSTMENT RING NUT**  
for Grinder-dispenser (ROSSI) CC45 - RR55 - RR65  
R80



ROSSI 2720

**1252354 HOPPER SOCKET UNION**  
for Grinder-dispenser (ROSSI) MC



ROSSI S5662

**1252378 THREADED RING NUT 15MCx1**  
for Grinder-dispenser (ROSSI) MAC64 - RR45  
RR550D



ROSSI 4983

## Ironmongery (screws,nuts,washers)

**1252414 ADJUSTMENT RING ROD**



ROSSI 3558

**1252376 COMPENSATION RING**  
for Grinder-dispenser (ROSSI) RR45



ROSSI 1634

**1528627 COUNTERSUNK FLAT HEAD SCREWS M8x20**  
hexagon socket - stainless steel  
UNI 5933 - DIN 7991 - ISO 10642



ROSSI 1218.10

**1528501 COUNTERSUNK HEAD SCREWS WITH SHELLM5x12**  
cross recessed - stainless steel  
UNI 7689 - DIN 966 - ISO 7047



ROSSI 1224.10

**1528631 CYLINDER HEAD SCREW M4x8**  
stainless steel - cross recessed  
UNI 7687 - DIN 7985 - ISO 7045



ROSSI 1256

**1184012 CYLINDER HEAD SCREW M5x10**  
stainless steel - with hexagon socket  
UNI 9327 - DIN 7984



ROSSI 1041



Suitable for:

# ROSSI



Suitable for:

## Microswitches, mechanical

**3240123** MICROSWITCH ROLD VRSRB1DA1  
16A 250V



ROSSI 3202

**1240044** MICROSWITCH 0.1A 250V  
for Grinder-dispenser (ROSSI) MAC64



ROSSI 3009.10

## Pins

**1252415** GRINDING ADJUSTMENT SCREW  
for Grinder-dispenser (ROSSI) MAC64



ROSSI 3549

**1252359** PAWL PIN



ROSSI 2690

**1252416** PIN FOR PAWL  $\varnothing$  4x14 mm



ROSSI 6263

## Relays

**3351007** POWER RELAY FINDER 55.32.8.230.0040  
230V 50/60Hz  
2 exchange contacts 10A  
with to test push-button + mechanic gauge



ROSSI 3068.10

**1351008** POWER RELAY FINDER 60.33.8.230.0000  
230V 50/60Hz  
3 changeover contacts 10A  
for Grinder-dispenser (ROSSI) R80



ROSSI 3068

## Springs

**1250123** DOSER LEVER RETURN SPRING  
for BRASILIA MC-MAC64  
for ROSSI MC-MAC64



ROSSI 2049




## Stars and spare parts

**1343055 DOSING SHEET**



ROSSI 6254

**1343057 MIDDLE STAR**  
for Grinder-dispenser (ROSSI) MAC64



ROSSI 6251

**1343058 TOP STAR**  
for Grinder-dispenser (ROSSI) MAC64



ROSSI 6250

## Switches

**3319934 BIPOLAR SWITCH ORANGE 16A 250V**  
16(4)A 250V - max. temperature 120°C  
with indicator lamp - silk screen printing 0 - I  
mounting hole 22x30 mm



ROSSI 3253

**3319780 BLOCK CONNECTION WHITE 22x30 mm**



**3319779 BLOCK CONNECTIONS BLACK 22x30 mm**



**3319782 FRAME SAFETY 2 SIDES BLACK 22x30 mm**



**3319783 FRAME SAFETY 4 SIDES BLACK 22x30 mm**



**3319501 PUSH-BUTTON PROTECTION CAP**  
external dimensions 29x36 mm  
for switches with mounting hole 22x30 mm







Suitable for:

**ROSSI**



**3319019 BIPOLAR SWITCH RED 16A 250V**  
16(4)A 250V - max. temperature 120°C  
with indicator lamp - mounting hole 22x30 mm



ROSSI 3253

**3319779 BLOCK CONNECTIONS BLACK 22x30 mm**



**3319783 FRAME SAFETY 4 SIDES BLACK 22x30 mm**



**9006081 THREE-PHASE SWITCH 10A 380V**  
for Grinder-dispenser (ROSSI) R80



ROSSI 3170.10

Suitable for:

**3319780 BLOCK CONNECTION WHITE 22x30 mm**



**3319782 FRAME SAFETY 2 SIDES BLACK 22x30 mm**



**3319501 PUSH-BUTTON PROTECTION CAP**  
external dimensions 29x36 mm  
for switches with mounting hole 22x30 mm



## Tampers for coffee

**1324932 PIN FOR MANUAL COFFEE TAMPER**



ROSSI 3910

The data herewith contained may change without notice and LF SpA cannot be held responsible for possible errors stated or resulting by the use of this document. All rights reserved. No part of this publication may be reproduced without written permission by LF SpA.



## Distributing Components, Spare Parts & Accessories in original quality worldwide

- 
- LF SpA HEADQUARTERS**  
via Voltri, 80 - 47522 Cesena (FC) ITALY  
Tel. +39 0547 34 11 11 - Fax +39 0547 34 11 10  
[www.lfircambi724.it](http://www.lfircambi724.it) - [info@lfircambi.it](mailto:info@lfircambi.it)  
Export Dept. Tel. +39 0547 34 11 50 - Fax +39 0547 34 11 55  
[www.lfspareparts724.com](http://www.lfspareparts724.com) - [export@lfspareparts.com](mailto:export@lfspareparts.com)
- LF SpA HOUSEHOLD COMPONENTS DIVISION**  
Via Padriciano, 99 - AREA Science Park - 34149 Trieste (TS) ITALY  
Tel. +39 0547 34 12 42 - Fax +39 0547 34 12 48  
[www.lfspareparts724.com](http://www.lfspareparts724.com) - [info@lfspareparts.com](mailto:info@lfspareparts.com)
- EPGC Sas FRANCE**  
13, Rue des Forts - 59960 Neuville en Ferrain  
Tel. +33 (0)3 20 25 06 21 - Fax +33 (0)3 20 25 34 12  
[www.epgc.com](http://www.epgc.com) - [epgc@epgc.com](mailto:epgc@epgc.com)
- LF GmbH GERMANY**  
Junkersstrasse, 3 - D-82178 Puchheim - München  
Tel. +49 89 89 45 78 66 - Fax +49 89 89 45 78 88  
[www.lfersatzteile724.de](http://www.lfersatzteile724.de) - [info@lfersatzteile.de](mailto:info@lfersatzteile.de)
- LF China REPUBLIC OF CHINA**  
Room 403, No.2, Huadu Mansion, Lane 422, Huanghua Rd.  
Minhang Dist. - 201103 Shanghai  
Tel. +86 (0)21 33 53 66 31 - Fax +86 (0)21 33 53 66 32  
[www.lfspareparts724.com](http://www.lfspareparts724.com) - [china@lfspareparts.com](mailto:china@lfspareparts.com)
- OOO LF RUSSIAN FEDERATION**  
Ul. Anatoliya Zhivova, 8 - office 1 - 123100 Moscow  
Tel./Fax +7 495 725 26 53  
[www.lfspareparts724.ru](http://www.lfspareparts724.ru) - [info@lfspareparts.ru](mailto:info@lfspareparts.ru)
- LF Repuestos Horeca S.L.U. SPAIN**  
Poligono Industrial Carpetania - C/Miguel Faraday, 8 - 28906 Getafe  
Tel. +34 91 477 91 00 - Fax +34 91 477 90 81  
[www.lfrepuestos-horeca724.es](http://www.lfrepuestos-horeca724.es) - [info@lfrepuestos.es](mailto:info@lfrepuestos.es)
- LF Scandinavia Aps - LF Spareparts S.p.A. DENMARK**  
Nupark, 51 - 7500 Holstebro  
Tel. +45 70 70 77 33  
[www.lfspareparts724.dk](http://www.lfspareparts724.dk) - [denmark@lfspareparts.dk](mailto:denmark@lfspareparts.dk)
- LF SpA Cesena (IT) Swiss Branch Steinhausen SWITZERLAND**  
Sennweidstrasse, 45 - CH-6312 Steinhausen  
Tel. +41 (0)41 760 15 80/1 - Fax +41 (0)41 760 15 85  
[www.lfersatzteile724.ch](http://www.lfersatzteile724.ch) - [info@lfersatzteile.ch](mailto:info@lfersatzteile.ch)
- LF Spare Parts Ltd. UNITED KINGDOM**  
A10a Lakeside Business Park, Broadway Lane  
South Cerney, Gloucestershire GL7 5XL  
Tel. +44 (0)1285 86 16 25 - Fax +44 (0)1285 86 39 49  
[www.lfspareparts724.co.uk](http://www.lfspareparts724.co.uk) - [info@lfspareparts.co.uk](mailto:info@lfspareparts.co.uk)
- LF Central Est Europe S.r.o. CZECH REPUBLIC**  
Antala Staska 1859/34  
14000 Praha 4 - KRC  
Tel. +420 730 156 910  
[www.lfspareparts724.cz](http://www.lfspareparts724.cz) - [info@lfspareparts.cz](mailto:info@lfspareparts.cz)
- LF SPARE PARTS INC. USA**  
Legal address:  
155 Office Plaza Dr - Suite A - Tallahassee, FL 32301  
Business/Mailing address:  
1100 South Tower, 225 Peachtree St., N.E. - Atlanta, GA 30303, USA  
Tel. +1-404-525-2600 - Fax +1-404-586-3528  
[www.lfspareparts724.us](http://www.lfspareparts724.us) - [info@lfspareparts.us](mailto:info@lfspareparts.us)  
Tel. West Coast and Midwest: 206-349-1525 Sauro  
Tel. East Coast and the Caribbean: 786-817-1764 Luis
- 
- AUSTRALIA AND NEW ZEALAND**  
[www.lfspareparts724.com](http://www.lfspareparts724.com)  
[andrea.calvio@lfspareparts.com](mailto:andrea.calvio@lfspareparts.com)
- AUSTRIA**  
[www.lfersatzteile724.at](http://www.lfersatzteile724.at)  
[info@lfersatzteile.at](mailto:info@lfersatzteile.at)
- BALKAN COUNTRIES**  
[www.lfspareparts724.com](http://www.lfspareparts724.com)  
[matija.ramov@lfspareparts.com](mailto:matija.ramov@lfspareparts.com)
- BALTIC COUNTRIES**  
[www.lfspareparts724.com](http://www.lfspareparts724.com)  
[inara.silina@lfspareparts.com](mailto:inara.silina@lfspareparts.com)
- LATIN AMERICA AND THE CARRIBEANS**  
[www.lfrepuestos-horeca724.es](http://www.lfrepuestos-horeca724.es)  
[export@lfrepuestos.es](mailto:export@lfrepuestos.es)
- POLAND**  
[www.lfspareparts724.pl](http://www.lfspareparts724.pl)  
[info@lfspareparts.pl](mailto:info@lfspareparts.pl)
- SOUTH KOREA**  
[www.lfspareparts724.com](http://www.lfspareparts724.com)  
[fabio.doni@lfspareparts.com](mailto:fabio.doni@lfspareparts.com)
- TURKEY**  
[www.lfyedekparca724.com](http://www.lfyedekparca724.com)  
[export@lfspareparts.com](mailto:export@lfspareparts.com)